

Shutdown Unit Buzzer Does Not Activate with Fault

Symptoms

- Fault code registered with no activation of SDU410 unit buzzer.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

The SDU410 input signals are switches. These switches are normally open and closed when activated.

The buzzer is internal to SDU410 unit and has no external wiring.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check for active fault codes.	Any fault codes active?
STEP 2.	Check the SDU410 unit.	
	STEP 2A. Check for buzzer function at the SDU410 unit.	Does buzzer function?
STEP 3.	Clear the fault codes.	
	STEP 3A. Clear the inactive fault codes.	All fault codes cleared?

STEP 1. Check the fault codes.

STEP 1A. Check for active fault codes.

Conditions :

- Turn keyswitch ON.
- Check the DCU410 for active fault codes.

Action	Specification/Repair	Next Step
Check for active fault codes.	Any active fault codes? YES Repair : Troubleshoot the appropriate fault code. • For QSK19 engines, refer to the Troubleshooting and Repair Manual, Electronic Control System, QSK19 CM850 Modular Common Rail System Series Engines, Bulletin 4021490. (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021490.html) • For QSK38, QSK50 and QSK60 engines, refer to the Troubleshooting and Repair Manual, Electronic Control System, QSK38, QSK50, and QSK60 CM850 Modular Common Rail System, Bulletin 4021533. (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021533.html)	Repair complete
	Any active fault codes? NO	2A

STEP 2. Check the SDU410 unit.

STEP 2A. Check for buzzer function at the SDU410 unit.

Conditions :

- No fault code registered at the SDU410 unit.

Action	Specification/Repair	Next Step
Check for buzzer function at the SDU410 unit.	Does buzzer function? YES	3A
	Does buzzer function? NO Repair : Replace the SDU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete

STEP 3. Clear the fault codes.

STEP 3A. Clear the inactive fault codes.

Conditions :

- Turn keyswitch ON.
- Check the DCU410 unit for inactive fault codes.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Clear the inactive fault codes. • Check the inactive fault codes.	All fault codes cleared? YES	Repair complete
	All fault codes cleared? NO Repair : Troubleshoot any remaining fault codes.	Contact a Cummins® Authorized Repair Location.

Last Modified: 15-Apr-2008
