

Diesel Control Unit Configured Incorrectly

Symptoms

- The DCU410 unit is configured incorrectly for the engine application.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

This fault code has no external wiring from the DCU410 unit except the +24-VDC DCU410 unit power supply.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the customer interface box wiring.	
	STEP 1A. Check the DCU410 unit display for faults.	DCU410 unit indicates fault(s)?
	STEP 1A-1. Check the DCU410 power supply for voltage +24-VDC.	Less than +24-VDC?

STEP 1. Check the customer interface box wiring.

STEP 1A. Check the DCU410 unit display for faults.

Conditions :

- Locate the DCU410 unit display.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the DCU410 unit display for faults.	DCU410 unit indicates fault(s)? YES Repair : Refer to the Electronic Control System Troubleshooting and Repair Manual, QSK19 CM850 Modular Common Rail System Series Engine, Bulletin 4021493 (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021493.html) or the Electronic Control System Troubleshooting and Repair Manual, QSK38, QSK50, and QSK60 CM850 Modular Common Rail System Series Engine, Bulletin 4021533. (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021533.html)	Repair complete
	DCU410 unit indicates fault(s)? NO	1A-1

STEP 1A-1. Check the DCU410 power supply wire for voltage +24-VDC.

Conditions :

- Open the customer interface box.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the voltage at the battery 1 voltage (switched power) wire at the DCU410 unit. - Place one test lead at the battery 1 voltage (switched power) supply wire at the DCU410 unit. - Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than +24-VDC? YES Repair : Check the batteries. Refer to the OEM service manual.	Repair complete
	Less than +24-VDC? NO	Contact a Cummins® Authorized Repair Location.