

FAULT CODE 5119 - Fuel Pump Lubricating Oil Pressure Sensor Circuit- Voltage Above Normal or Shorted to High Source

Warnings and Cautions

CAUTION

To reduce the possibility of damaging a new ECM, all other active fault codes must be investigated prior to replacing the ECM.

CAUTION

To reduce the possibility of pin and harness damage, use the following test leads when taking a measurement: Part Number 3164596 - male Framatome™ test lead and Part Number 3822917 - female Deutsch™/Amp™/Metri-Pack™ test lead.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check for sensor supply fault codes.	Fault Code 2185 active?
STEP 2.	Check the fuel pump lubricating oil pressure sensor and circuit.	
	STEP 2A. Inspect the pins and connectors for damage.	Dirty or damaged pins?
	STEP 2B. Check the sensor supply voltage and return circuit.	4.75 to 5.25 VDC?
	STEP 2C. Check the circuit response. Fuel pump lubricating oil pressure sensor circuit check.	Fault Code 5121 active?

STEPS		SPECIFICATIONS
STEP 3.	Fuel pump lubricating oil pressure sensor circuit check.	
	STEP 3A. Fuel pump lubricating oil pressure sensor open circuit check.	Resistance less than 10 ohms?
	STEP 3B. Fuel pump lubricating oil pressure sensor circuit pin to pin check.	Resistance less than 100k ohms?
STEP 4.	Check ECM calibration and clear fault codes.	
	STEP 4A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 4B. Disable the fault code.	Fault code inactive?

STEP 1. Check the fault codes.

STEP 1A. Check for sensor supply fault codes.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Check for sensor supply fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 2185 active? YES	Go to appropriate fault code troubleshooting tree.
	Fault Code 2185 active? NO	2A

STEP 2. Check the fuel pump lubricating oil pressure sensor and circuit.

STEP 2A. Inspect the fuel pump lubricating oil pressure sensor and engine wiring harness connector pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the fuel pump lubricating oil pressure sensor connector from the engine wiring harness connector.

Action	Specification/Repair	Next Step
Inspect the pins and connectors for the following: • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Dirt or debris in or on the connector pins • Wire insulation damage • Missing or damaged connector seals • Connector or shell broken • Damaged connector locking tab. Use the following procedure for general inspection techniques. Refer to Procedure 019-361 (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html) in Section 19.	Dirty or damaged pins? YES Repair : Repair or replace only the components that were found to be out of specification. • Replace the fuel pump lubricating oil pressure sensor. Refer to Procedure 019-679 (/qs3/pubsys2/xml/en/procedures/56/56-019-679.html) in Section 19. • Repair or replace the engine wiring harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/122/122-019-043.html) in Section 19.	4A
	Dirty or damaged pins? NO	2B

STEP 2B. Check the sensor supply voltage and return circuit.

Conditions :

- Turn keyswitch OFF.
- Disconnect the fuel pump lubricating oil pressure sensor connector from the engine wiring harness connector.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
Check the supply voltage and return circuit. • Measure the voltage from the fuel pump oil pressure, 5-volt SUPPLY pin to the fuel pump pressure RETURN pin at the sensor connector of the engine wiring harness.	4.75 to 5.25-VDC? YES	2C
See the circuit diagram or wiring diagram for connector pin identification. Use the following procedure for general multimeter usage techniques. Refer to Procedure 019-359 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-359.html)	4.75 to 5.52-VDC? NO	3A

STEP 2C. Check the circuit response.**Conditions :**

- Turn keyswitch OFF
- Disconnect the fuel pump lubricating oil pressure sensor connector from the engine wiring harness connector.
- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for appropriate circuit response after 30 seconds. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 5121 active? YES Repair : A damaged fuel pump lubricating oil pressure sensor has been detected. • Replace the fuel pump lubricating oil pressure sensor. Refer to Procedure 019-679 (/qs3/pubsys2/xml/en/procedures/56/56-019-679.html) in Section 19.	4A
	Fault Code 5121 active? NO	3A

STEP 3. Fuel pump lubricating oil pressure sensor circuit check.

STEP 3A. Fuel pump lubricating oil pressure sensor open circuit check.

Conditions :

- Turn keyswitch OFF
- Disconnect the fuel pump lubricating oil pressure sensor from the engine wiring harness.
- Disconnect the engine wiring harness connector from the ECM.

Action	Specification/Repair	Next Step

- Measure the resistance between the fuel pump lubricating oil pressure sensor SIGNAL pin at the fuel pump lubricating oil pressure sensor wiring harness connector and the fuel pump lubricating oil pressure sensor SIGNAL pin at the engine wiring harness ECM connector. - Measure the resistance between the fuel pump lubricating oil pressure sensor RETURN pin at the fuel pump lubricating oil pressure sensor wiring harness connector and the fuel pump lubricating oil pressure sensor RETURN pin at the engine wiring harness ECM connector.	Resistance less than 10 ohms? YES	3B
	Resistance less than 10 ohms? NO Repair : A malfunctioning engine wiring harness has been detected. Repair or replace the engine wiring harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/122/122-019-043.html) in Section 19.	4A

STEP 3B. Fuel pump lubricating oil pressure sensor circuit pin to pin check.

Conditions :

- Turn keyswitch OFF
- Disconnect the fuel pump lubricating oil pressure sensor from the engine wiring harness.
- Disconnect the engine wiring harness connector from the ECM.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Measure the resistance between the fuel pump lubricating oil pressure sensor SIGNAL pin at the engine wiring harness ECM connector and all other pins at the engine wiring harness ECM connector.	Resistance less than 100k ohms? YES Repair : A malfunctioning engine wiring harness has been detected. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/122/122-019-043.html) in Section 19.	4A
	Resistance less than 100k ohms? NO	4A

STEP 4. Check the ECM calibration and clear fault codes.

STEP 4A. Check if an ECM calibration update is available.

Conditions :

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step

Compare the ECM code and revision in the ECM to the calibration revision listed in the ECM Calibration Revision History for applicable changes related to this fault code. Use INSITE™ electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters.	If calibration update for this fault code is available, does the ECM contain that revision or higher? YES	4B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html) in Section 19.	4B

STEP 4B. Disable the fault code.

Conditions : - Connect all components - Connect INSITE™ electronic service tool.		
Action	Specification/Repair	Next Step
Disable and clear the fault code. Operate the engine within the "Conditions for Clearing the Fault Code" found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair complete.
	Fault code inactive? NO Repair : Verify that all steps have been completed. If all steps have been completed, then follow the technical escalation process.	Escalate or call for assistance.

Last Modified: 21-May-2020