

FAULT CODE 7314 - Engine Fuel Pump Oil Pressure - Data Valid But Below Normal Operating Range- Most Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check for primary fault codes.	Fault Code 143, 415, 1362 active or inactive with more than one count in the last 25 engine hours?
STEP 2.	Fuel pump lubricating oil pressure sensor stuck in-range.	
	STEP 2A. Visually inspect the sensor for damage.	Damage found on the fuel pump lubricating oil pressure sensor, connectors, or engine wiring harness?
	STEP 2B. Verify fuel pump lubricating oil pressure sensor's accuracy.	Sensor reading between the recommended Cummins® electronic service tool or equivalent and the mechanical gauge is within specification?
STEP 3.	Check the fuel pump drive lubricating oil filter for damage.	
	STEP 3A. Check for damage on the fuel pump drive lubricating oil filter.	Damaged or plugged fuel pump drive lubricating oil filter?
STEP 4.	Check Fuel Pump Oil Pressure.	
	STEP 4A. Verify oil pressure at the outlet of the fuel pump drive lubricating oil filter head.	Fuel pump oil pressure is above the minimum oil pressure?

STEPS		SPECIFICATIONS
	STEP 4B. Verify oil pressure at the outlet of the fuel pump drive lubricating oil filter head with the new oil filter installed.	Fuel pump oil pressure is above the minimum oil pressure?
STEP 5.	Check ECM calibration and clear the fault codes.	
	STEP 5A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 5B. Disable the fault code.	Fault code inactive?

STEP 1. Check the fault codes.

STEP 1A. Check for primary fault codes.

Conditions :

- Turn keyswitch ON
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Check for active fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 143, 415, 1362 active or inactive with more than one count in the last 25 engine hours? YES	Troubleshoot the appropriate fault codes.
	Fault Code 143 or 415 active or inactive with more than one count in the last 25 engine hours? NO	2A

STEP 2. Fuel pump lubricating oil pressure sensor stuck in-range.

STEP 2A. Visually inspect the sensor and connector pins.

Conditions :

- Turn keyswitch OFF
- Disconnect the fuel pump lubricating oil pressure sensor from the engine wiring harness.

Action	Specification/Repair	Next Step
Inspect the harness connector and fuel pump lubricating oil pressure sensor connector. • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Missing or damaged connector seals • Dirt or debris in or on the connector pins • Connector shell broken • Wire insulation damaged • Damaged connector locking tab. Use the following procedure for general inspection techniques. Refer to Procedure 019-361 (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html) in Section 19.	Damage found on the fuel pump lubricating oil pressure sensor, connectors or engine wiring harness? YES Repair : Repair or replace only the components that were found to be out of specification. Replace the fuel pump lubricating oil pressure sensor. Refer to Procedure 019-679 (/qs3/pubsys2/xml/en/procedures/56/56-019-679.html) in Section 19. Repair or replace the engine wiring harness or connectors. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/122/122-019-043.html) in Section 19.	5A
	Damage found on the fuel pump lubricating oil pressure sensor, connectors, or engine wiring harness? NO	2B

STEP 2B. Verify fuel pump lubricating oil pressure sensor's accuracy.

Conditions : Turn keyswitch OFF.		
Action	Specification/Repair	Next Step
- Check the fuel pump oil pressure at the outlet of the fuel pump oil filter head. - Refer to Procedure 019-679 (/qs3/pubsys2/xml/en/procedures/56/56-019-679.html) in Section 19.	Sensor reading between the recommended Cummins® electronic service tool or equivalent and the mechanical gauge is within specification? YES	3A
	Sensor reading between the recommended Cummins® electronic service tool or equivalent and the mechanical gauge is within specification? NO Repair : Replace the fuel pump lubricating oil pressure sensor. Refer to Procedure 019-679 (/qs3/pubsys2/xml/en/procedures/56/56-019-679.html) in Section 19.	5A

STEP 3. Check the fuel pump drive lubricating oil filter for damage.

STEP 3A. Check for damage on the fuel pump drive lubricating oil filter.

Conditions : Turn keyswitch OFF.		
Action	Specification/Repair	Next Step

- Check the fuel pump drive lubricating oil filter. - Refer to Procedure 007-110 in the Associated Procedures Table.	Damage found on the fuel pump drive lubricating oil filter? YES Repair : Replace the fuel pump drive lubricating oil filter. Refer to Procedure 007-110 in the Associated Procedures Table.	5A
	Damage found on the fuel pump drive lubricating oil filter? NO	4A

STEP 4. Check Fuel Pump Oil Pressure.

STEP 4A. Verify oil pressure at the outlet of the fuel pump drive lubricating oil filter head.

Conditions :

- Turn keyswitch OFF.

Action	Specification/Repair	Next Step

Verify oil pressure at the outlet of the fuel pump oil filter head. Refer to Procedure 007-110 in the Associated Procedures Table.	Fuel pump oil pressure is above the minimum oil pressure? YES	5A
	Fuel pump oil pressure is above the minimum oil pressure? NO Repair : Replace the fuel pump drive lubricating oil filter. Refer to Procedure 007-110 in the Associated Procedures Table.	4B

STEP 4B. Verify oil pressure at the outlet of the fuel pump drive lubricating oil filter head with new oil filter installed.

Conditions :

- Turn keyswitch OFF.

Action	Specification/Repair	Next Step
Verify oil pressure at the outlet of the fuel pump oil filter head. Refer to Procedure 007-110 in the Associated Procedures Table.	Fuel pump oil pressure is above the minimum oil pressure? YES	5A
	Fuel pump oil pressure is above the minimum oil pressure? NO	5A

STEP 5. Check ECM calibration and clear fault codes.

STEP 5A. Check if an ECM calibration update is available.

Conditions :

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Compare the ECM code and revision number in the ECM to the calibration revisions listed in the ECM Calibration Revision History for applicable changes related to this fault code. • Use INSITE™ electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters.	If a calibration update for this fault code is available, does the ECM contain that revision or higher? YES	5B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html) in Section 19.	5B

STEP 5B. Disable the fault code.**Conditions :**

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step

Disable and clear the fault code. Operate the engine within the “Conditions for Clearing the Fault Code” found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair complete.
	Fault code inactive? NO Repair : Verify that all steps have been completed. If all steps have been completed, then follow your technical escalation process.	Escalate or Call for assistance.

Associated Procedures			
Procedure Title	Procedure Number	Engine Model	Bulletin Number
Fuel Pump Drive Lubricating Oil Filter	Refer to Procedure 007-110 (/qs3/pubsys2/xml/en/procedures/56/56-007-110-tr.html)	QSK45 and QSK60	4021530