

# Manual Change History ( 3666087) B3.9, B4.5, B4.5 RGT, and B5.9 Service Manual

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 12-Mar-2002                                                       |
| <b>Section</b>          | Section i - Introduction                                          |
| <b>Procedure Number</b> | 99-204-004<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-004.html) |
| <b>Procedure Title</b>  | Symbols                                                           |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 12-Mar-2002                                                       |
| <b>Section</b>          | Section i - Introduction                                          |
| <b>Procedure Number</b> | 99-204-005<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-005.html) |
| <b>Procedure Title</b>  | Illustrations                                                     |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 14-Mar-2002                                                       |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                   |
| <b>Procedure Number</b> | 99-006-043<br>(/qs3/pubsys2/xml/en/procedures/99/99-006-043.html) |
| <b>Procedure Title</b>  | Fuel-Water Separator                                              |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 03-Apr-2002                                                       |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                             |
| <b>Procedure Number</b> | 99-t00-002<br>(/qs3/pubsys2/xml/en/procedures/99/99-t00-002.html) |
| <b>Procedure Title</b>  | Troubleshooting Symptoms Charts                                   |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 01-Oct-2002                                                             |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                                  |
| <b>Procedure Number</b> | 99-000-009<br>(/qs3/pubsys2/xml/en/procedures/99/99-000-009.html)       |
| <b>Procedure Title</b>  | Engine Steam Cleaning                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 08-Oct-2002                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 99-008-040<br>(/qs3/pubsys2/xml/en/procedures/99/99-008-040.html)       |
| <b>Procedure Title</b>  | Fan, Cooling                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 05-May-2003                                                             |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                            |
| <b>Procedure Number</b> | 100-016-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-016-010.html)    |
| <b>Procedure Title</b>  | Engine Mounts                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 14-May-2003                                                             |
| <b>Section</b>          | Section 4 - Cam Followers/Tappets - Group 04                            |
| <b>Procedure Number</b> | 40-022-001_04<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_04.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 14-May-2003                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-022-001_13<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_13.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| <b>Date</b>             | 26-Aug-2003                                                          |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                            |
| <b>Procedure Number</b> | 100-010-122<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-122.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Wiring Harness                            |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 26-Aug-2003                                                          |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                            |
| <b>Procedure Number</b> | 100-010-123<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-123.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Temperature Sensor                        |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 26-Aug-2003                                                          |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                            |
| <b>Procedure Number</b> | 100-010-125<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-125.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Control Module                            |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 26-Aug-2003                                                          |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                            |
| <b>Procedure Number</b> | 100-010-126<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-126.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Solenoid Switch                           |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 26-Aug-2003                                                          |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                            |
| <b>Procedure Number</b> | 100-010-127<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-127.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Speed Sensor                              |
| <b>Update Reason</b>    |                                                                      |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 15-Sep-2003                                                       |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                            |
| <b>Procedure Number</b> | 40-000-007<br>(/qs3/pubsys2/xml/en/procedures/40/40-000-007.html) |
| <b>Procedure Title</b>  | Engine Painting                                                   |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 23-Sep-2003                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-018<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-018.html) |
| <b>Procedure Title</b>  | Fuel Pump Control Lever and Spring                                |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 23-Sep-2003                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-028<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-028.html) |
| <b>Procedure Title</b>  | Fuel Pump High Idle Speed                                         |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 23-Sep-2003                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-058<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-058.html) |
| <b>Procedure Title</b>  | Speed Droop Governor                                              |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 01-Oct-2003                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-001<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-001.html) |
| <b>Procedure Title</b>  | AFC Assembly                                                      |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 08-Oct-2003                                                       |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                             |
| <b>Procedure Number</b> | 40-008-038<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-038.html) |
| <b>Procedure Title</b>  | Fan Shroud Assembly                                               |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 08-Oct-2003                                                       |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                             |
| <b>Procedure Number</b> | 40-008-045<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-045.html) |
| <b>Procedure Title</b>  | Radiator Hoses                                                    |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 08-Oct-2003                                                       |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                             |
| <b>Procedure Number</b> | 40-008-049<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-049.html) |
| <b>Procedure Title</b>  | Radiator Shutter Assembly                                         |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 29-Jan-2004                                                       |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                             |
| <b>Procedure Number</b> | 99-008-104<br>(/qs3/pubsys2/xml/en/procedures/99/99-008-104.html) |
| <b>Procedure Title</b>  | Sea Water Hoses                                                   |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 02-Feb-2004                                                       |
| <b>Section</b>          | Section 17 - Miscellaneous - Group 17                             |
| <b>Procedure Number</b> | 40-017-007<br>(/qs3/pubsys2/xml/en/procedures/40/40-017-007.html) |
| <b>Procedure Title</b>  | Pipe Plug                                                         |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 02-Feb-2004                                                             |
| <b>Section</b>          | Section 17 - Miscellaneous - Group 17                                   |
| <b>Procedure Number</b> | 40-017-015<br>(/qs3/pubsys2/xml/en/procedures/40/40-017-015.html)       |
| <b>Procedure Title</b>  | Expansion Plug                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 04-Feb-2004                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 40-014-006<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-006.html)       |
| <b>Procedure Title</b>  | Engine Run-in (Engine Dynamometer)                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 27-Feb-2004                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-025-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-025-tr.html) |
| <b>Procedure Title</b>  | Crankshaft Wear Sleeve, Front                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 27-Feb-2004                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-022-001_12<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_12.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 03-Mar-2004                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 99-018-010<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-010.html)       |
| <b>Procedure Title</b>  | Fraction, Decimal, Millimeter Conversions                               |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| <b>Date</b>             | 03-Mar-2004                                                          |
| <b>Section</b>          | Section V - Specifications                                           |
| <b>Procedure Number</b> | 99-018-011<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-011.html)    |
| <b>Procedure Title</b>  | Newton-Meter to Foot-Pound Conversions                               |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 03-Mar-2004                                                          |
| <b>Section</b>          | Section V - Specifications                                           |
| <b>Procedure Number</b> | 99-018-012<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-012.html)    |
| <b>Procedure Title</b>  | Pipe Plug Torque Values                                              |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 03-Mar-2004                                                          |
| <b>Section</b>          | Section V - Specifications                                           |
| <b>Procedure Number</b> | 99-018-013<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-013.html)    |
| <b>Procedure Title</b>  | Tap-Drill Chart - U.S. Customary and Metric                          |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 03-Mar-2004                                                          |
| <b>Section</b>          | Section V - Specifications                                           |
| <b>Procedure Number</b> | 99-018-014<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-014.html)    |
| <b>Procedure Title</b>  | Weights and Measures - Conversion Factors                            |
| <b>Update Reason</b>    |                                                                      |
| <b>Date</b>             | 09-Mar-2004                                                          |
| <b>Section</b>          | Front                                                                |
| <b>Procedure Number</b> | 3666087-toc<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-toc.html) |
| <b>Procedure Title</b>  | Table of Contents                                                    |
| <b>Update Reason</b>    |                                                                      |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 19-May-2004                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 100-010-031<br>(/qs3/pubsys2/xml/en/procedures/100/100-010-031.html)    |
| <b>Procedure Title</b>  | Air Intake Restriction                                                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 16-Dec-2004                                                             |
| <b>Section</b>          | Section 17 - Miscellaneous - Group 17                                   |
| <b>Procedure Number</b> | 40-017-002<br>(/qs3/pubsys2/xml/en/procedures/40/40-017-002.html)       |
| <b>Procedure Title</b>  | Cup Plug                                                                |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 12-Aug-2005                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-022-001_05<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_05.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 06-Sep-2005                                                             |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                   |
| <b>Procedure Number</b> | 100-t00-004<br>(/qs3/pubsys2/xml/en/procedures/100/100-t00-004.html)    |
| <b>Procedure Title</b>  | Troubleshooting Overview                                                |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 15-Nov-2005                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-053<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-053.html)       |
| <b>Procedure Title</b>  | Sea Water Heat Exchanger                                                |
| <b>Update Reason</b>    |                                                                         |



|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 15-Nov-2005                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-057<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-057.html)       |
| <b>Procedure Title</b>  | Sea Water Pump                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 03-Jan-2006                                                             |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                            |
| <b>Procedure Number</b> | 00-016-025<br>(/qs3/pubsys2/xml/en/procedures/00/00-016-025.html)       |
| <b>Procedure Title</b>  | Propeller Shaft                                                         |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 02-Feb-2006                                                             |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                            |
| <b>Procedure Number</b> | 00-016-026<br>(/qs3/pubsys2/xml/en/procedures/00/00-016-026.html)       |
| <b>Procedure Title</b>  | Marine Vibration Isolator                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 15-Feb-2006                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-200-002-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-002-tr.html) |
| <b>Procedure Title</b>  | Flow Diagram, Lubricating Oil System                                    |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 15-Feb-2006                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-200-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-003-tr.html) |
| <b>Procedure Title</b>  | Flow Diagram, Cooling System                                            |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section F - Familiarization                                       |
| <b>Procedure Number</b> | 40-000-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-000-999.html) |
| <b>Procedure Title</b>  | Complete Engine - Overview                                        |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section F - Familiarization                                       |
| <b>Procedure Number</b> | 40-002-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-999.html) |
| <b>Procedure Title</b>  | Cylinder Head - Overview                                          |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section F - Familiarization                                       |
| <b>Procedure Number</b> | 40-004-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-999.html) |
| <b>Procedure Title</b>  | Cam Followers/Tappets - Overview                                  |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section F - Familiarization                                       |
| <b>Procedure Number</b> | 40-007-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-999.html) |
| <b>Procedure Title</b>  | Lubricating Oil System - Overview                                 |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section F - Familiarization                                       |
| <b>Procedure Number</b> | 40-008-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-999.html) |
| <b>Procedure Title</b>  | Cooling System - Overview                                         |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section F - Familiarization                                                  |
| <b>Procedure Number</b> | 40-010-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-999.html)            |
| <b>Procedure Title</b>  | Air Intake System - Overview                                                 |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section F - Familiarization                                                  |
| <b>Procedure Number</b> | 40-013-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-999.html)            |
| <b>Procedure Title</b>  | Electrical Equipment - Overview                                              |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section F - Familiarization                                                  |
| <b>Procedure Number</b> | 40-014-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-999.html)            |
| <b>Procedure Title</b>  | Engine Testing - Overview                                                    |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t004-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t004-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Air Pressure Rises Slowly                                     |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t005-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t005-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Cycles Frequently                                             |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t006-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t006-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Noise is Excessive                                            |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t007-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t007-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Pumping Excess Lubricating Oil into the Air System            |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                                   |
|-------------------------|-----------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                       |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                             |
| <b>Procedure Number</b> | 3666087-t008-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t008-tr.html)      |
| <b>Procedure Title</b>  | Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously) |
| <b>Update Reason</b>    |                                                                                   |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t009-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t009-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Will Not Pump Air                                             |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t010-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t010-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Will Not Stop Pumping                                         |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t013-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t013-tr.html) |
| <b>Procedure Title</b>  | Alternator Not Charging or Insufficient Charging                             |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t014-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t014-tr.html) |
| <b>Procedure Title</b>  | Alternator Overcharging                                                      |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t018-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t018-tr.html) |
| <b>Procedure Title</b>  | Coolant Contamination                                                        |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t019-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t019-tr.html) |
| <b>Procedure Title</b>  | Coolant Loss                                                                 |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t022-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t022-tr.html) |
| <b>Procedure Title</b>  | Coolant Temperature Above Normal - Gradual Overheat                          |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t023-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t023-tr.html) |
| <b>Procedure Title</b>  | Coolant Temperature Above Normal - Sudden Overheat                           |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t024-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t024-tr.html) |
| <b>Procedure Title</b>  | Coolant Temperature Below Normal                                             |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t025-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t025-tr.html) |
| <b>Procedure Title</b>  | Coolant in the Lubricating Oil                                               |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t027-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t027-tr.html) |
| <b>Procedure Title</b>  | Crankcase Gases (Blowby) Excessive                                           |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t033-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t033-tr.html) |
| <b>Procedure Title</b>  | Engine Acceleration or Response Poor                                         |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t043-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t043-tr.html) |
| <b>Procedure Title</b>  | Engine Difficult to Start or Will Not Start (Exhaust Smoke)                  |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t044-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t044-tr.html) |
| <b>Procedure Title</b>  | Engine Difficult to Start or Will Not Start (No Exhaust Smoke)               |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t047-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t047-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive                                                       |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t048-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t048-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive - Combustion Knocks                                   |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t049-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t049-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive - Connecting Rod                                      |
| <b>Update Reason</b>    |                                                                              |

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t050-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t050-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive - Main Bearing                                        |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t051-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t051-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive - Piston                                              |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t052-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t052-tr.html) |
| <b>Procedure Title</b>  | Engine Noise Excessive - Turbocharger                                        |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t061-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t061-tr.html) |
| <b>Procedure Title</b>  | Engine Runs Rough at Idle                                                    |
| <b>Update Reason</b>    |                                                                              |
| <b>Date</b>             | 31-Mar-2006                                                                  |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                        |
| <b>Procedure Number</b> | 3666087-t062-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t062-tr.html) |
| <b>Procedure Title</b>  | Engine Runs Rough or Misfires                                                |
| <b>Update Reason</b>    |                                                                              |



|                         |                                                                                      |
|-------------------------|--------------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t066-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t066-tr.html)         |
| <b>Procedure Title</b>  | Engine Speed Surges at Low or High Idle                                              |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t072-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t072-tr.html)         |
| <b>Procedure Title</b>  | Engine Starts But Will Not Keep Running                                              |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t075-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t075-tr.html)         |
| <b>Procedure Title</b>  | Engine Vibration Excessive                                                           |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t080-005-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t080-005-tr.html) |
| <b>Procedure Title</b>  | Engine Will Not Reach High Idle                                                      |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t081-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t081-tr.html)         |
| <b>Procedure Title</b>  | Engine Will Not Shut Off                                                             |
| <b>Update Reason</b>    |                                                                                      |

|                         |                                                                                      |
|-------------------------|--------------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t081-001-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t081-001-tr.html) |
| <b>Procedure Title</b>  | Excessive Noise                                                                      |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t087-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t087-tr.html)         |
| <b>Procedure Title</b>  | Fuel Consumption Excessive                                                           |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t091-5-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t091-5-tr.html)     |
| <b>Procedure Title</b>  | Fuel Knock                                                                           |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t092-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t092-tr.html)         |
| <b>Procedure Title</b>  | Fuel in the Lubricating Oil                                                          |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 31-Mar-2006                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t093-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t093-tr.html)         |
| <b>Procedure Title</b>  | Fuel or Lubricating Oil Leaking From Exhaust Manifold                                |
| <b>Update Reason</b>    |                                                                                      |

|                         |                                                                                    |
|-------------------------|------------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t097-25-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t097-25-tr.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater System<br>Malfunctioning                                |
| <b>Update Reason</b>    |                                                                                    |
| <b>Date</b>             | 31-Mar-2006                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t102-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t102-tr.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Consumption Excessive                                              |
| <b>Update Reason</b>    |                                                                                    |
| <b>Date</b>             | 31-Mar-2006                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t103-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t103-tr.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Contaminated                                                       |
| <b>Update Reason</b>    |                                                                                    |
| <b>Date</b>             | 31-Mar-2006                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t104-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t104-tr.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Pressure High                                                      |
| <b>Update Reason</b>    |                                                                                    |
| <b>Date</b>             | 31-Mar-2006                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t105-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t105-tr.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Pressure Low                                                       |
| <b>Update Reason</b>    |                                                                                    |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t106-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t106-tr.html)    |
| <b>Procedure Title</b>  | Lubricating Oil Sludge in the Crankcase Excessive                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t107-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t107-tr.html)    |
| <b>Procedure Title</b>  | Lubricating Oil Temperature Above Specification                                 |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t108-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t108-tr.html)    |
| <b>Procedure Title</b>  | Lubricating or Transmission Oil in the Coolant                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t116-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t116-tr.html)    |
| <b>Procedure Title</b>  | Smoke, Black - Excessive                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-016-002-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-002-shopds.html) |
| <b>Procedure Title</b>  | Engine Support Bracket, Front                                                   |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-016-003-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-003-shopds.html) |
| <b>Procedure Title</b>  | Engine Support Bracket, Rear                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-051-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-051-shopds.html) |
| <b>Procedure Title</b>  | Injector Supply Lines (High Pressure)                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-021-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-021-shopds.html) |
| <b>Procedure Title</b>  | Fuel Manifold (Drain)                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-024-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-024-shopds.html) |
| <b>Procedure Title</b>  | Fuel Supply Lines                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-017-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-017-shopds.html) |
| <b>Procedure Title</b>  | Fuel Filter Head                                                                |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-011-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-011-shopds.html) |
| <b>Procedure Title</b>  | Rocker Lever Cover                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-013-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-013-shopds.html) |
| <b>Procedure Title</b>  | Rocker Lever Housing                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-008-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-008-shopds.html) |
| <b>Procedure Title</b>  | Rocker Lever                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-004-014-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-014-shopds.html) |
| <b>Procedure Title</b>  | Push Rods or Tubes                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-024-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-024-shopds.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Hoses                                              |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-023-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-023-shopds.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Valve                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-001-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-001-shopds.html) |
| <b>Procedure Title</b>  | AFC Air Tube                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-019-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-019-shopds.html) |
| <b>Procedure Title</b>  | Air Crossover                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-131-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-131-shopds.html) |
| <b>Procedure Title</b>  | Air Intake Connection Adapter                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-001-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-001-shopds.html) |
| <b>Procedure Title</b>  | Aftercooler                                                                     |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-124-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-124-shopds.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Element                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-045-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-045-shopds.html) |
| <b>Procedure Title</b>  | Turbocharger Oil Drain Line                                                     |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-011-007-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-011-007-shopds.html) |
| <b>Procedure Title</b>  | Exhaust Manifold, Dry                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-013-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-013-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Filter (Spin-On)                                                |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-026-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-026-shopds.html) |
| <b>Procedure Title</b>  | Fan Clutch, Electric                                                            |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-013-003-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-003-shopds.html) |
| <b>Procedure Title</b>  | Alternator Bracket                                                              |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-062-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-062-shopds.html) |
| <b>Procedure Title</b>  | Water Pump                                                                      |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-087-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-087-shopds.html) |
| <b>Procedure Title</b>  | Cooling Fan Belt Tensioner                                                      |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-051-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-051-shopds.html) |
| <b>Procedure Title</b>  | Vibration Damper, Rubber                                                        |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-052-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-052-shopds.html) |
| <b>Procedure Title</b>  | Vibration Damper, Viscous                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-031-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-031-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pump                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-009-001-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-001-shopds.html) |
| <b>Procedure Title</b>  | Accessory Drive                                                                 |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-009-039-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-039-shopds.html) |
| <b>Procedure Title</b>  | Accessory Drive Cover                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-012-004-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-004-shopds.html) |
| <b>Procedure Title</b>  | Air Compressor Coolant Lines                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-005-033-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-033-shopds.html) |
| <b>Procedure Title</b>  | Fuel Pump Support Bracket                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-003-018-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-018-shopds.html) |
| <b>Procedure Title</b>  | Crankcase Breather Tube                                                         |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-016-005-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-005-shopds.html) |
| <b>Procedure Title</b>  | Flywheel                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-035-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-035-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Suction Tube (Block-Mounted)                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-004-015-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-015-shopds.html) |
| <b>Procedure Title</b>  | Tappet                                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-033-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-033-shopds.html) |
| <b>Procedure Title</b>  | Gear Housing, Front                                                             |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-034-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-034-shopds.html) |
| <b>Procedure Title</b>  | Gear Housing, Rear                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-046-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-046-shopds.html) |
| <b>Procedure Title</b>  | Piston Cooling Nozzle                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-046-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-046-shopas.html) |
| <b>Procedure Title</b>  | Piston Cooling Nozzle                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-034-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-034-shopas.html) |
| <b>Procedure Title</b>  | Gear Housing, Rear                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-033-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-033-shopas.html) |
| <b>Procedure Title</b>  | Gear Housing, Front                                                             |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-004-015-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-015-shopas.html) |
| <b>Procedure Title</b>  | Tappet                                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-035-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-035-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Suction Tube (Block-Mounted)                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-016-005-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-005-shopas.html) |
| <b>Procedure Title</b>  | Flywheel                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-018-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-018-shopas.html) |
| <b>Procedure Title</b>  | Crankcase Breather Tube                                                         |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-005-033-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-033-shopas.html) |
| <b>Procedure Title</b>  | Fuel Pump Support Bracket                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-012-004-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-004-shopas.html) |
| <b>Procedure Title</b>  | Air Compressor Coolant Lines                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-009-039-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-039-shopas.html) |
| <b>Procedure Title</b>  | Accessory Drive Cover                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-009-001-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-001-shopas.html) |
| <b>Procedure Title</b>  | Accessory Drive                                                                 |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-031-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-031-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pump                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-052-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-052-shopas.html) |
| <b>Procedure Title</b>  | Vibration Damper, Viscous                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-051-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-051-shopas.html) |
| <b>Procedure Title</b>  | Vibration Damper, Rubber                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-087-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-087-shopas.html) |
| <b>Procedure Title</b>  | Cooling Fan Belt Tensioner                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-062-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-062-shopas.html) |
| <b>Procedure Title</b>  | Water Pump                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-013-003-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-003-shopas.html) |
| <b>Procedure Title</b>  | Alternator Bracket                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-026-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-026-shopas.html) |
| <b>Procedure Title</b>  | Fan Clutch, Electric                                                            |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-013-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-013-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Filter (Spin-On)                                                |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-011-007-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-011-007-shopas.html) |
| <b>Procedure Title</b>  | Exhaust Manifold, Dry                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-045-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-045-shopas.html) |
| <b>Procedure Title</b>  | Turbocharger Oil Drain Line                                                     |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-124-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-124-shopas.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Element                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-001-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-001-shopas.html) |
| <b>Procedure Title</b>  | Aftercooler                                                                     |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-131-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-131-shopas.html) |
| <b>Procedure Title</b>  | Air Intake Connection Adapter                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-019-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-019-shopas.html) |
| <b>Procedure Title</b>  | Air Crossover                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-001-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-001-shopas.html) |
| <b>Procedure Title</b>  | AFC Air Tube                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-023-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-023-shopas.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Valve                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-024-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-024-shopas.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Hoses                                              |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-004-014-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-014-shopas.html) |
| <b>Procedure Title</b>  | Push Rods or Tubes                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-008-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-008-shopas.html) |
| <b>Procedure Title</b>  | Rocker Lever                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-013-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-013-shopas.html) |
| <b>Procedure Title</b>  | Rocker Lever Housing                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-011-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-011-shopas.html) |
| <b>Procedure Title</b>  | Rocker Lever Cover                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-017-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-017-shopas.html) |
| <b>Procedure Title</b>  | Fuel Filter Head                                                                |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-024-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-024-shopas.html) |
| <b>Procedure Title</b>  | Fuel Supply Lines                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-021-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-021-shopas.html) |
| <b>Procedure Title</b>  | Fuel Manifold (Drain)                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-051-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-051-shopas.html) |
| <b>Procedure Title</b>  | Injector Supply Lines (High Pressure)                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-016-003-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-003-shopas.html) |
| <b>Procedure Title</b>  | Engine Support Bracket, Rear                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 31-Mar-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-016-002-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-002-shopas.html) |
| <b>Procedure Title</b>  | Engine Support Bracket, Front                                                   |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-005<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-005.html)       |
| <b>Procedure Title</b>  | Bearings, Connecting Rod                                                |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-006<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-006.html)       |
| <b>Procedure Title</b>  | Bearings, Main                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-033-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-033-tr.html) |
| <b>Procedure Title</b>  | Gear Housing, Front                                                     |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-034-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-034-tr.html) |
| <b>Procedure Title</b>  | Gear Housing, Rear                                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-046-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-046-tr.html) |
| <b>Procedure Title</b>  | Piston Cooling Nozzle                                                   |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-047<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-047.html)       |
| <b>Procedure Title</b>  | Piston Rings                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-049<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-049.html)       |
| <b>Procedure Title</b>  | Timing Pin Housing                                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-051-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-051-tr.html) |
| <b>Procedure Title</b>  | Vibration Damper, Rubber                                                |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-052-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-052-tr.html) |
| <b>Procedure Title</b>  | Vibration Damper, Viscous                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-057<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-057.html)       |
| <b>Procedure Title</b>  | Engine Dataplate                                                        |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-067<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-067.html)       |
| <b>Procedure Title</b>  | Crankshaft Wear Sleeve, Rear                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                    |
| <b>Procedure Number</b> | 40-022-001_02<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_02.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-008-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-008-tr.html) |
| <b>Procedure Title</b>  | Rocker Lever                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-011-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-011-tr.html) |
| <b>Procedure Title</b>  | Rocker Lever Cover                                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-013-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-013-tr.html) |
| <b>Procedure Title</b>  | Rocker Lever Housing                                                    |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-018-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-018-tr.html) |
| <b>Procedure Title</b>  | Crankcase Breather Tube                                                 |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-023-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-023-tr.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Valve                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-024-tr.html) |
| <b>Procedure Title</b>  | Closed Crankcase Ventilation Hoses                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 4 - Cam Followers/Tappets - Group 04                            |
| <b>Procedure Number</b> | 40-004-014-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-014-tr.html) |
| <b>Procedure Title</b>  | Push Rods or Tubes                                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 4 - Cam Followers/Tappets - Group 04                            |
| <b>Procedure Number</b> | 40-004-015-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-015-tr.html) |
| <b>Procedure Title</b>  | Tappet                                                                  |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-008<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-008.html) |
| <b>Procedure Title</b>  | Engine Fuel Heater, Electric                                      |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-010<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-010.html) |
| <b>Procedure Title</b>  | Fuel Consumption                                                  |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-011<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-011.html) |
| <b>Procedure Title</b>  | Fuel Flow                                                         |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-013<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-013.html) |
| <b>Procedure Title</b>  | Fuel Injection Pump, In-Line, Spill Port Timing                   |
| <b>Update Reason</b>    |                                                                   |
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                |
| <b>Procedure Number</b> | 40-005-029<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-029.html) |
| <b>Procedure Title</b>  | Fuel Pump Idle Speed                                              |
| <b>Update Reason</b>    |                                                                   |



|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-033-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-033-tr.html) |
| <b>Procedure Title</b>  | Fuel Pump Support Bracket                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-046<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-046.html)       |
| <b>Procedure Title</b>  | Cold Start Timing Advance System (KSB)<br>Remote                        |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-059<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-059.html)       |
| <b>Procedure Title</b>  | Fuel Pump Back Leakage Valve                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-060<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-060.html)       |
| <b>Procedure Title</b>  | Fuel Pump Pressure Regulator                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-069<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-069.html)       |
| <b>Procedure Title</b>  | Cold Start Timing Advance System (KSB)<br>Temperature Switch            |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-070<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-070.html)       |
| <b>Procedure Title</b>  | Cold Start Timing Advance System (KSB)<br>Pump Mounted                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-022-001_06<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_06.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-001-tr.html) |
| <b>Procedure Title</b>  | AFC Air Tube                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-003-tr.html) |
| <b>Procedure Title</b>  | Air in Fuel                                                             |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-012<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-012.html)       |
| <b>Procedure Title</b>  | Fuel Drain Line Restriction                                             |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-017-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-017-tr.html) |
| <b>Procedure Title</b>  | Fuel Filter Head                                                        |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-020<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-020.html)       |
| <b>Procedure Title</b>  | Fuel Inlet Restriction                                                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-021-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-021-tr.html) |
| <b>Procedure Title</b>  | Fuel Manifold (Drain)                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-024-tr.html) |
| <b>Procedure Title</b>  | Fuel Supply Lines                                                       |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-044<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-044.html)       |
| <b>Procedure Title</b>  | Fuel Return Overflow Valve                                              |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-051-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-051-tr.html) |
| <b>Procedure Title</b>  | Injector Supply Lines (High Pressure)                                   |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                     |
| <b>Procedure Number</b> | 40-007-001<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-001.html) |
| <b>Procedure Title</b>  | Engine Oil Heater                                                 |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-013-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-013-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Filter (Spin-On)                                        |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-029-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-029-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pressure Regulator (Main Rifle)                         |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-031-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-031-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pump                                                    |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-035-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-035-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Suction Tube (Block-Mounted)                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-037<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-037.html)       |
| <b>Procedure Title</b>  | Lubricating Oil System                                                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-044<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-044.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Contamination                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-052<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-052.html)       |
| <b>Procedure Title</b>  | Lubricating Oil Pressure Sensor, OEM                                    |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-002-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-002-tr.html) |
| <b>Procedure Title</b>  | Drive Belt, Cooling Fan                                                 |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-018-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-018-tr.html) |
| <b>Procedure Title</b>  | Cooling System                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-019<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-019.html)       |
| <b>Procedure Title</b>  | Cooling System - Air or Combustion Gas Test                             |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-020<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-020.html)       |
| <b>Procedure Title</b>  | Cooling System Diagnostics                                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-026-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-026-tr.html) |
| <b>Procedure Title</b>  | Fan Clutch, Electric                                                    |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-042<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-042.html)       |
| <b>Procedure Title</b>  | Radiator                                                                |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-047<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-047.html)       |
| <b>Procedure Title</b>  | Radiator Pressure Cap                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-062-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-062-tr.html) |
| <b>Procedure Title</b>  | Water Pump                                                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-087-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-087-tr.html) |
| <b>Procedure Title</b>  | Cooling Fan Belt Tensioner                                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 9 - Drive Units - Group 09                                      |
| <b>Procedure Number</b> | 40-009-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-001-tr.html) |
| <b>Procedure Title</b>  | Accessory Drive                                                         |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 9 - Drive Units - Group 09                                      |
| <b>Procedure Number</b> | 40-009-016<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-016.html)       |
| <b>Procedure Title</b>  | Hydraulic Pump Drive                                                    |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 9 - Drive Units - Group 09                                      |
| <b>Procedure Number</b> | 40-009-039-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-009-039-tr.html) |
| <b>Procedure Title</b>  | Accessory Drive Cover                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-001-tr.html) |
| <b>Procedure Title</b>  | Aftercooler                                                             |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-019-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-019-tr.html) |
| <b>Procedure Title</b>  | Air Crossover                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-024-tr.html) |
| <b>Procedure Title</b>  | Air Leaks, Air Intake and Exhaust Systems                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-027-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-027-tr.html) |
| <b>Procedure Title</b>  | Charge-Air Cooler                                                       |
| <b>Update Reason</b>    |                                                                         |



|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-045-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-045-tr.html) |
| <b>Procedure Title</b>  | Turbocharger Oil Drain Line                                             |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                         |
| <b>Procedure Number</b> | 40-010-050<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-050.html) |
| <b>Procedure Title</b>  | Turbocharger Wastegate Actuator                                   |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                         |
| <b>Procedure Number</b> | 40-010-055<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-055.html) |
| <b>Procedure Title</b>  | Turbocharger Wastegate Valve Body                                 |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                         |
| <b>Procedure Number</b> | 40-010-057<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-057.html) |
| <b>Procedure Title</b>  | Intake Manifold Pressure                                          |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                         |
| <b>Procedure Number</b> | 40-010-072<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-072.html) |
| <b>Procedure Title</b>  | Air Intake Manifold Heater                                        |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-124-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-124-tr.html) |
| <b>Procedure Title</b>  | Intake Manifold Air Heater Element                                      |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-131-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-131-tr.html) |
| <b>Procedure Title</b>  | Air Intake Connection Adapter                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 11 - Exhaust System - Group 11                                  |
| <b>Procedure Number</b> | 40-011-007-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-011-007-tr.html) |
| <b>Procedure Title</b>  | Exhaust Manifold, Dry                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 11 - Exhaust System - Group 11                                  |
| <b>Procedure Number</b> | 40-011-009-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-011-009-tr.html) |
| <b>Procedure Title</b>  | Exhaust Restriction                                                     |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-003-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Carbon Buildup                                           |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-004-tr.html) |
| <b>Procedure Title</b>  | Air Compressor Coolant Lines                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-010<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-010.html)       |
| <b>Procedure Title</b>  | Air Compressor Pin Bore Wear                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-013<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-013.html)       |
| <b>Procedure Title</b>  | Air Compressor Unloader and Valve Assembly                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-017<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-017.html)       |
| <b>Procedure Title</b>  | Air Governor (Air Compressor Will Not Pump)                             |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                     |
| <b>Procedure Number</b> | 40-012-018<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-018.html) |
| <b>Procedure Title</b>  | Air Governor (Air Compressor Pumps Continuously)                  |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                     |
| <b>Procedure Number</b> | 40-012-019<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-019.html) |
| <b>Procedure Title</b>  | Air Leaks, Compressed Air System                                  |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                     |
| <b>Procedure Number</b> | 40-012-101<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-101.html) |
| <b>Procedure Title</b>  | Air Compressor Cylinder Head (Holset® SS191 Model)                |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                     |
| <b>Procedure Number</b> | 40-012-104<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-104.html) |
| <b>Procedure Title</b>  | Air Compressor Cylinder Head (Holset® QE Models)                  |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-003-tr.html) |
| <b>Procedure Title</b>  | Alternator Bracket                                                      |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-006-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-006-tr.html) |
| <b>Procedure Title</b>  | Alternator Pulley                                                       |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                      |
| <b>Procedure Number</b> | 40-013-007<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-007.html) |
| <b>Procedure Title</b>  | Batteries                                                         |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                       |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                      |
| <b>Procedure Number</b> | 40-013-009<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-009.html) |
| <b>Procedure Title</b>  | Battery Cables and Connections                                    |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-017-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-017-tr.html) |
| <b>Procedure Title</b>  | Starter Magnetic Switch                                                 |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-018<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-018.html)       |
| <b>Procedure Title</b>  | Starter Switch                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-019<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-019.html)       |
| <b>Procedure Title</b>  | Starter Solenoid                                                        |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 40-014-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-003-tr.html) |
| <b>Procedure Title</b>  | Engine Run-in (Chassis Dynamometer)                                     |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 40-014-004<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-004.html)       |
| <b>Procedure Title</b>  | Engine Run-in (Without Dynamometer)                                     |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 31-Mar-2006                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 40-014-005-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-005-tr.html) |
| <b>Procedure Title</b>  | Engine Testing (Engine Dynamometer)                                     |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                  |
|-------------------------|----------------------------------------------------------------------------------|
| <b>Date</b>             | 31-Mar-2006                                                                      |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                     |
| <b>Procedure Number</b> | 40-016-002-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-002-tr.html)          |
| <b>Procedure Title</b>  | Engine Support Bracket, Front                                                    |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 31-Mar-2006                                                                      |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                     |
| <b>Procedure Number</b> | 40-016-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-003-tr.html)          |
| <b>Procedure Title</b>  | Engine Support Bracket, Rear                                                     |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 31-Mar-2006                                                                      |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                     |
| <b>Procedure Number</b> | 40-016-005-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-005-tr.html)          |
| <b>Procedure Title</b>  | Flywheel                                                                         |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 31-Mar-2006                                                                      |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                     |
| <b>Procedure Number</b> | 40-016-008<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-008.html)                |
| <b>Procedure Title</b>  | Flywheel Ring Gear                                                               |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 31-Mar-2006                                                                      |
| <b>Section</b>          | Back                                                                             |
| <b>Procedure Number</b> | 3666087-backcover<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-backcover.html) |
| <b>Procedure Title</b>  | Backcover                                                                        |
| <b>Update Reason</b>    |                                                                                  |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 03-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-022-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-022-shopds.html) |
| <b>Procedure Title</b>  | Crankshaft Pulley                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-022-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-022-shopas.html) |
| <b>Procedure Title</b>  | Crankshaft Pulley                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-022-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-022-tr.html)         |
| <b>Procedure Title</b>  | Crankshaft Pulley                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-023-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-023-shopds.html) |
| <b>Procedure Title</b>  | Crankshaft Seal, Front                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-012-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-012-shopds.html) |
| <b>Procedure Title</b>  | Camshaft Gear (Camshaft Installed)                                              |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-012-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-012-shopas.html) |
| <b>Procedure Title</b>  | Camshaft Gear (Camshaft Installed)                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-023-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-023-shopas.html) |
| <b>Procedure Title</b>  | Crankshaft Seal, Front                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-012-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-012-tr.html)         |
| <b>Procedure Title</b>  | Camshaft Gear (Camshaft Installed)                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-018<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-018.html)               |
| <b>Procedure Title</b>  | Crankshaft Gear, Front (Crankshaft Installed)                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-019<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-019.html)               |
| <b>Procedure Title</b>  | Crankshaft Gear, Front (Crankshaft Removed)                                     |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 04-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-023-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-023-tr.html)         |
| <b>Procedure Title</b>  | Crankshaft Seal, Front                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-011-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-011-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Dipstick Tube                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-052-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-052-shopds.html) |
| <b>Procedure Title</b>  | Fuel Connector (Head Mounted)                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-082-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-082-shopds.html) |
| <b>Procedure Title</b>  | Water Inlet Connection                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-016-004-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-004-shopds.html) |
| <b>Procedure Title</b>  | Flexplate                                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-104-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-104-shopds.html) |
| <b>Procedure Title</b>  | Crankshaft Seal Carrier, Rear                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-089-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-089-shopds.html) |
| <b>Procedure Title</b>  | Block Stiffener Plate                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-089-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-089-shopas.html) |
| <b>Procedure Title</b>  | Block Stiffener Plate                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-104-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-104-shopas.html) |
| <b>Procedure Title</b>  | Crankshaft Seal Carrier, Rear                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-016-004-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-004-shopas.html) |
| <b>Procedure Title</b>  | Flexplate                                                                       |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-082-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-082-shopas.html) |
| <b>Procedure Title</b>  | Water Inlet Connection                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-052-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-052-shopas.html) |
| <b>Procedure Title</b>  | Fuel Connector (Head Mounted)                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-011-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-011-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Dipstick Tube                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-089-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-089-tr.html)         |
| <b>Procedure Title</b>  | Block Stiffener Plate                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-104-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-104-tr.html)         |
| <b>Procedure Title</b>  | Crankshaft Seal Carrier, Rear                                                   |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 05-Apr-2006                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                         |
| <b>Procedure Number</b> | 40-006-052-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-052-tr.html) |
| <b>Procedure Title</b>  | Fuel Connector (Head Mounted)                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 05-Apr-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-007-011-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-011-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Dipstick Tube                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 05-Apr-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-082-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-082-tr.html) |
| <b>Procedure Title</b>  | Water Inlet Connection                                                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 05-Apr-2006                                                             |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                            |
| <b>Procedure Number</b> | 40-016-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-004-tr.html) |
| <b>Procedure Title</b>  | Flexplate                                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                                  |
| <b>Procedure Number</b> | 40-022-001_00<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_00.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                                          |
| <b>Procedure Number</b> | 40-000-001<br>(/qs3/pubsys2/xml/en/procedures/40/40-000-001.html)               |
| <b>Procedure Title</b>  | Engine Removal                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                                          |
| <b>Procedure Number</b> | 40-000-002<br>(/qs3/pubsys2/xml/en/procedures/40/40-000-002.html)               |
| <b>Procedure Title</b>  | Engine Installation                                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-002-001-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-001-shopds.html) |
| <b>Procedure Title</b>  | Crosshead                                                                       |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-002-001-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-001-shopas.html) |
| <b>Procedure Title</b>  | Crosshead                                                                       |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-013<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-013.html)               |
| <b>Procedure Title</b>  | Camshaft Gear (Camshaft Removed)                                                |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                    |
| <b>Procedure Number</b> | 40-002-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-001-tr.html) |
| <b>Procedure Title</b>  | Crosshead                                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-022-001_03<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_03.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 40-022-001_07<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_07.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-022-001_08<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_08.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 10-Apr-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-022-001_10<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_10.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 11 - Exhaust System - Group 11                                          |
| <b>Procedure Number</b> | 40-022-001_11<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_11.html)         |
| <b>Procedure Title</b>  | Service Tools                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                          |
| <b>Procedure Number</b> | 40-022-001_14<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_14.html)         |
| <b>Procedure Title</b>  | Service Tools                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                    |
| <b>Procedure Number</b> | 40-022-001_16<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_16.html)         |
| <b>Procedure Title</b>  | Service Tools                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Apr-2006                                                                     |
| <b>Section</b>          | Section 17 - Miscellaneous - Group 17                                           |
| <b>Procedure Number</b> | 40-022-001_17<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_17.html)         |
| <b>Procedure Title</b>  | Service Tools                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-023-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-023-shopds.html) |
| <b>Procedure Title</b>  | Air Intake Manifold                                                             |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-033-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-033-shopds.html) |
| <b>Procedure Title</b>  | Turbocharger                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-002-021-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-021-shopds.html) |
| <b>Procedure Title</b>  | Cylinder Head Gasket                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-011-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-011-shopds.html) |
| <b>Procedure Title</b>  | Coolant Heater                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-013-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-013-shopds.html) |
| <b>Procedure Title</b>  | Coolant Thermostat                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-012-014-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-014-shopds.html) |
| <b>Procedure Title</b>  | Air Compressor                                                                  |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-005-012-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-012-shopds.html) |
| <b>Procedure Title</b>  | Fuel Injection Pumps, In-Line                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-004-017-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-017-shopds.html) |
| <b>Procedure Title</b>  | Tappet Cover                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-013-020-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-020-shopds.html) |
| <b>Procedure Title</b>  | Starting Motor                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-016-006-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-006-shopds.html) |
| <b>Procedure Title</b>  | Flywheel Housing                                                                |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-016-006-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-006-shopas.html) |
| <b>Procedure Title</b>  | Flywheel Housing                                                                |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-013-020-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-020-shopas.html) |
| <b>Procedure Title</b>  | Starting Motor                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-004-017-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-017-shopas.html) |
| <b>Procedure Title</b>  | Tappet Cover                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-005-012-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-012-shopas.html) |
| <b>Procedure Title</b>  | Fuel Injection Pumps, In-Line                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-012-014-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-014-shopas.html) |
| <b>Procedure Title</b>  | Air Compressor                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-013-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-013-shopas.html) |
| <b>Procedure Title</b>  | Coolant Thermostat                                                              |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-011-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-011-shopas.html) |
| <b>Procedure Title</b>  | Coolant Heater                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-002-021-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-021-shopas.html) |
| <b>Procedure Title</b>  | Cylinder Head Gasket                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-033-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-033-shopas.html) |
| <b>Procedure Title</b>  | Turbocharger                                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-023-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-023-shopas.html) |
| <b>Procedure Title</b>  | Air Intake Manifold                                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Apr-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-003-004-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-004-shopas.html) |
| <b>Procedure Title</b>  | Overhead Set                                                                    |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                    |
| <b>Procedure Number</b> | 40-002-021-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-021-tr.html) |
| <b>Procedure Title</b>  | Cylinder Head Gasket                                                    |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 3 - Rocker Levers - Group 03                                    |
| <b>Procedure Number</b> | 40-003-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-003-004-tr.html) |
| <b>Procedure Title</b>  | Overhead Set                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 4 - Cam Followers/Tappets - Group 04                            |
| <b>Procedure Number</b> | 40-004-017-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-004-017-tr.html) |
| <b>Procedure Title</b>  | Tappet Cover                                                            |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-012-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-012-tr.html) |
| <b>Procedure Title</b>  | Fuel Injection Pumps, In-Line                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                      |
| <b>Procedure Number</b> | 40-005-043-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-043-tr.html) |
| <b>Procedure Title</b>  | Fuel Shutoff Valve                                                      |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                       |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                     |
| <b>Procedure Number</b> | 40-007-009<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-009.html) |
| <b>Procedure Title</b>  | Lubricating Oil Dipstick                                          |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-011-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-011-tr.html) |
| <b>Procedure Title</b>  | Coolant Heater                                                          |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                   |
| <b>Procedure Number</b> | 40-008-013-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-013-tr.html) |
| <b>Procedure Title</b>  | Coolant Thermostat                                                      |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-023-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-023-tr.html) |
| <b>Procedure Title</b>  | Air Intake Manifold                                                     |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-033-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-033-tr.html) |
| <b>Procedure Title</b>  | Turbocharger                                                            |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                           |
| <b>Procedure Number</b> | 40-012-014-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-014-tr.html) |
| <b>Procedure Title</b>  | Air Compressor                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                            |
| <b>Procedure Number</b> | 40-013-020-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-020-tr.html) |
| <b>Procedure Title</b>  | Starting Motor                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 40-014-008<br>(/qs3/pubsys2/xml/en/procedures/40/40-014-008.html)       |
| <b>Procedure Title</b>  | Engine Testing (In Chassis)                                             |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 24-Apr-2006                                                             |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                            |
| <b>Procedure Number</b> | 40-016-006-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-016-006-tr.html) |
| <b>Procedure Title</b>  | Flywheel Housing                                                        |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 22-May-2006                                                             |
| <b>Section</b>          | Front                                                                   |
| <b>Procedure Number</b> | shopds-frwd<br>(/qs3/pubsys2/xml/en/manual/preface/shopds-frwd.html)    |
| <b>Procedure Title</b>  | Foreword                                                                |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 24-May-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-054-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-shopds.html) |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-May-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-054-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-shopas.html) |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-May-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-054-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-tr.html)         |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 21-Jun-2006                                                                     |
| <b>Section</b>          | Section F - Familiarization                                                     |
| <b>Procedure Number</b> | 40-005-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-999.html)               |
| <b>Procedure Title</b>  | Fuel System - Overview                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 21-Jun-2006                                                                     |
| <b>Section</b>          | Section F - Familiarization                                                     |
| <b>Procedure Number</b> | 40-200-006-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-006-tr.html)         |
| <b>Procedure Title</b>  | Flow Diagram, Compressed Air System                                             |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 27-Jun-2006                                                             |
| <b>Section</b>          | Section L - Service Literature                                          |
| <b>Procedure Number</b> | 99-205-002<br>(/qs3/pubsys2/xml/en/procedures/99/99-205-002.html)       |
| <b>Procedure Title</b>  | Service Literature Ordering Location                                    |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 13-Jul-2006                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-012-999<br>(/qs3/pubsys2/xml/en/procedures/40/40-012-999.html)       |
| <b>Procedure Title</b>  | Compressed Air System - Overview                                        |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 11-Aug-2006                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-014<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-014.html)       |
| <b>Procedure Title</b>  | Connecting Rod                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 03-Oct-2006                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-200-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-001-tr.html) |
| <b>Procedure Title</b>  | Flow Diagram, Fuel System                                               |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 03-Oct-2006                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-200-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-004-tr.html) |
| <b>Procedure Title</b>  | Flow Diagram, Air Intake System                                         |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 03-Oct-2006                                                                     |
| <b>Section</b>          | Section F - Familiarization                                                     |
| <b>Procedure Number</b> | 40-200-005-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-005-tr.html)         |
| <b>Procedure Title</b>  | Flow Diagram, Exhaust System                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Dec-2006                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-005-014-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-014-shopds.html) |
| <b>Procedure Title</b>  | Fuel Injection Pump, Rotary                                                     |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Dec-2006                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-005-014-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-014-shopas.html) |
| <b>Procedure Title</b>  | Fuel Injection Pump, Rotary                                                     |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Dec-2006                                                                     |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                              |
| <b>Procedure Number</b> | 40-005-014-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-014-tr.html)         |
| <b>Procedure Title</b>  | Fuel Injection Pump, Rotary                                                     |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 11-Dec-2006                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-004<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-004.html)               |
| <b>Procedure Title</b>  | Balancer                                                                        |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 18-Dec-2006                                                                     |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                            |
| <b>Procedure Number</b> | 40-002-016<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-016.html)               |
| <b>Procedure Title</b>  | Valve Guide Seal, Cylinder Head                                                 |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Jan-2007                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-024-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-024-shopds.html) |
| <b>Procedure Title</b>  | Crankshaft Seal, Rear                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Jan-2007                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-024-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-024-shopas.html) |
| <b>Procedure Title</b>  | Crankshaft Seal, Rear                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Jan-2007                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-024-tr.html)         |
| <b>Procedure Title</b>  | Crankshaft Seal, Rear                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 07-Mar-2007                                                                     |
| <b>Section</b>          | Section E - Engine and System Identification                                    |
| <b>Procedure Number</b> | 40-100-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-100-001-tr.html)         |
| <b>Procedure Title</b>  | Engine Identification                                                           |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 07-Mar-2007                                                             |
| <b>Section</b>          | Section E - Engine and System Identification                            |
| <b>Procedure Number</b> | 40-100-002-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-100-002-tr.html) |
| <b>Procedure Title</b>  | Engine Diagrams                                                         |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 07-Mar-2007                                                             |
| <b>Section</b>          | Section L - Service Literature                                          |
| <b>Procedure Number</b> | 40-205-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-205-001-tr.html) |
| <b>Procedure Title</b>  | Additional Service Literature                                           |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 07-Mar-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-015-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-015-tr.html) |
| <b>Procedure Title</b>  | General Engine                                                          |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 17-Apr-2007                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-001-043<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-043.html)       |
| <b>Procedure Title</b>  | Piston                                                                  |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 23-Apr-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-016-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-016-tr.html) |
| <b>Procedure Title</b>  | Fuel System                                                             |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-018-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-018-tr.html) |
| <b>Procedure Title</b>  | Cooling System                                                          |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-019-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-019-tr.html) |
| <b>Procedure Title</b>  | Air Intake System                                                       |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 24-Apr-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-020-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-020-tr.html) |
| <b>Procedure Title</b>  | Exhaust System                                                          |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 25-Apr-2007                                                       |
| <b>Section</b>          | Section V - Specifications                                        |
| <b>Procedure Number</b> | 40-018-022<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-022.html) |
| <b>Procedure Title</b>  | Compressed Air System                                             |
| <b>Update Reason</b>    |                                                                   |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 25-Apr-2007                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-002-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-002-tr.html) |
| <b>Procedure Title</b>  | Fuel Recommendations and Specifications                                 |
| <b>Update Reason</b>    |                                                                         |

|                         |                                                                                  |
|-------------------------|----------------------------------------------------------------------------------|
| <b>Date</b>             | 25-Apr-2007                                                                      |
| <b>Section</b>          | Section V - Specifications                                                       |
| <b>Procedure Number</b> | 40-018-006<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-006.html)                |
| <b>Procedure Title</b>  | Engine Component Torque Values                                                   |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 21-May-2007                                                                      |
| <b>Section</b>          | Section V - Specifications                                                       |
| <b>Procedure Number</b> | 40-018-017-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-017-tr.html)          |
| <b>Procedure Title</b>  | Lubricating Oil System                                                           |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 22-May-2007                                                                      |
| <b>Section</b>          | Section V - Specifications                                                       |
| <b>Procedure Number</b> | 40-018-023<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-023.html)                |
| <b>Procedure Title</b>  | Engine Testing                                                                   |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 24-May-2007                                                                      |
| <b>Section</b>          | Front                                                                            |
| <b>Procedure Number</b> | 3666087-titlepage<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-titlepage.html) |
| <b>Procedure Title</b>  | Titlepage                                                                        |
| <b>Update Reason</b>    |                                                                                  |
| <b>Date</b>             | 22-Jun-2007                                                                      |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                               |
| <b>Procedure Number</b> | 40-005-037-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-037-tr.html)          |
| <b>Procedure Title</b>  | Fuel Pump Timing                                                                 |
| <b>Update Reason</b>    |                                                                                  |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 02-Jul-2007                                                                     |
| <b>Section</b>          | Section V - Specifications                                                      |
| <b>Procedure Number</b> | 40-018-021-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-021-tr.html)         |
| <b>Procedure Title</b>  | Electrical System                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 23-Jul-2007                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t118-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t118-tr.html)    |
| <b>Procedure Title</b>  | Smoke, White - Excessive                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Jul-2007                                                                     |
| <b>Section</b>          | Section i - Introduction                                                        |
| <b>Procedure Number</b> | 99-204-008<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-008.html)               |
| <b>Procedure Title</b>  | General Cleaning Instructions                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 07-Sep-2007                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-026-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-026-shopds.html) |
| <b>Procedure Title</b>  | Injector                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 14-Sep-2007                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-026-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-026-shopas.html) |
| <b>Procedure Title</b>  | Injector                                                                        |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 14-Sep-2007                                                                     |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                 |
| <b>Procedure Number</b> | 40-006-026-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-026-tr.html)         |
| <b>Procedure Title</b>  | Injector                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 20-Feb-2008                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-026<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-026.html)               |
| <b>Procedure Title</b>  | Cylinder Block                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Apr-2008                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-008-036-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-036-shopds.html) |
| <b>Procedure Title</b>  | Fan Hub, Belt Driven                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Apr-2008                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-008-036-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-036-shopas.html) |
| <b>Procedure Title</b>  | Fan Hub, Belt Driven                                                            |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Apr-2008                                                                     |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                           |
| <b>Procedure Number</b> | 40-008-036-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-036-tr.html)         |
| <b>Procedure Title</b>  | Fan Hub, Belt Driven                                                            |
| <b>Update Reason</b>    |                                                                                 |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 03-Apr-2008                                                                     |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                           |
| <b>Procedure Number</b> | 40-008-039-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-039-tr.html)         |
| <b>Procedure Title</b>  | Fan Spacer and Pulley                                                           |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Jun-2008                                                                     |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                                   |
| <b>Procedure Number</b> | 100-007-083<br>(/qs3/pubsys2/xml/en/procedures/100/100-007-083.html)            |
| <b>Procedure Title</b>  | Lubricating Oil and Filter Analysis                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Aug-2008                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-010-046-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-046-shopds.html) |
| <b>Procedure Title</b>  | Turbocharger Oil Supply Line                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Aug-2008                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-010-046-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-046-shopas.html) |
| <b>Procedure Title</b>  | Turbocharger Oil Supply Line                                                    |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Aug-2008                                                                     |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                                       |
| <b>Procedure Number</b> | 40-010-046-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-046-tr.html)         |
| <b>Procedure Title</b>  | Turbocharger Oil Supply Line                                                    |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 19-Aug-2008                                                                     |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                           |
| <b>Procedure Number</b> | 40-008-070<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-070.html)               |
| <b>Procedure Title</b>  | Coolant Temperature Sensor                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 28-Aug-2008                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-022-001_01<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_01.html)         |
| <b>Procedure Title</b>  | Service Tools                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 28-Aug-2008                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-010-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-010-tr.html)         |
| <b>Procedure Title</b>  | Camshaft Bushings                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 06-Oct-2008                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-016-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-016-shopds.html) |
| <b>Procedure Title</b>  | Crankshaft                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 06-Oct-2008                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-016-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-016-shopas.html) |
| <b>Procedure Title</b>  | Crankshaft                                                                      |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 06-Oct-2008                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-016-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-016-tr.html)         |
| <b>Procedure Title</b>  | Crankshaft                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 16-Jan-2009                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-006-015-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-015-shopds.html) |
| <b>Procedure Title</b>  | Fuel Filter (Spin-On Type)                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 16-Jan-2009                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-006-015-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-015-shopas.html) |
| <b>Procedure Title</b>  | Fuel Filter (Spin-On Type)                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 16-Jan-2009                                                                     |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                 |
| <b>Procedure Number</b> | 40-006-015-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-015-tr.html)         |
| <b>Procedure Title</b>  | Fuel Filter (Spin-On Type)                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 13-Feb-2009                                                                     |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                                   |
| <b>Procedure Number</b> | 40-007-048<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-048.html)               |
| <b>Procedure Title</b>  | Lubricating Oil System Diagnostics                                              |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 10-Mar-2009                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-005-045-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-045-shopds.html) |
| <b>Procedure Title</b>  | Fuel Lift Pump                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Mar-2009                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-005-045-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-045-shopas.html) |
| <b>Procedure Title</b>  | Fuel Lift Pump                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Mar-2009                                                                     |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                              |
| <b>Procedure Number</b> | 40-005-045-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-045-tr.html)         |
| <b>Procedure Title</b>  | Fuel Lift Pump                                                                  |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Jun-2009                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-008-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-008-shopds.html) |
| <b>Procedure Title</b>  | Camshaft                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 05-Jun-2009                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-008-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-008-shopas.html) |
| <b>Procedure Title</b>  | Camshaft                                                                        |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 05-Jun-2009                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-008-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-008-tr.html)         |
| <b>Procedure Title</b>  | Camshaft                                                                        |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Jun-2009                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-003-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-003-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Cooler                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Jun-2009                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-003-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-003-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Cooler                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Jun-2009                                                                     |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                                   |
| <b>Procedure Number</b> | 40-007-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-003-tr.html)         |
| <b>Procedure Title</b>  | Lubricating Oil Cooler                                                          |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Jun-2009                                                                     |
| <b>Section</b>          | Section 17 - Miscellaneous - Group 17                                           |
| <b>Procedure Number</b> | 100-017-011<br>(/qs3/pubsys2/xml/en/procedures/100/100-017-011.html)            |
| <b>Procedure Title</b>  | Straight Thread Plug                                                            |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                      |
|-------------------------|--------------------------------------------------------------------------------------|
| <b>Date</b>             | 25-Jun-2009                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 99-t00-001-tr<br>(/qs3/pubsys2/xml/en/procedures/99/99-t00-001-tr.html)              |
| <b>Procedure Title</b>  | Troubleshooting Procedures and Techniques                                            |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 08-Jul-2009                                                                          |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                               |
| <b>Procedure Number</b> | 100-014-002<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-002.html)                 |
| <b>Procedure Title</b>  | Engine Testing (Chassis Dynamometer)                                                 |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 22-Jul-2009                                                                          |
| <b>Section</b>          | Section L - Service Literature                                                       |
| <b>Procedure Number</b> | 99-205-004<br>(/qs3/pubsys2/xml/en/procedures/99/99-205-004.html)                    |
| <b>Procedure Title</b>  | Cummins Customized Parts Catalog                                                     |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 27-Jul-2009                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t074-005-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t074-005-tr.html) |
| <b>Procedure Title</b>  | Engine Will Not Crank - (Electric Starter)                                           |
| <b>Update Reason</b>    |                                                                                      |
| <b>Date</b>             | 27-Jul-2009                                                                          |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                |
| <b>Procedure Number</b> | 3666087-t074-010-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t074-010-tr.html) |
| <b>Procedure Title</b>  | Engine Cranks Slowly - (Electric Starter)                                            |
| <b>Update Reason</b>    |                                                                                      |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 07-Aug-2009                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-013-001-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-001-shopds.html) |
| <b>Procedure Title</b>  | Alternator                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 07-Aug-2009                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-013-001-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-001-shopas.html) |
| <b>Procedure Title</b>  | Alternator                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 07-Aug-2009                                                                     |
| <b>Section</b>          | Section 13 - Electrical Equipment - Group 13                                    |
| <b>Procedure Number</b> | 40-013-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-001-tr.html)         |
| <b>Procedure Title</b>  | Alternator                                                                      |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Sep-2009                                                                     |
| <b>Section</b>          | Section i - Introduction                                                        |
| <b>Procedure Number</b> | 99-204-002-shopds<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-002-shopds.html) |
| <b>Procedure Title</b>  | About the Manual                                                                |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 10-Sep-2009                                                                     |
| <b>Section</b>          | Section i - Introduction                                                        |
| <b>Procedure Number</b> | 99-204-003-shopds<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-003-shopds.html) |
| <b>Procedure Title</b>  | How to Use the Manual                                                           |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 08-Oct-2009                                                             |
| <b>Section</b>          | Section i - Introduction                                                |
| <b>Procedure Number</b> | 99-204-007-tr<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-007-tr.html) |
| <b>Procedure Title</b>  | General Repair Instructions                                             |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 09-Oct-2009                                                             |
| <b>Section</b>          | Section 0 - Complete Engine - Group 00                                  |
| <b>Procedure Number</b> | 99-000-005-tr<br>(/qs3/pubsys2/xml/en/procedures/99/99-000-005-tr.html) |
| <b>Procedure Title</b>  | Engine Storage - Long Term                                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 14-Oct-2009                                                             |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                           |
| <b>Procedure Number</b> | 99-007-043-tr<br>(/qs3/pubsys2/xml/en/procedures/99/99-007-043-tr.html) |
| <b>Procedure Title</b>  | Lubricating Oil Level                                                   |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 18-Nov-2009                                                             |
| <b>Section</b>          | Section V - Specifications                                              |
| <b>Procedure Number</b> | 40-018-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-024-tr.html) |
| <b>Procedure Title</b>  | Cummins®/Fleetguard® Filter Specifications                              |
| <b>Update Reason</b>    |                                                                         |
| <b>Date</b>             | 25-Jan-2010                                                             |
| <b>Section</b>          | Section i - Introduction                                                |
| <b>Procedure Number</b> | 99-204-006-tr<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-006-tr.html) |
| <b>Procedure Title</b>  | General Safety Instructions                                             |
| <b>Update Reason</b>    |                                                                         |



|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 25-Jan-2010                                                                     |
| <b>Section</b>          | Section V - Specifications                                                      |
| <b>Procedure Number</b> | 99-018-005<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-005.html)               |
| <b>Procedure Title</b>  | Drive Belt Tension                                                              |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 25-Jan-2010                                                                     |
| <b>Section</b>          | Section V - Specifications                                                      |
| <b>Procedure Number</b> | 99-018-009<br>(/qs3/pubsys2/xml/en/procedures/99/99-018-009.html)               |
| <b>Procedure Title</b>  | Capscrew Markings and Torque Values                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 12-Feb-2010                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-002-004-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-004-shopds.html) |
| <b>Procedure Title</b>  | Cylinder Head                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 12-Feb-2010                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-002-004-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-004-shopas.html) |
| <b>Procedure Title</b>  | Cylinder Head                                                                   |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 12-Feb-2010                                                                     |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                            |
| <b>Procedure Number</b> | 40-002-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-004-tr.html)         |
| <b>Procedure Title</b>  | Cylinder Head                                                                   |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 01-Mar-2010                                                                     |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                          |
| <b>Procedure Number</b> | 100-014-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-010.html)            |
| <b>Procedure Title</b>  | Crankcase Blowby, Measure                                                       |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Mar-2010                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-001-031-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-031-shopds.html) |
| <b>Procedure Title</b>  | Gear Cover, Front                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Mar-2010                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-001-031-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-031-shopas.html) |
| <b>Procedure Title</b>  | Gear Cover, Front                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 03-Mar-2010                                                                     |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                           |
| <b>Procedure Number</b> | 40-001-031-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-031-tr.html)         |
| <b>Procedure Title</b>  | Gear Cover, Front                                                               |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 24-Mar-2010                                                                     |
| <b>Section</b>          | Section i - Introduction                                                        |
| <b>Procedure Number</b> | 99-204-009<br>(/qs3/pubsys2/xml/en/procedures/99/99-204-009.html)               |
| <b>Procedure Title</b>  | Acronyms and Abbreviations                                                      |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                 |
|-------------------------|---------------------------------------------------------------------------------|
| <b>Date</b>             | 19-May-2010                                                                     |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                           |
| <b>Procedure Number</b> | 3666087-t057-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t057-tr.html)    |
| <b>Procedure Title</b>  | Engine Power Output Low                                                         |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 25-May-2010                                                                     |
| <b>Section</b>          | Section F - Familiarization                                                     |
| <b>Procedure Number</b> | 100-001-999<br>(/qs3/pubsys2/xml/en/procedures/100/100-001-999.html)            |
| <b>Procedure Title</b>  | Cylinder Block - Overview                                                       |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 01-Jun-2010                                                                     |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                      |
| <b>Procedure Number</b> | 40-007-025-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-025-shopds.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pan                                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 01-Jun-2010                                                                     |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                         |
| <b>Procedure Number</b> | 40-007-025-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-025-shopas.html) |
| <b>Procedure Title</b>  | Lubricating Oil Pan                                                             |
| <b>Update Reason</b>    |                                                                                 |
| <b>Date</b>             | 01-Jun-2010                                                                     |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                                   |
| <b>Procedure Number</b> | 40-007-025-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-025-tr.html)         |
| <b>Procedure Title</b>  | Lubricating Oil Pan                                                             |
| <b>Update Reason</b>    |                                                                                 |

|                         |                                                                                                                                                         |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 26-Jan-2011                                                                                                                                             |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                                                                                                   |
| <b>Procedure Number</b> | 100-008-042<br>(/qs3/pubsys2/xml/en/procedures/100/100-008-042.html)                                                                                    |
| <b>Procedure Title</b>  | Radiator                                                                                                                                                |
| <b>Update Reason</b>    | Made this a common procedure.                                                                                                                           |
| <b>Date</b>             | 11-Feb-2011                                                                                                                                             |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                                                                                                   |
| <b>Procedure Number</b> | 3666087-t118-tr<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t118-tr.html)                                                                            |
| <b>Procedure Title</b>  | White, Smoke - Excessive                                                                                                                                |
| <b>Update Reason</b>    | Added tree node for fuel inlet pressure restriction.                                                                                                    |
| <b>Date</b>             | 21-Feb-2011                                                                                                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 1                                                                                                                    |
| <b>Procedure Number</b> | 40-001-016<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-016.html)                                                                                       |
| <b>Procedure Title</b>  | Crankshaft                                                                                                                                              |
| <b>Update Reason</b>    | Added the balancer (Remove and Install) to the Preparatory and Finishing Steps.                                                                         |
| <b>Date</b>             | 28-Feb-2011                                                                                                                                             |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                                                                                         |
| <b>Procedure Number</b> | 40-006-026-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-026-tr.html)                                                                                 |
| <b>Procedure Title</b>  | Injector                                                                                                                                                |
| <b>Update Reason</b>    | Revision of caution note advising technicians to not use any sort of abrasive to clean injector tips to prevent possible damage and performance issues. |

|                         |                                                                                                              |
|-------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 10-Jan-2012                                                                                                  |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                                        |
| <b>Procedure Number</b> | 40-001-047<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-047.html)                                            |
| <b>Procedure Title</b>  | Piston Rings                                                                                                 |
| <b>Update Reason</b>    | Changes were made to the procedure to include a cross reference table for top and intermediate piston rings. |
| <b>Date</b>             | 11-Jan-2012                                                                                                  |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                                                         |
| <b>Procedure Number</b> | 40-002-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-004-tr.html)                                      |
| <b>Procedure Title</b>  | Cylinder Head                                                                                                |
| <b>Update Reason</b>    | Updated the Clean and Inspect for Reuse section for combustion seal ring.                                    |
| <b>Date</b>             | 11-Jan-2012                                                                                                  |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                                        |
| <b>Procedure Number</b> | 40-001-026<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-026.html)                                            |
| <b>Procedure Title</b>  | Cylinder Block                                                                                               |
| <b>Update Reason</b>    | Added information for torque plate tool release; the release of the 107 mm [4.21 in] bore sleeve.            |
| <b>Date</b>             | 07-Feb-2012                                                                                                  |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                                              |
| <b>Procedure Number</b> | 40-006-026<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-026.html)                                            |
| <b>Procedure Title</b>  | Injector                                                                                                     |
| <b>Update Reason</b>    | Added information covering injector protrusion specifications for the Mechanical B series engines.           |

|                         |                                                                                    |
|-------------------------|------------------------------------------------------------------------------------|
| <b>Date</b>             | 02-Mar-2012                                                                        |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                              |
| <b>Procedure Number</b> | 40-001-067<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-067.html)                  |
| <b>Procedure Title</b>  | Crankshaft Wear Sleeve, Rear                                                       |
| <b>Update Reason</b>    | Updated Loctite™ and torque specifications.                                        |
| <b>Date</b>             | 02-Mar-2012                                                                        |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                              |
| <b>Procedure Number</b> | 40-001-104-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-104-tr.html)            |
| <b>Procedure Title</b>  | Crankshaft Seal Carrier, Rear                                                      |
| <b>Update Reason</b>    | Updated Loctite™ and torque specifications.                                        |
| <b>Date</b>             | 18-Apr-2012                                                                        |
| <b>Section</b>          | Section 8 - Cooling System                                                         |
| <b>Procedure Number</b> | 40-008-026-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-026-tr.html)            |
| <b>Procedure Title</b>  | Fan Clutch, Electric                                                               |
| <b>Update Reason</b>    | Install Step: Revised torque value to (1) 102N.M [75 ft-lb] (2) Rotate 60 degrees. |
| <b>Date</b>             | 20-Apr-2012                                                                        |
| <b>Section</b>          | Section 5 - Fuel System                                                            |
| <b>Procedure Number</b> | 40-005-045-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-045-tr.html)            |
| <b>Procedure Title</b>  | Fuel Lift Pump                                                                     |
| <b>Update Reason</b>    | Test Step: Added Note.                                                             |

|                         |                                                                                                                                        |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 28-Jun-2012                                                                                                                            |
| <b>Section</b>          | Section 13- Electrical Equipment                                                                                                       |
| <b>Procedure Number</b> | 40-013-020-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-013-020-tr.html)                                                                |
| <b>Procedure Title</b>  | Starting Motor                                                                                                                         |
| <b>Update Reason</b>    | Replaced graphics in Install Step: Changed graphic to show PA90 starter. Added statement concerning jumper start protection cover nut. |

|                         |                                                                                                                                                                                                                                  |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 28-Sep-2012                                                                                                                                                                                                                      |
| <b>Section</b>          | Section 16 - Mounting Adaptations - Group 16                                                                                                                                                                                     |
| <b>Procedure Number</b> | 00-016-026-tr<br>(/qs3/pubsys2/xml/en/procedures/00/00-016-026-tr.html)                                                                                                                                                          |
| <b>Procedure Title</b>  | Marine Vibration Isolator                                                                                                                                                                                                        |
| <b>Update Reason</b>    | Procedure was revised to include information specific to the new isolator design introduced with the marine engine and to align with the most recent installation angularity requirements in the Marine Installation Directions. |

|                         |                                                                             |
|-------------------------|-----------------------------------------------------------------------------|
| <b>Date</b>             | 07-Jan-2013                                                                 |
| <b>Section</b>          | Section 1 - Cylinder Block                                                  |
| <b>Procedure Number</b> | 40-001-016-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-016-tr.html)     |
| <b>Procedure Title</b>  | Crankshaft                                                                  |
| <b>Update Reason</b>    | Revised Thrust Distance to 37.475 mm MIN 1.4754 in, 37.576 mm MAX 1.4794 in |

|                         |                                                                                    |
|-------------------------|------------------------------------------------------------------------------------|
| <b>Date</b>             | 11-Jan-2013                                                                        |
| <b>Section</b>          | Section TS - Troubleshooting Symptoms                                              |
| <b>Procedure Number</b> | 3666087-t104<br>(/qs3/pubsys2/xml/en/manual/3666087/3666087-t104.html)             |
| <b>Procedure Title</b>  | Lubricating Oil Pressure High                                                      |
| <b>Update Reason</b>    | Changed correction from Check to Replace the main oil pressure regulator assembly. |

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| <b>Date</b>             | 18-Mar-2013                                                          |
| <b>Section</b>          | Section 14 - Engine Testing                                          |
| <b>Procedure Number</b> | 100-014-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-010.html) |
| <b>Procedure Title</b>  | Crankcase Blowby, Measure                                            |
| <b>Update Reason</b>    | Revised MidRange Blowby Specifications Chart to include B6.7s        |

|                         |                                                                                            |
|-------------------------|--------------------------------------------------------------------------------------------|
| <b>Date</b>             | 04-Dec-2013                                                                                |
| <b>Section</b>          | Section 1 - Cylinder Block                                                                 |
| <b>Procedure Number</b> | 40-001-008-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-008-tr.html)                    |
| <b>Procedure Title</b>  | Camshaft                                                                                   |
| <b>Update Reason</b>    | Revised Camshaft Gear Backlash Limits (B) to 0.076 mm MIN 0.003 in, 0.280 mm MAX 0.011 in. |

|                         |                                                                                                                                               |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 28-Jan-2014                                                                                                                                   |
| <b>Section</b>          | Section 14 - Engine Testing                                                                                                                   |
| <b>Procedure Number</b> | 100-014-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-010.html)                                                                          |
| <b>Procedure Title</b>  | Crankcase Blowby, Measure                                                                                                                     |
| <b>Update Reason</b>    | Revised Blowby Specification for New or Rebuild for C8.3 to 101.6 mm [4 H20] and Blowby Specification for Troubleshooting to 254 mm [10 h20]. |

|                         |                                                                               |
|-------------------------|-------------------------------------------------------------------------------|
| <b>Date</b>             | 04-Apr-2014                                                                   |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                          |
| <b>Procedure Number</b> | 40-002-016<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-016.html)             |
| <b>Procedure Title</b>  | Valve Guide Seal, Cylinder Head                                               |
| <b>Update Reason</b>    | Had a incorrectly stated service tool part number 3164055. Removed reference. |



|                         |                                                                                                |
|-------------------------|------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 22-Jul-2014                                                                                    |
| <b>Section</b>          | Section 5 - Fuel System                                                                        |
| <b>Procedure Number</b> | 40-005-043-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-043-tr.html)                        |
| <b>Procedure Title</b>  | Fuel Shutoff Valve                                                                             |
| <b>Update Reason</b>    | Updated procedure for inline type injection pumps.                                             |
| <b>Date</b>             | 29-Jan-2015                                                                                    |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                                |
| <b>Procedure Number</b> | 40-006-017<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-017.html)                              |
| <b>Procedure Title</b>  | Fuel Filter Head                                                                               |
| <b>Update Reason</b>    | Torque spec applied to the filter adapter threads that are engaging the fuel filter head only. |
| <b>Date</b>             | 08-Apr-2015                                                                                    |
| <b>Section</b>          | Section 8 - Cooling System - Group 08                                                          |
| <b>Procedure Number</b> | 40-008-018-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-018-tr.html)                        |
| <b>Procedure Title</b>  | Cooling System                                                                                 |
| <b>Update Reason</b>    | Added directions to allow the engine to cool before draining coolant.                          |
| <b>Date</b>             | 16-May-2015                                                                                    |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                          |
| <b>Procedure Number</b> | 40-001-047<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-047.html)                              |
| <b>Procedure Title</b>  | Piston Rings                                                                                   |
| <b>Update Reason</b>    | Added missing Intermediate Ring, Part Number 3897719, to the Standard Size Piston Ring table.  |

|                         |                                                                                                   |
|-------------------------|---------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 24-Jun-2015                                                                                       |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                             |
| <b>Procedure Number</b> | 40-001-047<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-047.html)                                 |
| <b>Procedure Title</b>  | Piston Rings                                                                                      |
| <b>Update Reason</b>    | Added part numbers to the Standard and Oversize Size Piston Ring tables.                          |
| <b>Date</b>             | 28-Mar-2016                                                                                       |
| <b>Section</b>          | Section 7 - Lubricating Oil System                                                                |
| <b>Procedure Number</b> | 40-007-025-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-025-tr.html)                           |
| <b>Procedure Title</b>  | Lubricating Oil Pan                                                                               |
| <b>Update Reason</b>    | Remove and Install Steps for four piece oil pan gasket.                                           |
| <b>Date</b>             | 28-Mar-2016                                                                                       |
| <b>Section</b>          | Section DS - Engine Disassembly - Group 00                                                        |
| <b>Procedure Number</b> | 40-001-054-shopds<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-shopds.html)                   |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                                                |
| <b>Update Reason</b>    |                                                                                                   |
| <b>Date</b>             | 28-Mar-2016                                                                                       |
| <b>Section</b>          | Section AS - Engine Assembly - Group 00                                                           |
| <b>Procedure Number</b> | 40-001-054-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-shopas.html)                   |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                                                |
| <b>Update Reason</b>    | Note is added to the Grading section informing users that graded pistons were introduced in 1994. |

|                         |                                                                                                   |
|-------------------------|---------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 28-Mar-2016                                                                                       |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                             |
| <b>Procedure Number</b> | 40-001-054-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-tr.html)                           |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                                                |
| <b>Update Reason</b>    | Note is added to the Grading section informing users that graded pistons were introduced in 1994. |
| <b>Date</b>             | 13-May-2016                                                                                       |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                             |
| <b>Procedure Number</b> | 40-001-024-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-024-tr.html)                           |
| <b>Procedure Title</b>  | Crankshaft Seal, Rear                                                                             |
| <b>Update Reason</b>    | Edited to bring procedure inline with the other B engines.                                        |
| <b>Date</b>             | 24-Jul-2016                                                                                       |
| <b>Section</b>          | Section 6 - Injectors and Fuel Lines - Group 06                                                   |
| <b>Procedure Number</b> | 40-006-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-003-tr.html)                           |
| <b>Procedure Title</b>  | Air in Fuel                                                                                       |
| <b>Update Reason</b>    | Added new step in the Vent Step.                                                                  |
| <b>Date</b>             | 29-Jul-2016                                                                                       |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                                                |
| <b>Procedure Number</b> | 40-005-043-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-043-tr.html)                           |
| <b>Procedure Title</b>  | Fuel Shutoff Valve                                                                                |
| <b>Update Reason</b>    | Added the Generator Set applications to the procedure.                                            |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 06-Oct-2016                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block                                              |
| <b>Procedure Number</b> | 40-001-006<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-006.html)       |
| <b>Procedure Title</b>  | Bearings, Main                                                          |
| <b>Update Reason</b>    | Revised, Main Bearing Dimensions and graphic.                           |
| <b>Date</b>             | 02-Jan-2017                                                             |
| <b>Section</b>          | Section 5 - Fuel System                                                 |
| <b>Procedure Number</b> | 40-005-012-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-012-tr.html) |
| <b>Procedure Title</b>  | Fuel Injection Pumps, In-Line                                           |
| <b>Update Reason</b>    | Added: Adjust to procedure.                                             |
| <b>Date</b>             | 06-Mar-2017                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-001-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-001-tr.html) |
| <b>Procedure Title</b>  | Aftercooler                                                             |
| <b>Update Reason</b>    | Updated entire procedure.                                               |
| <b>Date</b>             | 07-Mar-2017                                                             |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                               |
| <b>Procedure Number</b> | 40-010-005-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-005-tr.html) |
| <b>Procedure Title</b>  | Aftercooler Assembly (Sea Water)                                        |
| <b>Update Reason</b>    | Added this procedure to the manual.                                     |
| <b>Date</b>             | 07-Mar-2017                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-200-003-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-200-003-tr.html) |
| <b>Procedure Title</b>  | Flow Diagram, Cooling System                                            |
| <b>Update Reason</b>    | Added Engine Coolant Flow and Sea Water Coolant Flow diagrams.          |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 09-Mar-2017                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-006-062<br>(/qs3/pubsys2/xml/en/procedures/40/40-006-062.html)       |
| <b>Procedure Title</b>  | Fuel Cooler                                                             |
| <b>Update Reason</b>    | Added this procedure to the manual.                                     |
| <b>Date</b>             | 09-Mar-2017                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-008-041-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-041-tr.html) |
| <b>Procedure Title</b>  | Marine Gear Oil Cooler                                                  |
| <b>Update Reason</b>    | Added this procedure to the manual.                                     |
| <b>Date</b>             | 09-Mar-2017                                                             |
| <b>Section</b>          | Section F - Familiarization                                             |
| <b>Procedure Number</b> | 40-008-059<br>(/qs3/pubsys2/xml/en/procedures/40/40-008-059.html)       |
| <b>Procedure Title</b>  | Zinc Anode                                                              |
| <b>Update Reason</b>    | Added this procedure to the manual.                                     |
| <b>Date</b>             | 09-Oct-2017                                                             |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                                  |
| <b>Procedure Number</b> | 100-014-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-010.html)    |
| <b>Procedure Title</b>  | Crankcase Blowby, Measure                                               |
| <b>Update Reason</b>    | Added ISB6.7 CM2250 engine instructions for installing the blowby kit.  |
| <b>Date</b>             | 09-Aug-2018                                                             |
| <b>Section</b>          | Section 2 - Cylinder Head - Group 02                                    |
| <b>Procedure Number</b> | 40-002-004-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-002-004-tr.html) |
| <b>Procedure Title</b>  | Cylinder Head                                                           |
| <b>Update Reason</b>    | Updated the valve stem diameter specification.                          |

|                         |                                                                         |
|-------------------------|-------------------------------------------------------------------------|
| <b>Date</b>             | 27-Aug-2018                                                             |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                   |
| <b>Procedure Number</b> | 40-022-001_01<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_01.html) |
| <b>Procedure Title</b>  | Service Tools                                                           |
| <b>Update Reason</b>    | Added new tools for removing and installing rear crankshaft seal.       |

|                         |                                                                            |
|-------------------------|----------------------------------------------------------------------------|
| <b>Date</b>             | 27-Aug-2018                                                                |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                      |
| <b>Procedure Number</b> | 100-001-024<br>(/qs3/pubsys2/xml/en/procedures/100/100-001-024.html)       |
| <b>Procedure Title</b>  | Crankshaft Seal, Rear                                                      |
| <b>Update Reason</b>    | Replaced existing procedure with new procedure using new service tool kit. |

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| <b>Date</b>             | 18-Sep-2018                                                          |
| <b>Section</b>          | Section 14 - Engine Testing - Group 14                               |
| <b>Procedure Number</b> | 100-014-010<br>(/qs3/pubsys2/xml/en/procedures/100/100-014-010.html) |
| <b>Procedure Title</b>  | Crankcase Blowby, Measure                                            |
| <b>Update Reason</b>    | Added naturally aspirated B5.9 engine specification to blowby table. |

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 28-Jun-2019                                                       |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                             |
| <b>Procedure Number</b> | 40-001-026<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-026.html) |
| <b>Procedure Title</b>  | Cylinder Block                                                    |
| <b>Update Reason</b>    | Update to a wider specifications for B5.9 engines.                |

|                         |                                                                                                                                                             |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Date</b>             | 12-Dec-2019                                                                                                                                                 |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                                                                                       |
| <b>Procedure Number</b> | 40-001-054-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-tr.html)                                                                                     |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                                                                                                          |
| <b>Update Reason</b>    | Added piston ring compressor part numbers for B3.9, B5.9, B4.5, and B4.5 RGT engines.                                                                       |
| <b>Date</b>             | 12-Dec-2019                                                                                                                                                 |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                                                                                                       |
| <b>Procedure Number</b> | 40-001-054-shopas<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-054-shopas.html)                                                                             |
| <b>Procedure Title</b>  | Piston and Connecting Rod Assembly                                                                                                                          |
| <b>Update Reason</b>    | Added piston ring compressor part numbers for B3.9, B5.9, B4.5, and B4.5 RGT engines.                                                                       |
| <b>Date</b>             | 12-Dec-2019                                                                                                                                                 |
| <b>Section</b>          | Section V - Specifications                                                                                                                                  |
| <b>Procedure Number</b> | 40-018-015-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-018-015-tr.html)                                                                                     |
| <b>Procedure Title</b>  | General Engine                                                                                                                                              |
| <b>Update Reason</b>    | Added Bore specifications for the B4.5.                                                                                                                     |
| <b>Date</b>             | 12-Dec-2019                                                                                                                                                 |
| <b>Section</b>          | Section 12 - Compressed Air System - Group 12                                                                                                               |
| <b>Procedure Number</b> | 40-022-001_12<br>(/qs3/pubsys2/xml/en/procedures/40/40-022-001_12.html)                                                                                     |
| <b>Procedure Title</b>  | Service Tools                                                                                                                                               |
| <b>Update Reason</b>    | Added new B3.9, B5.9, B4.5, and B4.5 RGT engine piston ring compressor tool numbers.<br>Added updated graphic for Service Tool numbers 3164330 and 4918294. |

|                         |                                                                           |
|-------------------------|---------------------------------------------------------------------------|
| <b>Date</b>             | 09-Nov-2021                                                               |
| <b>Section</b>          | Section 10 - Air Intake System - Group 10                                 |
| <b>Procedure Number</b> | 40-010-005-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-010-005-tr.html)   |
| <b>Procedure Title</b>  | Aftercooler Assembly (Sea Water)                                          |
| <b>Update Reason</b>    | Added information for both vertical component options into the procedure. |
| <b>Date</b>             | 27-Sep-2022                                                               |
| <b>Section</b>          | Section 5 - Fuel System - Group 05                                        |
| <b>Procedure Number</b> | 40-005-014-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-005-014-tr.html)   |
| <b>Procedure Title</b>  | Fuel Injection Pump, Rotary                                               |
| <b>Update Reason</b>    | Updated graphics. Adding barring instructions.                            |
| <b>Date</b>             | 21-Feb-2023                                                               |
| <b>Section</b>          | Section 7 - Lubricating Oil System - Group 07                             |
| <b>Procedure Number</b> | 40-007-083-tr<br>(/qs3/pubsys2/xml/en/procedures/40/40-007-083-tr.html)   |
| <b>Procedure Title</b>  | Lubricating Oil and Filter Analysis                                       |
| <b>Update Reason</b>    | Added to manual on 2/21/2023. Updated links in manual.                    |
| <b>Date</b>             | 04-Dec-2023                                                               |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                                     |
| <b>Procedure Number</b> | 40-001-043<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-043.html)         |
| <b>Procedure Title</b>  | Piston                                                                    |
| <b>Update Reason</b>    | Minor wording correction made to procedure.                               |



|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| <b>Date</b>             | 01-Aug-2025                                                       |
| <b>Section</b>          | Section 1 - Cylinder Block - Group 01                             |
| <b>Procedure Number</b> | 40-001-014<br>(/qs3/pubsys2/xml/en/procedures/40/40-001-014.html) |
| <b>Procedure Title</b>  | Connecting Rod                                                    |
| <b>Update Reason</b>    | Fixed issue with the minimum/maximum table format and structure.  |

---

**Last Modified: 26-Aug-2025**

---