

## Trainings ▾

### Preparatory Steps

#### WARNING

Depending on the circumstance, diesel fuel is flammable. When inspecting or performing service or repairs on the fuel system, to reduce the possibility of fire and resulting severe personal injury, death, or property damage, never smoke or allow sparks or flames (such as pilot lights, electrical switches, or welding equipment) in the work area.

#### WARNING

Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

#### CAUTION

A very small amount of dirt or debris can be very harmful to the fuel system components. Extra care is required to keep the fuel connections clean during the removal and installation. Connections must be covered immediately to keep them clean when the components are removed from the fuel system.

- Disconnect the batteries. See equipment manufacturer service information.
- Close the fuel supply valve.

### Remove

Disconnect and drain the fuel hose from the check valve.

Use a back-up wrench to hold the check valve body in the fuel drain tube adapter when removing the fuel hose from the inlet at check valve body.

Remove the check valve assembly from the fuel drain tube.

## Clean and Inspect for Reuse

Clean and inspect the check valve assembly.

Clean the threads of the existing thread-locker. Make sure all debris has been cleared from the threads of the check valve.

Replace the check valve if any cuts, grooves, nicks, or other damage is evident in the body seat.

## Install

Apply a ring of Loctite® 271, Part Number 3824038, or equivalent, thread-locker to the check valve threads starting a minimum of two threads above the end of the fitting.

Install the check valve assembly into the fuel drain tube adapter.

**Torque Value:** 95 n•m [ 70 ft-lb ]

Install the fuel hose to the check valve.

Use a back-up wrench to hold the check valve body when installing the fuel hose to the check valve body.

## Finishing Steps

### WARNING

**Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.**

- Connect the batteries. See equipment manufacturer service information.
- Prime the fuel system.
- Start the engine. Check for any fuel leaks.
- Shut the engine off. Check for any fuel leaks.

