

Trainings ▾

General Information

Complete the following steps after each oil change, or after the engine has been shut down for longer than five days, to make sure the engine components are lubricated.

©Cummins Inc.

- Disconnect the electrical wire from the fuel shutoff valve.
- Rotate the crankshaft using the starter motor until oil pressure is indicated on the gauge or the warning light goes out.
- Connect the electrical wire to the fuel shutoff valve.
- Start the engine.

Note : Emergency Standby Genset engines are exempt from the requirement provided they are fitted with coolant heaters and are exercised at least once every thirty days for a minimum of thirty days.

Prior to starting the engine, all three of the following requirements **must** be met before the engine is exempt from disconnecting the fuel pump and cranking the engine until oil pressure is indicated on the gauge.

- The engine is used as an Emergency Standby Genset.
- The engine is fitted with coolant heaters.
- The engine **must** follow the Cummins procedure for exercising at least once every thirty days.