

Display Vessel Personality File Will Not Import and/or Export

Symptoms

- Vessel personality file will **not** download into the display.
- Vessel personality file will **not** export from the display.

How To Use This Tree

This symptom tree can be used to troubleshoot vessel personality file download and export issues. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Possible causes include:

- Incompatible universal serial bus (USB) stick
- USB stick **not** plugged in correctly
- Vessel personality file corrupted.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check USB stick and port.	
	STEP 1A. Check vessel personality file.	Vessel personality file downloaded?
	STEP 1B. Check USB stick compatibility.	USB stick compatible?
	STEP 1C. Check the USB stick installation.	USB stick installed properly?
STEP 2.	Importing vessel personality file.	
	STEP 2A. Importing vessel personality file.	Vessel personality file download properly?
	STEP 2B. Import vessel personality file to another display.	Vessel personality file download into the other ED-4 display?

STEPS		SPECIFICATIONS
	STEP 2C. Importing vessel personality file to another USB stick.	Vessel personality file download properly?
STEP 3.	Exporting the ED-4 display.	
	STEP 3A. Check ED-4 display.	Vessel personality file export properly?
	STEP 3B. Export vessel personality file to another display.	Vessel personality file export from the other ED-4 display?
	STEP 3C. Exporting vessel personality file to another USB stick.	Vessel personality file export properly?
STEP 4.	Check the ED-4 display software.	
	STEP 4A. Check display software.	Vessel personality file download?

STEP 1. Check USB stick and port.

STEP 1A. Download the vessel personality file to the ED-4 display.

Conditions :

- Turn system enable switch OFF.
- Turn system enable switch ON.

Action	Specification/Repair	Next Step
Download the vessel personality file to the ED-4 display. • Re-Attempt to download or export the vessel personality file to the ED-4 display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Vessel personality file downloaded? YES Repair : The download of vessel personality file has corrected the issue.	Repair complete.
	Vessel personality file downloaded? NO	1B

STEP 1B. Check USB stick compatibility.

Conditions :

- None.

Action	Specification/Repair	Next Step
Check USB stick compatibility. • Verify the USB stick is compatible with the display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	USB stick compatible? YES	1C
	USB stick compatible? NO Repair : Download the vessel personality file to a compatible USB stick. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 1C. Check the USB stick installation.

Conditions :

- Turn system enable switch OFF.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the USB stick installation. Verify the USB stick is installed in the display USB port properly. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html) If a Cummins® extension harness is not being used, verify USB connection. Some USB connectors are reversible.	USB stick installed properly? YES Repair : - Skip to Step 2A for import issues. - Skip to Step 3A for export issues.	Go to the appropriate troubleshooting steps.
	USB stick installed properly? NO Repair : Install USB stick properly. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Repair complete.

STEP 2. Importing the vessel personality file.

STEP 2A. Importing the vessel personality file.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step

Check vessel personality file requirements. - Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) - Download latest version of the vessel personality file from Cummins QuickServe® Online. Replace to the USB stick. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) - Download the vessel personality file to the ED-4 display again.	Vessel personality file download properly? YES Repair : The download of the vessel personality file has corrected the issue.	Repair complete.
	Vessel personality file download properly? NO	2B

STEP 2B. Import vessel personality file to another display.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step

Import vessel personality file to another display. • Install the USB stick in another ED-4 display, if available. • Download the vessel personality file into the ED-4 display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) If another ED-4 is not available, proceed to the next step.	Vessel personality file download into the other ED-4 display? YES	2C
	Vessel personality file download into the other ED-4 display? NO	2C

STEP 2C. Importing the vessel personality file to another USB stick.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step
Download the latest version of the vessel personality file to another USB stick. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) • Download the vessel personality file to the malfunctioning ED-4 again.	Vessel personality file download properly? YES	Repair complete.
	Vessel personality file download properly? NO	4A

STEP 3. Exporting the ED-4 display.

STEP 3A. Check ED-4 display.

Conditions : Turn enable switch ON.		
Action	Specification/Repair	Next Step
Check ED-4 display. Verify instruction and export the vessel personality file. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Vessel personality file export properly? YES	Repair complete.
	Vessel personality file export properly? NO	3B

STEP 3B. Export vessel personality file to another display.

Conditions : Turn enable switch ON.		
Action	Specification/Repair	Next Step
Export vessel personality file to another display. Install the USB stick in another ED-4 display, if available. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) If another ED-4 is not available, proceed to the next step.	Vessel personality file export from other ED-4 display? YES	3C
	Vessel personality file export from other ED-4 display? NO	3C

STEP 3C. Exporting vessel personality file to another USB stick.

Conditions : Turn enable switch ON.		
Action	Specification/Repair	Next Step

Exporting vessel personality file to another USB stick. Export the vessel personality file from the malfunctioning ED-4 display again. If another ED-4 is not available, proceed to the next step. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Vessel personality file export properly? YES Repair : The download of the vessel personality file has corrected the issue.	Repair complete.
	Vessel personality file export properly? NO	4A

STEP 4. Check the ED-4 display software.

STEP 4A. Check the display software.

Conditions : Turn enable switch ON.		
Action	Specification/Repair	Next Step

Check the display software. • Download the latest software to the malfunctioning ED-4 display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html) • Download the vessel personality file into the malfunctioning ED-4 display again. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Vessel personality file download? YES Repair : The download of display software has corrected the issue.	Repair complete.
	Vessel personality file download? NO Repair : Replace the ED-4 display. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html)	Repair complete.