

Display Data Alternates Between Different Values

Symptoms

- Data parameters repeatedly switch between different values on the display.

How To Use This Tree

This symptom tree can be used to troubleshoot accessory relay control devices. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- Possible causes are:
- Incorrect vessel personality file
 - ED-4 display setup improperly.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the ED-4 display.	
	STEP 1A. Check ED-4 display configuration.	J1939 source 1 and 2 set properly?
	STEP 1B. Check vessel personality file.	Vessel personality file correct?

STEP 1. Check the ED-4 display.

STEP 1A. Check ED-4 display configuration.

Conditions :		
• Turn system enable switch ON.		
Action	Specification/Repair	Next Step

Verify engine J1939 source. Go to the configuration in the menu in the ED-4 display. Verify engine J1939 source 1 and 2 settings. Refer to Procedure 015-108 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-108.html)	J1939 source 1 and 2 set properly? YES	1B
	J1939 source 1 and 2 set properly? NO Repair : Configure the ED-4 display properly. Refer to Procedure 015-108 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-108.html)	Repair complete.

STEP 1B. Check the vessel personality file.

Conditions : Turn system enable switch ON.		
Action	Specification/Repair	Next Step

Measure the resistance. • Verify correct vessel personality file is downloaded in the display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) Refer to the circuit diagram or wiring diagram for connector pin identification. Use the following procedure for general resistance measurement techniques. Refer to Procedure 019-360 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html)	Vessel personality file correct? YES Repair : Request a Cummins® Marine application engineer on site.	Repair complete.
	Vessel personality file correct? NO Repair : Download correct vessel personality file to the display for Cummins QuickServe® Online. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html)	Repair complete.