

OEM Installed Sensor - Condition Exists

Symptoms

- Original Equipment Manufacturer (OEM) Sensor alarm code displayed on ED-4 screen.
- OEM sensor parameter value exceeds over or under limit defined in ED-4 Vessel Personality File by the OEM.

How To Use This Tree

This symptom tree can be used to troubleshoot display data issues. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Verify correct vessel personality file is downloaded in the display. Refer to Procedure 015-044 (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) in Section 15.

This OEM Sensor Alarm is activated when the input from the OEM sensor exceeds the limit defined in the vessel personality file defined for the OEM needs.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the OEM Sensor Alarm Code.	
	STEP 1A. Check for OEM Sensor Alarm.	Active or inactive counts of OEM Sensor Alarm.

STEP 1. Check the OEM Sensor Alarm.

STEP 1A. Check for OEM Sensor Alarm.

Conditions : • Turn keyswitch ON.		
Action	Specification/Repair	Next Step

Check for an inactive alarm code. • Use ED-4 Advanced Fault screen to read the alarm codes.	Active or inactive status of OEM Sensor Alarm? YES Repair : The limit has been exceeded for the OEM supplied input. Refer to the OEM service manual or repair manual.	Go to the OEM service manual.
	Active or inactive counts status of OEM Sensor Alarm ? NO	Repair complete.