

Trainings ▾

Remove

Note : The left bank idler gear is shown in the illustration and **must** be removed first.

Cummins Inc., recommends measuring the end play before removing the idler gear.

Remove the four capscrews, the thrust retainer plate, and the thrust bearings on the left-bank camshaft idler gear.

Remove the camshaft idler gear.

Remove the idler shaft.

