

Trainings ▾

Inspect for Reuse

Inspect the thrust bearing for damage.

Measure the thrust bearing thickness.

mm		in
13.95	MIN	0.549
14.05	MAX	0.553

