


Trainings ▾

General Information

There are two good methods to check for air in the fuel.

1. Sight glass method
2. Gear pump drain method.




Test

Sight Glass Method

⚠ WARNING ⚠

Depending on the circumstances fuel is flammable. Keep all cigarettes, flames, pilot lights, arcing equipment, and switches out of the work area and areas sharing ventilation to reduce the possibility of severe personal injury or death when working on the fuel system.



⚠ WARNING ⚠

Do not vent the fuel system on a hot engine; this can cause fuel to spill onto a hot exhaust manifold, which can cause a fire.

Remove the fuel inlet line.

Install a sight glass, Part Number 3163270, at the inlet of the fuel pump.

Operate the engine at high idle with no load.


A small air leak will have a "milky" appearance.

A large air leak will look like bubbles in the fuel.

Note : If the application incorporates a Day tank or a Positive Head Fuel System it is recommended to apply a sight glass before this accessory as these devices may mask the presence of air in fuel upstream.

If an air leak is found, perform the following:

- Systematically inspect the entire fuel supply routing for sources of air ingress starting at the fuel tank followed by all hose/tube interconnections, fuel filtration hardware and day tank/positive head fuel system, if provisioned. Tighten any loose connections as needed.
- Check the drop tube in the fuel tank for damage.
- Check the fuel return to tank and ensure the tube is both above fuel level and at a minimum distance of 305 mm [12 in] from the fuel supply connection.
- Check o-rings for damage.




Continue to test and look for source of air until no air bubbles are visible.

Remove the sight glass.

Install and tighten the fuel inlet hose.

Torque Value: 88 n•m [65 ft-lb]


Retest the engine duplicating the operating conditions when performance complaint occurred to confirm air in fuel correction. This is especially important for standby Generator applications with infrequent starts and may require testing after an extended rest period.



Gear Pump Drain Method


To perform a pressure-side air-in-fuel test, use the following items:

- Quick-Disconnect Fitting - Female
- High-pressure hose
- Pressure valve (capable of 2758 kPa [400 psi])
- Clear tubing
- Clean container.




Connect the equipment to the quick-connect fitting at the fuel pump outlet.

Put the end of the clear tubing into the clean container.



⚠ WARNING ⚠

Depending on the circumstances fuel is flammable. Keep all cigarettes, flames, pilot lights, arcing equipment, and switches out of the work area and areas sharing ventilation to reduce the possibility of severe personal injury or death when working on the fuel system.



⚠ WARNING ⚠


Do not vent the fuel system on a hot engine; this can cause fuel to spill onto a hot exhaust manifold, which can cause a fire.

Operate the engine at high idle with no load. Slowly open the valve until a steady stream of fuel is visible.

Put the end of the tube below the surface of the fuel.


If there is an air leak, bubbles will be visible.

Note : If the application incorporates a Day tank or a Positive Head Fuel System it is recommended to use the Sight Glass Method placed before this accessory as these devices may mask the presence of air in fuel upstream.



If an air leak is found, perform the following:

- Systematically inspect the entire fuel supply routing for sources of air ingress starting at the fuel tank followed by all hose/tube interconnections, fuel filtration hardware and day tank/positive head fuel system, if provisioned. Tighten any loose connections as needed.
- Check the drop tube in the fuel tank for damage.
- Check the fuel return to tank and ensure the tube is both above fuel level and at a minimum distance of 305 mm [12 in] from the fuel supply connection.



- Check the o-rings for damage.

Continue to test and look for air leaks until there are no bubbles visible.

Remove the test equipment.

Retest engine duplicating the operating conditions when performance complaint occurred to confirm air in fuel correction. This is especially important for standby Generator applications with infrequent starts and may require testing after an extended rest period.

Install and tighten the fuel inlet hose.

Torque Value: 88 n•m [65 ft-lb]

