

Trainings ▾

Remove

The clearance **must** be sufficient from the oil suction tube before the adapter can be removed from the bottom of the engine.

The QSK45 oil pan adapter assembly is held on by 36 capscrews, and the QSK60 oil pan adapter assembly is held on by 46 capscrews.

Remove the capscrews (1) from the oil pan adapter assembly (2), the gasket (3), and the engine (4).

Remove the oil pan adapter assembly (2) and the gasket (3).

