

Trainings ▾

Install

Install the small support bracket, if applicable (11).

Torque Value: 45 n•m [33 ft-lb]

Install the lubricating oil suction tube (1) and seal (10) to oil pump with the three capscrews (6).

Torque Value: 45 n•m [33 ft-lb]

Note : If the rear housing has been removed and reinstalled, it will possibly be necessary to realign it when installing the lubricating oil suction tube.

Hand tighten the strap on the small bracket, if applicable (12).

Install the lubricating oil suction tube support bracket (2) and hand tighten the two to four supporting capscrews (8).

Note : The bracket may have two or four capscrews depending on the oil pan style.

In the slotted holes, the bolts **must** be at the tube end of the slot.

Install the vertical support bracket straps (3) on the lubricating oil suction tube bracket (2) with two capscrews (4) and nuts (5).

Tighten the nuts and capscrews (4)(5).

Torque Value: 45 n•m [33 ft-lb]

Tighten the capscrews supporting the main bracket (2). The capscrews **must** be at the tube end of the slot.

Torque Value: 45 n•m [33 ft-lb]

Tighten the top support strap, if applicable (12).

Torque Value: 45 n•m [33 ft-lb]



