



Technical Service Bulletin

Technical Service Bulletin: TSB150086

Released Date: 04-Jun-2015

Service Manual Procedures for NT-855 Equipped Rail Applications using Wabco™ 636 Twin Air Compressor

Service Manual Procedures for NT-855 Equipped Rail Applications using Wabco™ 636 Twin Air Compressor

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

Product Affected

Diesel Multiple Unit and Railcar Applications **Only**

ReCon® NT-855 Engines Affected:

- DR0683800RX (R1)
- DR0683900RX (R1)
- DR0684100RX (R3)
- DR0684200RX (R3)

Description of Change

The Holset® ST773 air compressor, Part Number 3048671, can no longer be supported. An air compressor upfit kit has been created to allow Wabco™ 636 twin air compressors, Part Number 4337583, to be used on the product affected. For information on the air compressor upfit kit, see TSB150085.

This document contains a complete list Service Manual procedures needed to remove, install, and troubleshoot the Wabco™ 636 twin air compressor. See Tables 1 and 2.

Associated Publications

As an interim solution use Tables 1 and 2. A Master Repair Manual will be developed to support the Wabco™ 636 twin air compressor, but is **not** available at this time.

For Section TS - Troubleshooting Symptoms, see the following procedures in Bulletin 2883445.

Note : <https://qsol.cummins.com/qs3/portal/service/manual/en/2883445/>
(<https://qsol.cummins.com/qs3/portal/service/manual/en/2883445/>)

Table 1, Section TS - Troubleshooting Symptoms	
Procedure Number	Procedure Title
t00-001	Troubleshooting Procedures and Techniques
t00-002	Troubleshooting Symptoms Charts
t004	Air Compressor Air Pressure Rises Slowly
t005	Air Compressor Cycles Frequently
t006	Air Compressor Noise is Excessive
t007	Air Compressor Pumping Excess Lubricating Oil into the Air System
t008	Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously)
t009	Air Compressor Will Not Pump Air
t010	Air Compressor Will Not Stop Pumping
For Section 12 - Compressed Air System - Group 12, see the following procedures.	
Table 2, Section 12 - Compressed Air System - Group 12	
Procedure Number	Procedure Title
04-022-001_12	Service Tools
Refer to Procedure 012-003 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-003-tr-mixar5.html)	Air Compressor Carbon Buildup
Refer to Procedure 012-004 in Section 12. (/qs3/pubsys2/xml/en/procedures/132/132-012-004-tr-mixar5.html)	Air Compressor Coolant Lines
Refer to Procedure 012-008 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-008-tr-mixab.html)	Air Compressor Cylinder Head, Two Cylinder
Refer to Procedure 012-013 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-013-tr-mixab.html)	Air Compressor Unloader and Valve Assembly
Refer to Procedure 012-014 in Section 12. (/qs3/pubsys2/xml/en/procedures/133/133-012-014-tr-mixab.html)	Air Compressor
Refer to Procedure 012-017 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-017-tr-mixab.html)	Air Governor (Air Compressor Will Not Pump)
Refer to Procedure 012-018 in Section 12. (/qs3/pubsys2/xml/en/procedures/133/133-012-018-tr-mixab.html)	Air Governor (Air Compressor Pumps Continuously)

Table 2, Section 12 - Compressed Air System - Group 12	
Procedure Number	Procedure Title
Refer to Procedure 012-015 in Section 12. (/qs3/pubsys2/xml/en/procedures/133/133-012-015-tr-mixab.html)	Air Compressor Discharge Lines
Refer to Procedure 012-019 in Section 12. (/qs3/pubsys2/xml/en/procedures/133/133-012-019.html)	Air Leaks, Compressed Air System
Refer to Procedure 012-020 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-020.html)	Air Compressor (Oil Carryover)
Refer to Procedure 012-024 in Section 12. (/qs3/pubsys2/xml/en/procedures/101/101-012-024-tr-mixab.html)	Air Pressure Relief Valve
Refer to Procedure 012-109 in Section 12. (/qs3/pubsys2/xml/en/procedures/133/133-012-109-tr-mixab.html)	Air Compressor Inlet Tube

Document History

Date	Details
2015-5-29	Module Created