

2024 D-ILA Remode Control Codes Table (ver 1.0)

1.Maker code
73 H(Code:A)
63 H(Code:B)

NZ500 = DLA-NZ500, DLA-RS1200, DLA-N799, DLA-N788, DLA-N700, DLA-Z5
NZ700 = DLA-NZ700, DLA-RS2200, DLA-N899, DLA-N888, DLA-N800, DLA-Z7

2.Operation code			Model		CONTENTS
Update	Code	Button	RM-MH27	Repeat	
	01H	↑	✓	✓	UP
	02H	↓	✓	✓	DOWN
	03H	BACK	✓	✓	Back/Undisplays message, adjustment gauge, menu
	05H	ON	✓	✓	Powers on
	06H	STAND BY	✓	✓	Stand By
	08H	INPUT	✓	✓	Switches Input Port
	18H	ContentsType(Auto)		✓	Switches Contents Type Auto
	19H	ContentsType(SDR)		✓	Switches Contents Type SDR
	1AH	ContentsType(HDR10+)		✓	Switches Contents Type HDR10+
	1BH	ContentsType(HDR10)		✓	Switches Contents Type HDR10
	1CH	ContentsType(HLG)		✓	Switches Contents Type HLG
	1DH	HIDE (/ BEFORE/AFTER)	✓	✓	Switches Hide ON/OFF
	20H	LENS AP		✓	Displays adjustment bar of Iris setting
	23H	Anamorphic(A)		✓	Switches Anamorphic A
	24H	Anamorphic(Off)		✓	Switches Anamorphic off
	27H	Aspect(Zoom)		✓	Switches Aspect to Zoom
	2BH	Anamorphic(B)		✓	Switches Anamorphic B
	2EH	Menu	✓	✓	Displays/undisplays menu
	2FH	OK	✓	✓	OK
	30H	Lens (/ LENS CONTROL)	✓	✓	Displays adjustment menu of Lens control/Switches setting of lens(focus/zoom/shift)
	33H	Anamorphic(C)		✓	Switches Anamorphic C
	34H	→	✓	✓	Moves the cursor to right/+ in adjustment gauge
	36H	←	✓	✓	Moves the cursor to left/- in adjustment gauge
	38H	HDR Level(Auto Normal)		✓	Switches HDR Level to Auto Normal
	39H	HDR Level(-2)		✓	Switches HDR Level to -2
	3AH	HDR Level(-1) / (Low)		✓	Switches HDR Level to -1 or Low
	3BH	HDR Level(0) / (Midium)		✓	Switches HDR Level to 0 or Midium
	3CH	HDR Level(+1) / (High)		✓	Switches HDR Level to +1 or High
	3DH	HDR Level(+2)		✓	Switches HDR Level to +2
	3EH	HDR Level(Auto Wide)		✓	Switches HDR Level to Auto Wide
	45H	Anamorphic(D)		✓	Switches Anamorphic D
	47H	Clear Motion Drive(Off)		✓	Switches Clear Motion Drive to Off
	58H	ISF(Adjust)		✓	Switches to ISF(Adjust)
	5AH	ISF(Off)		✓	Switches to ISF(Off)
	5BH	ISF(On)		✓	Switches to ISF(On), combined operations are also possible [BACK]/[BACK]/[←]/[→]/[↑]/[↓]/[OK]
✓	5BH	Clear Motion Drive(High)		✓	Switches to ISF(On), combined operations are also possible [BACK]/[BACK]/[↑]/[↓]/[←]/[→]/[OK]
✓	5FH	Clear Motion Drive(Low)		✓	Switches Clear Motion Drive to Low
	64H	isf-DAY		✓	Switches to "isf-DAY" in Picture Mode
	65H	isf-NIGHT		✓	Switches to "isf-NIGHT" in Picture Mode
	68H	CINEMA		✓	Switches to "CINEMA" in Picture Mode
	6AH	NATURAL		✓	Switches to "NATURAL" in Picture Mode
	6CH	SDR1		✓	Switches to "SDR1" in Picture Mode
	6DH	SDR2		✓	Switches to "SDR2" in Picture Mode
	6EH	HDR1		✓	Switches to "HDR1" in Picture Mode
	70H	HDMI 1		✓	Switches to HDMI 1
	71H	HDMI 2		✓	Switches to HDMI 2
	73H	ADVANCED MENU	✓	✓	Press and hold for 3 seconds to register the favorite menu screen. A short press displays the registered menu screen.
	74H	INFO	✓	✓	Displays information page of menu
	75H	GAMMA		✓	Switches Gamma mode
	76H	C.TEMP		✓	Switches Color Temp mode
	88H	COLOR PROFILE	✓	✓	Displays "Color Profile" popup menu
	8AH	CLEAR MOTION DRIVE	✓	✓	Displays "CMD" popup menu
	AEH	Aspect(Auto)		✓	Switches Aspect to Auto
	AFH	Aspect(Just) / Aspect(Native)		✓	Switches Aspect to Just (Native)
	CSH	Anamorphic		✓	Switches Anamorphic mode
	CAH	HDR2		✓	Switches to "HDR2" in Picture Mode
	DOH	HIDE(On)		✓	Switches Hide to On
	D1H	HIDE(Off)		✓	Switches Hide to Off
	D2H	Solenoid(Normal) / C.FILTER(Normal)		✓	Switches Solenoid to Normal (*1) / Switches C.FILTER to Normal (*1)
	D3H	Solenoid(Wide) / C.FILTER(Wide)		✓	Switches Solenoid to Wide (*1) / Switches C.FILTER to Wide (*1)
	D4H	Lens Memory / SETTING MEMORY	✓	✓	Displays "Installation Mode Load Popup Menu"
	D7H	User		✓	Switches User mode (Picture mode)
	D8H	Lens Memory1 / Installation MODE1		✓	Load Lens memory1
	D9H	Lens Memory2 / Installation MODE2		✓	Load Lens memory2
	DAH	Lens Memory3 / Installation MODE3		✓	Load Lens memory3
	E1H	HLG		✓	Switches to "HLG" in Picture Mode
	E5H	Lens Memory4 / Installation MODE4		✓	Load Lens memory4
	E6H	Lens Memory5 / Installation MODE5		✓	Load Lens memory5
	ECH	Frame Adapt HDR		✓	Switches/Toggles to "Frame Adapt HDR" in Picture Mode
	F0H	MPC	✓	✓	Displays "MPC Level Menu"
	F4H	Picture Mode	✓	✓	Displays "Picture Mode" popup menu
	F5H	Gamma Settings	✓	✓	Displays "Gamma Setting Menu"
	F7H	Name Edit		✓	Open "Name Edit" OSD only when SDR1/SDR2/HDR1/HDR2 in PictureMode is selected
	F9H	HDR10+		✓	Switches to "HDR10+" in Picture Mode
	FBH	FILMMAKER MODE		✓	Switches to "FILMMAKER MODE" in Picture Mode

(*1) This command is effective in the following cases.
- No Input
- Displaying test pattern.