

SB327 feature

For SB327 compliance, it is necessary to set a password before use LAN function.
The detail commands and rules are described below.

1. RS232 Command

Name	Command	Response	Definition	Description
LAN Password 1	06 14 00 0B 00 34 0C 24 D1 ~ D8 CS	03 14 00 00 00 14	D1 ~ D8, password bytes	First input password
LAN Password 2	06 14 00 0B 00 34 0C 25 D1 ~ D8 CS	03 14 00 00 00 14	D1 ~ D8, password bytes	Second input password

2. Rules of password command

(1) Password bytes need to be eight Arabic numbers (0, 1, 2, 3, 4, 5, 6, 7, 8 and 9).

(2) CS is a checksum in hex that can be calculated by the formula:

$$CS = P + B$$

P: Password byte number

B: Basic number

$$P = (D1 + D2 + D3 + D4 + D5 + D6 + D7 + D8)$$

B = 0x83 in LAN password 1.

B = 0x84 in LAN password 2.

(3) Example of LAN password commands:

Assume a set of password bytes is (**1, 2, 3, 4, 5, 6, 7, 8**)

Then,

$$P = 1 + 2 + 3 + 4 + 5 + 6 + 7 + 8 = 36 (= 0x24)$$

$$CS \text{ of LAN password 1 (CS1)} = 0x83 + 0x24 = A7$$

$$CS \text{ of LAN password 2 (CS2)} = 0x84 + 0x24 = A8$$

Thus,

LAN password 1 command is {06 14 00 0B 00 34 0C 24 **1 2 3 4 5 6 7 8** A7}

LAN password 2 command is {06 14 00 0B 00 34 0C 25 **1 2 3 4 5 6 7 8** A8}

3. Operation

3.1 Input LAN Password

- (1) LAN Password commands can be executed by Lan or User RS232 after projector is powered on.
- (2) LAN function is workable after input password by RS232 commands correctly and the criteria:
 - i. Must input both password 1 and password 2.
 - ii. After power on, the first input password will record as password 1.
 - iii. Password 2 is taking as a confirmed one and must be same as password 1.
 - iv. If password 2 confirmation doesn't pass, password 1 will be reset at next power on.

3.2 LAN function

- (1) LAN function is not workable if LAN password had never been inputted correctly.
- (2) LAN function is always workable after LAN password had been inputted correctly once.
- (3) LAN password only can be reset by factory reset if has already inputted correctly.

3.3 Power on from LAN standby

LAN standby control item will be gray out and no function if LAN password had never been inputted correctly previously.