Sheet1

Radio Shack MIDI Lights - Ordering Board Bill Of Materials

Quantity Part	Vendor	Part Number
1 1N4148 Diode	Radio Shack	276-1122
8 Red LED	Radio Shack	276-0041
8 1N4004 Rectifier Diode	Radio Shack	276-1103
4 PC Board Terminals	Radio Shack	276-1388
1 100 Ohm 1/4W Resistor	Radio Shack	276-1311
1 220 Ohm 1/4W Resistor	Radio Shack	271-1313
4 560 Ohm, 1/2W Resistor	Radio Shack	271-1116
4 100K Ohm 1/4W Resistor	Radio Shack	271-1347
5 10K Ohm 1/4W Resistor	Radio Shack	271-1335
16 12VDC PC Mount Relay	Radio Shack	275-241
1 SPDT Center Off Toggle Switch	Radio Shack	275-0325
1 SPST Toggle Switch	Radio Shack	275-0324
16 2N2222 NPN BJT Transistor	Radio Shack	276-2009
1 Arduino Uno Rev 3	Radio Shack	276-128
1 Arduino Maker Shield	Radio Shack	276-138
1 Enercell DC Power Adapter	Radio Shack	273-318
1 Enercell K Size Adaptaplug	Radio Shack	273-342
1 Large Perfboard	Radio Shack	276-147
* Optional – Depending on how you build your circuit board.		
1 MIDI Connector	Spark Fun Electronics	PRT-09536
1 0.1" Pin Headers	Spark Fun Electronics	PRT-00116
22 Pin, 6" Jumper Wire	Spark Fun Electronics	PRT-10367
1 3 Pin, 6" Jumper Wire	Spark Fun Electronics	PRT-10368
1 4 Pin, 6" Jumper Wire	Spark Fun Electronics	PRT-10369
1 DC Power Connector	DigiKey	CP-202A
1 SPDT Slide Switch	DigiKey	450-1598
1 6N138 Optocoupler	DigiKey	6N138QT
2 74HC595 Shift Register	DigiKey	296-1600-5