
Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YND003X
Title: LIGHTING (INT): FRONT DOOR COURTESY SWITCH: COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**



.


⊕TOYOTA :

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNE003X
Title: LIGHTING (INT): FRONT DOOR COURTESY SWITCH: REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. REMOVE FRONT DOOR COURTESY LIGHT SWITCH ASSEMBLY



(a) Using a T30 "TORX" socket wrench, remove the screw and courtesy light switch.

(b) Disconnect the connector.






Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003YNC003X
Title: LIGHTING (INT): FRONT DOOR COURTESY SWITCH: INSPECTION (2010 4Runner)		

### **INSPECTION**

#### 1. INSPECT FRONT DOOR COURTESY LIGHT SWITCH ASSEMBLY

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



TESTER CONNECTION	SWITCH CONDITION	SPECIFIED CONDITION
1 Cuitab badu	Pin not pushed	Below 1 Ω
1 - Switch body	Pin pushed	10 kΩ or higher

If the result is not as specified, replace the front door courtesy light switch assembly.

### **Text in Illustration**

\*a Component without harness connected
(Front Door Courtesy Light Switch Assembly)

Œ

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNB003X
Title: LIGHTING (INT): FRONT DOOR COURTESY SWITCH: INSTALLATION (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL FRONT DOOR COURTESY LIGHT SWITCH ASSEMBLY


- (a) Connect the connector.
- (b) Using a T30 "TORX" socket wrench, install the courtesy light switch with the screw.






Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO0002X
Title: LIGHTING (INT): IGNITION KEY CYLINDER LIGHT: COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO1002X
Title: LIGHTING (INT): IGNITION KEY CYLINDER LIGHT: REMOVAL (2010 4Runner)		

- 1. REMOVE NO. 2 SWITCH HOLE BASE
- 2. REMOVE LOWER INSTRUMENT PANEL FINISH PANEL ASSEMBLY
- 3. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY
- 4. REMOVE LOWER STEERING COLUMN COVER
- 5. REMOVE UPPER STEERING COLUMN COVER
- **6. REMOVE TRANSPONDER KEY AMPLIFIER**



(a) Remove the screw and cover.



(b) Turn the key amplifier as shown in the illustration to detach the 2 claws and remove the key amplifier.

(c) Disconnect the connector.

(2)


Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNZ002X
Title: LIGHTING (INT): IGNITION K	EY CYLINDER LIGHT:	INSPECTION (2010 4Runner)

### **INSPECTION**

#### 1. INSPECT TRANSPONDER KEY AMPLIFIER

(a) Apply battery voltage to the connector and check the LED illumination.

OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive $(+) \rightarrow Terminal\ 2$ (ILL+) Battery negative $(-) \rightarrow Terminal\ 6$ (ILL-)	LED illuminates

If the result is not as specified, replace the transponder key amplifier.

### **Text in Illustration**


\*a (Transponder Key Amplifier)

(92)

(W) IOTOIA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNY002X
Title: LIGHTING (INT): IGNITION KEY CYLINDER LIGHT: INSTALLATION (2010 4Runner)		

#### 1. INSTALL TRANSPONDER KEY AMPLIFIER



(a) Connect the connector.


- (b) Turn the key amplifier as shown in the illustration to attach the 2 claws and install the key amplifier.
- (c) Install the cover with the screw.
- 2. INSTALL UPPER STEERING COLUMN COVER
- 3. INSTALL LOWER STEERING COLUMN COVER MFO
- 4. INSTALL INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY
- 5. INSTALL LOWER INSTRUMENT PANEL FINISH PANEL ASSEMBLY
- 6. INSTALL NO. 2 SWITCH HOLE BASE

(9)

⊕TOYOTA

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNO004X
Title: LIGHTING (INT): PERSONAL LIGHT (for Front Door): COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




⊕ TOYOTA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNP004X
Title: LIGHTING (INT): PERSONAL LIGHT (for Front Door): REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.
- 1. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH
- 2. REMOVE NO. 2 DOOR INSIDE HANDLE BEZEL LH
- 3. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH
- 4. REMOVE FRONT DOOR GLASS WEATHERSTRIP INNER LH
- 5. REMOVE NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY

(a) Using a screwdriver, detach the claw and remove the light.



#### **HINT:**

Tape the screwdriver tip before use.

### **Text in Illustration**

\*1 Protective Tape

(b) Disconnect the connector.

ூ


Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003YNN004X
Title: LIGHTING (INT): PERSONAL LIGHT (for Front Door): INSPECTION (2010 4Runner)		

### **INSPECTION**

#### 1. INSPECT NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY

(a) Apply battery voltage to the connector and check the LED illumination.

OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive $(+) \rightarrow Terminal\ 2$ $(+B)$ Battery negative $(-) \rightarrow Terminal\ 1$ $(GND)$	LED illuminates

If the result is not as specified, replace the No. 1 interior illumination light assembly.

### **Text in Illustration**

\*a Component without harness connected (No. 1 Interior Illumination Light Assembly)

(92)

★ TOYOTA


	E	
	C	
	C	)
	D	
i		
		)
	$\mathcal{D}$	5
	(	)

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNM004X
Title: LIGHTING (INT): PERSONAL LIGHT (for Front Door): INSTALLATION (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY



(a) Connect the connector.


- (b) Attach the claw to install the light.
- 2. INSTALL FRONT DOOR GLASS WEATHERSTRIP INNER LH
- 3. INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH
- 4. INSTALL NO. 2 DOOR INSIDE HANDLE BEZEL LH
- 5. INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH



⊕ TOYOTA ::

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNS001X
Title: LIGHTING (INT): PERSONAL LIGHT (for Rear Door): COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




.⊕. ⊕royota :

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNT001X
Title: LIGHTING (INT): PERSONAL LIGHT (for Rear Door): REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.
- 1. REMOVE REAR DOOR INSIDE HANDLE BEZEL LH
- 2. REMOVE REAR DOOR TRIM BOARD SUB-ASSEMBLY LH
- 3. REMOVE REAR DOOR GLASS WEATHERSTRIP INNER LH
- 4. REMOVE NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY



(a) Using a screwdriver, detach the claw and remove the light.

#### **HINT:**

Tape the screwdriver tip before use.

### **Text in Illustration**

* 1	Protective Tane
T 1	Protective Tape

(b) Disconnect the connector.

(4)




Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003YNR001X
Title: LIGHTING (INT): PERSONAL LIGHT (for Rear Door): INSPECTION (2010 4Runner)		

### **INSPECTION**

#### 1. INSPECT NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY

(a) Apply battery voltage to the connector and check the LED illumination.

OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive $(+) \rightarrow Terminal\ 2$ $(+B)$ Battery negative $(-) \rightarrow Terminal\ 1$ $(GND)$	LED illuminates

If the result is not as specified, replace the No. 1 interior illumination light assembly.

### **Text in Illustration**

\*a Component without harness connected (No. 1 Interior Illumination Light Assembly)

(92)


(W) IOTOIA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNQ001X
Title: LIGHTING (INT): PERSONAL LIGHT (for Rear Door): INSTALLATION (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY



(a) Connect the connector.

- (b) Attach the claw to install the light.
- 2. INSTALL REAR DOOR GLASS WEATHERSTRIP INNER LH
- 3. INSTALL REAR DOOR TRIM BOARD SUB-ASSEMBLY LH








Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNH005X
Title: LIGHTING (INT): REAR DOOR COURTESY SWITCH: COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




(<del>(</del>)

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNI005X
Title: LIGHTING (INT): REAR DOOR COURTESY SWITCH: REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. REMOVE REAR DOOR COURTESY LIGHT SWITCH ASSEMBLY



(a) Using a T30 "TORX" socket wrench, remove the screw and courtesy light switch.

(b) Disconnect the connector.



⊕ TOYOTA 😲


Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNG005X
Title: LIGHTING (INT): REAR DOOR COURTESY SWITCH: INSPECTION (2010 4Runner)		

### **INSPECTION**

#### 1. INSPECT REAR DOOR COURTESY LIGHT SWITCH ASSEMBLY

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



TESTER CONNECTION	SWITCH CONDITION	SPECIFIED CONDITION
1 Cuitab badu	Pin not pushed	Below 1 Ω
1 - Switch body	Pin pushed	10 kΩ or higher

If the result is not as specified, replace the rear door courtesy light switch assembly.

### **Text in Illustration**

\*a Component without harness connected (Rear Door Courtesy Light Switch Assembly)

(2)

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNF005X
Title: LIGHTING (INT): REAR DOOR	COURTESY SWITCH:	INSTALLATION (2010 4Runner)

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL REAR DOOR COURTESY LIGHT SWITCH ASSEMBLY


- (a) Connect the connector.
- (b) Using a T30 "TORX" socket wrench, install the courtesy light switch with the screw.





Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO8003X
Title: LIGHTING (INT): ROOM LIGHT (for Front): COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




(2)

— GDYOTA —}

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO9003X
Title: LIGHTING (INT): ROOM LIGHT (for Front): REMOVAL (2010 4Runner)		


#### 1. REMOVE DRIVE MONITOR SWITCH



(a) Detach the 3 claws and remove the switch.

(b) Disconnect the connector.

#### 2. REMOVE MAP LIGHT ASSEMBLY




(a) Remove the 2 screws.

- (b) Detach the 3 clips and remove the light.
- (c) Disconnect the connector.

#### 3. REMOVE MAP LIGHT BULB

(a) Turn the 2 map light bulbs in the direction indicated by the arrows and remove them.



.


Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO7003X
Title: LIGHTING (INT): ROOM LIGHT (for Front): INSPECTION (2010 4Runner)		

### **INSPECTION**

#### 1. INSPECT MAP LIGHT ASSEMBLY

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



TESTER CONNECTION	SWITCH CONDITION	SPECIFIED CONDITION
0 (LP1) 1 (CND)	Spot light switch off	10 kΩ or higher
9 (+B1) - 1 (GND)	Spot light switch on	Below 1 Ω
9 (+B1) - 6 (CTY)	Not door position	10 kΩ or higher
9 (+D1) - 0 (C11)	Door position	Below 1 Ω

If the result is not as specified, replace the map light assembly.

### **Text in Illustration**

* -	Component without harness connected
_ <sup>™</sup> a	(Map Light Assembly)


(b) Apply battery voltage to the connector and check the LED illumination.

OK:

MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive $(+) \rightarrow Terminal 8 (ACC1)$ Battery negative $(-) \rightarrow Terminal 10 (CILL)$	LED illuminates

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YO6003X
Title: LIGHTING (INT): ROOM LIGHT (for Front): INSTALLATION (2010 4Runner)		

#### 1. INSTALL MAP LIGHT BULB



(a) Turn the 2 map light bulbs in the direction indicated by the arrows to install them.

#### 2. INSTALL MAP LIGHT ASSEMBLY

- (a) Connect the connector.
- (b) Attach the 3 clips to install the light.
- (c) Install the 2 screws.

#### 3. INSTALL DRIVE MONITOR SWITCH


- (a) Connect the connector.
- (b) Attach the 3 claws to install the switch.

(B)

ATOYOT (#)

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003MUA00GX
Title: LIGHTING (INT): ROOM LIGHT (for Rear): COMPONENTS (2010 4Runner)		


# **ILLUSTRATION**



E ATOYOTA ...

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003MUN00GX
Title: LIGHTING (INT): ROOM LIGHT (for Rear): REMOVAL (2010 4Runner)		

#### 1. REMOVE NO. 1 ROOM LIGHT ASSEMBLY




(a) Using a screwdriver, detach the 4 claws and remove the No. 1 room light lens.

#### **HINT:**

Tape the screwdriver tip before use.

### **Text in Illustration**

*1	Protective Tape
----	-----------------



(b) Using a screwdriver, detach the 2 claws and 2 guides and remove the 2 No. 1 room light covers.

#### **HINT:**

Tape the screwdriver tip before use.

### **Text in Illustration**

*1 Protective Tape	
--------------------	--


(c) Using a screwdriver, detach the 4 claws and disconnect the No. 1 room light assembly as shown in the illustration.

#### **HINT:**

Tape the screwdriver tip before use.

### **Text in Illustration**






(d) Using a screwdriver, detach the 4 claws and disconnect the room light switch base from the No. 1 room light assembly.

\_00

⊕ TOYOTA 🤾

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003MUM00GX
Title: LIGHTING (INT): ROOM LIGHT (for Rear): INSTALLATION (2010 4Runner)		


#### 1. INSTALL NO. 1 ROOM LIGHT ASSEMBLY




(a) A lign the switch parts as shown in the illustration and attach the 4 claws to install the room light switch base to the No. 1 room light assembly.

### **Text in Illustration**

*1	Switch Part of Room Light Switch Base
* 2	Switch Part of No. 1 Room Light Assembly




(b) Attach the 4 claws to install the No. 1 room light assembly.



(c) Attach the 2 claws and 2 guides to install the 2 No. 1 room light covers.


(d) Attach the 4 claws to install the No. 1 room light lens.



(B)

Last Modified: 5-10-2010	6.4 K	From: 200908	
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNK003X	
Title: LIGHTING (INT): VANITY LIGHT: COMPONENTS (2010 4Runner)			

# **ILLUSTRATION**



.

- ATOYOT (#)


Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNL007X
Title: LIGHTING (INT): VANITY LIGHT: REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. REMOVE ROOF HEADLINING ASSEMBLY

(a) Remove the roof headlining assembly



#### 2. REMOVE VANITY LIGHT ASSEMBLY LH

- (a) Detach the 2 claws (A) and separate the bulb holder from the vanity light as shown in the illustration.
- (b) Detach the claw (B) and remove the vanity light.

### **Text in Illustration**

*1	Claw A
*2	Claw B
*3	Bulb Holder

#### 3. REMOVE VANITY LIGHT BULB

(a) Remove the bulb.



**ЭТОУОТА** 

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNJ007X
Title: LIGHTING (INT): VANITY LIGHT: INSTALLATION (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL VANITY LIGHT BULB

(a) Install the bulb.

#### 2. INSTALL VANITY LIGHT ASSEMBLY LH

(a) Attach the 3 claws to install the vanity light.

#### 3. INSTALL ROOF HEADLINING ASSEMBLY


(a) Install the roof headlining assembly





Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN9005X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Front Door): COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




⊕ TOYOTA -

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNA005X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Front Door): REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.
- 1. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH
- 2. REMOVE NO. 2 DOOR INSIDE HANDLE BEZEL LH
- 3. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH
- 4. REMOVE FRONT DOOR GLASS WEATHERSTRIP INNER LH
- **5. REMOVE COURTESY LIGHT ASSEMBLY**



(a) Detach the 2 claws and remove the light.

- (b) Disconnect the connector.
- (c) Remove the bulb.



ATOYOT ®

		_
	Ū	5
		)
	D	5
		5

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN8005X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Front Door): INSTALLATION (2010		
4Runner)		

#### HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL COURTESY LIGHT ASSEMBLY


- (a) Install the bulb.
- (b) Connect the connector.
- (c) Attach the 2 claws to install the light.
- 2. INSTALL FRONT DOOR GLASS WEATHERSTRIP INNER LH
- 3. INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH
- 4. INSTALL NO. 2 DOOR INSIDE HANDLE BEZEL LH
- 5. INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH





Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN9006X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Rear Door): COMPONENTS (2010 4Runner)		

# **ILLUSTRATION**




- W

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YNA006X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Rear Door): REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.
- 1. REMOVE REAR DOOR INSIDE HANDLE BEZEL LH
- 2. REMOVE REAR DOOR TRIM BOARD SUB-ASSEMBLY LH
- 3. REMOVE REAR DOOR GLASS WEATHERSTRIP INNER LH
- 4. REMOVE COURTESY LIGHT ASSEMBLY



(a) Detach the 2 claws and remove the light.

- (b) Disconnect the connector.
- (c) Remove the bulb.



ATOYOT ®

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN8006X
Title: LIGHTING (INT): DOOR COURTESY LIGHT (for Rear Door): INSTALLATION (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.


#### 1. INSTALL COURTESY LIGHT ASSEMBLY

- (a) Install the bulb.
- (b) Connect the connector.
- (c) Attach the 2 claws to install the light.
- 2. INSTALL REAR DOOR GLASS WEATHERSTRIP INNER LH
- 3. INSTALL REAR DOOR TRIM BOARD SUB-ASSEMBLY LH
- 4. INSTALL REAR DOOR INSIDE HANDLE BEZEL LH

(<del>(2)</del>

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN6001X
Title: LIGHTING (INT): LUGGAGE C	OMPARTMENT ROOM	LIGHT: COMPONENTS (2010 4Runner)

# **ILLUSTRATION**




Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	<b>Doc ID:</b> RM000003YN7001X
Title: LIGHTING (INT): LUGGAGE COMPARTMENT ROOM LIGHT: REMOVAL (2010 4Runner)		

#### **HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.


#### 1. REMOVE SPOT LIGHT ASSEMBLY



(a) Detach the claw and remove the light.

(b) Disconnect the connector.

#### 2. REMOVE BULB



(a) Detach the 4 claws and remove the lens.

(b) Remove the bulb.

9

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000003YN5001X
Title: LIGHTING (INT): LUGGAGE COMPARTMENT ROOM LIGHT: INSTALLATION (2010 4Runner)		

#### HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

#### 1. INSTALL BULB

- (a) Install the bulb.
- (b) Attach the 4 claws to install the lens.

#### 2. INSTALL SPOT LIGHT ASSEMBLY

- (a) Connect the connector.
- (b) Attach the claw to install the light.



⊕TOYOTA →