

Sample Vehicle X1 - Owner's Guide

1. About this guide

This sample owner's guide describes the fictional Sample Vehicle X1. It was written for learning and testing purposes only. Always follow the manual of your real vehicle.

2. Instrument cluster warning lights

Warning lights use colours. RED means a serious problem: stop the vehicle safely as soon as possible. AMBER (yellow/orange) means a fault or service need: have the vehicle checked soon. GREEN or BLUE means a system is on or active.

- Engine malfunction light (amber): the engine management system found an emission or engine fault. Drive carefully and visit a workshop.
- Engine oil pressure light (red): oil pressure is too low. Stop the engine immediately and do not drive on.
- Battery charge light (red): the charging system is not working. Switch off unneeded electrical consumers and visit a workshop.
- Brake system light (red): low brake fluid or a brake fault, or the parking brake is still applied. Check the parking brake first. If it stays on, do not continue driving.
- ABS light (amber): the anti-lock braking system is faulty. Normal braking still works but the wheels can lock under hard braking.
- ESC light (amber, flashing during action): flashing means the stability control is currently working, for example on a slippery road. Steady means a fault.
- Tyre pressure (TPMS) light (amber): one or more tyres have low pressure. Check and correct the pressure.
- Airbag light (red): a fault in the airbag or seat belt system. Have it checked at once.
- Coolant temperature light (red): the engine is overheating. Stop safely and let the engine cool down.
- Seat belt reminder (red): a front seat belt is not fastened.

3. Infotainment system

The 10-inch touchscreen controls navigation, media, phone and vehicle settings. To pair a phone by Bluetooth: 1) turn Bluetooth on in your phone, 2) on the screen select Phone > Add Device, 3) choose the vehicle name on your phone, 4) confirm that the 6-digit code is the same on both devices. The system supports Apple CarPlay and Android Auto through a USB cable. Say 'Hey Vehicle' to start the voice assistant, for example 'Navigate home' or 'Call John'. If the screen is frozen, press and hold the power knob for 10 seconds to restart the system. A factory reset is available under Settings > System > Reset, but it deletes all paired phones and saved addresses.

4. Driver assistance systems (ADAS)

Sample Vehicle X1 has these assistance functions:

- Adaptive Cruise Control (ACC): keeps a set speed and a selected distance to the vehicle ahead and can brake to a stop.
- Lane Keeping Assist (LKA): gives a gentle steering correction if you leave the lane without using the indicator.
- Autonomous Emergency Braking (AEB): warns of a possible collision and brakes automatically if the driver does not react.
- Blind Spot Warning: a light in the mirror shows a vehicle in the blind spot.
- Parking Assist: shows distance to obstacles with sensors and a 360-degree camera.

Limitations: the systems use cameras and radar. Heavy rain, snow, fog, dirt or ice on the windscreen or bumper sensors, and bad lane markings can reduce performance. The driver stays fully responsible and must always keep attention on the road and hands on the steering wheel.

5. Maintenance schedule

- Engine oil and oil filter: every 10,000 km or 12 months, whichever comes first.
- Tyre rotation: every 10,000 km.
- Tyre pressure check: once a month and before long trips.
- Brake fluid: replace every 2 years.
- Engine coolant: check yearly, replace every 5 years.
- Cabin air filter: every 15,000 to 20,000 km.
- Windscreen wiper blades: check every 6 months.
- 12-volt battery: test every year after the third year.
- Brake pads and discs: inspect at every service.

6. Tyre pressure

Recommended cold tyre pressure for Sample Vehicle X1: front 230 kPa (2.3 bar), rear 250 kPa (2.5 bar). With full load, add 20 kPa to the rear tyres. Always measure when the tyres are cold, because driving heats the tyres and raises the pressure.

7. Troubleshooting

Problem: the engine does not start. Check that the brake pedal is pressed, the key fob battery is not empty (hold the fob near the start button) and the 12-volt battery is not discharged.

Problem: Bluetooth does not connect. Delete the vehicle from the phone, delete the phone from the vehicle, switch Bluetooth off and on, then pair again.

Problem: the reversing camera image is black. Clean the camera lens. If it stays black, restart the infotainment system. If it is still black, visit a workshop.

Problem: the navigation shows the wrong position. Drive in an open area for a few minutes so the GPS can find satellites.

Problem: ACC or LKA is not available. Clean the windscreen camera area and the front radar cover. The systems return automatically when the sensors see clearly again.

8. Over-the-air (OTA) software updates

Sample Vehicle X1 can receive software updates through its built-in mobile connection or Wi-Fi. When an update is ready the screen shows a message. To install: park the vehicle, select Settings > System > Software Update > Install Now. The 12-volt battery should be healthy. Updates normally take 20 to 45 minutes and the vehicle cannot be driven during installation. Do not open the doors or press the start button during the update. If an update fails, the system automatically goes back to the previous working software version.

9. Emergency and safety

In an accident with airbag deployment, the eCall system automatically calls the emergency number and sends the vehicle location. You can also start an emergency call by pressing the SOS button in the overhead console. Switch on the hazard warning lights using the red triangle button. Use the warning triangle and wear the safety vest before leaving the vehicle on a road.