PB-220 Centrifugal Pump Installation Guide (DOC-PI-220)

Section 1

1 Foundation and alignment

Align the coupling within 0.05 mm parallel and 0.08 mm axial using the dial indicator method at motor operating temperature. Shims must be stainless.

Section 2

2 Fastener torque table

M8 fasteners: 25 Nm. M10 fasteners: 40 Nm. M12 fasteners: 70 Nm.

Torque values apply to lightly oiled threads and must be re-checked after the first heat-up cycle.

Section 3

3 Vibration limits

Alarm limit 4.5 mm/s RMS measured at the bearing housing, trip limit 7.1 mm/s RMS. Measure with the pump at rated flow; readings between 7.1 and 9.0 mm/s RMS for more than 10 minutes require shutdown.

Section 4

4 Commissioning run

Crack open the discharge valve to 50 percent, run 15 minutes, check bearing temperature below 80 degC, then ramp to rated duty in 10 percent flow steps.