

○単接点トリガ

自動運転中にある入力信号に対して起動信号（Lo→Hi）を入力することでその信号に対してあらかじめ割り振られたタスクまたはシステムコマンドを起動できます。

入力信号1つに対して1つのタスクを割り振ります。

デメリットとして、品種設定は接点の数しか切り替えることができません

入力信号 VTV9000 Input

1	トリガ1(Task G01T01)
2	トリガ1(Task G01T02)
3	トリガ1(Task G01T03)
4	トリガ1(Task G01T04)
5	トリガ1(Task G01T05)
6	トリガ1(Task G01T06)
7	トリガ1(Task G01T07)
8	トリガ1(Task G01T08)
9	トリガ1(Task G01T09)
10	トリガ1(Task G01T10)
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	
21	
22	カメラ列実行制御(Cam1)
23	カメラ列実行制御(Cam2)
24	カメラ列実行制御(Cam3)
25	カメラ列実行制御(Cam4)
26	カメラ列実行制御(Cam5)
27	カメラ列実行制御(Cam6)
28	カメラ列実行制御(Cam7)
29	カメラ列実行制御(Cam8)
30	接点入力待ち解除
31	
32	システム起動保持信号

使用例

21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF

- ①タスク実行(グループ01タスク01)
- ②タスク実行(グループ01タスク05)
- ③タスク実行(グループ01タスク01)
- ④タスク実行(グループ01タスク05)

