Maintenance and Troubleshooting Guide

Demo Pumps Pvt. Ltd. · Document MT-04 · Version 1.0, effective 01-Apr-2026

1. Safety first

• Switch off and lock the motor before any work on the pump.

• Release the system pressure: a hydraulic line can stay under pressure after the motor stops.

• Let the pump cool down: oil and pump bodies can be hotter than 60 °C.

• Wear safety glasses and oil-resistant gloves.

2. Maintenance schedule

When	What to do
Every day	Check the oil level and look for leaks; listen for unusual noise.
Every 500 running hours	Change the suction strainer and the return-line filter.
Every 2,000 running hours	Change the hydraulic oil; check the coupling and the shaft seal.
Every 8,000 running hours or yearly	Full overhaul by our service team: bearings, seals, gears.

Use mineral hydraulic oil ISO VG 46 (ISO VG 32 below 10 °C room temperature). Keep the oil clean: most pump failures start with dirty oil.

3. Troubleshooting

Problem	Likely cause	What to do
Pump is noisy	Air enters the suction line, or the oil level is low (cavitation)	Tighten the suction fittings, fill oil to the mark, clean the suction strainer
Low pressure	Relief valve set too low, or worn gears / rotor	Reset the relief valve to the catalogue value; if still low, send for overhaul
Oil leaks at the shaft	Shaft seal worn or damaged	Replace the shaft seal (seal kit for the model)
Pump gets too hot (above 70 °C)	Wrong oil, dirty oil, or the pump runs above its pressure	Change to ISO VG 46 oil, change the filter, check the working pressure
No flow at start	Wrong rotation direction or the pump is not primed	Check the arrow on the pump body; fill the pump with oil before the first start
Motor trips	Motor power too small for the pressure	Check the motor power against the catalogue (Product Catalogue PC-01)

4. Spare parts

Seal kits and bearing kits are kept in stock for every model in the Product Catalogue (PC-01). Order spare parts with the model and the serial number from the name plate.

5. Service

Our service team visits within 48 hours in the main industrial cities. An annual maintenance contract (AMC) covers two visits a year and a 10% discount on spare parts.