TH450A
TH550A /TS2000

Industrial Robot

MAINTENANCE MANUAL

Notice

1. Make sure that this instruction manual is delivered to the final user of SHIBAURA MACHINE's industrial robot.
2. Before operating the industrial robot, read through and completely understand this manual.
3. After reading through this manual, keep it nearby for future reference.

Rev.2
April 1, 2020

Shibaura Machine

Copyright 2020 by SHIBAURA MACHINE CO.,LTD.

All rights reserved.

No part of this document may be reproduced in any form without obtaining prior written permission from SHIBAURA MACHINE CO.,LTD.

The information contained in this manual is subject to change without notice to effect improvements.

WARRANTY

This machine is delivered to each customer only after it is inspected very carefully to make sure that it satisfies the SHIBAURA MACHINE's standard. Should it cause an inconvenience, we will guarantee as described below.

1. Warranty period
   SHIBAURA MACHINE agrees to repair or replace as necessary all defective material or workmanship up to the period shown below, whichever comes first.
   1) Twenty-four (24) months from the date of dispatch from our plant.
   2) Eighteen (18) months from the date of machine installation at customer's job site.
   3) 4,000 running hours from the date of initial machine operation.

2. Contents of warranty
   1) Only the product delivered to the customer is subject to SHIBAURA MACHINE's Guarantee. Such Guarantee covers the specifications and functions as defined in the product specifications manual, catalog, instruction manual, etc. In no event does the Guarantee cover any secondary or associated damage caused by malfunction of the delivered product.
   2) SHIBAURA MACHINE repairs the product free of charge only when it malfunctioned after handling or use according to the instruction manual attached to the product within the specified warranty period.

3. Exemption from responsibility
   SHIBAURA MACHINE's Guarantee shall not cover the following cases.
   1) Incorrect use not described in the instruction manual, and trouble or damage caused by negligent use.
   2) Inconvenience caused by aged deterioration or long-term usage (natural fading of coating or painting, deterioration of consumable parts (*1), etc.).
   3) Inconvenience caused by sensuous phenomena (noise generation, etc. which will not affect the function).
   4) Remodeling or disassembly which SHIBAURA MACHINE will not permit.
   5) Trouble and damage caused by insufficient maintenance/inspection or improper repair.

6) Trouble and damage caused by disaster, fire or other external factor.

7) Internal data such as program and point which were created by the customer.

8) When the robot purchased in Japan was shipped overseas.

4. Precautions

1) Unless the robot was used pursuant to its specifications, SHIBAURA MACHINE will not guarantee the basic performance of the robot.

2) If the customer did not observe the warnings and cautions described in this manual, SHIBAURA MACHINE will not assume the responsibility for any consequential accident resulting in injury or death, damage or trouble.

3) Please note that the warnings, cautions and other descriptions stipulated in this manual are only those which can be assumed by SHIBAURA MACHINE as of now.

(*1) The consumable parts signify the replacement parts for maintenance as listed in Section 5 of this manual.

INTRODUCTION

This manual describes the maintenance of the TH450A and TH550A industrial robots and TS2000 controller.
The TH850A and TH1050A robots differ only in the length of arm 1, and all other mechanisms, assembly and inspection and maintenance are the same. In this manual, therefore, only the descriptions on the TH850A robot are contained.

The maintenance and inspection are essential to maintain the robot performance for long years to prevent a trouble and improve the safe work.
Before starting an actual operation, it is strongly recommended to read through this manual and draw up a maintenance schedule.

CAUTIONS ON SAFETY

This manual contains the important information on the robot and controller to prevent injury to the operators and persons nearby, to prevent damage to assets and to assure correct use.
Make sure that the following details (indications and symbols) are well understood before reading this manual. Always observe the information that is noted.

[Explanation of indications]

Indication	Meaning of indication
! **DANGER**	This means that "incorrect handling will imminently lead to fatalities or serious injuries."
! **WARNING**	This means that "incorrect handling may lead to fatalities or serious injuries."
! **CAUTION**	This means that "incorrect handling may lead to personal injuries *1) or physical damage *2)."

*1) Injuries refer to injuries, burns and electric shocks, etc., which do not require hospitalization or long-term medical treatment.

*2) Physical damage refers to damages due to destruction of assets or resources.

[Explanation of symbols]

Symbol	Meaning of symbol
	This means that the action is prohibited (must not be done). Details of the actions actually prohibited are indicated with pictures or words in or near the symbol.
	This means that the action is mandatory (must be done). Details of the actions that must be done are indicated with pictures or words in or near the symbol.
	This means danger or caution. Details of the actual danger or caution are indicated with pictures or words in or near the symbol.

[Maintenance and inspection]

Be sure to observe the following items to use the robot safely.

 **DANGER**	
 Prohibited	• DO NOT incinerate, disassemble or charge the batteries. Otherwise, they may rupture.
 Mandatory	• Be sure to turn off the main power switch of the controller before starting inspection or maintenance. • Batteries should be disposed of according to the user's in-house regulations.

! CAUTION	
 Disassembly prohibited	• The user must NEVER replace or modify parts other than those described in the instruction manual. Otherwise, the performance may deteriorate or faults or accidents will be caused.
 Mandatory	• Always use the SHIBAURA MACHINE's designated spare parts when replacing the parts. • Maintenance and inspection should be performed regularly. Otherwise, the system may malfunction or accidents will be caused.

Table of Contents

Page

1. Maintenance 11
1.1 Maintenance Schedule 11
1.2 Items for Maintenance and Inspection 12
1.2.1 Inspection at Power OFF (at Non-Operation) 12
1.2.2 Inspection at Power ON (at Operation) 13
1.2.3 Overhaul 13
1.3 Maintenance Tools 14
1.4 Maintenance Contract and Repair 14
1.4.1 Maintenance Contract 14
1.4.2 Repair 14
1.4.3 Modification 15

2. Maintenance of the Main Robot 16
2.1 Cautions on Maintenance and Inspection 16
2.1.1 Clamping Hexagon Socket Head Cap Screws 16
2.2 Details of Inspection 18
2.2.1 Check of Each Bolt (or Screw) for Clamping 18
2.2.2 Check of Each Connector for Clamping 20
2.2.3 Check of Each Cable and Air Tube for Abrasion 21
2.2.4 Check of Each Axis for Operation 22
2.3 Layout of Robot Components and Drive Mechanism 22
2.4 Dismounting and Mounting Each Cover 24
2.4.1 Arm 2 Cover 25
2.4.2 Base Covers 26
2.5 Replacing Motor 27
2.5.1 Type of Motor 28
2.5.2 Motor Locations 29
2.5.3 Dismounting Axis 1 Motor 29
2.5.4 Mounting Axis 1 Motor 31
2.5.5 Dismounting Axis 2 Motor 33
2.5.6 Mounting Axis 2 Motor 34
2.5.7 Dismounting Axis 3 Motor 36
2.5.8 Mounting Axis 3 Motor 38
2.5.9 Dismounting Axis 4 Motor 39

2.5.10 Mounting Axis 4 Motor 40
2.6 Adjusting and Replacing Timing Belt 41
2.6.1 Type of Timing Belt 41
2.6.2 Timing Belt Locations 42
2.6.3 Replacing Axis 3 Timing Belt 42
2.6.4 Replacing Axis 4 Timing Belt 45
2.7 Filling Grease to Ball Screw Spline Unit and Replacement 48
2.7.1 Type of Ball Screw Spline Unit 49
2.7.2 Ball Screw Spline Unit Location 49
2.7.3 Filling Grease to Ball Screw Spline Unit 50
2.7.4 Dismounting Ball Screw Spline Unit 52
2.7.5 Mounting Ball Screw Spline Unit 55
2.8 Reduction Gear Replacement 58
2.8.1 Type of Reduction Gear 58
2.8.2 Reduction Gear Locations 59
2.8.3 Dismounting Axis 1 Reduction Gear 59
2.8.4 Mounting Axis 1 Reduction Gear 62
2.8.5 Dismounting Axis 2 Reduction Gear 64
2.8.6 Mounting Axis 2 Reduction Gear 66
2.8.7 Replacing Axis 4 Reduction Gear 68
2.9 Replacing Position Detector (or Encoder) Batteries 70
2.9.1 Battery Box Location 71
2.9.2 Replacing Batteries 71
2.9.3 Battery Error Code 72

3. Maintenance of Controller 73
3.1 Cautions on Maintenance and Inspection 73
3.2 Layout of Controller Parts 74
3.3 Maintenance Procedures 75
3.3.1 Check of Controller Air Vent Holes 75
3.3.2 Check of Safety Devices for Function 76
3.3.3 Battery Replacement 78
3.3.4 Replacement of Switching Power Supply Unit 81
3.3.5 Replacement of Fuse (X8HN, X8HI Printed Board) 84
3.3.6 Replacement of Output ICs (X8HN, X8HI Printed Board) 85

4. Robot Home Point and Position Detector Error 87
4.1 Setting Robot Home Point 87


4.2 Position Detector Error 88
4.3 Restoring Operation from Position Detector Error 91
4.3.1 Encoder Status Display 91
4.3.2 Encoder Error Reset Operation 92
4.4 Restoring Home Position Data by HOME Function 93
4.4.1 Outline of HOME Function 93
4.4.2 Setting HOME1 and HOME2 94
4.4.3 How to Restore Data by HOME1 or HOME2 95
4.4.4 Locations of Robot Home Point Match-Marks 96
4.4.5 How to Restore Data by HOME3 or HOME4 96
4.5 Restoring Home Position Data by ZEROP Function 98
4.5.1 Preparation before Restoring Operation 98
4.5.2 Setting New Home Position Data 99
4.5.3 Confirming Home Position 101
4.5.4 Saving Data 101
4.6 Restoring Home Position Data by Multi-Turn Data Clear 102

5. Replacement Parts for Maintenance 103
5.1 List of Replacement Parts – Main Robot 103
5.2 List of Replacement Parts – Controller 104
5.3 List of Servo Amplifier Module 104

1. Maintenance

1.1 Maintenance Schedule

Maintenance comes in the two (2) types; daily inspection, and regular inspection and maintenance. For the regular inspection and maintenance, inspection items are added every 1,200 running hours.



Inspection schedule

- When the system is operated for 16 hours per day:
  16 hours × 25 days × 3 months = 1,200 hours
- When the system is operated for 24 hours per day:
  24 hours × 25 days × 3 months = 1,800 hours

1.2 Items for Maintenance and Inspection

This section describes the items for maintenance and inspection.
For the executing procedures, see the relevant paragraph listed in the table below.

1.2.1 Inspection at Power OFF (at Non-Operation)

D: Daily inspection Q: Quarterly inspection
S: Semi-annual inspection A: Annual inspection

Description	Check position	D	Q	S	A	Refer to
Make sure that all bolts are completely tightened and secured. Otherwise, tighten the bolts completely.	Tool set bolts	○	○	○	○	Para. 2.2.1
	Robot installation bolts	○	○	○	○	
	Bolts for each joint reduction gear				○	
	Motor set bolts				○	
Make sure that all connectors are tightened completely	Base connector	○	○	○	○	Para. 2.2.2
Make sure that no cut or scratch is found. Clean the contaminant, if any.	Entire robot	○	○	○	○	
	Arm 2 interior			○	○	
Make sure that enough volume of grease is filled. Otherwise, fill the grease.	Ball screw shaft	○	○	○	○	Para. 2.7.3
Make sure that the cables and air tubing are not worn out.	Cables and air tubing of each unit			○	○	Para. 2.2.3
Make sure that each axis can be operated properly by moving the axis by hand.	Entire robot			○	○	Para. 2.2.4

1.2.2 Inspection at Power ON (at Operation)

D: Daily inspection Q: Quarterly inspection
S: Semi-annual inspection A: Annual inspection

Description	Check position	D	Q	S	A	Refer to
Push each arm by hand in the servo ON condition to make sure that the arm is secured.	Each joint				○	
Make sure that no abnormal vibration or noise is caused.	Entire robot	○	○	○	○	
Check for the repeatability.	Entire robot		○	○	○	
Replace the batteries for position detection with new ones.	Battery box				○	Para. 2.9.2

1.2.3 Overhaul

Description	Maintenance parts	Every 5 years	Refer to
Check for the consumable parts and replace as necessary.	Reduction gears, ball screws, motors, belts	○	Para. 2.4 ~ 2.8
Replace the battery with a new one.	Backup battery in the controller	○	Para. 3.3.3
Replace the switching power supply unit with a new one.	In the controller	○	Para. 3.3.4

1.3 Maintenance Tools

We recommend to use the following tools for maintaining the robot and controller.

- Phillips screwdrivers
- Hexagonal wrench set: M3 ~ M16
- Torque wrench set: M3 ~ M10
- Nippers

Recommended provisions other than the tools:

- Grease gun
- Waste cloth
- Vice (clamp)
- Liquid gasket (recommendation: 1221H made by ThreeBond)
- Seal tape
- Loctite adhesives (242; mid adhesive force)
- Belt tension meter
- TSPC program creation/teaching support software (option)

1.4 Maintenance Contract and Repair

1.4.1 Maintenance Contract

For the inspection items for maintenance and inspection to be done semi-annually and after, it is rather difficult for the user to execute, except for greasing and lubrication. We recommend that the user contact SHIBAURA MACHINE Service Department and conclude an after-sale service contract with us.


1.4.2 Repair

If a fault has occurred or if repair is necessary, turn off the controller power and contact the SHIBAURA MACHINE Service Department. At this time, advise us of the details of the fault and the following information stated on the robot and controller.

- Robot model
- Manufacture number
- Manufacture number of controller
- Date of manufacture of robot
- Running hours

For the manufacture number and date of manufacture, see the following labels attached to main base of the robot.





1.4.3 Modification

The robot and controller MUST NOT be modified or disassembled without a prior consent from SHIBAURA MACHINE.

CAUTION

- The user must NEVER replace or modify parts other than those described in the instruction manual. Otherwise, the performance may deteriorate or faults or accidents will be caused.

2. Maintenance of the Main Robot

2.1 Cautions on Maintenance and Inspection

When performing inspection or maintenance of the robot, strictly observe the following precautions to protect yourself and coworkers.

! DANGER


- Be sure to turn off the main power switch of the controller before approaching the robot for maintenance and inspection.
- When moving the robot by hand while the power is turned on, be sure to assure the safe work and effect an emergency stop beforehand.
- In the above situation, if the work is to be done while the axis 3 motor brake OFF switch is pressed, be sure to perform the work by two (2) persons. One person should carry out the work while the other is monitoring the work outside the hazardous zone. The latter person should watch the work and be ready to turn off the controller switch if any abnormality occurs. Once the controller power is turned off, the motor brake actuates even if the axis 3 motor brake OFF switch is kept pressed.
- If the axis 3 motor brake OFF switch is pressed while the robot is carrying a heavy workpiece, the axis 3 may drop suddenly. To avoid this, the customer should take all necessary measures by themselves.

2.1.1 Clamping Hexagon Socket Head Cap Screws

This robot uses hexagon socket head cap screws at places requiring mechanical strength. At the time of factory-assembly, lock adhesives are applied and each screw is tightened with the following clamping torque.
When these screws are tightened again according to the inspection and maintenance as stipulated in this manual, use a torque wrench, etc. to assure the appropriate clamping torque.
The places which do not fall under the table below are detailed in the paragraph of the replacement procedures.

Screw	M3	M4	M5	M6	M8	M10
Clamping torque	2.0 N·m	4.7 N·m	9.0 N·m	15 N·m	37 N·m	75 N·m

For the screws arranged on a circle for mounting the reduction gear, etc., tighten them in the diagonal order, as shown below.



DO NOT tighten one (1) screw at a time. Tighten each screw in multiple steps, using a hexagonal wrench key, and secure with appropriate clamping torque by means of a torque wrench.

2.2 Details of Inspection

2.2.1 Check of Each Bolt (or Screw) for Clamping

(1) Tool Set Bolts

Make sure, using the hexagonal wrench key, that the hexagon socket head cap screws of the tool set flange, which are clamped to the tool shaft are tightened completely. If loosened, tighten them completely.

Make sure, using the hexagonal wrench key, that the hexagon socket head cap screws securing the tool flange and tool are tightened completely. Otherwise, tighten them completely.




Fig. 2.1 Tool set bolts

(2) Robot Installation Bolts

Make sure, using the hexagonal wrench key, that the installation bolts of the main robot base are tightened completely. If loosened, tighten them completely.




Fig. 2.2 Robot base set bolts

(3) Bolts for each joint

Make sure, using the hexagonal wrench key, that the bolts for the axis 1 and 2 joints (i.e., bolts for clamping each reduction gear and arm) are tightened completely. If loosened, tighten them completely.




Fig. 2.3 Axes 1 and 2 set bolts (TH450A/TH550A)

(4) Motor Set Bolts

Make sure, using the hexagonal wrench key, that the bolts for securing each axis drive motor are tightened completely. If loosened, tighten them completely.
Also make sure that the motor base set bolts are tightened completely.
For the places where the following bolts are used, see Para. 2.5.

[TH450A/TH550A]

Axis 1 motor set bolt:	M5 x 16, 4 pcs.	Recommended clamping torque: see page 16
Axis 1 motor bracket set bolt:	M8 x 30, 4 pcs.	Recommended clamping torque: 27 N·m
Axis 2 motor set bolt:	M4 x 12, 4 pcs.	Recommended clamping torque: see page 16
Axis 2 motor bracket set bolt:	M5 x 12, 10 pcs.	Recommended clamping torque: see page 16
Axis 3 motor set bolt:	M4 x 12, 4 pcs.	Recommended clamping torque: see page 16
Axis 3 motor base set bolt:	M4 x 10, 4 pcs.	Recommended clamping torque: see page 16
Axis 4 motor set bolt:	M3 x 12, 4 pcs.	Recommended clamping torque: see page 16
Axis 4 reduction gear set bolt:	M3 x 12, 4 pcs.	Recommended clamping torque: see page 16
Axis 4 motor base set bolt:	M4 x 10, 4 pcs.	Recommended clamping torque: see page 16

For the axis 4 reduction gear set bolts and axis 4 motor base set bolts, see Para. 2.8.8 and Para. 2.6.4, respectively.

2.2.2 Check of Each Connector for Clamping

Make sure that the cable connectors connected to the robot main base are tightened completely. If loosened, lock the lever.




Fig. 2.4 Base connectors

2.2.3 Check of Each Cable and Air Tube for Abrasion

Disassemble the arm 2 cover and base cover and make sure that each cable and air tube are not worn out, broken or cracked. Especially, take careful precautions to inspect the vicinity of the cable outlets of the axis 1 joint and axis 2 joint.
For how to dismounting the covers, see Para. 2.4.




Fig. 2.5 Cable and air tube check points

2.2.4 Check of Each Axis for Operation

Turn on the main power switch of the controller, then keep the EMERGENCY pushbutton switch in the depressed condition. Move each axis by hand and make sure that it can move smoothly.
For the axis 3, when the brake OFF pushbutton switch is pressed, the brake is released. Take careful precautions at this time as the tool shaft may drop according to the weight of the hand and tool.

2.3 Layout of Robot Components and Drive Mechanism

The layout of the robot mechanical components is shown in Fig. 2.6 .




Fig. 2.6 Layout of robot mechanical components (TH450A/TH550A)

The drive mechanism of each axis is described below.

1) Axis 1

The axis 1 AC servo motor is mounted on the base.
The motor revolution is input to the reduction gear via the input gear and reduction center gear. The output of the reduction gear directly controls the arm 1 motion.

2) Axis 2

The axis 2 AC servo motor is mounted on the axis 2 arm.
The motor revolution is input to the reduction gear via the input gear and reduction center gear. The output of the reduction gear directly controls the arm 2 motion.

3) Axis 3

The axis 3 AC servo motor is mounted on the axis 2 arm.
The motor revolution is input to the ball screw nut through the timing belt to move the ball screw spline shaft up and down.

4) Axis 4

The axis 4 AC servo motor is mounted on the axis 2 arm.
The motor revolution is input to the ball spline nut through the reduction gear and timing belt to revolve the ball screw spline shaft.

2.4 Dismounting and Mounting Each Cover

This paragraph describes the dismounting and mounting of the covers, which are common to the maintenance and replacement of each unit.

CAUTION

- When mounting the arm 2 cover, take careful precautions not to catch any cable in it. If the cable is bent and pushed by force, it will be broken. Each cable is secured to the plate, etc. with TY-RAP. **After the cover is disconnected, make sure of the cable layout and return the cables to natural wiring state.**

DANGER

- When opening the cover, take careful precautions not to allow entry of moisture or contaminant into the robot. If the power is turned on while moisture or contaminant is left, you may get an electric shock or the robot may malfunction, which is very dangerous.

2.4.1 Arm 2 Cover

The arm 2 cover is secured to the cover set bracket with six (6) socket head bolts (M4 x 8). As the arm 2 cover is inserted into the arm 2, it can be lifted once the screws are removed. The inserted unit may not be disengaged easily, however. When this happens, it is recommended that the axis 3 be lowered beforehand until the ball screw stopper enters the cover so that you can hold the ball screw hole ("A" part in Fig. 2.7) when lifting up the cover. The packing attached to the cover can be disconnected together with the cover.




Fig. 2.7 Arm 2 cover (Common to TH450A, TH550A)

Take utmost care not to turn up the packing attached under the cover. After the cover is mounted, manually move up and down the ball screw spline shaft while pressing the brake OFF switch, and make sure that the ball screw hole will not interfere with the ball screw stopper.

2.4.2 Base Covers

In all, two (2) base covers are provided; the cover also serving as the connector panel cover and cover also used as the battery box cover.
The former cover is secured to the base with eight (8) cross truss head screws (M4 x 6).
The latter cover is secured to the base with nine (9) hexagon flat head screws (M5 x 10). Though each cover can be disconnected when the clamp bolts are removed, it is connected to the cables inside. DO NOT pull the cover by force.
The two covers also serving as the connector panel cover are provided with packing. Take careful precautions when handling this cover.




Fig. 2.8 Base covers

2.5 Replacing Motor

The motor is to be replaced by our service engineer. If it is replaced by the customer, we will not guarantee any consequential trouble or accident.

! DANGER

- The motor should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.

! CAUTION

- When replacing the motor, take careful precautions not to exert a heavy impact on the motor shaft. Otherwise, the motor and encoder may be damaged.
- NEVER disassemble the motor and encoder. Otherwise, they cannot be used due to positional shift, etc.
- **Once the motor has been changed, the mechanical home point origin (or origin) will shift and precise control will not be possible. To avoid this, home return operation is necessary after motor replacement.**
  For the home return procedures, see Section 4.

2.5.1 Type of Motor

The motors employed in this robot are shown below. When you place an order for a new motor, make sure of the robot model, axis name, type and our drawing number according to the following table.
For the axis 3 also, a pulley on the motor side is driven by means of the key.
For our drawing numbers on the input gear and pulley and type of the key, also see the table below.

Description	Axis name	Type	Our drawing No.	Unit code	Model name
AC servo motor	Axis 1	MSMD092S2U	S746326	Y610A3400	TH450A/TH550A
	Axis 2	MSMD042S2U	S746328	Y610A34C0	TH450A/TH550A
	Axis 3	MSMD022S2V	S746337	Y610A3430	TH450A/TH550A
	Axis 4	MSMD022S2U	S746329	Y610A34D0	TH450A/TH550A
Pulley	Axis 3		S854452		TH450A/TH550A
Key	Axis 1	Square key 6 x 6 x 20			
	Axis 2	Square key 5 x 5 x 16			
	Axis 3	Square key 4 x 4 x 16			

2.5.2 Motor Locations





Fig. 2.9 Motor locations (TH450A/TH550A)


2.5.3 Dismounting Axis 1 Motor

1) Disconnect the two (2) covers attached to the base. (See Para. 2.4.3.)
2) Disconnect connectors J1AS and J1AP (power drive cables) and connectors J1BS and J1BP (encoder cables) of the axis 1 motor.
3) Remove the eight bolts (M10 x 25) securing the arm 1 and base, and dismount the arm 1.
4) Remove the four bolts (M8 x 30) securing the bracket and base, and detach the bracket.



5) Remove the bolts (M6 x 30) securing the bracket and reduction gear. Dismount the reduction gear, using the bracket's taps for disassembly (M6 at 2 positions).

6) Remove the bolt (M5 x 10) from the end of the axis while holding the protrusion on the wave generator with pliers or the likes.
Use a waste cloth (or the like) as a cushion to protect the wave generator from scratches when securing it. After removing the bolt, lift off the washers and wave generator. Be sure to remove the key.



! CAUTION

- When dismounting the wave generator, DO NOT knock it with excessive force. Otherwise, the encoder may be damaged.

7) Remove the four (4) bolts (M5 x 16) securing the motor.

8) Disengage the motor from the bracket. As the motor set surface is applied with liquid gasket, disengage them, using the taps for disassembly (M5, two (2) places).

2.5.4 Mounting Axis 1 Motor

1) Perform key alignment, using the new motor and wave generator. At this time, no clearance should exist between the motor shaft and wave generator.


! CAUTION

- Perform key alignment very carefully. If there is a clearance between the motor shaft and wave generator, an abnormal noise may be heard at the time of operation. Also, positioning accuracy will drop and the life of the parts will shorten.

2) Mount the motor on the motor base with four (4) bolts (M5 x 16). At this time, apply the liquid gasket to the motor set surface.
3) Mount the wave generator and key, and secure them with the bolt (M5 x 10) and the washers. Be sure to insert the wave generator with the groove around the circumference on the motor side. Tighten the bolt (M5 x 10) on the end of the axis while holding the protrusion on the wave generator with pliers or the likes. Use a waste cloth (or the like) as a cushion to protect the wave generator from scratches when securing it.
4) Secure the reduction gear to the bracket with the 12 bolts (M6 x 30). Be sure to apply Loctite to the threaded portion of each bolt. In doing so, be sure to fit the O-ring (provided as an accessory) into the O-ring groove in the reduction gear.

! CAUTION

- When mounting the wave generator, DO NOT knock it with excessive force. Otherwise, the encoder may be damaged.



5) Some grease is wiped off the reduction gear when the procedure in Para. 2.5.3 is performed, so supply the amount of grease (SK-1A) wiped off.

6) Secure the bracket and reduction gear to the base.

7) To secure the O-ring set in the O-ring groove of the motor base, follow the Steps 3) and 4) of Para. 2.5.3 in the reversed order.

8) Connect the axis 1 motor connectors (for the power drive cable and encoder cable).

9) Return the cables in the base as originally arranged, then attach the cover to the base.

10) After the axis 1 motor is replaced with a new one and before the power is turned on, move the arm 1 by hand to make sure that no abnormal noise is heard.

11) Turn the power on and perform home setting for the axis 1. Now, the motor replacement completes.
(Check for the coordinates of the axes 2, 3 and 4, and perform home setting when necessary.)

! CAUTION


- Be sure to apply the liquid gasket. Otherwise, grease will leak from the bracket set surface.

2.5.5 Dismounting Axis 2 Motor


1) Disconnect the arm 2 cover. (See Para. 2.4.1.)

2) Disconnect connectors J2AS and J2AP (power drive cables) and connectors J2BS and J2BP (encoder cables) of the axis 2 motor.


3) Remove the three bolts (M4 x 8) securing the arm 2 and cover bracket, and then the eight bolts (M8 x 16) securing the arm 2 to the arm 1.



4) Remove the two bolts (M3 x 6) securing the connector panel.
Remove the ten bolts (M5 x 16) securing the motor bracket and arm 2, and pull it out of the arm 2.
Remove the ten bolts (M5 x 12) securing the motor bracket and reduction gear, and pull out the reduction gear.



5) Remove the bolt (M4 x 10) from the end of the axis while holding the protrusion on the wave generator with pliers or the likes. Use a waste cloth (or the like) as a cushion to protect the wave generator from scratches when securing it. After removing the bolts, remove the washer and wave generator. Bear in mind that the key is removed.




2.5.6 Mounting Axis 2 Motor

1) Perform key alignment, using the new motor and wave generator. At this time, no clearance should exist between the motor shaft and wave generator.

CAUTION

- Perform key alignment very carefully. If there is a clearance between the motor shaft and wave generator, an abnormal noise may be heard at the time of operation. Also, positioning accuracy will drop and the life of the parts will shorten.

2) Mount the motor on the motor bracket in the reverse order of Step 5) of Para. 2.5.5 above. Before mounting, apply the liquid gasket to the motor set surface. After that, assemble the motor and wave generator.



3) Assemble the motor and die arm 2 in the reverse order of Step 4) of Para. 2.5.5 above.

CAUTION

- Be sure to apply the liquid gasket. Otherwise, grease will leak from the motor set surface.

4) Assemble the cover bracket in the reverse order of Step 3) of Para. 2.5.5 above.
Apply the liquid gasket to the side surface of the protrusion on the die arm 1 when mounting the die arms 1 and 2. Be sure to apply Loctite to the threaded portion of each bolt.

5) Move the arm 2 by hand and make sure that no abnormal noise is heard.

6) Mount the arm 2 cover and perform home point setting for the axis 2. Now, the motor replacement completes.


2.5.7 Dismounting Axis 3 Motor

! CAUTION

- The axis 3 motor is provided with a brake. At replacement of the axis 3 motor, this brake becomes inoperative. Before starting the work, therefore, move down the ball screw spline to the lower limit. Otherwise, the shaft will drop due to the dead weight of the shaft or workpiece, and your hand or finger may be caught.


1) Remove the arm 2 cover. (See Para. 2.4.1.)

2) Disconnect connectors J3AS and J3AP (power drive cables), connectors J3BS and J3BP (encoder cables) and connectors J3DS and J3DP (brake cables) for the axis 3, which are connected to the connector panel.
For the connector layout, see the figure below.



3) Cut the TY-RAP for the cables secured to the axes 3 and 4 motor base plate.


4) Remove the axis 3 tension adjustment bolts (M4 x 16) and loosen the flange head bolts (M4 x 10) securing the axis 3 motor base to cancel the axis 3 timing belt tension. Then draw out the motor together with the motor base upward.



5) Secure the axis 3 motor pulley, using a vice, etc. and remove the bolt (M3 x 8) at the shaft end. When securing the pulley, take careful precautions not to distort the pulley flange and not to damage the pulley.

6) After removing the bolt, draw out the washer, pulley and key.

7) Remove the four (4) bolts (M4 x 12) securing the motor, and separate the axis 3 motor from the motor base.



2.5.8 Mounting Axis 3 Motor

1) Perform key alignment, using the new motor and pulley. At this time, no clearance should exist between the motor shaft and pulley.

! CAUTION

- Perform key alignment very carefully. If there is a clearance between the motor shaft and pulley, positioning accuracy will drop and the life of the parts will shorten.

2) Mount the axis 3 motor on the motor base in the reverse order of Step 7) of Para. 2.5.7 above.

3) Mount and secure the pulley and key with the washers and bolts in the reverse order of Steps 5) and 6) of Para. 2.5.7 above.

4) Temporarily secure the motor base to the arm 2 with four flange head bolts (M4 x 10).
Place the axis 3 timing belt on the axis 3 motor pulley, and exert a tension on the timing belt, using the axis 3 two tension adjustment bolt (M4 x 16) .

(For the belt replacement procedures and tension adjustment value, see Para. 2.6.3.) Then completely tighten and secure the bolts which were set temporarily.

5) Connect the connectors which were disconnected in Step 2) of Para. 2.5.7 above.

6) Return the cables which were disconnected in Step 3) of Para. 2.5.7 above to the original condition.

7) Mount the arm 2 cover and perform home setting for the axes 3 and 4. Now, the motor replacement completes.

8) Carry out a test operation of the axis 3 and make sure that each part operates properly.


2.5.9 Dismounting Axis 4 Motor


1) Remove the arm 2 cover. (See Para. 2.4.1.)

2) Disconnect connectors J4AS and J4AP (power drive cables) and connectors J4BS and J4BP (encoder cables) of the axis 4 motor. For the connector layout, see Para. 2.5.7.

3) Remove the cap attached to the lateral side of the axis 4 reduction gear and loosen the coupling bolt (M4) securing the axis 4 motor shaft and input shaft of the axis 4 reduction gear.
If the phases disagree, turn the ball screw shaft by hand to align the phases.

4) Remove the four bolts (M4 x 12) securing the motor, and lift off the motor without letting it hit the cover bracket.







2.5.10 Mounting Axis 4 Motor

1) Mount the new motor on the axis 4 reduction gear with the four bolts (M4 x 12), paying attention to the phases.

2) To mount the cap, tighten the coupling of the axis 4 reduction gear by means of the attached bolt (M4 in the case of the TH450A/TH550A: Recommended clamping torque: 4.7 N·m)





3) Connect the axis 4 motor connectors.

4) Mount the arm 2 cover and perform home setting for the axes 3 and 4. Now, the motor replacement completes.
After replacement of the axis 4 motor, be sure to execute home setting for the axis 3.

5) Carry out a test operation of the axis 4 and make sure that each part operates properly.

2.6 Adjusting and Replacing Timing Belt

The timing belt is to be replaced by our service engineer. If it is replaced by the customer, we will not guarantee any consequential trouble or accident.

DANGER

- The timing belt should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.

CAUTION

- The axis 3 motor is provided with a brake. At replacement of the axis 3 timing belt, this brake becomes inoperative. Before starting the work, therefore, move down the ball screw spline to the lower limit. Otherwise, the shaft will drop due to the dead weight of the shaft or workpiece, and your hand or finger may be caught.
- Because the timing belt is disconnected, the mechanical home point shifts and proper control cannot be done. To avoid this, home return operation is necessary after replacement of the timing belt. For the home return procedures, see Section 4.

2.6.1 Type of Timing Belt

The timing belts used in this robot are shown below.
When you place an order for the timing belt for replacement, specify the robot model, axis name, type and our drawing number.

Description	Axis name	Width	Type	Our drawing No.	Model
Timing belt	Axis 3	10 mm	BG318UP3M10-HC	S854456	TH450A/TH550A
	Axis 4	15 mm	BG470UP5M15-HC	S854457	TH450A/TH550A

2.6.2 Timing Belt Locations




Fig. 2.10 Timing belt locations (TH450A/TH550A)

2.6.3 Replacing Axis 3 Timing Belt

1) Remove the arm 2 cover. (See Para. 2.4.1.)


2) Disconnect the axis 3 motor base which remains attached with the motor and pulley. For the disconnecting procedures, see Steps 1) through 4) of Para. 2.5.7.

! CAUTION

- The axis 3 motor is provided with a brake. At replacement of the axis 3 timing belt, this brake becomes inoperative. Before starting the work, therefore, move down the ball screw spline to the lower limit. Otherwise, the shaft will drop due to the dead weight of the shaft or workpiece, and your hand or finger may be caught.

3) Remove the six bolts (M4 x 12), and pull out the ball screw nut together with the shaft and stopper from the arm 2. Caution should be taken when pulling them out. If they cannot be pulled out by hand, use a tap for disassembly. Note that if the ball screw nut is pulled out of the shaft, the ball drops off the ball screw nut, and the ball screw spline can no longer be used.


4) Disconnect the axis 3 timing belt.



5) Mount the new timing belt.

6) Temporarily secure the motor set, which was dismounted in Step 2), to the arm 2 with four flange head bolts (M4 x 10). Place the timing belt on the axis 3 motor pulley, and exert a tension on the timing belt, using the axis 3 tension adjustment bolt (M4 x 16).
While pushing the axis 3 motor base by means of the axis 3 tension adjustment bolts, measure the tension on the tension meter. Tighten the flange head bolts at a position where the tension is between 49.7 and 58.3 N .
The values used for the tension meter are tabled below.

	Value of tension [N]	Unit mass [g/m]	Belt width [mm]	Span [mm]	Model
Tension after belt replacement	49.7 ~ 58.3	2.2	10	85	TH450A/TH550A
Tension after belt readjustment	35 ~ 38	2.2	10	85	



7) Connect the connectors and perform home point setting for the axis 3. Also make sure of the axis 4 coordinates and perform home setting for the axis 4, if necessary.

8) Carry out a test operation of the axis 3 and make sure that each part operates properly.


9) Mount the arm 2 cover. Now replacement of the axis 3 timing belt completes.


2.6.4 Replacing Axis 4 Timing Belt

! CAUTION

- When the axis 4 timing belt is replaced with a new one, the axis 3 should be disassembled also due to the structure. Therefore, strictly observe the cautions on replacement of the axis 3 timing belt and motor also.
- When the ball screw nut integrated with the ball screw spline shaft is disconnected, take utmost care not to cause the ball screw spline shaft to come off. Otherwise, the ball in the ball screw nut will drop and the ball screw nut integrated with the ball screw spline shaft cannot function any further.

1) Remove the arm 2 cover. (See Para. 2.4.1.)
2) Remove all the connectors except the axis 2 from the connector panel. (See Step 2) of Para. 2.5.9.)
3) Disconnect the axis 3 motor base which remains attached with the motor and pulley. For the disconnecting procedures, see Steps 1) through 3) of Para. 2.5.7.
4) Remove the stopper. (The hand, etc. should be disconnected beforehand.)
5) Remove the six bolts (M4 x 12), and pull out the ball screw nut together with the shaft from the arm 2. Caution should be taken when pulling them out. If they cannot be pulled out by hand, use a tap for disassembly. Note that if the ball screw nut is pulled out of the shaft, the ball drops off the ball screw nut, and the ball screw spline can no longer be used.
6) Dismount the axis 3 timing belt.
7) Loosen the axis 4 tension adjustment bolt (M4 x 16) remove the flange head bolts (M4 x 10) securing the axis 4 motor base, then pull out the motor base upward.






8) Draw out the axis 4 timing belt upward, then set a new belt.

9) Secure the ball screw nut and ball screw spline shaft which were disconnected in Step 4) above, and nut flange to the arm 2, using the six (6) bolts (M4 x 12). At first, tighten the bolts temporarily. Move the shaft up and down by hand and make sure that it moves smoothly, then tighten the bolts completely.


   * A phase mark is provided on both the ball screw spline shaft and ball spline nut. For details, see Step 7) of Para. 2.7.5.

10) Attach the tool flange and stopper to the ball screw shaft.

11) Temporarily set the motor base which was disconnected in Step 6) above to the arm 2 with the three (4) flange head bolts (M4 x 10) after setting the axis 4 timing belt to the axis 4 motor pulley. Also mount the axis 4 tension adjustment bolt (M4 x 12).



12) While pulling the axis 4 motor base by means of the axis 4 tension adjustment bolt, measure the tension on the tension meter. At a position where the tension has reached the values in the table below, tighten the flange head bolts. The values used for the tension meter are tabled below.



	Value of tension [N]	Unit mass [g/m]	Belt width [mm]	Span [mm]	Model
Tension after belt replacement	154 ~ 180	4.1	15	155	TH450A/TH550A
Tension after belt readjustment	110 ~ 117	4.1	15	155	

13) Mount the axis 3 motor and timing belt. For the mounting procedures, see Para. 2.5.8.

14) Arrange the connectors and cables as originally set.

15) Perform home setting for the axes 3 and 4.

16) Carry out a test operation of the axes 3 and 4 and make sure that the belt tension is appropriate.

17) Attach the arm 2 cover. Now replacement of the axis 4 timing belt completes.

2.7 Filling Grease to Ball Screw Spline Unit and Replacement

The ball screw spline unit is to be replaced by our service engineer. If it is replaced by the customer, we will not guarantee any consequential trouble or accident.



DANGER

- The ball screw spline unit should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.



CAUTION

- Because the timing belt, nut and pulley are disconnected, the mechanical home point shifts and proper control cannot be done. To avoid this, home return operation is necessary after replacement of the ball screw spline unit. For the home return procedures, see Section 4.

2.7.1 Type of Ball Screw Spline Unit

The ball screw spline unit used in this robot is shown below.
When you place an order for the ball screw spline unit for replacement, specify the robot model and our drawing number.

Description	Stroke	Our drawing No.	Unit code	Model
Ball screw spline unit	150mm	H846367	Y610A3EP0	TH450A/TH550A
	300mm	H846387	Y610A3EQ0	

* Stroke 300 mm is optional.

2.7.2 Ball Screw Spline Unit Location




Fig. 2.11 Ball screw spline unit location

2.7.3 Filling Grease to Ball Screw Spline Unit

CAUTION

- When vertically moving the ball screw by hand, take careful precautions not to have your hand or finger caught.
- As there is a fear that the grease drops, cover the peripheral equipment, etc.


CAUTION

- When the grease has run short, cut or scratch will be caused on the slide unit, etc., resulting in drop of the performance. To avoid this, take careful precautions to prevent shortage of the grease.
- Be sure to use the grease designated by SHIBAURA MACHINE.

Fill the grease to the ball screw spline unit every three (3) months.
At daily inspection also, make sure that the ball screw spline unit is filled with a sufficient volume of grease.


Recommended grease	Maker	Model
AFF grease	THK	TH450A/TH550A

1) Turn on the controller power and turn off the servo system.
2) Move the arm to a position where the axis 3 can be moved over the full stroke.
3) Push down the ball screw spline shaft to the lower limit while pressing the axis 3 brake OFF switch.
4) Directly apply the grease to the exposed shaft area by hand or finger.
   Apply the grease to such an extent that the shaft groove can be filled. Wipe out the surplus grease.



5) Push up the shaft up to the upper limit while pressing the axis 3 brake OFF switch.

6) Directly apply the grease by hand or finger to the shaft area sticking up from the cover. Apply the grease to such an extent that the shaft groove can be filled. Wipe out the surplus grease.



7) Move the shaft up and down repeatedly while pressing the axis 3 brake OFF switch to fill the grease uniformly. Wipe out the surplus grease. Now the work completes.

2.7.4 Dismounting Ball Screw Spline Unit

! DANGER


- The ball screw spline unit should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.

! CAUTION

- Handle the ball screw spline unit with extreme care. If the unit drops or an unusually large external force is exerted on it, it cannot function any further.
- Replacement of the ball screw spline unit involves mounting and dismounting of the axis 3 and 4 motors and timing belts. Also observe the cautions on each work.
- Because the motor, timing belt, nut and pulley are disconnected, the mechanical home point shifts and proper control cannot be done. To avoid this, home return operation is necessary after replacement of the ball screw spline unit. For the home return procedures, see Section 4.


In the descriptions on replacing the ball screw spline unit, the procedures for changing the axis 3 and 4 motors and timing belts are not included. For details, refer to the descriptions on replacement of each part.

1) Remove the arm 2 cover. (See Para. 2.4.1.)
2) Disconnect the axis 3 and 4 motors and timing belts.
3) Remove the stopper attached to the bottom of the ball screw spline shaft.
4) Remove the six bolts (M4 x 12) securing the ball screw nut, and lift off the ball screw nut together with the ball screw spline shaft. Caution should be taken when lifting them off. If they cannot be lifted off by hand, use a tap for disassembly. Note that if the ball screw nut is pulled out of the shaft, the ball drops off the ball screw nut, and the ball screw spline can no longer be used.
5) Remove the belts of axes 3 and 4.
6) Remove the four bolts (M4 x 20) to dismount the axis 3 pulley.




! CAUTION

- When the ball screw nut integrated with the spline shaft is disconnected, take utmost care not to cause the ball screw spline shaft to come off. Otherwise, the ball in the ball screw nut will drop and the ball screw nut integrated with the ball screw spline shaft cannot function any further.



7) Remove the six (6) bolts (M4 x 12) securing the ball spline nut and draw out the ball spline nut downward.
   When the ball spline nut is hard to disconnect, screw the bolt into the tap for disassembly (M4) machined on the ball spline nut and disconnect.
8) Disconnect the axis 4 nut pulley secured to the ball spline nut with six (6) bolts (M5 x 12). When it is hard to disconnect, screw the bolt into the tap for disassembly (M4) machined on the pulley and disconnect.
9) Insert the disconnected ball spline nut into the shaft. Wind the TY-RAP around the vicinity of top and bottom of the shaft to prevent the nut from slipping off.



2.7.5 Mounting Ball Screw Spline Unit


DANGER

- The ball screw spline unit should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.

CAUTION

- Handle the ball screw spline unit with extreme care. If the unit drops or an unusually large external force is exerted on it, it cannot function any further.
- Replacement of the ball screw spline unit involves mounting and dismounting of the axes 3 and 4 motors and timing belts. Also observe the cautions on each work.
- Because the motor, timing belt, nut and pulley are disconnected, the mechanical home point shifts and proper control cannot be done. To avoid this, home return operation is necessary after replacement of the ball screw spline unit. For the home return procedures, see Section 4.
- DO NOT pull out the ball screw shaft from the ball screw nut. Otherwise, the ball in the ball screw nut will drop and the ball screw nut integrated with the ball screw shaft cannot function any further.

1) Disconnect the ball spline nut from the new ball screw spline unit.
2) Mount the axis 4 nut pulley on the spline nut with the six bolts (M5 x 12). The bolts are difficult to tighten because the pulley rotates. Thus, hold the pulley with pliers or the likes while protecting it from scratches.
3) Mount the screw spline nut on the arm 2 with the six bolts (M4 x 12).




4) Mount the axis 4 timing belt and axis 4 motor, then adjust the belt tension.

5) Mount the axis 3 nut pulley on the ball screw nut with the four bolts (M5 x 20).

6) Put the axis 3 timing belt through the clearance in the surface where the ball screw nut is secured.

7) Mount the ball screw nut integrated with the shaft onto the nut flange, then pass them through the ball spline nut. At this time, align the phases of both markings put on the tip of the ball spline nut and the shaft.

8) Secure the nut flange to the arm 2 with the four (4) bolts (M4 x 12).
At first, tighten the bolts temporarily. Move the shaft up and down by hand and make sure that it moves smoothly, then tighten the bolts completely.



9) Mount the stopper at a position 42 mm from the lower end of the ball screw shaft.

10) Mount the axis 3 motor, then adjust the belt tension.

11) Arrange the connectors and cables as originally set.

12) Perform home setting for the axes 3 and 4.

13) Carry out a test operation of the axes 3 and 4 and make sure that each part operates properly.

14) Mount the arm 2 cover. Now replacement of the ball screw spline unit completes.

2.8 Reduction Gear Replacement

The reduction gear is to be replaced by our service engineer. If it is replaced by the customer, we will not guarantee any consequential trouble or accident.

DANGER

- The reduction gear should be replaced with a new one only after the controller power is turned off with the power supply plug removed. If the work is done while the power is turned on, you may get an electric shock or the robot may malfunction, which is very dangerous.

CAUTION

- Because the reduction gear is disconnected, the mechanical home point shifts and proper control cannot be done. To avoid this, home return operation is necessary after replacement of the reduction gear. For the home return procedures, see Section 4.

2.8.1 Type of Reduction Gear

The reduction gears used in this robot are shown below.
When you place an order for the reduction gear for replacement, specify the robot model, axis name, type and our drawing number.

Description	Axis name	Type	Our drawing No.	Unit code	Model name
Reduction gear	Axis 1	CSG-32-80-2UH-SP	M153235	Y610A34N0	TH550A
	Axis 1	CSG-32-50-2UH-SP	M147090	Y610A34L0	TH450A
	Axis 2	CSG-25-50-2UH-SP	M147091	Y610A34M0	TH450A/TH550A
	Axis 4	HPG-14A-11-F0AXU	S854401	Y610A3EN0	TH450A/TH550A

2.8.2 Reduction Gear Locations




Fig. 2.12 Reduction gear locations (TH450A/TH550A)

2.8.3 Dismounting Axis 1 Reduction Gear


1) Remove the arm 1 top cover. (See Para. 2.4.2.)


! CAUTION

- The arm should always be mounted and dismounted by three (3) or more persons. When removing the arm set bolts, take careful precautions because the arm will drop. Also, if an excessively large impact is imposed on the arm, the robot will be damaged.

2) Remove the nine countersunk head screws (M5 x 10) from the base cover, and disconnect the cables.

3) While more than one (1) person are holding the arm, another person should remove the eight (8) bolts (M10 x 25) securing the arm 1, then disconnect the arm 1. Place the arm thus disconnected in such a manner that no impact is exerted on it.






4) Remove the four bolts (M8 x 30) securing the bracket.

5) Remove the twelve (12) bolts (M6 x 30) securing the reduction gear, then draw out the reduction gear upward. If it is hard to disconnect, screw the bolt into the tap for disassembly (M6) which is machined on the reduction gear.
Take careful precautions not to miss the exclusive O-ring attached to the bottom of the reduction gear.
When dismounting the reduction gear, it is recommended to prepare a waste cloth, etc. because the grease is filled to the vicinity of the wave generator on the lower side.

6) Dismount the wave generator after the reduction gear. See Para. 2.5.3.
A wave generator is used as a pair with a reduction gear. Therefore, be sure to replace the wave generator at the same time as replacing the reduction gear.
A wave generator comes with a new reduction gear.


M6 x 30
M5 x 10
Bracket
O-ring
Tap for disassembly (M6)
Reduction gear

2.8.4 Mounting Axis 1 Reduction Gear


! CAUTION

- Handle the reduction gear with extreme care. If it drops or an unusually large external force is exerted on it, the reduction gear cannot function any further.
- Use the wave generator which is attached to the new reduction gear. If the old wave generator is used as it is, abnormal noise will be caused, the service life will shorten or positioning accuracy will deteriorate due to incompatibility with the new reduction gear.
- Also use the O-ring attached to the new reduction gear. Be sure to set the O-ring. Unless the O-ring is set, grease will leak from the axis 1 reduction gear set surface. When mounting the reduction gear, take careful precautions not to break the O-ring.

1) Mount the wave generator that has come with a new reduction gear. Be sure to insert the wave generator with the groove around the circumference on the motor side. Tighten the bolt (M5 x 10) on the end of the axis while holding the protrusion on the wave generator with pliers or the likes. Use a waste cloth (or the like) as a cushion to protect the wave generator from scratches when securing it.

2) Fill the new wave generator and new reduction gear with grease (SK-1A) -- 22 g for the wave generator and 28 g for the reduction gear.

3) Mount the reduction gear with the 12 bolts (M6 x 30). Be sure to apply Loctite to the threaded portion of each bolt. Before mounting the reduction gear, set the O-ring in the O-ring groove on the bottom of the reduction gear. The O-ring is attached to the new reduction gear.




4) Secure the reduction gear to the base with the four bolts (M8 x 30). Be sure to apply Loctite to the threaded portion of each bolt.

5) Mount the arm 1 with eight bolts (M10 x 25). Be sure to apply Loctite to the threaded portion of each bolt. In doing so, be sure to fit the O-ring into the O-ring groove in the top surface of the reduction gear. The O-ring comes with the reduction gear.

6) Connect the cable connectors as originally set.

7) Mount the arm 1 cover and perform home setting for the axis 1. Now replacement of the axis 1 reduction gear completes.

8) Carry out a test operation of the axis 1 and make sure that each part operates properly.




2.8.5 Dismounting Axis 2 Reduction Gear

1) Remove the arm 2 cover. (See Para. 2.4.1.)

2) Cut the TY-RAP for the cables secured to the cover bracket, using diagonal cutting pliers (or the likes), and remove the three hexagon socket head bolts (M4 x 8) securing the cover bracket.


3) Disconnect the connectors J2AS and J2AP (power drive cables), and J2BS and J2BP (encoder cables) for the axis 2 from the connector panel.

4) Remove the two bolts (M3 x 6) to remove the connector panel.



5) Remove the eight bolts (M8 x 16) to dismount the arm 2.

6) Remove the ten bolts (M5 x 16) to dismount the axis 2 motor assembly from the arm 2.




7) Remove the ten bolts (M5 x 12) to dismount the reduction gear. The reduction gear contains grease, so prepare a waste cloth in case it comes out when dismounting the reduction gear.

8) Remove the bolt (M4 x 10) to dismount the wave generator. The bolt is difficult to remove because the wave generator rotates. Thus, hold the protrusion on the wave generator with pliers or the likes while protecting it with a waste cloth as a cushion. This wave generator should also be replaced at the same time as the reduction gear is replaced. See Para. 2.5.5.

! CAUTION

- The arm should always be mounted and dismounted by two (2) or more persons. When removing the arm set bolts, take careful precautions because the arm will drop. Also, if an excessively large impact is imposed on the arm, the robot will be damaged.



2.8.6 Mounting Axis 2 Reduction Gear


! CAUTION

- Handle the reduction gear with extreme care. If it drops or an unusually large external force is exerted on it, the reduction gear cannot function any further.
- Also use the O-ring attached to the new reduction gear. Be sure to set the O-ring. Unless the O-ring is set, grease will leak from the axis 2 reduction gear set surface. When mounting the reduction gear, take careful precautions not to break the O-ring.

1) Mount the wave generator (provided with the new reduction gear) on the motor with the bolt (M4 x 10). Be sure to insert the wave generator with the groove around the circumference on the motor side. The bolt is difficult to tighten because the wave generator rotates. Thus, hold the protrusion on the wave generator with pliers or the likes. Use a waste cloth (or the like) as a cushion to protect the wave generator from scratches when securing it.


2) Fill the new wave generator and new reduction gear with grease (SK-1A) -- 12.8 g for the wave generator and 12.2 g for the reduction gear.

3) Mount the new reduction gear with ten bolts (M5 x 12). In doing so, be sure to fit the O-ring into the O-ring groove in the reduction gear. The O-ring comes with the reduction gear.



4) Mount the axis 2 motor assembly on the arm 2 with the ten bolts (M5 x 16).

5) Mount the arm 2 on the arm 1 with the eight bolts (M8 x 16). In doing so, be sure to fit the O-ring into the O-ring groove in the axis 2 reduction gear. If the arm is secured with the O-ring not in place, the O-ring may be broken, causing a grease leak.
Be sure to apply Loctite to the threaded portion of each bolt.
Apply the liquid gasket to the side surface of the protrusion on the die arm 1.




! CAUTION

- Be sure to apply Loctite to at least three threads of each bolt (M8 x 16) circumferentially.

6) Mount the connector panel.

7) Mount the cover bracket, and secure it together with the connector panel.



8) Connect the axis 2 motor connectors (for power drive cable and encoder cable).

9) Set the cables in the arm 2 as originally arranged, then attach all covers.

10) Perform home setting for the axis 2. Now replacement of the axis 2 reduction gear completes.
(Check the axis 1 for the coordinates and perform home setting as necessary.)

11) Carry out a test operation of the axis 2 and make sure that each part operates properly.

2.8.7 Replacing Axis 4 Reduction Gear

! CAUTION

- Handle the reduction gear with extreme care. If it drops or an unusually large external force is exerted on it, the reduction gear cannot function any further.
- Be sure to tighten the coupling connecting the reduction gear and motor shaft.

1) Remove the arm 2 cover. (See Para. 2.4.1.)


2) Disconnect the axis 4 motor and motor base, axis 3 motor and motor base, and axes 3 and 4 timing belts from the arm 2, referring to Steps 1) to 6) inclusive of Para. 2.6.4 above.

3) Remove the four (4) bolts (M5 x 12) securing the reduction gear to the motor base, then dismount the reduction gear.

4) Remove the four (4) bolts (M4 x 12) securing the motor, and draw out the motor upward.

5) Remove the six bolts (M4 x 10) to dismount the axis 4 motor pulley. In doing so, hold the pulley with pliers or the likes while protecting it from scratches.

6) Remove the cap attached to the lateral side of the axis 4 reduction gear, then loosen the coupling bolt (M4) securing the axis 4 motor shaft and the input shaft of the axis 4 reduction gear.



7) Assemble the new reduction gear, motor and pulley in the reverse order of Steps 5) and 6) above.

8) Assemble the axis 4 motor and timing belt according to Steps 15) through 19) of Para. 2.6.4 above, then mount the arm 2 cover.

9) Perform home setting for the axes 3 and 4. Now replacement of the axis 4 reduction gear completes.

2.9 Replacing Position Detector (or Encoder) Batteries

CAUTION

- The batteries should be disposed of according to the user's in-house regulations.
  NEVER drop the battery into fire. NEVER short-circuit, charge, disassemble or heat it. Otherwise, liquid leakage or rupture may be caused.

To keep the data of the position detector attached to the motor, they are backed up by batteries. **Be sure to replace the batteries with new ones at the time of annual inspection. When the robot is not used for a long term (i.e., the batteries are left intact in the power OFF condition), replace the batteries at the time of robot startup. As a yardstick, the shutdown period is two (2) months.**
(Three (3) size AA batteries)

CAUTION

- When the battery voltage has dropped, a battery alarm will generate. If the batteries are replaced just after generation of the battery alarm, the battery voltage returns to normal with the battery alarm reset automatically. Unless the batteries are changed just after generation of the battery alarm, however, the battery voltage will drop further and a battery error will occur. Under this condition, position data detected by the encoder is not reliable. As a result, a position detection error occurs and the robot enters an emergency stop state so that the servo system cannot be turned on. If the power is turned off in this condition, the position data is lost.

  To avoid the above, be sure to replace the batteries with new ones at the time of annual inspection.

2.9.1 Battery Box Location

The battery box for the position detector is provided inside the battery box cover of the base unit.




Fig. 2.13 Battery box location

2.9.2 Replacing Batteries


! DANGER

- Only after assuring the safe work, replace the batteries with new ones while the power is turned on and an emergency stop is effected on the robot.

1) **Assure the safe work. Then keep the power ON and press the EMERGENCY pushbutton switch** to effect an emergency stop on the robot. Unless the safe work can be assured, turn the power off.

2) Disconnect the battery box cover which is secured to the base unit with the nine (9) hexagonal flat head screws (M5 x 10). As the cables are connected, DO NOT pull them by force.

3) Remove the battery box cover followed by the batteries.
Set the three (3) new batteries, taking care of the “+” and “–“ polarities.
To replace the batteries while the power is turned off, finish the replacement within five (5) minutes.



4) Attach the battery box cover to the base unit. Now replacement of the batteries completes.

2.9.3 Battery Error Code

When a position detector error including battery error has occurred, the following error code is shown on the error display.

8–065 Axis1 Encoder abnormal
8–097 Axis2 Encoder abnormal
8–129 Axis3 Encoder abnormal
8–161 Axis4 Encoder abnormal
8–193 Axis5 Encoder abnormal

When a battery alarm has occurred, the following error code is shown on the error display. When the following error code is shown in the error history at generation of a position detector error, the error can be identified as the battery error.

1–049 Axis1 Battery alarm
1–065 Axis2 Battery alarm
1–081 Axis3 Battery alarm
1–097 Axis4 Battery alarm
1–113 Axis5 Battery alarm

The battery error is one of the position detector errors (i.e., encoder errors), and there is other cause leading to the position detector error. The restoring method from the position detector error varies with the error contents generated. To properly execute the restoring method from the position detector error, therefore, read through and completely understand the descriptions carried in Section 4.

3. Maintenance of Controller

3.1 Cautions on Maintenance and Inspection

When performing maintenance and inspection of the controller, follow the items given below so that the work can be carried out safely.

! CAUTION

- Before removing the controller cover for maintenance or inspection, be sure to turn off the main power switch of the controller.
  Also, turn off the power breaker when connecting or disconnecting the power cable.
- DO NOT touch the servo driver for at least two (2) minutes after the main power switch is turned off. The large-capacity capacitor in the servo driver may be charged with voltage, and touching the servo driver could lead to electric shocks.
- DO NOT disconnect the battery connector at other than battery replacement. Otherwise, files saved in the memory may be lost.

! DANGER

- Be sure to turn off the main power switch. If the main power switch remains ON, the servo power printed board, servo printed board and switching power supply are charged, and touching them could lead to electric shocks. To avoid this, be sure to turn off the main power switch before starting the work.

3.2 Layout of Controller Parts




図 3.1　コントローラ部品配置図

Fig. 3.1　Layout of controller parts

Part name	Descriptions
PS1	P5V, P24V switching power supply
PWB set bracket	Bracket for mounting PS1, etc.
X8HP	Servo power printed board
X8HC	Main control printed board
X8HN (X8HI)	I/O output printed board
X8HRA	Servo printed board
X8HB	Mother board
R1	Regenerative resistor
NF1	Noise filter

3.3 Maintenance Procedures

3.3.1 Check of Controller Air Vent Holes

If the air vent holes are blocked, the controller may overheat and malfunction. To avoid this, perform check on the air vent holes to make sure that air is flowing freely through them.




Fig. 3.2 Controller side views

a) If there is any obstacle, move it away from the air vent hole so that air flow is not blocked.

b) Make sure that no contaminant is left on the air vent holes. If any contaminant is left on the vent hole, remove it.

c) If the controller is placed sideways, make sure that the air vent holes on the bottom surface of the controller are more than 11 mm away from the floor surface. Always keep the space of 11 mm or over. The length of rubber shoe is approximately 11 mm.

3.3.2 Check of Safety Devices for Function

Make sure that the EMERGENCY stop pushbutton switches equipped on the control panel and teach pendant work properly. Also make sure that the safety devices controlled by the external operation input signals work correctly.




Fig. 3.3 Layout of control panel switches

a) Make sure that the EMERGENCY (emergency stop) switch [2] provided on the control panel functions properly.

1) Press the SERVO ON switch [1] provided on the control panel to turn the servos on and make sure that the SERVO ON switch [1] LED is illuminated.

2) Press the EMERGENCY switch [2] and make sure that the servos are turned off. The SERVO ON switch [1] LED goes out and the SERVO OFF switch [3] LED is illuminated. At this time, make sure that the EMERGENCY switch [2] remains depressed.

3) Turn the EMERGENCY switch [2] clockwise and make sure that the same switch turns off.

b) Make sure that the EMERGENCY STOP switch [6] provided on the teach pendant functions properly.

1) To turn on the servo power, press the SERVO ON switch [4] on the teach pendant while keeping the ENABLE switch at the neutral position. Make sure that the SERVO ON switch LED [5] is illuminated.

Note: The servo power cannot be turned on in the INTERNAL and EXT modes.

2) Press the EMERGENCY STOP switch [6] on the teach pendant and make sure that the servos are turned off. The SERVO ON switch LED [5] goes out.




Fig. 3.4 EMERGENCY STOP switch provided on teach pendant

At this time, make sure that the EMERGENCY STOP switch [6] remains depressed.

3) Turn the EMERGENCY STOP switch [6] clockwise and make sure that the same switch turns off.

c) Make sure that the safety devices controlled by the external operation input signals work properly.

1) Press the SERVO ON switch [1] equipped on the control panel to turn on the servo power. Then turn on (or trip) the safety devices connected with external operation input signal “emergency stop” (such as external emergency stop switch, photoelectric type sensing safety device and foot switch) to make sure that the servo power is turned off.

2) Set ON the safety devices connected with external operation input signal “low speed command”, and make sure that each signal functions properly.

3.3.3 Battery Replacement

The memory equipped on the X8GC printed board of the robot controller is backed up by a lithium battery to save the data. Replace the battery every five (5) years. The lithium battery will turn its life when used for a predetermined time. If it is used, neglecting the life, the battery voltage will drop to below the voltage required for keeping the memory data, resulting in the data being lost and faults caused by leakage of the battery liquid.
If the following alarm has occurred, replace the battery with a new one.

- 1–145 MAIN Battery alarm




Fig. 3.5 Location of lithium battery

Type of battery	Manufacturer	Battery service life
ER3V-C	TOSHIBA LIFESTYLE PRODUCTS & SERVICES Corp.	10 years (at room temperature)

Note: The battery life is ten (10) years at the room temperature. As it differs with the external environment such as operating temperature and humidity, we recommend to replace the battery every five (5) years.
Only the battery shown in the table above should be used. As this is an exclusive battery, contact SHIBAURA MACHINE at order entry.

[Battery replacement procedures]

1) If the battery is to be kept removed for more than one (1) minute, copy all programs and various parameters stored in the internal memory to the personal computer. In the worst case, all memory data are lost.

2) Set OFF the main power switch.

3) Prepare a new battery, then remove the cover from the controller.

4) Disconnect the battery connector from CN3 of the X8GC printed board, and remove the battery from the TY-RAP securing the battery.
(For the battery position, see Fig. 3.5.)

5) Set the new battery immediately. (If the battery is kept removed for more than one (1) minute, all memory data are lost.)
Even if not used, the lithium battery capacity decreases by natural discharge. Use a lithium battery which is within three (3) years (kept at the room temperature) from purchasing.

6) Mount the cover on the controller.

7) If the battery is kept removed for more than one (1) minute, turn on the main power switch and load the programs and various parameters from the floppy disk unit or personal computer in which the TSPC (option) is already installed.
If the controller has detected the battery voltage drop alarm even before the five (5)-year replacement period, replace the battery immediately.



CAUTION

- Waste battery should be disposed of according to the user's in-house regulations.

  NEVER drop the battery into fire. NEVER short-circuit, charge, disassemble or heat it. Otherwise, liquid leakage or rupture may be caused.

3.3.4 Replacement of Switching Power Supply Unit

The life of the switching power supply unit (DC5V, DC24V) used in the robot controller differs with the operating conditions. This unit uses an aluminum electrolytic capacitor. If the load current is large, the running time is long and the ambient temperature is high, the life will reduce.
Though the life varies largely with the user's operating conditions (5 ~ 10 years), replace the power supply unit every five (5) years for preventive maintenance.

[Replacement procedures]

1) Turn off the main power switch.

2) Turn off the power breaker.


3) Remove the cover from the controller.

4) Remove all connectors in the control panel, which are connected to the X8HC, X8HRA (2 pcs.) and X8HP printed boards. (For the location of each printed board, see Fig. 3.1.)

5) Remove the X8HC, X8HN (X8HI), X8HRA (2 pcs.) and X8HP printed boards from the controller.

6) Disconnect the cables connected to the parts on the PWB set bracket.

7) Remove the screws (3 places) which secure the controller and PWB set bracket. (For the location of the PWB set bracket, see Fig. 3.1.)



Upper side view

Fig. 3.6 PWB set bracket (upper side view)

8) Disconnect the PWB set bracket from the controller.




Fig. 3.7 PWB set bracket

9) Remove each power supply unit from the PWB set bracket, and set a new power supply unit.




Fig. 3.8 PWB set bracket (front view)

10) Restore the PWB set bracket to the controller, where the new power supply unit is set. Then connect the connector.

11) Secure the PWB set bracket to the controller, using the three (3) screws. (See Fig. 3.6.)


12) Mount the disconnected printed boards on the controller.

13) Connect the disconnected connectors with respective printed boards.

14) Attach the cover to the controller.

3.3.5 Replacement of Fuse (X8HN, X8HI Printed Board)

If the current exceeding the specified current has run through the I/O unit, the fuse of the X8HN (X8HI) printed board will blow out. If the alarm saying "I/O FUSE Broken (8–273)" is displayed, replace the fuse with a new one.
If the fuse of the output module has blown out, examine and identify an fault circuit, remedy the cause, then replace the fuse.




Type of fuse	Manufacturer
51NM030H	PICO

[Replacement procedures]

1) Turn off the controller main power.
2) Remove the cover attached to the fuse unit as shown above.
3) Remove the fuse and set a new fuse.
4) Mount the removed cover.
5) Turn on the controller main power and make sure that no error will occur.

3.3.6 Replacement of Output ICs (X8HN, X8HI Printed Board)

If the current exceeding the specified current has run through the output unit, the ICs on the X8HN (X8HI) printed board will be damaged.
When this happens, replace the ICs.
Before the replacement, examine and identify an fault circuit, remedy the cause, then replace the ICs.
The relationship between the output ICs [2] and output signals is shown below.



	Name of board	Type of IC	Manufacturer
[1]	X8HN	TD62082AP	Toshiba Corp.
[2]	X8HI	M54562P	Mitsubishi Electric

[Replacement procedures]

1) Turn off the controller main power.
2) Remove the cover from the controller.
3) Disconnect all connectors connected to the X8HC printed board in the controller.
4) Disconnect the X8HC, X8HN (X8HI) printed boards from the controller.
5) Remove the ICs shown above from respective sockets.
6) Attach the new ICs to the sockets.
7) Mount the X8HC, X8HN (X8HI) printed boards on the controller.
8) Connect all disconnected connectors to the X8HC printed board, then attach the controller cover.
9) Turn on the controller main power.

4. Robot Home Point and Position Detector Error

4.1 Setting Robot Home Point

Before delivery from our plant, home point setting is performed for the robot after its arm is secured with clamp for home point setting.
At the time of home point setting, position data of the motor position detector (i.e., encoder) is backed up by batteries, and coordinates of the robot need not be set each time the power is turned on.
The position data of the motor position detector comes in the two (2) types; home position data within one (1) full turn of motor and motor multi-turn data.

Home position data within one (1) full turn of motor:
At home point setting operation of the robot (i.e., ZEROP operation and REORG operation), the data are written into the parameter file. As the data is backed up by batteries, the parameters should be loaded again from the attached system disk at replacement of the main control printed board.

Motor multi-turn data:
This data is kept in the encoder by battery backup, which differs from the backup battery of the main control printed board. When the battery voltage drops, correct multi-turn data cannot be guaranteed and the encoder itself outputs an alarm. This data is set to zero (0) at home point setting operation of the robot (i.e., ZEROP operation and REORG operation). Likewise, it is set to zero (0) also by multi-turn data reset operation.

4.2 Position Detector Error

If a position detector error (encoder error) occurs, either of the following errors is shown on the error display of the robot controller.

Error code	Error content
8–065	Axis1 Encoder abnormal
8–097	Axis2 Encoder abnormal
8–129	Axis3 Encoder abnormal
8–161	Axis4 Encoder abnormal
8–193	Axis5 Encoder abnormal

The position detector error is an error detected by the encoder itself. Even if the data in the parameter file is lost (or changed) to change the home point coordinates of the robot, for instance, a position detector error will not occur. If the machine coordinates have changed without causing a position detector error, the mechanical connecting position of the servo motor and mechanical unit shifted or the data in the parameter file described above was changed. (Ex.: Tooth skip of timing belt, etc.)

Errors detected by the encoder itself include the battery voltage drop, error caused by temperature rise in the encoder, counter overflow, internal counter data inconsistency, etc. Among these errors, the error which occurs most frequently is the battery voltage drop which is caused by the absence of maintenance at specified change intervals (once a year) due to a long-term shutdown or cable breakage.
To prevent the position detector error, therefore, replace the batteries on a regular basis. For the battery replacement, see Para. 2.9.
Also, a heavy vibration should not be exerted on the robot or the robot should not be moved suddenly by hand during power OFF. Especially, when transporting and storing the robot, secure the robot in a posture for shipment, using the attached clamps.

Restoration from position detector error:
The restoring operation from the position detector error comes in the following four (4) manners.

[1] Encoder error reset operation: See Para. 4.3.2.
[2] HOME operation: See Para. 4.4.
[3] ZEROP operation: See Para. 4.5.
[4] Multi-turn data reset operation: See Para. 4.6.

(1) When the mechanical connecting position with the motor has changed after motor or belt replacement:

A position detector error may occur after replacement and adjustment of the servo motor or timing belt. When this happens, execute the following restoring operation.

1) Execute “[2] HOME operation.”
2) Execute “[3] ZEROP operation.” At this time, the contents in the parameter file (i.e., home position data within one (1) full turn of motor) are updated. Rewriting of the data into the system disk is necessary.
3) Make sure that the error has been reset, referring to the error display.
4) In the “[2] HOME operation” and “[3] ZEROP operation”, some error may be caused according to the adjusting method. Re-teaching of the teach points may be required under some circumstances.

After resetting the error, effect an emergency stop, manually move each axis to the motion limit and make sure that a soft stroke limit error generates. If the mechanical interference is caused before generation of the soft stroke limit error, repeat the restoring operation in the manner described above.

(2) When a position detection error has occurred during normal operation with the mechanical connection position unchanged:

A position detector error may occur after battery voltage drop, or battery or cable replacement. When this happens, execute the following restoring operation.

1) Execute “[1] Encoder error reset operation.”
2) Make sure that the error has been reset, referring to the error display.

After resetting the error, effect an emergency stop, manually move each axis to the motion limit and make sure that a soft stroke limit error generates.

! DANGER

- When moving the robot by hand while the power is turned on, be sure to assure the safe work and effect an emergency stop beforehand.
- In the above situation, if the work is to be done while the axis 3 motor brake OFF switch is pressed, be sure to perform the work by two (2) persons. One person should carry out the work while the other is monitoring the work outside the hazardous zone. The latter person should watch the work and be ready to turn off the controller switch if any abnormality occurs. Once the controller power is turned off, the motor brake actuates even if the axis 3 motor brake OFF switch is kept pressed.
- If the axis 3 motor brake OFF switch is pressed while the robot is carrying a heavy workpiece, the axis 3 may drop suddenly. To avoid this, the customer should take all necessary measures by themselves.

2.1) **When the error has been reset:**

Turn on the controller power only (DO NOT turn on the servo power), and make sure by moving the arm, etc. by hand that the position detector error will not occur again. Then turn off the controller power and turn on again to make sure that the same error will not recur.

2.1.1) **When the error occurs again:**

The position detector has possibly malfunctioned.

2.1.2) **When the error will not occur again:**

Turn on the servo power. Select the TEACHING mode and gradually move each axis at low speed to make sure of its soft stroke. If the soft stroke or machine coordinate is abnormal, perform “[4] Multi-turn data reset operation.”

2.2) **When the error is not reset:**

Replace the batteries, then perform “[1] Encoder error reset operation” again. Make sure again that the error has been reset, referring to the error display.

2.2.1) **When the error has been reset:**

Execute the same operation as in Para. 2.1) above.

2.2.2) **When the error cannot be reset:**

The position detector has possibly malfunctioned, or the encoder cable has broken.

4.3 Restoring Operation from Position Detector Error

Make sure on the error display that a position detector error is generated. Identify the type of the position detector error and position data on the encoder status display, then perform each restoring operation.

4.3.1 Encoder Status Display


Call the encoder status screen on the teach pendant display, and make sure of the position data and the type of position detector error there. The type of the position detector error (i.e., error status) is expressed as shown below. The motor multi-turn data, home position data within one (1) full turn of motor and error status are displayed under the column of [MULTI], [SINGLE] and [Err-df], respectively.
To call the encoder status screen, observe the following procedures.

Table 4.1 Error status table

Error status	Description
0000	Signifies the normal condition.
0100	This error occurs when a heavy vibration has been exerted on the robot or when the robot has been moved fast by hand while the power drive cable was disconnected during power OFF. The multi-turn data has possibly shifted.
0200	Because axis feed was not executed after power ON, the encoder resolution has deteriorated. During axis feed, the encoder resolution returns to normal. No alarm will generate.
8000	The battery voltage has dropped. Replace the batteries.
4000	The battery voltage has dropped further than the above. An error has possibly occurred in the multi-turn data.
4200	Errors 4000 and 0200 have occurred at the same time.
C200	Errors 8000, 4000 and 0200 have occurred at the same time.

[1] Press the “UTILITY” key provided on the teach pendant. Press the [NEXT] key until [ENC] is displayed on the function menu.

[2] Press the [ENC] (F5) key, and the encoder status screen appears on the display.




If the error status shown in the error status table above is displayed, you can restore from the position detector error.

4.3.2 Encoder Error Reset Operation

When the mechanical connecting position of the servo motor and mechanical unit remains unchanged, that is, after battery replacement due to battery voltage drop or cable replacement due to cable breakage, execute this operation.

[1] Call the encoder status screen on the teach pendant display, referring to Para. 4.3.1 above.

[2] Just after the encoder status screen is called, the cursor points out the [Err-df] column on the [E1] line. Move the cursor to a line for the system you wish to execute the encoder error reset operation by means of the cursor keys (i.e., “↑” and “↓” keys).



[3] To reset the axis 3 encoder error, for instance, move the cursor to the [Err-df] column on the [E3] line and press the [RESET] (F3) key. If everything is OK, press the “EXE” key. Now the axis 3 encoder error has been reset.

[4] Call the normal error screen, press the [RESET] (F3) key to reset the error of “8–403 Axis3 Encoder Abnormal.”

4.4 Restoring Home Position Data by HOME Function


Batteries for backing up the position information of the position detector are housed in the base unit of the robot. Unless the robot has been used for a long term, the battery voltage drops and the home position data will be lost. Also, when the battery voltage for backing up the internal memory of the X8HC printed board has dropped, user’s set programs, parameters and absolute coordinates will be lost. To avoid this, replace the batteries on a regular basis.

4.4.1 Outline of HOME Function

This function memorizes a specific coordinate value in each axis and restores the original home position data by using the HOME function when the machine home position data has been destroyed.

The set points are provided for HOME1 to HOME4, and the axis 1 to axis 3 plus (+) side mechanical stopper positions are set in HOME3, and the axis 1 to axis 3 minus (–) mechanical stopper positions in HOME4. The axis 4 is set at the 0° position according to the home point match-mark.
For HOME1 and HOME2, you can specify any values. It is recommended that when building up a system, you specify the place for securing the robot end.

(Page 1)



(Page 2)

```
SYSTEM  HOME3          HOME4
  (J1)    1183468    -   1180474   [deg]
  (J2)    1450716    -   1450720   [deg]
  (J3)    1239092    -     36711   [mm ]
  (J4)          0              0   [deg]
  (J5)          0              0   [mm ]

 SET                          TEACH
```

Caution: This function is used to restore the machine home point of each axis. NEVER use the function at other than the setting for restoration.


4.4.2 Setting HOME1 and HOME2

1) Guide the robot to secure the tool shaft at a desired position.

2) Turn off the servo power.

3) Press the “UTILITY” key equipped on the teach pendant.

4) Press the [NEXT] key until the [REORG] menu appears, then press the [REORG] key.



5) When the above screen appears, memorize the position where the robot was secured for each axis by moving the cursor and using the [TEACH] mode.

4.4.3 How to Restore Data by HOME1 or HOME2

1) Guide the robot and secure it at the position set in HOME1 or HOME2 above.
2) Turn off the servo power.
3) Press the “UTILITY” key equipped on the teach pendant.
4) Press the [NEXT] key until the [REORG] menu appears, then press the [REORG] key.
5) Move the cursor to each axis under HOME1 of the REORG screen, then press the [SET] key to update the coordinate value set in HOME1 to the position where the robot was secured. Thus, the machine home position can be restored.

! CAUTION

- The axis 3 and axis 4 of the robot are interlocked with each other. Unless the specified procedures are followed, therefore, the current position of the robot may shift.
  When restoring the home point of the axis 3 (or axis 4) by using the [REORG] function, be sure to restore the home point of the axis 4 (or axis 3) also.

  Operating procedures

  1) Secure the axes 3 and 4 to each mechanical stopper or specified position.
  2) Move the cursor to (J3) on the screen and press the [SET] key to restore the axis 3 home point.
  3) Likewise, move the cursor to (J4) on the screen and press the [SET] key to restore the axis 4 home point.

4.4.4 Locations of Robot Home Point Match-Marks





Fig. 4.1 Locations of home point match-marks
(Common to TH450A and TH550A)

4.4.5 How to Restore Data by HOME3 or HOME4

The plus (+) side mechanical stopper positions and minus (–) side mechanical stopper positions of the axes 1 to 3 are factory-set in HOME3 and HOME4, respectively. The axis 4 is set to the home point match-mark.
The machine home point can be restored, using the above.
This paragraph deals with the restoration procedures, using HOME3.

1) Turn off the servo power.
2) Press the “UTILITY” key provided on the teach pendant.
3) Press the [NEXT] key until the [REORG] menu appears, then press the [REORG] key.
4) Press the [NEXT] key to call Page 2.



5) Contact the axis 1 of the robot to the plus (+) side mechanical stopper by hand.

6) Move the cursor to (J1) of HOME3, then press the [SET] key. Now, the machine home point of the axis 1 is restored.

7) Likewise, contact the axis 2 of the robot to the plus (+) side mechanical stopper by hand.

8) Move the cursor to (J2) of HOME3, then press the [SET] key. Now, the machine home point of the axis 2 is restored.

9) Press the [ESC] key to escape from the REORG screen once.

10) Turn on the servo power, and set the axes 3 and 4 in the servo-free state.

11) Set the axis 4 to the home point match-mark.

12) Contact the axis 3 of the robot to the plus (+) side mechanical stopper by hand.

13) Turn off the servo power.

14) Repeat Steps [2] to [4] inclusive to call the HOME screen again.

15) Move the cursor to (J4) of HOME3, then press the [SET] key. Now, the machine home point of the axis 4 is restored.

16) Move the cursor to (J3) of HOME3, then press the [SET] key. Now, the machine home point of the axis 3 is restored.

17) Press the [ESC] key to escape from the HOME screen. Now, the operation has finished.


4.5 Restoring Home Position Data by ZEROP Function

Batteries for backing up the position information of the position detector are housed in the base unit of the robot. Unless the robot has been used for a long term, the battery voltage drops and the home position data will be lost. Also, when the battery voltage for backing up the internal memory of the X8HC printed board has dropped, user's set programs, parameters and absolute coordinates will be lost. To avoid this, replace the batteries on a regular basis.

When the robot arm is moved fast during power OFF, the absolute coordinate counter cannot follow the robot motion, resulting in destruction of the home point data.
This paragraph deals with the restoring procedures when the home position data was destroyed by mistake.
This restoring operation may cause some error according to the adjusting method.

4.5.1 Preparation before Restoring Operation

1) Turn on the controller power and align the home point match-marks of each axis in the manual mode.
2) If this is not possible, mark the reference position of each axis and jot down its coordinate beforehand.
3) Move the axis 3 down to near the lower limit and set it to the dimension shown in the figure below (i.e., distance between the boss end surface of tool shaft and the tool flange end surface).




This figure shows when the standard axis stroke (150 mm) is used for the axis 3.


Fig. 4.2 Dimension of axis 3 home point

4.5.2 Setting New Home Position Data


1) Select the TEACHING mode by means of the master mode switch.
2) Press the “UTILITY” key equipped on the teach pendant.
3) Press the [NEXT] (F6) key on the teach pendant twice.
4) Turn off the servo power.
5) Press the [F3] key on the teach pendant to select the ZEROP mode.
6) The following home point setting screen is called.




7) Press the “ALT” and “0” keys on the teach pendant at the same time.
8) The following home point editing screen appears.
9) The numerical value of E1 (axis 1) is inversely displayed.



10) Press the “EXE” key on the teach pendant, and the value of “E1” is displayed at the lower left side. Set “0” in lieu of this value and press the “EXE” key. Then the E1 value becomes “0”.
11) Unless the axis could be located at the home point mark, enter the coordinate value registered beforehand.



12) When the "↓" key on the teach pendant is pressed, the following E2 value is displayed by reversed image. Perform setting in the same manner as above.



! CAUTION

- The axis 3 and axis 4 of the robot are interlocked with each other. Be sure to strictly observe the order of the home point setting.

  E1 (axis 1) → E2 (axis 2) → E4 (axis 4) → E3 (axis 3)

13) Turn off the controller power, then turn it on again.

4.5.3 Confirming Home Position

1) Make sure of the robot current position according to the POS data of the UTILITY mode. Guide the robot to the approximate home position by manual operation and confirm the position. Unless it could be located at the home point match-mark, make sure that the approximate position is the reference position marked in advance.

2) Execute the following program and make sure of the robot machine home position. Unless the robot could be located at the home point match-mark, DO NOT use the following program.
Create a program in which the robot moves to the position recorded beforehand, referring to the following program. Then make sure that the robot moves to the reference position mark according to the program thus created.

```
PROGRAM ZERO
 SPEED=30
 MOVEA 3,100
 MOVEA 1,0
 MOVEA 2,0
 MOVEA 3,0
 MOVEA 4,0
END
```

4.5.4 Saving Data

Save the system parameters in the system disk.
Connect the personal computer and controller using TSPC (option), then save the “MACHINE.PAR” file from the robot controller to the hard disk, etc. of the personal computer. Load the home position data to the system parameter file.
The home position data is the data characteristic of the robot, which differs with the robot you use. This data is necessary when you effect a cold start and restore the home position data again. Be sure to save the data.

Now, the operation completes.

4.6 Restoring Home Position Data by Multi-Turn Data Clear

1) Home point match-marks are provided for the axes 1, 2 and 4. When only the multi-turn data of these axes has been cleared, move the robot to each home point match-mark. For the axis 3, move it to the position shown in Fig. 4.2 above.

2) Turn off the servo power, select the TEACHING mode by means of the master mode switch, then press the “UTILITY” key equipped on the teach pendant.

3) When the [UTILITY] screen is called, press the [NEXT] key once, then press the [F5] function key corresponding to the [ENC] menu.

4) When the encoder information screen appears, press the “ALT” and “0” keys at the same time to cancel the editing lock mode.

5) Set the cursor to an axis whose multi-turn data is to be reset to zero (0), and press the [F3] function key corresponding to the [RESET] menu.

6) Move the robot to the teach points, etc. and make sure that the robot can be located at them exactly. (Thus, the robot can be restored completely to the original condition.)

5. Replacement Parts for Maintenance

5.1 List of Replacement Parts – Main Robot

	Part name	Type	Dwg. No.	Unit code	Maker	Q'ty	Remarks
1	AC servo motor	MSMD092S2U	S746326	Y610A3400	SHIBAURA MACHINE	1	Axis 1
2		MSMD042S2U	S746328	Y610A34C0		1	Axis 2
3		MSMD022S2V	S746337	Y610A3430		1	Axis 3
4		MSMD022S2U	S746329	Y610A34D0		1	Axis 4
5	Reduction gear	CSG-32-80-2 UH-SP	M153235	Y610A34N0	SHIBAURA MACHINE	1	TH550A Axis 1
6		CSG-32-50-2 UH-SP	M147090	Y610A34L0		1	TH450A Axis 1
7		CSG-25-50-2 UH-SP	M147091	Y610A34M0		1	Axis 2
8		HPG-14-11A	S854401	Y610A3EN0		1	Axis 4
9	Timing pulley		S854453 (ball screw side)		SHIBAURA MACHINE	1	Axis 3
10			S854452 (motor side)			1	Axis 3
11			S854455 (ball screw side)			1	Axis 4
12			S854454 (motor side)			1	Axis 4
13	Timing belt	BG318UP3M10 -HC	S854456			1	Axis 3
14		BG470UP5M15 -HC	S854457			1	Axis 4
15	Ball screw spline unit		H846367 (Z150)	Y610A3EP0	SHIBAURA MACHINE	1	Axis 3
16			H846387 (Z300)	Y610A3EQ0		1	
17	Grease	SK-1A grease	For reduction gear		HDS		Axes 1, 2
18		AFF grease (Lithium-based)	For ball screw		THK		Axis 3
19	Encoder backup battery	Size AA alkali battery				3	All axes

! CAUTION

- With the exception of the encoder backup batteries and greases, all parts listed in previous page are custom-made to SHIBAURA MACHINE specifications. Contact SHIBAURA MACHINE at order entry.
- Parts replacement work must be done by SHIBAURA MACHINE service engineer.

  SHIBAURA MACHINE's warranty does not cover failures, accidents or any damages.

5.2 List of Replacement Parts – Controller

No.	Part name	Type		Q'ty	Remarks
1	PS1 (Switching power supply)	LEB100F-0524		1	
3	Main power switch	IR-11-AB-10A-1B		1	
4	Lithium battery	ER3V-C		1	
5	Fuse	51NM030H		1	For X8HN, X8HI printed boards
6	Printed board	X8HC (Main control)	Y610A4000	1	
		X8HJ（connecter）	Y610A2320	1	
		X8HN (I/O board)	Y610A2120	1	Type N
		X8HI (I/O board)	Y610A2130	1	Type P
		X8HRA (Servo)	See Para. 5.3.	2	Two (2)-axis control per board
		X8HP (Servo power supply)	Y610A2190	1	
		X8HBA (Mother board)	Y610A2140	1	Standard: Four (4)-axis control
		X8HBB (Mother board)	Y610A2110	1	Special five (5)-axis control is possible.
7	Operation panel unit	X8HO	Y610A2310	1	
8	Teach pendant	TP1000	Y610A2600	1	With 5 m-long cable
9	System disk	TS2000SYS		1	CD-R

5.3 List of Servo Amplifier Module

Type of servo amplifier module		
Type	Unit code	Remarks
X8HRA 10A/30A	Y610A28L0	Axes 1 and 4
X8HRA 10A/15A	Y610A28E0	Axis 2 and 3