TS1000
Robot Controller

SIMPLE PLC FUNCTION MANUAL

Rev.6
April 1, 2020

Notice

- Make sure that this instruction manual is delivered to the final user of SHIBAURA MACHINE's industrial robot.
- Before operating the industrial robot, read through and completely understand this manual.
- After reading through this manual, keep it nearby for future reference.

Shibaura Machine

Copyright 2020 by SHIBAURA MACHINE CO.,LTD.
All rights reserved.

No part of this document may be reproduced in any form without obtaining prior written permission from SHIBAURA MACHINE CO.,LTD.

The information contained in this manual is subject to change without prior notice to effect improvements.

Preface

Structure of TH series robot and TS1000 controller instruction manuals:
These instruction manuals were published in parts according to the application and purpose, and the name and outline of each manual are as follows:

[Safety Manual]

This manual contains the important information to use the robot safety and correctly. Be sure to read through and understand this manual before operating the robot. Also, strictly observe the descriptions made there.

[Setup Manual]

This manual describes the procedures covering from power ON of the robot after installation to robot operation by manual guide. When you use the TH series robot for the first time, be sure to read through this manual.

[Operator's Manual]

This manual deals with the TS1000 controller operating procedures. Read through this manual before operating the robot, and refer to it as necessary.

[Robot Language Manual]

This manual refers to the robot language called "SCOL". When you have to create a program based on this language, read through the manual.

[Interface Manual]

This manual describes the external signals for the robot. Concerning the interface conditions between the robot and peripheral equipment, specifications, timing, etc., refer to the manual when necessary.

[Installation & Transport Manual]

This manual describes the transport, unpacking and installation of the robot and controller. Be sure to read through this manual before unpacking the shipment containing the robot.

[Maintenance Manual]

This manual deals with the daily and regular inspections to be made on the robot and controller. Read through this manual to use the robot safely over long years to come.

[Communication Manual]

This manual describes the serial communication between the robot controller and other equipment. Refer to this manual when connecting the robot controller with a host computer, optical sensor, etc., via a serial cable.

[User Parameter Manual]

This manual describes the setting of the robot controller. Read this manual when performing the setting of communication, I/O, motion condition, etc.

Cautions on Safety


This manual contains the important information on the robot and controller to prevent injury to the operators and persons nearby, to prevent damage to assets and to assure correct use.
Make sure that the following details (indications and symbols) are well understood before reading this manual. Always observe the information that is noted.

[Explanation of indications]


Indication	Meaning of indication
! **DANGER**	This means that "incorrect handling will lead to fatalities or serious injuries."
! **CAUTION**	This means that "incorrect handling may lead to personal injuries *1) or physical damage *2).


*1) Injuries refer to injuries, burns and electric shocks, etc., which do not require hospitalization or long-term medical treatment.
*2) Physical damage refers to damages due to destruction of assets or resources.

[Explanation of symbols]

Symbol	Meaning of symbol
	This means that the action is prohibited (must not be done). Details of the actions actually prohibited are indicated with pictures or words in or near the symbol.
	This means that the action is mandatory (must be done). Details of the actions that must be done are indicated with pictures or words in or near the symbol.
	This means danger. Details of the actual danger are indicated with pictures or words in or near the symbol.
	This means caution. Details of the actual caution are indicated with pictures or words in or near the symbol.

[Operation]

! DANGER	
 Prohibited	• During operation, NEVER enter the dangerous area of the robot. Otherwise, you will be injured seriously. • DO NOT leave in the working range any machinery or materials which will hinder the operation. If the equipment went wrong, a person nearby will be injured or involved in an accident. • Anyone other than the operator MUST NOT approach the equipment. Should he negligently touch the dangerous part of the equipment, he will get injured or involved in a serious accident. • NEVER perform an inappropriate operation which is not described in the instruction manual. Otherwise, the equipment will start by mistake, resulting in personal injury or serious accident.
 Danger	• If you feel even a little that you are exposed to danger or that the equipment works abnormally, press the EMERGENCY stop pushbutton switch to stop the equipment. If the equipment is used as it is, you will be injured or involved in a serious accident. When this happens, ask our after-sale service agent for repair. • During operation, be sure to close the equipment cover. Should the cover be opened during operation, you will be struck by an electric shock or get injured. • Only a well-trained and qualified person is allowed to perform the operation. Should the equipment be operated improperly, it will start by mistake, causing a personal injury or serious accident. • If the equipment has malfunctioned, turn the power off, identify and remove the cause of the abnormality, maintain the peripheral equipment and completely restore the malfunctioned equipment. Then start the equipment at a slow speed. If the equipment starts, leaving the abnormality, you will be involved in a serious accident.

 **CAUTION**	
 Prohibited	• DO NOT change the data of the system structure file. Otherwise, the robot will move abnormally, resulting in damage or an accident.
 Mandatory	• In principle, teaching operation should be performed outside the dangerous area of the robot. If it should be performed inevitably within the dangerous area, strictly observe the following matters. (1) The teaching operation should always be performed by two (2) persons. One person performs the job and the other person watches outside the dangerous area. Also, both persons should try to prevent mis-operation with each other. (2) The operator should do the job in an attitude ready to press the EMERGENCY stop pushbutton switch at any time. Also, he should perform the job at a position from which he can evacuate immediately at the time of an emergency after confirming the robot working range and shields nearby. (3) The supervisor should keep watch on the job at a position where he can see the entire robot system and operate the EMERGENCY stop pushbutton switch at the time of an emergency. Also, he should keep anyone from entering the dangerous area. Unless the operator or other person follows the instructions of the supervisor, an accident will be caused. • If an abnormality has generated or the POWER LED lamp on the control panel remains off after the main power switch of the equipment was turned on, turn off the main power immediately and confirm the wiring. Otherwise, you will be struck by an electric shock or a fire will break out. • Unless the robot operates toward a designated direction at manual guide, turn off the servo power. Otherwise, the robot will be damaged or you will be involved in an accident. When this happens, call us at the after-sale service agent. • Pushbutton operations on the control panel and teach pendant should be confirmed visually. Otherwise, you will be involved in an accident due to mis-operation. • After the power is turned on, be sure to reset a program to start an automatic operation. If the program is executed continuously, the robot will interfere with the peripheral equipment, resulting in damages or accidents.

CAUTION	
 Mandatory	• Before operating the equipment, perform the following inspection. (1) Make sure that visual appearance of the robot, controller, peripheral equipment and cables is in the good condition. (2) Make sure that no obstacle stands in or near the working range of the robot and peripheral equipment. (3) Make sure that the emergency stop and other safety devices operate properly. (4) Make sure that no abnormal noise or vibration is involved in the robot operation. If the above prior inspection is skipped, the equipment will be damaged or you will be involved in an accident.
 Caution	• The speed of test operations is initially set at 25 % of the maximum robot speed. • The speed of automatic operation is initially set at 100 % of the maximum robot speed.

Table of Contents

Page

Section 1 General Descriptions 1-1

Section 2 TCmini 2-1
2.1 Sequence Program 2-2
2.2 Instruction Words 2-3
2.3 System Sequence and User Sequence 2-4
2.4 Change of Sequence Program Area 2-5
2.5 Procedures for Creating Sequence 2-6

Section 3 Inputs and Outputs 3-1
3.1 Outline of Inputs and Outputs 3-1
3.2 External Input 3-2
3.3 External Output 3-5
3.4 Hand Input and Output 3-7
3.5 Panel I/Os 3-10
3.6 7-Segment User Display 3-10
3.7 Extension Input and Output 3-11
3.7.1 Outline of TR48DIOC 3-11
3.7.2 Connecting TR48DIOC 3-12
3.7.3 Setting of TR48DIOC 3-14
3.7.4 TR48DIOC Input 3-17
3.7.5 TR48DIOC Output Circuit 3-19
3.7.6 Remote I/O Module 3-20
3.8 Field Bus Input and Output (Option) 3-22

Section 4 Relays 4-1
4.1 Input/Output Relays 4-1
4.2 Internal Relay 4-2
4.3 Interface Relay 4-3
4.4 Edge Relay 4-4
4.5 Latch Relay 4-4
4.6 Timer/Counter 4-5
4.7 Special Auxiliary Relay 4-6

Page

Section 5 Registers 5-1
5.1 Data Register 5-1
5.2 Interface Register 5-2
5.3 Timer Counter Current Value Register 5-2
5.4 Timer Counter Set Value Register 5-3

Section 6 Robot Interface 6-1
6.1 TCmini → Main Unit of Robot Controller 6-1
DIN1~64, DIN101~164 (Digital Input Signal) 6-3
HANDIN1~8 (Hand Input Signal) 6-4
AL8–269~272 (Alarm Level 8) 6-5
AL4–077~080 (Alarm Level 4) 6-5
AL1–037~044 (Alarm Level 1) 6-5
J_MOVE (JOG Motion) 6-7
J_REMOTE (Selection of JOG Remote) 6-7
J_SPEED (Selection of JOG Speed) 6-7
J_COOD (Selection of JOG Coordinate) 6-7
J_DIRECT (Selection of JOG Direction) 6-7
J_AXIS1~3 (Selection of JOG Guidance Axis) 6-7
STROBE (Strobe Signal) 6-9
PRG_RST (Program Reset) 6-11
STEP_RST (Step Reset) 6-12
CYC_RST (Cycle Reset) 6-13
DO_RST (Output Signal Reset) 6-14
ALM_RST (Alarm Reset) 6-15
RUN (Start) 6-16
EX_SVON (External Servo ON) 6-17
STOP (Stop) 6-18
CYCLE (Cycle Operation Mode) 6-19
LOW_SPD (Low Speed Command) 6-20
BREAK (Deceleration and Stop) 6-21
SVOFF (Servo OFF) 6-22
I_TEACH 6-22A

Page

6.2 Main Unit of Robot Controller → TCmini 6-23
DOUT1 ~ 64, DOUT101 ~ 164 6-24
HANDOUT1 ~ 8 6-25
SEQPAR1 ~ 8 6-26
I9_SEL ~ I16SEL 6-27
O9_SEL ~ O16SEL 6-27
EMG_ST 6-28
SV_RDY 6-29
ACK (Acknowledge) 6-30
TEACH (Teach Mode ON) 6-31
INT (Internal Automatic Mode ON) 6-31
EXTSIG (External Automatic Signal Mode ON) 6-31
EXTHOST (External Automatic Host Mode ON) 6-31
SYS_RDY (System Ready) 6-32
AUTORUN (Auto Mode ON) 6-33
CYC_END (Cycle End) 6-34
LOW_ST (Low Speed Mode ON) 6-35
CYC_ST (Cycle Mode ON) 6-36
BT_ALM (Battery Alarm) 6-37
ALARM (Alarm) 6-38
6.3 Interface Register 6-39
STEP 6-40
ALNO,AL01 ~,AL10 6-40
USER 6-40
PLCDATAR1 ~ 8 6-41
PLCDATAW1 ~ 8 6-41
PSN_W1 ~ 8 6-42
PSN_J1 ~ 8 6-42

Page

Section 7 PLC Language 7-1
7.1 Sequence Program 7-1
7.2 Program Capacity and Length of Instruction Word 7-3
7.3 Address 7-6
7.4 Configuration of Instruction Word 7-12
7.4.1 Contact 7-14
7.4.2 Unconditional Connection 7-14
7.4.3 Blank 7-15
7.4.4 Internal Relay 7-15
7.4.5 Latch Relay 7-16
7.4.6 Timer 7-17
7.4.7 Counter 7-19
7.5 Standard Application Instruction 7-21
7.5.1 Selection of Executing Condition 7-21
7.5.2 Arbitrary Setting of Argument 7-21
7.5.3 Numeric Expression 7-22
7.5.4 Operation Flag 7-29
7.5.5 Order of Execution 7-33
7.5.6 Descriptions on Standard Application Instruction 7-34
F*000 Data Transfer 7-34
F*001 Constant Set 7-36
F*002 High-Order 8-Bit Data Transfer 7-37
F*006 Block Transfer (Constant Designation) 7-38
F*009 Data Extraction and Distribution 7-40
F*010 BIN → BCD Conversion (Unsigned) 7-41
F*011 BCD → BIN Conversion (Unsigned) 7-42
F*012 BIN → BCD Conversion (Signed) 7-43
F*013 BCD → BIN Conversion (Signed) 7-44
F*020 BIN Addition 7-46
F*021 Carried BIN Addition 7-48
F*022 BIN Subtraction 7-49

Page

F*023 Borrowed BIN Subtraction 7-51
F*024 Unsigned BIN Multiplication 7-52
F*025 Unsigned BIN Division 7-53
F*032 Logical Product (AND) 7-55
F*033 Logical Sum (OR) 7-56
F*034 Exclusive Logical Sum (XOR) 7-57
F*035 Increment 7-58
F*036 Decrement 7-58
F*037 Unsigned Comparison 7-59
F*038 Signed Comparison 7-60
F*040 Arithmetic Left Shift 7-62
F*041 Left rotation 7-63
F*042 Right Shift 7-65
F*043 Right Rotation 7-66
F*045 4 → 16 Decoder 7-68
F*047 Bit Test (Constant Designation) 7-69
F*049 Subroutine Start 7-70
F*058 Subroutine Call 7-72
F*059 Subroutine Return/Program End 7-72
F*063 1-Scan ON 7-73

7.6 Programming 7-74
7.6.1 Limitation on Creating Circuit 7-74
7.6.2 Influence by Program Sequence 7-78
7.6.3 Influence by Input/Output Processing 7-80
7.6.4 Promoting Programming Efficiency 7-81

Page

Section 8 TCPRGOS 8-1
8.1 Operating Environment of TCPRGOS 8-1
8.2 Connection 8-2
8.3 How to Install the TCPRGOS 8-3
8.4 Starting the TCPRGOS 8-6
8.5 Creating a Circuit 8-7
8.5.1 Start of New Ladder Editor 8-7
8.5.2 Creation of Circuit 8-9
8.5.3 Input of Perpendicular Line Symbol 8-12
8.5.4 Input of Timer in Coil 8-13
8.5.5 Input of Function Command in Coil 8-15
8.5.6 Input of Pair Coil 8-18
8.5.7 Change of Connecting Cine with Contact 8-20
8.5.8 Renumber of Circuits 8-21
8.5.9 Saving in File 8-22
8.5.10 Opening of Existing File 8-24
8.5.11 Modifying and Saving of Existing Circuit 8-26
8.6 Transferring Circuit 8-29
8.6.1 Check for Communication Setup 8-29
8.6.2 Connection 8-30
8.6.3 Transfer 8-30
8.7 Online Operation 8-33
8.7.1 Start Online Ladder Editor 8-33
8.7.2 Change of Online Ladder Editor Circuit 8-35
8.8 Monitor 8-38
8.8.1 Selection of Monitor Mode 8-38
8.8.2 Designation of PLC RUN or STOP and Compulsive Setting of Contact 8-39
8.8.3 Quit of Monitor Mode 8-43
8.9 Monitoring Register Data 8-45
8.9.1 Start of Online Register Editor 8-45
8.9.2 Compulsive Setting of Device 8-46
8.9.3 Modification of Word Data Specified by Address 8-47

Page

8.10 Quitting the TCPRGOS 8-48
8.10.1 Exit from Active Editor 8-48
8.10.2 Quit of TCPRGOS 8-49
8.11 How to Uninstall 8-50

Section 9 Advice of Sequence Program Creation 9-1
9.1 Turning ON/OFF External Output by DOUT Command 9-1
9.2 Input of External Signal by DIN Command 9-1
9.3 Output of AUTORUN Signal to External Device 9-1
9.4 Generating Alarm in TS1000 by External Signal 9-2
9.5 Output of Value to Control Panel 9-2
9.6 Change of Output Destination by Sequence Parameter 9-2
9.7 Circuit Generating 1 Pulse at Power ON 9-3
9.8 Circuit Generating 1 Pulse at Start 9-3
9.9 Circuit Generating 1 Pulse at Fall (1) 9-4
9.10 Circuit Generating 1 Pulse at Fall (2) 9-4
9.11 Self-Holding Circuit (Priority Is Given to Reset) 9-5
9.12 Self-Holding Circuit (Priority Is Given to Set) 9-5
9.13 Interlock Circuit 9-6
9.14 Alternate Circuit 9-6
9.15 Non-Modal Timer Circuit 9-7
9.16 Non-Modal Start Timer Circuit 9-7
9.17 Circuit Turning ON and OFF at Predetermined Intervals 9-8
9.18 Step Sequence Circuit 9-9

Section 10 Troubleshooting 10-1
10.1 Robot Servo Will Not Turn ON 10-1
10.2 Program Cannot Run 10-2
10.3 Sequence Program Cannot Be Transferred by TCPRGOS 10-2
10.4 Sequence Program Is Cleared at Power ON 10-2
10.5 TCPRGOS Will Not Start 10-2

Page

10.6 Sequence-Related Alarm Occurred in TS1000 10-3
8-227 PLC STOP 10-3
1-164 PLC Backup data error 10-3
1-166 PLC Remote unit error 10-4
1-169 PLC Undefine label 10-4
1-170 PLC Invalid command 10-4
1-173 PLC Overlap label 10-4

Section 11 Appendix 11-1
List of Relays 11-1
List of Registers 11-6
Standard ladder sequence program 11-7

Section 1 General Descriptions


Small-size SCARA robot controller TS1000 incorporates a simple programmable controller (hereinafter called the "TCmini").

Programs (DOUT commands) analyzed by the main unit and system output signals are once sent to the TCmini where they are processed and output to an external device. The TCmini also receives external input signals and transmits them to the main unit after processing. In other words, the TCmini can unrestrictedly determine the locations where input/output processing of robot programs by the main unit and system signals are to be input or output.

Also, the TCmini can directly respond to (or output) input signals sent from the external device. As the TCmini operates while the TC1000 controller power is turned on, it is capable of performing I/O control, irrespective of robot program execution.

External input/output signals described in the Interface Manual refer to the operation of a standard sequence program. When you create this sequence program, you can design a more flexible system.

This manual deals with the TCmini.




Section 2 TCmini

The TCmini built in robot controller TS1000 is a simple programmable controller resided in the robot, which can control external I/Os (21 inputs and 17 outputs), hand I/Os (5 inputs and 4 outputs), panel I/Os (2 inputs and 2 outputs) and extension I/Os (64 inputs and 64 outputs).

The TCmini is connected with the TS1000 main unit via common RAM to transfer I/O data and status.


When this TCmini is connected with a remote I/O module via RS485 communication cable (EXTI/O), up to 64 each of inputs and outputs can be connected.

By connecting the TCPRG port (RS232C) on the TS1000 front side with your personal computer, you can create, debug (I/O monitor) and transfer sequence programs, using TCPRGOS.



2.1 Sequence Program

Sequence programs of the TCmini use graphical (or ladder) programming.




I/O processing in the TCmini is batch-refreshed. Before arithmetic operation of a sequence program, ON/OFF status of inputs is transferred to the data memory with results of preceding sequence operation transferred to outputs.
After the I/O processing, the sequence program is scanned sequentially from the top.

In the TCmini, scanning is executed by the CPU. If the program size increases, it takes more time to scan, resulting in delay of the input and output. Yardstick of the scanning time is about ten (10) msec per 1,000 basic commands (1 K words).


For details on the programming, see Section 7 of this manual.

2.2 Instruction Words

The TCmini can use the following sixteen (16) instruction words.



In the TCmini, thirty-two (32) application instructions (or commands) can be used.




The application instruction comes with the following types.

- Transfer instruction
- Data change instruction
- BIN operation instruction
- Comparison instruction
- Bit operation instruction
- Subroutine instruction
- Pulse instruction

For further information on the instructions, see Section 7 of this manual.

2.3 System Sequence and User Sequence

The PLC (TCmini) built in the TS1000 has the following three (3) working areas and the sequence program capacity of each working area is 4 K words. The user can create sequence programs in areas 1 and 2 alone.



Area 0: Standard sequence area (Cannot be changed.)

Area 1: User's RAM area for debugging (RAM contents are cleared by power OFF and ON.)

Area 2: User's flash memory area (The number of writing counts is limited to 50.)

- The factory-setting is area 0, and the standard sequence is operating.
- The flash memory contents will not be cleared by power OFF and ON, but limitation is imposed on the writing counts (50 counts).
  Completely debug a sequence program in area 1 (RAM), then transfer it to area 2 (flash memory).

2.4 Change of Sequence Program Area

Changeover of working areas is performed by the user parameter.
The sequence to be operated is changed over by changing the set value of [U11] I/O mode of the USER.PAR file to 0, 1 or 2.


[U11] I/O mode (Setting of I/O operation mode)

```
[U11] I/O mode
    {Default/User} (0: Default, 1: User)
= 0
```

In the TS1000, I/Os specified in the program are processed for input or output. The storage location of this sequence program can be specified as shown below.

Set value = 0 Standard sequence (Cannot be changed.)
= 1 User's RAM for debugging (User's created sequence)
= 2 User's flash memory (User's created sequence)

2.5 Procedures for Creating Sequence



See Para. 2.4.

Selected area becomes valid.

See Section 8.

See Para. 2.4.

Selected area becomes valid.


See Section 8.

Transferred sequence becomes valid.

Section 3 Inputs and Outputs

3.1 Outline of Inputs and Outputs

In the TS1000, the following four (4) kinds of input and output signals can be controlled by the TCmini.




Panel input/output
2 inputs/2 outputs (UFI1 ~ 2/UFO1 ~ 2)

External input/output
21 inputs/17 outputs (IN1 ~ 21/OUT1 ~ 17)

Hand input/output
5 inputs/4 outputs (HI1 ~ 5/HO1 ~ 4)

Extension input/output
Max. 64 inputs/64 outputs (EI1 ~ 64/EO1 ~ 64)


A value can be written to the 7-segment USER display on the TS1000 controller panel.



7-segment USER display
(Displayed when "USER" is selected by means of the SELECT pushbutton switch.)

3.2 External Input

The external input signals (IN1 ~ 21) should be connected to the INPUT connector on the front side of the controller. The external signals thus connected are assigned to I/O relays X000 ~ X014 of the TCmini, using an attached dummy connector. (For details, see Section 4 of this manual.) Though X010, X013 and X014 of this dummy connector are jumpered, they can serve as the input in the user sequence mode. Use them by disconnecting when necessary.



Note 1: An example connection of X000 ~ X007 is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM1 and P24G to X000~ X007.

Note 2: An example connection of X008 ~ X00F is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM2 and P24G to X008~ X00F.

Note 3: An example connection of X010 ~ X014 is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM3 and P24G to X010~ X014.


- EMS1B ~ EMS1C, EMS2B ~ EMS2C are the external emergency stop signals. They are directly input to the internal safety circuit. (The input cannot be referred to from the TCmini.) For the connecting procedures, see the Interface Manual.

Specifications of external input signals


- Type of input:
  Non-voltage contact input or transistor open collector input.

- Example of application circuit and structure of input circuit:

P24G (–) common connection



P24V (+) common connection




- Contact (transistor) specifications:

Non-voltage contact specification		Transistor specification	
Contact rating	DC24 V, 100 mA or over	Voltage between collector and emitter	30 V or over
Circuit current	Approx. 7 mA	Current between collector and emitter	10 mA
Minimum current	DC24 V, 1 mA	Circuit current	Approx. 7 mA
Connected impedance	100 Ω or less	Leak current between collector and emitter	100 μA

- Type of connector
  Pin type connector: XM2A–3701 made by OMRON
  Connector cover: XM2S–3711 made by OMRON

3.3 External Output

The external output signals (OUT1 ~ 17) should be connected to the OUTPUT connector on the front side of the controller. The external signals thus connected are assigned to I/O relays Y000 ~ Y110 of the TCmini, using an attached connector. (For details, see Section 4 of this manual.)




Note 1: All of Y100 ~ Y110 in the figure above are the transistor outputs.

SVST_A ~ SVST_B (servo ON) and EMSST_A ~ EMSST_B (emergency stop ON) are the non-voltage contact output signals directly output from the controller (hardware). (They cannot be controlled from the TCmini.) For the connecting procedures, see the Interface Manual.

Specifications of external output signals

- Type of output:
  Transistor output.

- Example of application circuit and structure of output circuit:



- Electric rating


Electric rating	Caution
Rated voltage DC24 V Rated current 100 mA (max.)	Rated built-in power current is 3 A. (Total current of the hand, external output and extension output modules should be 3 A or less.) If the current which exceeds the rated output current is supplied, the output element may be damaged or the printed board may burn. To avoid this, be sure to use within the rated output current. NEVER use the external power supply. Otherwise, the system may be troubled.

- Type of connector
  Pin type connector: XM2A–2501 made by OMRON
  Connector cover: XM2S–2511 made by OMRON

3.4 Hand Input and Output

The hand input and output signals (HI1 ~ 5, HO1 ~ 4) should be connected to the HAND connector on the front side of the controller. The external signals thus connected are assigned to I/O relays X018 ~ X01C and Y118 ~ Y11B of the TCmini. To connect them to JOES on top of the arm 2, use an attached connector (XM2A–1501 made by OMRON).

To connect the TS1000 (HAND) and robot base (HAND), use an optional HAND cable.




Specifications of hand input signals

- Type of input:
  Non-voltage contact input or transistor open collector input.
- Example of application circuit and structure of input circuit:
  Same as the external input. For connecting the common line, see the figure above.
- Contact (transistor) specifications:

Non-voltage contact specification		Transistor specification	
Contact rating	DC24 V, 100 mA or over	Voltage between collector and emitter	30 V or over
Circuit current	Approx. 7 mA	Current between collector and emitter	10 mA
Minimum current	DC24 V, 1 mA	Circuit current	Approx. 7 mA
Connected impedance	100 Ω or less	Leak current between collector and emitter	100 μA

Specifications of hand output signals

- Type of output: FET output.
- Example of application circuit and structure of output circuit:



- Electric rating

Electric rating		Caution
Rated voltage	DC24 V (Max. DC25 V)	The current of a total of four (4) hand output signals should be 1 A or less.
Rated current	1A	Rated built-in power current is 3 A. (Total current of the hand, external output and extension output modules should be 3 A or less.) If the current which exceeds the rated output current is supplied, the output element may be damaged or the printed board may burn. To avoid this, be sure to use within the rated output current. NEVER use the external power supply. Otherwise, the system may be troubled.


- Type of connector

  Pin type connector: XM2A–2501 made by OMRON


  Connector cover: XM2S–2511 made by OMRON

3.5 Panel I/Os

User function switches:
The user can assign a function to each user function switch (UF1, UF2) in the sequence program.
The switches and lamps are assigned to I/O relays X016, X017, Y116 and Y117.



3.6 7-Segment User Display




The 7-segment user display can be used while "USER" is selected by means of the SELECT pushbutton switch. The value of data register D150 is displayed there. (0 ~ 65535) Any value exceeding this range will not be displayed correctly. (A negative value cannot be displayed.)

3.7 Extension Input and Output

The TCmini can extend I/Os as necessary. TR48DIOC is available as an exclusive I/O extension module for the TS1000. Also, our standard remote I/O module can be connected.

3.7.1 Outline of TR48DIOC


TR48DIOC is an exclusive I/O extension module for the TS1000, having 28 input signals and 20 output signals. In the TS1000, up to two (2) stations can be extended, using TS48DIOC modules.




3.7.2 Connecting TR48DIOC

The TR48DIOC modules are connected as shown below.


- When one (1) TR48DIOC module is added:



- When two (2) TR48DIOC modules are added:




 The maximum current of 24 V power supplied from the TS1000 is 1.2 A. If the current exceeds 1.2 A, use an external power supply which can supply 24 V and 0 V power. At this time, the external power supply should be turned on prior to the TS1000 power supply. (With the TS1000 power ON, presence or absence of extension I/Os is judged.)


DC24 V power supply
+
–
TS1000
TR48DIOC (Station 0)
24V(Max1.2A)
0V
A(485A＋)
B(485B－)
FG
1
2
3
4
5
1
2
3
4
5
24V
0V
A(485A+)
B(485B–)
FG
TR48DIOC (Station 1)

3.7.3 Setting of TR48DIOC


- Setting of station number and terminator
  For the TR48DIOC module or modules connected, the station number and terminator should be specified.



Terminator ON direction

Use the switches equipped on the upper side of the TR48DIOC unit.

Example 1: When one (1) TR48DIOC module is added



Station 0

Example 2: When two (2) TR48DIOC modules are added



Station 0 Station 1

For the terminator, when only one (1) TR48DIOC module is used, set ON the terminator setting switch equipped on the module.
When two (2) TR48DIOC modules are used, see the figure in Para. 3.7.1 for example. As the TR48DIOC module on the extreme right side as viewed from the controller front side is the terminal station in terms of cable wiring, set ON the terminator setting switch equipped on this module alone.

- Setting of user parameter
  To recognize an I/O extension module by the TCmini built in the TS1000, setting of appropriate user parameter is necessary.

  To designate the slave station number of the TS1000, observe the following steps. Under [U12] of the USER.PAR (user parameter) file, you can find the following parameter setting related to the extension input and output.

  [U12] Extend I/O setting
  {Use/Not Use} (0: Not Use, 1: Use)
  {Not Use}
  {Not Use}
  = 0 0 0 → Corresponds to station 0.
  = 0 0 0 → Corresponds to station 1.

  If you wish to use only station 0 (i.e., one (1) TR48DIOC module), for instance, change the underlined bit corresponding to station 0 to "1".
  = 1 0 0
  = 0 0 0

  After saving the parameter file, turn off the controller power and on again. Then the above parameter becomes effective.

  If you wish to use both stations 0 and 1 (i.e., two (2) TR48DIOC modules), specify as follows and perform the same operation as above to make the parameter valid.
  = 1 0 0
  = 1 0 0

When using the TR48DIOC module, careful precautions should be taken on the following matters.

[1] Make sure that the slave station number set in "USER.PAR" coincides with the station number setting of the TR48DIOC module.

[2] When the TR48DIOC module or modules are connected, set ON the terminator setting switch equipped on the TR48DIOC module which is located on the extreme right side in terms of cable wiring when seen from the controller front side.


The switches (2 pins) provided on the front upper side of the TR48DIOC module represent pin 1 (upper) for slave station number setting and pin 2 (lower) for terminator setting.

Be sure to execute Items [1] and [2] above, irrespective of the presence or absence of external power supply. Otherwise, the system may not function normally or go wrong.

With the above setting, make sure that both the POWER and RUN LEDs on each TR48DIOC module are illuminated.

3.7.4 TR48DIOC Input

TR48DIOC input signals (EI01 ~ EI28 for station 0 and EI33 ~ EI60 for station 1) should be connected to the INPUT (TR) connector on the front side of the module. The extension input signals thus connected are assigned to I/O relays X040 ~ X05B (station 0) and X060 ~ X07B (station 1) of the TCmini.
(For details, see Section 4 of this manual.)



Note 1: An example connection of X040 ~ X047/X060 ~ X067 is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM1 and P24G to X040~ X047/X060 ~ X067.

Note 2: An example connection of X048 ~ X04F/X068 ~ X06F is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM2 and P24G to X048 ~ X04F/X068 ~ X06F.


Note 3: An example connection of X050 ~ X05B/X070 ~ X07B is shown in the figure above, taking P24G as common. If P24V serves as common, connect P24V to INCOM3 and P24G to X050 ~ X05B/X070 ~ X07B.

Specifications of TR48DIOC input signals

The specifications of TR48DIOC input signals are the same as those of the external input signals. For details, see Para. 3.2 of this manual.

3.7.5 TR48DIOC Output Circuit

TR48DIOC output signals (EO01 ~ EO20 for station 0 and EO33 ~ EO52 for station 1) should be connected to the OUTPUT (TR) connector on the front side of the module. The extension output signals thus connected are assigned to I/O relays Y140 ~ Y153 (station 0) and Y160 ~ Y173 (station 1) of the TCmini.
(For details, see Section 4 of this manual.)



Note 1: All of Y140 ~ Y153, Y160 ~ Y173 in the figure above are the transistor outputs.

Specifications of TR48DIOC output signals


The specifications of TR48DIOC output signals are the same as those of the external output signals. For details, see Para. 3.3 of this manual.

3.7.6 Remote I/O Module

In addition to the TR48DIOC modules, the TCmini built in the TS1000 can also connect our standard remote I/O modules which are tabled below.

Construction	Type	Input spec.	No. of inputs	Output spec.	No. of outputs	Remarks
Unit	TR48DIOC	DC24	28	DC24	20	Exclusively used for the robot. Internal power supply.
Printed board	TR64DIRYC	DC24	32	Relay	32	I/O external power supply
Printed board	TR32DIRYC	DC24	16	Relay	16	
Printed board	TR32DIDOPC	DC24	16	DC24	16	(+) common
Printed board	TR32DIDONC	DC24	16	DC24	16	(–) common
Terminal block	TR16DIC	DC24	16		0	Slave station
Terminal block	TR16DIE	DC24	16		0	Extension
Terminal block	TR16DOPC		0	DC24	16	Slave station (+) common
Terminal block	TR16DOPE		0	DC24	16	Extension (+) common
Terminal block	TR16DONC		0	DC24	16	Slave station (–) common
Terminal block	TR16DONE		0	DC24	16	Extension (–) common
Terminal block	TR16AOC		0	AC100	16	Slave station
Terminal block	TR16AOE		0	AC100	16	Extension
Terminal block	TR16RYC		0	Relay	16	Slave station
Terminal block	TR16RYE		0	Relay	16	Extension

Conditions for selecting remote I/O module:



[1] Up to two (2) remote I/O modules can be connected.
Alphabet "C" at the end of the type signifies the slave station, and a total of two (2) modules of this type can be connected.

[2] The number of inputs and outputs per station is 0 ~ 32 each.

[3] One (1) printed board serves as one (1) station.

[4] For the terminal block type module, up to three (3) TR16**E modules can be combined with a TR16**C module serving as the slave station. Be sure to observe the restrictions in Item [2], however.

3.8 Field Bus Input and Output (Option)

Input and output signals of the field bus slave function (option) can also be controlled from the TCmini.

Input signals from the field bus are assigned to X200 ~ X23F.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
X20W	FI16	FI15	FI14	FI13	FI12	FI11	FI10	FI9	FI8	FI7	FI6	FI5	FI4	FI3	FI2	FI1
X21W	FI32	FI31	FI30	FI29	FI28	FI27	FI26	FI25	FI24	FI23	FI22	FI21	FI20	FI19	FI18	FI17
X22W	FI48	FI47	FI46	FI45	FI44	FI43	FI42	FI41	FI40	FI39	FI38	FI37	FI36	FI35	FI34	FI33
X23W	FI64	FI63	FI62	FI61	FI60	FI59	FI58	EI57	FI56	FI55	FI54	FI53	FI52	FI51	FI50	FI49

Output signals to the field bus are assigned to Y300 ~ Y33F.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
Y30W	FO16	FO15	FO14	FO13	FO12	FO11	FO10	FO9	FO8	FO7	FO6	FO5	FO4	FO3	FO2	FO1
Y31W	FO32	FO31	FO30	FO29	FO28	FO27	FO26	FO25	FO24	FO23	FO22	FO21	FO20	FO19	FO18	FO17
Y32W	FO48	FO47	FO46	FO45	FO44	FO43	FO42	FO41	FO40	FO39	FO38	FO37	FO36	FO35	FO34	FO33
Y33W	FO64	FO63	FO62	FO61	FO60	FO59	FO58	FO57	FO56	FO55	FO54	FO53	FO52	FO51	FO50	FO49

Section 4 Relays

4.1 Input/Output Relays

Inputs to and outputs from the TCmini are assigned to X relays (X000 ~ X07F) and Y relays (Y100 ~ Y17F), respectively.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
X00W	IN16	IN15	IN14	IN13	IN12	IN11	IN10	IN9	IN8	IN7	IN6	IN5	IN4	IN3	IN2	IN1
X01W				HI5	HI4	HI3	HI2	HI1	UFI2	UFI1		IN21	IN20	IN19	IN18	IN17
X02W	Reserved for the system								Reserved for the system							
X03W																
X04W	EI16	EI15	EI14	EI13	EI12	EI11	EI10	EI9	EI8	EI7	EI6	EI5	EI4	EI3	EI2	EI1
X05W	EI32	EI31	EI30	EI29	EI28	EI27	EI26	EI25	EI24	EI23	EI22	EI21	EI20	EI19	EI18	EI17
X06W	EI48	EI47	EI46	EI45	EI44	EI43	EI42	EI41	EI40	EI39	EI38	EI37	EI36	EI35	EI34	EI33
X07W	EI64	EI63	EI62	EI61	EI60	EI59	EI58	EI57	EI56	EI55	EI54	EI53	EI52	EI51	EI50	EI49
Y10W	OUT 16	OUT 15	OUT 14	OUT 13	OUT 12	OUT 11	OUT 10	OUT 9	OUT 8	OUT 7	OUT 6	OUT 5	OUT 4	OUT 3	OUT 2	OUT 1
Y11W					HO4	HO3	HO2	HO1	UFO 2	UFO 1						OUT 17
Y12W	Reserved for the system								Reserved for the system							
Y13W																
Y14W	EO16	EO15	EO14	EO13	EO12	EO11	EO10	EO9	EO8	EO7	EO6	EO5	EO4	EO3	EO2	EO1
Y15W	EO32	EO31	EO30	EO29	EO28	EO27	EO26	EO25	EO24	EO23	EO22	EO21	EO20	EO19	EO18	EO17
Y16W	EO48	EO47	EO46	EO45	EO44	EO43	EO42	EO41	EO40	EO39	EO38	EO37	EO36	EO35	EO34	EO33
Y17W	EO64	EO63	EO62	EO61	EO60	EO59	EO58	EO57	EO56	EO55	EO54	EO53	EO52	EO51	EO50	EO49
X20W	FI16	FI15	FI14	FI13	FI12	FI11	FI10	FI9	FI8	FI7	FI6	FI5	FI4	FI3	FI2	FI1
X21W	FI32	FI31	FI30	FI29	FI28	FI27	FI26	FI25	FI24	FI23	FI22	FI21	FI20	FI19	FI18	FI17
X22W	FI48	FI47	FI46	FI45	FI44	FI43	FI42	FI41	FI40	FI39	FI38	FI37	FI36	FI35	FI34	FI33
X23W	FI64	FI63	FI62	FI61	FI60	FI59	FI58	EI57	FI56	FI55	FI54	FI53	FI52	FI51	FI50	FI49
X24W	Reserved for the system								Reserved for the system							
X25W																
X26W																
X27W																
Y30W	FO16	FO15	FO14	FO13	FO12	FO11	FO10	FO9	FO8	FO7	FO6	FO5	FO4	FO3	FO2	FO1
Y31W	FO32	FO31	FO30	FO29	FO28	FO27	FO26	FO25	FO24	FO23	FO22	FO21	FO20	FO19	FO18	FO17
Y32W	FO48	FO47	FO46	FO45	FO44	FO43	FO42	FO41	FO40	FO39	FO38	FO37	FO36	FO35	FO34	FO33
Y33W	FO64	FO63	FO62	FO61	FO60	FO59	FO58	FO57	FO56	FO55	FO54	FO53	FO52	FO51	FO50	FO49
Y34W	Reserved for the system								Reserved for the system							
Y35W																
Y36W																
Y37W																


X*** Represents an exclusive input relay which is connected to the standard input, panel input, hand input or extension input signal.
The ON or OFF status is read at I/O processing in each scanning cycle.
It can be used as the contact input information and data register source in the sequence program.

Y*** Signifies an exclusive output relay which is connected to the standard output, panel output, hand output or extension output signal.
It serves as the destination of coil and data register in the sequence program, where operation result is written.
The operation result can be used as the source of contact and data register in the sequence program.
The operation result is transferred as the ON/OFF information to the output device at I/O processing in each scanning cycle.

 Relays reserved for future extension of the system functions. Values are undecided and cannot be used.

For further information on the input and output specifications, see Section 3.

I_TEACH (Manual Interrupt Signal; Option)

Address	R33D
Direction	TCmini → Main unit of robot controller
Function	Used to temporarily change the TS1000 robot controller mode to "MANUAL" from the TCmini. When this signal is OFF (i.e., low), the manual mode (TEACHING) takes effect. When this signal is ON (i.e., high), the external mode (EXTSIG) effective before the change takes effect again.
Timing chart	
Remarks	This signal is optional, which can be used only when the external mode (EXTSIG) is selected for the master mode.

4.2 Internal Relay

A total of 256 relays (R000 ~ R17F) can be used as the internal relay.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R00W																
R01W																
R02W																
R03W																
R04W																
R05W																
R06W																
R07W																
R10W																
R11W																
R12W																
R13W																
R14W																
R15W																
R16W																
R17W																

R000 ~ R17F:
Serve as the destination of coil and data register in the user program, where operation result is written.
They can be used as a temporary storage of operation result which need not be output to the external device.
The operation result can be used as the source of contact and data register in the user program.

4.3 Interface Relay

The interface relay serves as the interface area for transferring signals with the main unit of the robot controller.
For details, see Section 6 of this manual.

TCmini → Robot controller main unit (R200 ~ R37F)

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R20W																
R21W																
R22W																
R23W																
R24W																
R25W																
R26W																
R27W																
R30W																
R31W																
R32W																
R33W																
R34W																
R35W																
R36W																
R37W																

Robot controller main unit → TCmini (R400 ~ R57F)

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R40W																
R41W																
R42W																
R43W																
R44W																
R45W																
R46W																
R47W																
R50W																
R51W																
R52W																
R53W																
R54W																
R55W																
R56W																
R57W																

4.4 Edge Relay

A total of 64 edge relays (E000 ~ E03F) are available.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
E00W																
E01W																
E02W																
E03W																

E*** Once the condition is ON, the edge relay turns on only for one (1) scan time. To turn on the relay again, set OFF the condition once, then ON.

4.5 Latch Relay

A total of 32 latch relays (L000 ~ L01F) are available.

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
L00W																
L01W																

L*** Once the condition is ON, the latch relay remains on until the reset input is ON.

4.6 Timer/Counter

T/C000 ~ T/C05F are the common relays of the timer and counter.
Relay T000 used as the timer cannot be used as the C000 counter. Select either one.



ビット	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
T/C00W																
T/C01W						Timer (100 ms) or counter										
T/C02W																
T/C03W																
T/C04W						Timer (10 ms) or counter										
T/C05W																




T*** 100 msec timer (T000 ~ T03F) / 10 msec timer (T040 ~ T05F)
Once the condition is ON, the timer relay decrements a value set on the timer every 100 ms or 10 ms. When the value has reached zero (0), the timer turns on.

C*** The counter relay turns on when the number of pulses equal to a value set on the counter is input.
When the counter reset input turns on, the counter value is reset to the set value.

4.7 Special Auxiliary Relay

A relay whose address starts with A signifies the special auxiliary relay.

Register	Address	Descriptions	
Operation flag	A000	[Carry flag]: Turns on when the result of arithmetic operation includes a carry or borrow.	
	A002	[Overflow flag]: Turns on when the result of arithmetic operation includes an overflow.	
	A006	[Zero flag]: Turns on when the result of arithmetic operation is zero (0).	
	A007	[Sign flag]: Turns on when the MSB of arithmetic operation result is "1".	
Alarm flag	A014	Instantaneous power failure flag.	
	A016	Fuse blowout detection flag.	
Scan time	A03L	The scan time is displayed in BIN code and in units of "ms" under the byte register address (A03L).	
50 ms clock pulse	A038	50 ms	50 ms clock pulse The reference clock is 50 ms (A038). 
	A039	100 ms	
	A03A	200 ms	
	A03B	400 ms	
	A03C	800 ms	
	A03D	1600 ms	
	A03E	3200 ms	
	A03F	6400 ms	
10 ms clock pulse	A040	10 ms	10 ms clock pulse The reference clock is 10 ms (A040). 
	A041	20 ms	
	A042	40 ms	
	A043	80 ms	
	A044	160 ms	
	A045	320 ms	
	A046	640 ms	
	A047	1280 ms	

Register	Address	Descriptions	
100 ms clock pulse	A048	100 ms	100 ms clock pulse The reference clock is 100 ms (A048). 
	A049	200 ms	
	A04A	400 ms	
	A04B	800 ms	
	A04C	1600 ms	
	A04D	3200 ms	
	A04E	6400 ms	
	A04F	12800 ms	
1 s clock pulse	A050	1 s	1 s clock pulse The reference clock is 1 s (A050). 
	A051	2 s	
	A052	4 s	
	A053	8 s	
	A054	16 s	
	A055	32 s	
	A056	64 s	
	A057	128 s	
10 s clock pulse	A058	10 s	10 s clock pulse The reference clock is 10 s (A058). 
	A059	20 s	
	A05A	40 s	
	A05B	80 s	
	A05C	160 s	
	A05D	320 s	
	A05E	640 s	
	A05F	1280 s	

Section 5 Registers

A total of 256 registers (D000 ~ D17F) are available for the TCmini.

5.1 Data Register

Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
D00*																
D01*							Data registers									
D02*																
D03*																
D04*																
D05*																
D06*						Data registers (backup)										
D07*																
D10*																
D11*																

The data register is a word length (16-bit) register which cannot be specified as the byte (8-bit) register.
The operation result is written as the destination in the user's program.
The operation result can be used as the source in the user's program.

Each time the data of D060 ~ D11F has been changed, it is written to the EEPROM and held there. Writing of up to one (1) million counts is possible. When using this register as the job register, take careful precautions. (Each time the data has been changed, writing of EEPROM is executed.)

5.2 Interface Register

The interface register serves as the interface area for transferring data with the main unit of the robot controller.

Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
D12*																
D13*																
D13*																
D14*																
D15*																
D16*																
D17*																

For details, see Section 6 of this manual.

5.3 Timer/Counter Current Value Register

P000 ~ P05F are the timer/counter current value registers. Current values can be referred to and set in the sequence program.

Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
P00*					Timer (100 ms)/counter current values											
P01*																
P02*																
P03*																
P04*					Timer (10 ms) /counter current values											
P05*																

P*** If used as the source in the user's program, the timer/counter current value can be read. (Backward timer and counter)
If written as the destination in the user's program during counting, the current value can be changed.
For the register used as the timer current value, the set value is equal to the current value at power ON, fall time (RUN → STOP) or timer OFF.
This is a word length (16-bit) register which cannot be specified as the byte register.

5.4 Timer/Counter Set Value Register

V000 ~ V05F are the timer/counter set value registers. Current values can be referred to and set in the sequence program.

Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
V00*					Timer (100 ms)/counter set values											
V01*																
V02*																
V03*																
V04*					Timer (10 ms) /counter set values											
V05*																

V*** If used as the destination in the user's program, the set value can be changed.
The area not used as the timer/counter can be used as the register.
This is a word length (16-bit) register which cannot be specified as the byte register.

Section 6 Robot Interface

Transfer of signals between the main unit of robot controller and TCmini is all performed through the interface relays and interface registers.
Each interface register has signal input and output directions.

6.1 TCmini → Main Unit of Robot Controller

TCmini → Main unit of robot controller (R200 ~ R37F)


Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R20W	DIN 16	DIN 15	DIN 14	DIN 13	DIN 12	DIN 11	DIN 10	DIN 9	DIN 8	DIN 7	DIN 6	DIN 5	DIN 4	DIN 3	DIN 2	DIN 1
R21W	DIN 32	DIN 31	DIN 30	DIN 29	DIN 28	DIN 27	DIN 26	DIN 25	DIN 24	DIN 23	DIN 22	DIN 21	DIN 20	DIN 19	DIN 18	DIN 17
R22W	DIN 48	DIN 47	DIN 46	DIN 45	DIN 44	DIN 43	DIN 42	DIN 41	DIN 40	DIN 39	DIN 38	DIN 37	DIN 36	DIN 35	DIN 34	DIN 33
R23W	DIN 64	DIN 63	DIN 62	DIN 61	DIN 60	DIN 59	DIN 58	DIN 57	DIN 56	DIN 55	DIN 54	DIN 53	DIN 52	DIN 51	DIN 50	DIN 49
R24W	DIN 116	DIN 115	DIN 114	DIN 113	DIN 112	DIN 111	DIN 110	DIN 109	DIN 108	DIN 107	DIN 106	DIN 105	DIN 104	DIN 103	DIN 102	DIN 101
R25W	DIN 132	DIN 131	DIN 130	DIN 129	DIN 128	DIN 127	DIN 126	DIN 125	DIN 124	DIN 123	DIN 122	DIN 121	DIN 120	DIN 119	DIN 118	DIN 117
R26W	DIN 148	DIN 147	DIN 146	DIN 145	DIN 144	DIN 143	DIN 142	DIN 141	DIN 140	DIN 139	DIN 138	DIN 137	DIN 136	DIN 135	DIN 134	DIN 133
R27W	DIN 164	DIN 163	DIN 162	DIN 161	DIN 160	DIN 159	DIN 158	DIN 157	DIN 156	DIN 155	DIN 154	DIN 153	DIN 152	DIN 151	DIN 150	DIN 149
R30W						LMIT OFF	MLT RST	OFS MOD	HAND IN8	HAND IN7	HAND IN6	HAND IN5	HAND IN4	HAND IN3	HAND IN2	HAND IN1
R31W	AL1-044	AL1-043	AL1-042	AL1-041	AL1-040	AL1-039	AL1-038	AL1-037	AL4-080	AL4-079	AL4-078	AL4-077	AL8-272	AL8-271	AL8-270	AL8-269
R32W									J_AXIS3	J_AXIS2	J_AXIS1	J_DIRECT	J_COD	J_SPEED	J_REMOTE	J_MOVE
R33W			I_TEACH	SV OFF	BREAK	LOW_SPD	CYCLE	STOP	EX_SVON	RUN	ALM_RST	DO_RST	CYC_RST	STEP_RST	PRG_RST	STROBE
R34W	DIN 316	DIN 315	DIN 314	DIN 313	DIN 312	DIN 311	DIN 310	DIN 309	DIN 308	DIN 307	DIN 306	DIN 305	DIN 304	DIN 303	DIN 302	DIN 301
R35W	DIN 332	DIN 331	DIN 330	DIN 329	DIN 328	DIN 327	DIN 326	DIN 325	DIN 324	DIN 323	DIN 322	DIN 321	DIN 320	DIN 319	DIN 318	DIN 317
R36W	DIN 348	DIN 347	DIN 346	DIN 345	DIN 344	DIN 343	DIN 342	DIN 341	DIN 340	DIN 339	DIN 338	DIN 337	DIN 336	DIN 335	DIN 334	DIN 333
R37W	DIN 364	DIN 363	DIN 362	DIN 361	DIN 360	DIN 359	DIN 358	DIN 357	DIN 356	DIN 355	DIN 354	DIN 353	DIN 352	DIN 351	DIN 350	DIN 349

R200 ~ R37F:
Signifies an exclusive output relay which outputs a signal to the main unit of the robot controller.
It serves as the destination of coil and data register in the sequence program, where operation result is written.
The operation result can be used as the source of contact and data register in the sequence program.
The operation result ON/OFF is transferred to the output device at I/O processing of every scan cycle.

Relays in the shaded areas are reserved for future extension of the system functions. Values are undecided and cannot be used.

The five (5) signals of STOP, CYCLE, LOW_SPD, BREAK and SVOFF are valid when they are low. Unless the signals are processed legally, the robot cannot be moved.

DIN1 ~ 64, DIN101 ~ 164 (Digital Input Signal)

Address	R200 ~ R23F, R240 ~ R27F
Direction	TCmini → Main unit of robot controller
Function	Interface relay corresponding to the robot's DIN command. In the WAIT DIN (1) command, it waits until DIN1 (R200) turns on.
Timing chart	 The width of a signal to be output should be 100 msec or over. If the signal width is too short, change in signal status may not be identified by the DIN command in some circumstances.
Remarks	Though the relay name is DIN (digital input signal), it is the output relay.


HANDIN1 ~ 8 (Hand Input Signal)

Address	R300 ~ R307
Direction	TCmini → Main unit of robot controller
Function	Interface relay corresponding to the robot's DIN command. Except for the exclusive monitor display for the hand (Para. 12.3 of Operator's Manual), the function is the same as DIN***.

Each signal corresponds to the DIN command as shown below.

Signal name	Relay address	Command
HANDIN1	R300	DIN201
HANDIN2	R301	DIN202
HANDIN3	R302	DIN203
HANDIN4	R303	DIN204
HANDIN5	R304	DIN205
HANDIN6	R305	DIN206
HANDIN7	R306	DIN207
HANDIN8	R307	DIN208

Timing chart



The width of a signal to be output should be 100 msec or over. If the signal width is too short, change in signal status may not be identified by the DIN command in some circumstances.

Remarks

Though the relay name is HANDIN (hand input signal), it is the output relay.


AL1–037 ~ 044 (Alarm of Level 1)
AL4–077 ~ 080 (Alarm of Level 4)
AL8–269 ~ 272 (Alarm of Level 8)

Address	AL1–037 ~ 044: R310 ~ R317 AL4–077 ~ 080: R318 ~ R31B AL8–269 ~ 272: R31C ~ R31F
Direction	TCmini → Main unit of robot controller
Function	Makes the robot in an alarm state from the TCmini.

Signal name	Relay address	Robot status
AL1–037	R310	Emergency stop
AL1–038	R311	
AL1–039	R312	
AL1–040	R313	
AL1–041	R314	Motion stop
AL1–042	R315	
AL1–043	R316	
AL1–044	R317	
AL4–077	R318	Message display
AL4–078	R319	
AL4–079	R31A	
AL4–080	R31B	
AL8–269	R31C	
AL8–270	R31D	
AL8–271	R31E	
AL8–272	R31F	

When alarm messages for respective alarms are registered in user parameters beforehand, any message can be displayed. For details, see the User Parameter Manual.

Timing chart



The width of a signal to be output should be 100 msec or over. If the signal width is too short, appropriate alarm may not be identified in some circumstances.

Remarks

Connect a signal relating to safety (such as emergency stop switch) to an external emergency stop signal processed by hardware (EMS1B ~ EMS1C, EMS2B ~ EMS2C).

J_MOVE (Jog Motion)
J_REMOTE (Selection of Jog Remote)
J_SPEED (Selection of Jog Speed)
J_COOD (Selection of Jog Coordinate)
J_DIRECT (Selection of Jog Direction)
J_AXIS1~3 (Selection of Jog Guidance Axis)

Address	R230 ~ R327

Direction	TCmini → Main unit of robot controller

Function	Commands a jog motion from the TCmini.

This signal is effective only in the EXT. SIG mode.
As long as the J_MOVE signal (R320) is kept ON, an axis specified under the following condition is moved by jog.
Signals of condition of motion and axis selection are judged at the start of J_MOVE.


Selection of condition for jog motion

Signal name	Relay address	0	1
J_REMOTE	R321	JOG	INCHING
J_SPEED	R322	LOW	HI
J_COOD	R323	JOINT	WORLD
J_DIRECT	R324	–	+

Axis/coordinate selection

Signal name	J_AXIS3	J_AXIS2	J_AXIS1
Relay address	R327	R326	R325
Axis 1/X	0	0	1
Axis 2/Y	0	1	0
Axis 3/Z	0	1	1
Axis 4/C	1	0	0
Axis 5/T	1	0	1


Timing chart



Remarks

Even if the motion condition or axis select signal has been changed while J_MOVE was ON, the motion remains the same.

STROBE (Strobe Signal)


Address	R330
Direction	TCmini → Main unit of robot controller
Function	Selects a program registered in the robot controller from the TCmini. This signal is valid only in the EXT. SIG mode. The program number selected uses any consecutive "n" external digital input signals (max. four (4) signals) and is input by code.
Timing chart	 With the start of STROBE, the above digital signals are read to select an appropriate program. When the program has been selected, the ACK signal turns on. Set ON the RUN signal and execute the program.
Remarks	DO NOT input the STROBE signal together with the PRG_RST, CYC_RST, STEP_RST or DO_RST signal. Because the ACK signal is used in common, only the first signal which is input becomes valid and all other signals are invalid. If a file other than the current file is selected, the program is reset to step 1 and all values of variables are also reset. The program name and external select signal should be set in the USER.PAR file.

```
[U07] Specify signal for EXTSELECT
   {Signal No } (1 – 64,101 – 164)
   {Bit length } (1 – 4)
= 2   3
[U08] EXTSELECT file
= "PROG0"
= "PROG1"
= "PROG2"
= "PROG3"
····· Omitted ·····
```


When the setting is as shown above, a file is selected by the three (3) signals, starting from DIN2 (R201 ~ R203).

DIN4	DIN3	DIN2	
OFF	OFF	ON	Selection of PROG1
OFF	ON	ON	Selection of PROG3


PRG_RST (Program Reset)

Address	R331
Direction	TCmini → Main unit of robot controller
Function	Resets an interrupted program to step 1 from the TCmini. Also resets the value of each variable to "0". This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	DO NOT input the PRG_RST signal together with the STROBE, CYC_RST, STEP_RST or DO_RST signal. Because the ACK signal is used in common, only the first signal which is input becomes valid and all other signals are invalid.


STEP_RST (Step Reset)

Address	R332
Direction	TCmini → Main unit of robot controller
Function	Resets an interrupted program to step 1 from the TCmini. The value of each variable used in the program remains intact. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	DO NOT input the STEP_RST signal together with the STROBE, PRG_RST, CYC_RST, or DO_RST signal. Because the ACK signal is used in common, only the first signal which is input becomes valid and all other signals are invalid.


CYC_RST (Step Reset)

Address	R333
Direction	TCmini → Main unit of robot controller
Function	Resets an interrupted program to the step of RCYCLE label from the TCmini. The value of each variable used in the program remains intact. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	DO NOT input the CYC_RST signal together with the STROBE, PRG_RST, STEP_RST, or DO_RST signal. Because the ACK signal is used in common, only the first signal which is input becomes valid and all other signals are invalid.


DO_RST (Output Signal Reset)

Address	R334
Direction	TCmini → Main unit of robot controller
Function	Interface relay which resets the digital output signals (DOUT1 ~ DOUT64, DOUT101 ~ DOUT164) from the TCmini. Once reset, all of R400 ~ R47F turn off. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	DO NOT input the DO_RST signal together with the STROBE, PRG_RST, CYC_RST or STEP_RST signal. Because the ACK signal is used in common, only the first signal which is input becomes valid and all other signals are invalid. The hand control signals (HANDOUT1 ~ 8) are not reset at all.


ALM_RST (Alarm Reset)

Address	R335
Direction	TCmini → Main unit of robot controller
Function	Resets from the TCmini an alarm which occurred in the robot controller. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	If an alarm of the emergency stop level in which servo ON is not possible, or the "emergency stop ON" is output, alarm reset by ALM_RST is not allowed.



RUN (Start)

Address	R336
Direction	TCmini → Main unit of robot controller
Function	Starts a program registered in the robot controller from the TCmini to execute an automatic cycle operation. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	With the start of RUN, automatic operation starts. Set ON the RUN signal only after the SV_RDY signal is ON and the robot is ready to operate. If the RUN signal is set ON while the SV_RDY signal is OFF, the RUN signal is neglected.

EX_SVON (External Servo ON)


Address	R337
Direction	TCmini → Main unit of robot controller
Function	Turns on the servo driver power from the TCmini. Once the servo power is turned on, it is maintained even after this signal turns off. This signal is operative only in the EXT. SIG mode.
Timing chart	
Remarks	It takes about 1.5 seconds from the servo ON to the time when the robot is actually ready to work (i.e., the time when the SV_RDY signal is ON). To set ON this signal again just after the servo OFF, wait at least five (5) seconds. When setting on the RUN signal, etc., wait until SV_RDY turns on.

STOP (Stop)

Address	R338
Direction	TCmini → Main unit of robot controller
Function	Stops executing a program registered in the robot controller from the TCmini. The program stops only after the current motion command has been executed while this signal was OFF (i.e., low). After the stop, the robot enters a STOP (CONT) state. The robot will not work even if this signal is set ON after stop of the robot motion. This signal is always operative, irrespective of the master mode selected by means of the MODE switch.
Timing chart	 Note: Duration covering from the start of one motion command to just before the start of next motion command is called the"1 segment".
Remarks	1. When the RUN command is executed after cancel of the stop, the program restarts from the step next to the interrupted step. 2. RUN signal input is ineffective at the input of stop signal. 3. Unless this signal is used, always set it ON in the sequence circuit. 

CYCLE (Cycle Operation Mode)

Address	R339
Direction	TCmini → Main unit of robot controller
Function	Stops from the TCmini a program registered in the robot controller after current one (1) cycle operation has been executed during automatic operation. When this signal is OFF (i.e., low), cycle stop is effected. This signal is operative only in the EXT. SIG mode.
Timing chart	




Note 1: Duration covering from the start of one motion command to just before the start of next motion command is called the"1 segment".



Note 2: Duration from the top of the main program to the END command is called the "1 cycle".

Remarks

1. When the RUN command is executed after cancel of the cycle operation mode, the continuous operation starts from the cycle next to the interrupted cycle.
2. Unless this signal is used, always set it ON in the sequence circuit.




LOW_SPD (Low Speed Command)

Address	R33A
Direction	TCmini → Main unit of robot controller
Function	Causes the robot operation speed to low speed from the TCmini. The robot operates at a low speed while this signal is OFF (i.e., low). The robot operation speed in the low speed mode can be set by means of the parameter. (Initial set value: 25 %) When this signal is OFF (i.e., low), the override value changes. When the signal is ON, the previously set value takes effect again. This signal is always effective, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	1. During the low speed command, an override set in the parameter beforehand is effected on all motion speeds. 2. Unless this signal is used, always set it ON in the sequence circuit. 

BREAK (Deceleration and Stop)

Address	R33B
Direction	TCmini → Main unit of robot controller
Function	Stops the robot motion from the TCmini. The robot slows down and stops at the same time that this signal is OFF (i.e., low). After the stop, the robot enters a STOP (RETRY) state. The robot will not work even if this signal is set ON after stop of the robot motion. This signal is always effective, irrespective of the master mode selected by means of the MODE switch.


Timing chart





Note: Duration covering from the start of one motion command to just before the start of next motion command is called the"1 segment".

Remarks

1. When the RUN command is executed after cancel of the break, the program restarts from the step next to the interrupted step.
2. RUN signal input is ineffective at the input of BREAK signal.
3. Unless this signal is used, always set it ON in the sequence circuit.



SVOFF (Servo OFF)

Address	R33C
Direction	TCmini → Main unit of robot controller
Function	Turns off the servo driver main power from the TCmini. While this signal is OFF (i.e, low), the servo power is turned off. This signal is always effective, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	1. While the this signal is OFF, the servo power cannot be turned on in any mode. 2. Unless this signal is used, always set it ON in the sequence circuit. 

6.2 Main Unit of Robot Controller → TCmini

Main unit of robot controller → TCmini (R400 ~ R57F)

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R40W	DOUT 16	DOUT 15	DOUT 14	DOUT 13	DOUT 12	DOUT 11	DOUT 10	DOUT 9	DOUT 8	DOUT 7	DOUT 6	DOUT 5	DOUT 4	DOUT 3	DOUT 2	DOUT 1
R41W	DOUT 32	DOUT 31	DOUT 30	DOUT 29	DOUT 28	DOUT 27	DOUT 26	DOUT 25	DOUT 24	DOUT 23	DOUT 22	DOUT 21	DOUT 20	DOUT 19	DOUT 18	DOUT 17
R42W	DOUT 48	DOUT 47	DOUT 46	DOUT 45	DOUT 44	DOUT 43	DOUT 42	DOUT 41	DOUT 40	DOUT 39	DOUT 38	DOUT 37	DOUT 36	DOUT 35	DOUT 34	DOUT 33
R43W	DOUT 64	DOUT 63	DOUT 62	DOUT 61	DOUT 60	DOUT 59	DOUT 58	DOUT 57	DOUT 56	DOUT 55	DOUT 54	DOUT 53	DOUT 52	DOUT 51	DOUT 50	DOUT 49
R44W	DOUT 116	DOUT 115	DOUT 114	DOUT 113	DOUT 112	DOUT 111	DOUT 110	DOUT 109	DOUT 108	DOUT 107	DOUT 106	DOUT 105	DOUT 104	DOUT 103	DOUT 102	DOUT 101
R45W	DOUT 132	DOUT 131	DOUT 130	DOUT 129	DOUT 128	DOUT 127	DOUT 126	DOUT 125	DOUT 124	DOUT 123	DOUT 122	DOUT 121	DOUT 120	DOUT 119	DOUT 118	DOUT 117
R46W	DOUT 148	DOUT 147	DOUT 146	DOUT 145	OUT 144	DOUT 143	DOUT 142	DOUT 141	DOUT 140	DOUT 139	DOUT 138	DOUT 137	DOUT 136	DOUT 135	DOUT 134	DOUT 133
R47W	DOUT 164	DOUT 163	DOUT 162	DOUT 161	DOUT 160	DOUT 159	DOUT 158	DOUT 157	DOUT 156	DOUT 155	DOUT 154	DOUT 153	DOUT 152	DOUT 151	DOUT 150	DOUT 149
R50W							MLT END	OFS END	HAND OUT8	HAND OUT7	HAND OUT6	HAND OUT5	HAND OUT4	HAND OUT3	HAND OUT2	HAND OUT1
R51W									SEQ PAR8	SEQ PAR7	SEQ PAR6	SEQ PAR5	SEQ PAR4	SEQ PAR3	SEQ PAR2	SEQ PAR1
R52W	O16_ SEL	O15_ SEL	O14_ SEL	O13_ SEL	O12_ SEL	O11_ SEL	O10_ SEL	O9_ SEL	I16_S EL	I15_S EL	I14_S EL	I13_S EL	I12_S EL	I11_ SEL	I10_S EL	I9_ SEL
R53W			ALAR M	BT_ ALM	CYC _ST	LOW _ST	CYC _END	AUTO RUN	SYS_ RDY	EST HOST	EXT SIG	INT	TEAC H	ACK	SV_ RDY	EMG_ ST
R54W	DOUT 316	DOUT 315	DOUT 314	DOUT 313	DOUT 312	DOUT 311	DOUT 310	DOUT 309	DOUT 308	DOUT 307	DOUT 306	DOUT 305	DOUT 304	DOUT 303	DOUT 302	DOUT 301
R55W	DOUT 332	DOUT 331	DOUT 330	DOUT 329	DOUT 328	DOUT 327	DOUT 326	DOUT 325	DOUT 324	DOUT 323	DOUT 322	DOUT 321	DOUT 320	DOUT 319	DOUT 318	DOUT 317
R56W	DOUT 348	DOUT 347	DOUT 346	DOUT 345	OUT 344	DOUT 343	DOUT 342	DOUT 341	DOUT 340	DOUT 339	DOUT 338	DOUT 337	DOUT 336	DOUT 335	DOUT 334	DOUT 333
R57W	DOUT 364	DOUT 363	DOUT 362	DOUT 361	DOUT 360	DOUT 359	DOUT 358	DOUT 357	DOUT 356	DOUT 355	DOUT 354	DOUT 353	DOUT 352	DOUT 351	DOUT 350	DOUT 349

R400 ~ R57F:


Signifies an exclusive input relay which receives an output signal from the main unit of the robot controller.

The ON/OFF is read at I/O processing of every scan cycle.

This relay can be used as the source of contact input information and data register in the sequence program. It cannot be used as the coil.

Relays in the shaded areas are reserved for future extension of the system functions. Values are undecided and cannot be used.

DOUT1 ~ 64, DOUT101 ~ 164

Address	R400 ~ R43F, R440 ~ R47F
Direction	Main unit of robot controller → TCmini
Function	Interface relay corresponding to the robot's DOUT command. It turns on and off when the I/O status has changed by the DOUT command, or AUX (auxiliary signal) operation or I/O (external I/O signal display) operation through the teach pendant. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	Though the relay name is DOUT, it is an input signal from the TCmini.

HANDOUT1 ~ 8

Address	R500 ~ R507
Direction	Main unit of robot controller → TCmini
Function	Interface relay corresponding to the robot's DOUT command.

It turns on and off when the I/O status has changed by the DOUT command, or AUX (auxiliary signal) operation or I/O (external I/O signal display) operation through the teach pendant.

HANDOUT1 ~ 8 cannot be reset by the DO_RST signal or output signal reset operation through the teach pendant.


This relay can be turned on and off manually on the exclusive hand monitor screen. (See Para. 12.3 of Operator's Manual.)

Each signal corresponds to the DOUT command as shown below.

Signal name	Relay address	Command
HANDOUT1	R500	DOUT201
HANDOUT2	R501	DOUT202
HANDOUT3	R502	DOUT203
HANDOUT4	R503	DOUT204
HANDOUT5	R504	DOUT205
HANDOUT6	R505	DOUT206
HANDOUT7	R506	DOUT207
HANDOUT8	R507	DOUT208

This relay is output, irrespective of the master mode selected by means of the MODE switch.


Timing chart



Remarks

Though the relay name is HANDOUT, it is an input signal from the TCmini.


SEQPAR1 ~ 8

Address	R510 ~ R517
Direction	Main unit of robot controller → TCmini
Function	Interface relay corresponding to the robot's user parameter ([U15] Sequence parameter). When the power is turned on, parameter values are set in respective relays. If you form a circuit that allows access to this relay, the sequence motion can be changed by the user parameter, without changing over the sequence.
Timing chart	 The destination changes with the setting of user parameter [U15].
Remarks	The sequence parameter should be set in [U15] of USER.PAR. [U15] Sequence Parameter (User I/Omode only) = 0 0 0 0 0 0 0 0 Set in the order of R510, R511, R512, R513, R514, R515, R516 and R517 in this order. 0 : OFF 1 : ON


I9_SEL ~ I16SEL
O9_SEL ~ O16SEL

Address	R520 ~ R527, R528 ~ R52F
Direction	Main unit of robot controller → TCmini
Function	Interface relays corresponding to the robot's user parameters [U13] and [U14]. When the power is turned on, parameter values are set in respective relays.
Timing chart	
Remarks	This interface relay is used in the maker's standard sequence. DO NOT use it in the user's sequence.


EMG_ST

Address	R530
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating the state of the EMERGENCY stop pushbutton switch. It turns off when the emergency stop is effected. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	

SV_RDY


Address	R531
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating the robot servo status. When the robot program can be started after servo ON, this relay also turns on. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	It takes about 1.5 seconds until RV_RDY turns on after servo power ON. Keep five (5) seconds or over from the servo power OFF to the next servo power ON.

ACK (Acknowledge)

Address	R532
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating a response to the input of STROBE, PRG_RST, STEP_RST, CYC_RST and DO_RST. When one of these signals is input, the ACK signal is sent back to inform that the appropriate processing has finished.
Timing chart	
Remarks	If two (2) or more signals shown above are input at the same time, only the signal which was input first is processed, then the ACK signal is output.


TEACH (Teach Mode ON)
INT (Internal Automatic Mode ON)
EXTSIG (External Automatic Signal Mode ON)
EXTHOST (External Automatic Host Mode ON)

Address	R533 ~ R536
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating the master mode status of the robot. The master mode can be changed over by means of the MODE switch equipped on the control panel.
Timing chart	




SYS_RDY (System Ready)


Address	R537
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating a status in which the controller can be operated normally. When the internal startup processing has finished following power ON, this signal turns on. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	



AUTORUN (Auto Mode ON)


Address	R538
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating that the robot is working in the automatic operation mode. This signal remains on as long as the robot is working in the automatic operation mode. Note: The automatic operation stated above signifies a status of program execution (RUN) in the INTERNAL (i.e., internal automatic mode), EXT. SIGNAL (i.e., external automatic signal mode) or EXT. HOST (i.e., external automatic host mode).
Timing chart	
Remarks	This signal is not output during the TEACHING mode.

CYC_END (Cycle End)

Address	R539
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating the finish of program execution. This signal turns on after the stop of 1-cycle automatic operation only when the cycle operation mode is selected and an automatic operation is executed. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	This relay turns off when the program execution (RUN) mode takes effect. It turns on when the cycle operation has been stopped by the STOP, BREAK or ALARM signal.


LOW_ST (Low Speed Mode ON)

Address	R53A
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating that the robot is operating in the low speed mode. It turns on while the robot is working in the low speed mode by the input of LOW_SPD (interface relay). This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	




CYC_ST (Cycle Mode ON)


Address	R53B
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating that the robot is operating in the cycle mode. It turns on while the robot is working in the cycle mode by the input of CYCLE (interface relay) or by the operation through the teach pendant. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	



BT_ALM (Battery Alarm)

Address	R53C
Direction	Main unit of robot controller → TCmini
Function	Turns on if a battery alarm has occurred in the robot controller. The battery alarm comes in the following six (6) kinds. 1–049 Axis1 Battery alarm 1–065 Axis2 Battery alarm 1–081 Axis3 Battery alarm 1–097 Axis4 Battery alarm 1–113 Axis5 Battery alarm 1–145 MAIN Battery alarm This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	
Remarks	If the battery alarm has occurred, replace the battery immediately, referring to the Maintenance Manual.

ALARM (Alarm)

Address	R53D
Direction	Main unit of robot controller → TCmini
Function	Interface relay indicating an error of level 2, 4 or 8 in the robot controller or robot. This relay is kept ON during error detection and turns off after the error has been cleared. For details on the errors, see the Operator's Manual. This relay is output, irrespective of the master mode selected by means of the MODE switch.
Timing chart	

6.3 Interface Register

This is an interface area for transferring data with the main unit of the robot controller.

Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
D12*																
D11*	AL10	AL09	AL08	AL07	AL06	AL05	AL04	AL03	AL02	AL01	AL NO					STEP
D14*																
D15*																USER
D16*			PSN_W6	PSN_W5	PSN_W4	PSN_W3	PSN_W2	PSN_W1	PLC DATA R8	PLC DATA R7	PLC DATA R6	PLC DATA R5	PLC DATA R4	PLC DATA R3	PLC DATA R2	PLC DATA R1
D17*			PSN_J6	PSN_J5	PSN_J4	PSN_J3	PSN_J2	PSN_J1	PLC DATA W8	PLC DATA W7	PLC DATA W6	PLC DATA W5	PLC DATA W4	PLC DATA W3	PLC DATA W2	PLC DATA W1

Data registers reserved for the system

STEP

Address	D130
Direction	Main unit of robot controller → TCmini
Function	Used to indicate the line number of an active program. As the robot program is executed during execution of pre-analysis, the indicated line number may not coincide with real robot motion. This data can provide only a yardstick.

ALNO, AL01 ~ AL10

Address	D135 ~ D13F
Direction	Main unit of robot controller → TCmini
Function	ALNO (D135) signifies the number of alarms currently generated. During alarm generation, relevant alarm number is indicated by AL01 (D136) ~ AL10 (D13F). Ex.) When the alarm of "8–014" has occurred: D135: 1 D136: 8014 (decimal number)

USER

Address	D150
Direction	TCmini → Main unit of robot controller
Function	Used to output a value to the 7-segment display on the user panel. The displayed value ranges from 0 to 65535.

PLCDATAR1 ~ 8

Address	D160 ~ D167
Direction	TCmini → Main unit of robot controller
Function	Transfers ladder operation result and other data to the main unit of the robot controller. Transferred data can be referred to by the robot program. In the robot program, values can be read by system variables PLCDATAR1 ~ 8. A value written in PLCDATAR* should be 0 ~ 65535. If it exceeds this range, it cannot be transferred accurately.

PLCDATAW1 ~ 8

Address	D170 ~ D177
Direction	Main unit of robot controller → TCmini
Function	The TCmini can receive the operation results of the robot program. In the robot program, values can be written to system variables PLCDATAW1 ~ 8. A value written in PLCDATAW* should be 0 ~ 65535. If it exceeds this range, it cannot be transferred accurately.

PSN_W1 ~ 6

Address	D168 ~ D16D
Direction	Main unit of robot controller → TCmini
Function	Current position in the world coordinate system of robot can be received by the TCmini. This value is an integer in the range of –32768 ~ 32767 mm (deg). All fractions are ignored.


PSN_J1 ~ 6

Address	D178 ~ D17D
Direction	Main unit of robot controller → TCmini
Function	Current position in the joint coordinate system of robot can be received by the TCmini. This value is an integer in the range of –32768 ~ 32767 mm (deg). All fractions are ignored.

Section 7 PLC Language

7.1 Sequence Program

The TCmini supports sequence programs made according to the graphical programming method. They can be created by the user in any format.



I/O processing

Batch refreshing of inputs and outputs is used for I/O processing.
(Before starting arithmetic operation, the input ON/OFF state is transferred to the data memory, and the arithmetic result of the data memory is transferred to the output device.)

Execution of user's program


On completion of I/O processing, the user's program is sequentially operated from the leading circuit.

The operation is as follows:


- Sequentially on a circuit basis.
- From left to right on a column basis within one (1) circuit. (The input part is first operated, then the output part is processed .)
- The operation continues to the P. END instruction (program end instruction). The P. END instruction is automatically included at the end of the user's program. Thus only actually used words of the user's program are operated.

Note 1: The coil instruction is written into the data memory every time the operation is executed and has an influence on the subsequent contacts. However, the output state remains unchanged until the output processing is executed in the pack after completion of entire operation.

Note 2: State change of the contact written before the coil occurs in the scan next to the one in which the coil state changed.



Coil R000 is turned on with delay of one (1) scan after X000 is ON.




If the order of the left circuit is replaced, R100 is turned on in the same scan as X000 ON.

As known from the above, if the circuit order is replaced, the operation result may differ.

7.2 Program Capacity and Length of Instruction Word


The TCmini instruction has 16 bits as the basic length. According to the type of instruction, five (5) types of word length (1-word, 2-word, 3-word, 4-word and 5-word) are available for the instruction length.
The program memory is Approx. 4000 words and secured according to each instruction.

1-word instruction



2-word instruction

Note: In addresses E000 ~ E03F, two (2)-word instructions are set.



3-word instruction

F*035 Increment	F*036 Decrement	F*040 Arithmetic left shift	F*041 Left rotate
F*042 Right shift	F*043 Right rotate	F*049 Subroutine start	F*058 Subroutine call
F*059 Subroutine return	F*063 1-scan ON		

4-word instruction

F*000 Data transfer	F*001 Constant set	F*002 High-order 8 bits data transfer	F*010 BIN → BCD conversion without sign
F*011 BCD → BIN conversion without sign	F*012 BIN → BCD conversion with sign	F*013 BCD → BIN conversion with sign	F*045 4 → 16 decoder


5-word instruction

F*006 Block transfer by constant designation	F*009 Data extraction and distribution	F*020 BIN addition	F*021 BIN addition with carry
F*022 BIN subtraction	F*023 BIN subtraction with borrow	F*024 BIN multiplication without sign	F*025 BIN division without sign
F*032 Logical product	F*033 Logical sum	F*034 Exclusive logical sum	F*037 Comparison without sign
F*038 Comparison with sign	F*047 Bit test by constant designation		

7.3 Address

(1) Relay address

The relay address consists of a relay number following the function division symbol.
The I/O relay address corresponds to actual relay mounted position, and the other relays correspond to physically absent devices. The relay address is assigned for each I/O number (1 bit).




Relay No. 1st digit (0 ~ F) Hexadecimal number
Relay No. 2nd digit (0 ~ 7) Octal number
Relay No. 3rd digit (0 ~ F) Hexadecimal number
Function division symbol (X, Y, R, T, C, L, E, A)

The function division symbol is an uppercase letter.

(2) Data register address


The data register address is represented in the same manner as the relay address.
The relay address is assigned on a number (1 bit) basis while the data register address is assigned on a word (16-bit) basis.



Register No. 1st digit (0 ~ F) Hexadecimal number
Register No. 2nd digit (0 ~ 7) Octal number
Register No. 3rd digit (0 ~ F) Hexadecimal number
Function division symbol (D, V, P)

The function division symbol is an uppercase letter.

Data register configuration



(3) Byte register address and word register address of relay area

The relay area can be used as a byte register on an eight (8)-number basis and as a word register on a 16-number basis.
For the register address, relay number 1st digit of the relay address signifies the register type instead.

□ □ □ □

Register type
W : Word register (16 numbers F ~ 0)
H : High-order byte register (8 numbers F ~ 8)
L : Low-order byte register (8 numbers 7 ~ 0)
Relay/register No. 2nd digit (0 ~ 7)
Relay/register No. 3rd digit (0 ~ F)
Function division symbol (X, Y, R, T, C, L, E, A)

The function division symbol is an uppercase letter.

Example: When X130 to X13F are specified by the word register and byte register, each bit corresponds to the following relay address.

X13W

MSB 15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	LSB 0
X13F	X13E	X13D	X13C	X13B	X13A	X139	X138	X137	X136	X135	X134	X133	X132	X131	X130

X13L


MSB 7	6	5	4	3	2	1	LSB 0
X137	X136	X135	X134	X133	X132	X131	X130

X13H

MSB 7	6	5	4	3	2	1	LSB 0
X13F	X13E	X13D	X13C	X13B	X13A	X139	X138


(4) Indirect register address

In the indirect register, an address can be identified by the specified register content (data) and a content under this address can be handled as the word data. The function division symbol at the head of the indirect register address is represented by a small letter (data register or relay register) and the remaining data of the same address are expressed in the same manner as in the data register address or relay register address.



The function division symbol is a lowercase letter.

Example:



If 100H is specified for D020 in the above circuit, for instance, d020 signifies D100. (See the correspondence table below.) Thus, in this circuit, data in D100 is transferred to D000.

Correspondence table of data value and indirect address

Data value (Hex.)	Corresponding address
D register	
0000H (0001H)	D000
0002H (0003H)	D001
≈	
001EH (001FH)	D00F
0020H (0021H)	D010
≈	
00FEH (00FFH)	D07F
0100H (0101H)	D100
≈	
01FEH (01FFH)	D17F
P register	
1000H (1001H)	P000
1002H (1003H)	P001
≈	
101EH (101FH)	P00F
1020H (1021H)	P010
≈	
10BEH (10BFH)	P05F
V register	
1800H (1801H)	V000
1802H (1803H)	V001
≈	
181EH (181FH)	V00F
1820H (1821H)	V010
≈	
18BEH (18BFH)	V05F


Data value (Hex.)	Corresponding address
X/Y register	
3000H (3001H)	X/Y00W
3002H (3003H)	X/Y01W
≈	
300EH (300FH)	X/Y07W
3010H (3011H)	X/Y10W
≈	
301EH (301FH)	X/Y17W
R register	
3100H (3101H)	R00W
3102H (3103H)	R01W
≈	
310EH (310FH)	R07W
3110H (3111H)	R10W
≈	
311EH (311FH)	R17W
T/C register	
3180H (3181H)	T/C00W
3182H (3183H)	T/C01W
≈	
31BAH (318BH)	T/C05W
L register	
31C0H (31C1H)	L00W
31C2H (31C3H)	L01W
A register	
31E0H (31E1H)	A00W
≈	
31FCH (31FDH)	A16W


Data value (Hex.)	Corresponding address
E register	
3480H (3481H)	E00W
3482H (3483H)	E01W
3484H (3485H)	E02W
3486H (3487H)	E03W

A register signified by the indirect register is identified from the correspondence table given in Para. (4) above. As data values and addresses are arranged consecutively for each register, this function is very useful for a program requiring table processing.

Example: Assume that positioning parameter information consisting of four (4) words per block is set in registers D000 to D043. To set in registers D050 to D053 the four (4)-word positioning information corresponding to the parameter number (0 ~ 16) input in external input register X00L, program as follows:

<Positioning information table>





<Descriptions on program>





[1] The parameter number (X00L) is multiplied by the number of bytes per block (in this example, 4 words = 8) to identify a relative address from the table.


[2] Four (4)-word data are transferred in block into D050 and after, taking the data value set in D05F as the start address (in this example, either of D000 ~ D043).

7.4 Configuration of Instruction Word


As the TCmini uses the ladder symbolic direct input method for the programming language, it has the instructions corresponding to the circuit diagram.

Configuration of 1-word instruction

Instruction code	Function division symbol	Address
⇓	⇓	⇓
	X: Input Y: Output R: Internal relay R: Interface relay L: Latch T: Timer C: Counter A: Special auxiliary relay	000 ~ 17F Note: Same addresses are shared by X and Y. 000 ~ 17F 200 ~ 57F 000 ~ 01F 000 ~ 05F Note: Same addresses cannot be shared by T and C. 000 ~ 16F
	Y: Output R: Internal relay R: Interface relay L: Latch	000 ~ 17F 000 ~ 17F 200 ~ 37F 000 ~ 01F
	L: Latch reset	000 ~ 01F
	T: Timer C: Counter	000 ~ 05F Note: Same addresses cannot be shared by T and C.
	C: Counter reset	


	None	None


Configuration of 2-word instruction

Instruction code	Function division symbol	Address
⇓	⇓	⇓
	E: Differentiating relay	000 ~ 03F

7.4.1 Contact


(a) Serial connection operation






The operation serially connected to the operation result so far is made. (logical product: AND)

(b) Branch-connected operation







The operation branch-connected (in parallel) with the operation result so far is made. (logical sum: OR)

7.4.2 Unconditional Connection

(a) Unconditional connection







The operation result so far is operated serially, serially and in parallel, and in parallel.

7.4.3 Blank



(a) Blank






Corresponds to the part enclosed by dotted line in the figure. It can be ignored at programming.
This instruction is effective to delete an instruction at circuit correction.






7.4.4 Internal Relay

Symbol		
Function	Turned ON when the input signal is ON.	
Executing condition	The input signal must be ON.	
R1 range	R000 ~ R17F (256 Nos.) R200 ~ R37F (Interface relay)	When inputs X000 and X001 are turned ON or when X002 is turned ON, R000 is turned ON.


7.4.5 Latch Relay


Symbol	Latch condition Reset input 	
Function	Kept ON until the reset input is ON when the latch condition is turned ON.	When X000 is ON with X001 set OFF, L000 is ON and this state is held until X001 is ON.
Executing condition	The latch condition must be turned ON with the reset input OFF.	
L1 range	L000 ~ L01F (32 Nos.)	
Power failure backup function	Power failure can't be backed up through the entire area.	

7.4.6 Timer

Symbol		
Function	Relay T1 is turned ON after the time specified by constant K2 has passed.	T000 is ON five (5) seconds after X000 is ON.
Executing condition	The input signal must be ON.	
T1 range (BIN)	T000 ~ T05F (96 Nos.) 0.1 ~ 3276.7 sec. □ Shared with counter address.	
Set value K2 range	1 ~ 65535 1H ~ FFFFH (BIN data)	• The timer set value is set in a program, which can be changed through data transfer to V000 to V05F.
Timer set value register	V000 ~ V05F (96 Nos.) Shared with counter.	
Timer current value register	P000 ~ P05F (96 Nos.) Shared with counter.	• Backward timer


- OFF delay timer circuit





When X000 is ON, R000 is ON. X000 is OFF. One (1) second after the set time on T000 following X000 OFF, R000 is OFF.
It should be noted that R000 is ON for the T000 set time after the PC runs by power ON.



- ON/OFF delay timer circuit



When X000 is ON, R000 is turned ON three (3) seconds after the set time of T000. R000 is OFF two (2) seconds after the set time of T001 following X000 OFF.


The timer is of a backward type and the current value is equal to the set value at start and zero (0) at ON.

7.4.7 Counter


Symbol	Counter input Reset input 	
Function	Relay C1 is turned ON when pulses are input by the number specified by constant K2.	
Executing condition	When the counter input rises from OFF to ON.	
C1 range	C000 ~ C05F (96 Nos.) Shared with timer address.	
Set value K2 range	1 ~ 32767 1H ~ FFFFH (BIN data)	• The counter set value is set in a program, which can be changed through data transfer to V000 to V05F.
Counter set value register	V000 ~ V05F (96 Nos.) Shared with timer.	
Counter current value register	P000 ~ P05F (96 Nos.) Shared with timer.	• Backward counter

The counter current value register is set to zero (0) at program loading. Reset the counter coil to the set value.

- Large-capacity counter circuit



With countup of C000, C001 is counted. C001 is turned ON after counting is made (9999 + 1872 –1 = 11870).




7.5 Standard Application Instruction

The TCmini has a total of thirty-two (32) kinds of application instructions.
In the user's program, up to 512 application instructions can be used.


7.5.1 Selection of Executing Condition

The TCmini allows selection of the condition for executing an application instruction. When executing the application instruction while the condition is set ON, write "FL***" (L: level). To execute the application instruction at start, write "FE***" (E: edge).

Example:



When condition X000 is ON, data is transferred from D100 to D000 at each scanning.




Only in one (1) scan in which condition X000 has changed from OFF to ON, data is transferred from D100 to D000.

7.5.2 Arbitrary Setting of Argument

In the TCmini application instruction, the type of argument (i.e., direct register, indirect register or constant) can be selected arbitrarily. (However, the type of argument is predetermined for some application instructions.)

Example:




7.5.3 Numeric Expression

(1) Binary code

A numeric value represented by two (2) states of "0" (OFF) and "1" (ON) is called the binary code.
In a decimal number, a number increases to 0, 1, 2, ⋯ 8, 9. When it reaches 10, it is carried. In a binary number, a number next to 1 is carried to 10.
Binary number 10 corresponds to 2 in the decimal notation.


Decimal number	0	1	2	3	4	5	6	7	8
Binary number	0	1	10	11	100	101	110	111	1000

When the decimal number is compared with the binary number, binary numbers corresponding to 2, 4 and 8 in decimal notation are carried.
The decimal number is carried when it is 1, 10, 100, 1000. When these numbers are expressed in power, they are 10^0 (= 1), 10^1 (= 10), 10^2 (= 100) and 10^3 (= 1000). These are called the "significance" of each digit of decimal numbers. From the above table, each digit of binary number is as shown below.



Each digit has the significance of 2. Each digit of binary number is called the "bit".
A set of eight (8) bits is called the "byte", and a set of 16 bits is called the "word".
In the TCmini, an eight (8)-bit length register is called the "byte register".
Now let's investigate the range of byte numeric values.

When all eight (8) bits are 1, a byte is the maximum value.




Summing up the significances of each bit,

$2^0 + 2^1 + 2^2 + 2^3 + 2^4 + 2^5 + 2^6 + 2^7$

$= 1 + 2 + 4 + 8 + 16 + 32 + 64 + 128$

$= 255$

Likewise, a word (16 bits) is as follows:



Summing up the significances of all bits, it can be expressed as a decimal number of 0 ~ 65535. Each register of the TCmini can handle the numeric values in binary notation of this range.

Additionally, the set value and current value of timer and counter are processed as the binary number.

(2) Negative expression of binary number (Expression of complement of 2)

In Para. (1) above, all binary numbers are positive. Then how is a negative binary number expressed? If the binary number is decreased one by one,


	1	1	1	7
	1	1	0	6
	1	0	1	5
	1	0	0	4
		1	1	3
		1	0	2
			1	1
			0	0

From the above, you can see that a borrow takes place at the time of 4 → 3 and 2 → 1 in decimal notation.


If there is a "1" at a position higher by one when decreasing 1 from 0, the expression is as follows:

1 Borrow				0	0
	1	1	1	1	–1
	1	1	1	0	–2

Let's compare 1 with –1.




All bits of –1 are reversed (1 → 0) and –1 added with 1 becomes 1.
On the contrary, reverse all bits of 1, then add 1. The result is –1.



This operation is called as taking the complement of 2, which is used for conversion from positive to negative and vice versa.
In the above example, the highest-order digit is 1 when the number is negative and 0 when it is positive. This highest-order digit is called the "sign bit", and four (4) bits in the above example can be expressed as a decimal number of –8 to 7.

For a word (16 bits), the expression is as shown below.



It can handle a decimal number of –32768 ~ 32767.
The TCmini can handle the numeric numbers in this range as a signed binary number. The programmer and CRT programmer can specify the numeric values in this range as a decimal number. In the CPU, a specified numeric value is converted into a signed binary number and processed. A signed binary number is handled only in the word register, and the byte register handles a word as a positive integer (0 ~ 255).

(3) Hexadecimal number

When 0 and 1 of binary number are arranged, the expression becomes longer and is difficult to read. To solve this problem, four (4) bits are taken as one (1) unit. A hexadecimal number has four (4) bits, and a carry takes place at 16 after $2^0 + 2^1 + 2^2 + 2^3 = 1 + 2 + 4 + 8 = 15$. It uses numbers 0 to 9 and alphabets A to F.

Binary number	Decimal number	Hexa-decimal number	Binary number	Decimal number	Hexa-decimal number
0000	0	0	1000	8	8
0001	1	1	1001	9	9
0010	2	2	1010	10	A
0011	3	3	1011	11	B
0100	4	4	1100	12	C
0101	5	5	1101	13	D
0110	6	6	1110	14	E
0111	7	7	1111	15	F

Example: A word (16 bits) can be expressed by a four (4) digit number in hexadecimal notation.

0	0	0	1	0	1	0	1	1	0	1	0	1	1	0	0
1				5				A				C			

(4) Binary coded decimal (BCD)

In the decimal number, 10 comes after 0, 1, ⋯ 9 and a carry takes place. A number having the function carrying 9 to 10 like the binary number is called the binary coded decimal (BCD).

Decimal number	Binary number	BCD	
0	0		0
1	1		1
2	10		10
3	11		11
4	100		100
5	101		101
6	110		110
7	111		111
8	1000		1000
9	1001		1001
10	1010	1	0000
11	1011	1	0001
:	:		:
99	1100011	1001	1001

Carry

A binary number is classified by four (4) bits, and combinations of 1010 or more (1010 ~ 1111) are banned to cause a carry.
Each bit is expressed in the range of 0 to 9 of decimal number.

Example:

0	0	0	1	0	1	0	1	0	1	1	0	1	0	0	1

1 5 6 9

Thus, the BCD expression can be regarded as a variation of hexadecimal number.
The BCD numeric value can also be specified in hexadecimal notation. (Only 0 to 9 for each digit.)
The content of the register in which BCDs are stored can be displayed in hexadecimal notation.

(5) Negative expression of binary coded decimal (BCD)

A negative of BCD is handled as a sign + absolute value. In the TCmini, it can be handled in the two (2) instructions of F*012 (BIN → BCD conversion with sign) and F*013 (BCD → BIN conversion with sign).

The negative is set as the sign digit to "13 (1101)", the value not found in the BCD expression, and handled only as a long word (32-bit, BCD eight (8) digits). The eighth (8th) digit is assigned for the sign digit.
This is because the word (BCD, four (4) digits) is exceeded as a result of BCD conversion when the word numeric range is –32768 to 32767.

Example: Signed BIN to BCD conversion by F*012

–25089

1	0	0	1	1	1	0	1	1	1	1	1	1	1	1	1

Conversion

–	0	0	2	5	0	8	9
1 1 0 1	0 0 0 0	0 0 0 0	0 0 1 0	0 1 0 1	0 0 0 0	1 0 0 0	1 0 0 1

Sign digit: Negative (–) for 1101 and positive (+) for 0000

7.5.4 Operation Flag

(1) Type

The following four (4) types of flags are assigned to the relays (special auxiliary relays) to use the operation result in the coming operation.

Relay address	Flag name	Function
A000	Carry flag	Turned ON if there is a carry or borrow as a result of operation.
A002	Overflow flag	Turned ON if there is an overflow as a result of operation.
A006	Zero flag	Turned ON if the operation result is zero (0).
A007	Sign flag	Turned ON when the MSB (i.e., highest-order bit) of the word register is 1 as a result of operation.

(2) Instruction with change in operation flag

In the following ten (10) kinds of instructions, the flag changes with the operation result.


Type	Code	Function
BIN operation	F*010	BIN → BCD conversion
	F*020	BIN addition
	F*021	BIN addition with carry
	F*022	BIN subtraction
	F*023	BIN subtraction with borrow
	F*025	BIN division
Bit shift	F*040	Arithmetic left shift
	F*041	Left rotate
	F*042	Right shift
	F*043	Right rotate

The flag will not change in other than the above instructions.

(3) Cautions on flag

The carry flag and zero flag may change illegally when operated by the byte register.

Example:




In the operation between byte registers, high-order eight (8) bits of word register are taken as zero (0) and operated as the byte register. Thus, even if the byte register is specified for the destination and a result error is checked by the carry bit, a carry will not take place at the seventh (7th) bit, but the 15th bit becomes the carry flag. In the example above, the carry flag is zero (0).

The sign flag indicates the state of the highest-order bit (15th bit) of the word register. Therefore, the positive or negative sign flag makes sense only when the range of numeric values is handled as a signed binary code (–32768 ~ 32767) by the user.

(4) Available range of operation flag


A flag in the user's program maintains its state during the time from a flag operating instruction to the next flag operating instruction.



Note: If a flag operating instruction is not encountered to the program end, the flag keeps its state until another flag operating instruction appears first in the program during the next scan.


(5) Flag holding

Through the flag state is maintained until the next flag operating instruction, it is changed thereafter.
When the flag state must be held during one (1) scan cycle, move and hold it at the coil (internal relay, output relay, etc.).




R000 can maintain the flag state in one (1) scan cycle until the flag state is changed by the next [1] FL020 instruction. However, when X000 is turned OFF, the flag state of the flag operating instruction located in the circuit before [1] prevails.

To monitor and confirm the flag state through the peripheral equipment, it is convenient to make self backup or use a latch relay. If held by the coil, the flag state can be maintained only in one (1) scan cycle.




Or




7.5.5 Order of Execution

If the standard application instruction is programmed as a multi-output under the same operating condition, it is executed in the order of top to down in the circuit diagram. Thus it is possible to transfer the operation result to the next operation.



When R000 is ON:




Register D000 is used as the temporary operation result storing register.


7.5.6 Descriptions on Standard Application Instruction

F*000 Data Transfer

Symbol MOV	Code	Argument Ag.1	Ag.2	Ag.3
	F*000	d1 D1	d2 D2	
Function	Transfers the content of the register specified by Ag.2 to the register specified by Ag.1.			
Content of operation	MOV (d1 D1) ← (d2 D2)			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Flag	Data specified by Ag.2. Unchanged Unchanged			




When input X000 is ON, the content of register D001 is transferred to register D005.




Both the word register and byte register can transfer the data.


- When register D1 is the byte register (R00H, Y01L, etc.) and register D2 is the word register (R00W, Y01W, etc.),




When X000 is ON, the low-order eight (8)-bit data of D000 is transferred to the eight (8) bits of R00H.



- When register D1 is the word register and register D2 is the byte register,




When X000 has turned ON from OFF, the eight (8)-bit data of R02L is transferred to the low-order eight (8) bits of D000. The high-order eight (8)-bit data is zero-cleared.



Note: For data transfer of two (2) words or more, use the block transfer instruction by F*006 or F*008.

When the indirect register is used,




When X000 is ON, the content of D100 is transferred to the address which is identified as per the data set in D002. (If #100H is set in D002, D100 is the address.)


F*001 Constant Set

Symbol SET	Code	Argument Ag.1	Ag.2	Ag.3
	F*001	d1 D1	K2	

Function	Stores the constant specified by Ag.2 in the register specified by Ag.1.
Content of operation	SET (d1 / D1) ← K2
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Flag	 Value of constant K2 Unchanged Unchanged




When input X000 has turned ON from OFF, binary constant 1120 is stored in register D100.




When the register is the byte register, the low-order eight (8)-bit data of the constant is stored in the register. (The high-order eight (8)-bit data of the constant is ignored.)

- When register D1 is the byte register,




The high-order eight (8)-bit data of the constant is ignored.




F*002 High-Order 8-Bit Data Transfer

Symbol MOV	Code	Argument Ag.1	Ag.2	Ag.3
	F*002	d1 D1	d2 D2	
Function	Transfers the low-order eight (8)-bit data of the register specified by Ag.2 to the high-order eight (8) bits of the register specified by Ag.1.			
Content of operation	$\binom{d1}{D1}$ (H) ← $\binom{d2}{D2}$ (L)			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content	The high-order eight (8) bits are set as the low-order eight (8) bits of the data value specified by Ag.2.			
• Ag.2 content	Unchanged			
• Flag	Unchanged			





When input X000 is ON, the low-order eight (8)-bit data of register D013 is transferred to the high-order eight (8) bits of register D005.




The low-order eight (8) bits of D005 remain unchanged after operation.

- When register D2 is the byte register,






- When register D1 is the byte register,




The low-order eight (8)-bit data of D017 is stored in R05H.




(Same operation as F*000.)

F*006 Block Transfer (Constant Designation)

Symbol MOV	Code	Argument Ag.1	Ag.2	Ag.3
	F*006	d1 D1	d2 D2	K3
Function	Transfers block data of constant K3 word from registers headed by the one specified by Ag.2 to registers headed by the one specified by Ag.1.			
Content of operation	$\binom{d2}{D2}, \binom{d2+1}{D2+1} \cdots \binom{d2+K3-1}{D2+K3-1}$ ↓ $\binom{d1}{D1}, \binom{d1+1}{D1+1} \cdots \binom{d1+K3-1}{D1+K3-1}$			
Range of argument 1	Direct register: Entire range (word designation) Indirect register: Entire range (word designation)			
Range of argument 2	Direct register: Entire range (word designation) Indirect register: Entire range (word designation)			
Range of argument 3	Constant: 0 ~ 255			
After operation • Ag.1 content • Ag.2 content • Ag.3 content	 Data value specified by Ag.2. Unchanged Unchanged			



When input X000 is ON, the two (2)-word data stored in registers (R03W, R04W) headed by register R03W is transferred to register D000 and after (D000, D001).




If the designation is outside the register area, data transfer is not performed.


Note: Even if the byte register is specified for the source and destination registers, the word register takes effect.

If the same addresses are used both for the source and destination registers,


a) When register D1 address > register D2 address,




After operation, the same value is set in D000 to D004.



b) When register D1 address < register D2 address,




After operation, the content of each register is transferred into the registers with an address number just preceding the number of the source register, respectively.




F*009 Data Extraction and Distribution

Symbol IDX	Code	Argument Ag.1	Ag.2	Ag.3
	F*009	d1 D1	d2 D2	d3 D3
Function	Offsets the 2-byte data of the table headed by the Ag.2 register by the low-order byte of the Ag.3 register and transfers the result to the table headed by the Ag.1 register which offsets the data by the high-order byte of the Ag.3 register.			
Content of operation	$\begin{pmatrix} d2 \\ D2 \end{pmatrix} + \begin{bmatrix} d3(L) \\ D3(L) \end{bmatrix}$ ↓ $\begin{pmatrix} d1 \\ D1 \end{pmatrix} + \begin{bmatrix} d3(H) \\ D3(H) \end{bmatrix}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
Range of argument 3	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Operation result Unchanged Unchanged Unchanged			




When register D020 = 0204H, the data are extracted and distributed as shown below.



Transferred data is the two (2) bytes.

When register D2 is the byte register, the high-order byte of D1 becomes zero (0).


When register D1 is the byte register, the low-order byte of the data read is written.




F*010 BIN → BCD Conversion (Unsigned)

Symbol BCD	Code	Argument Ag.1	Ag.2	Ag.3
	F*010	d1 D1	d2 D2	

Function	Converts the unsigned BIN data of register specified by Ag.2 into the BCD data and stores in the register specified by Ag.1.
Content of operation	BIN (D2 / d2) → BCD (D1 / d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range
After operation • Ag.1 content • Ag.2 content • Flag	Operation result Unchanged Overflow is ON when the D2 binary data is larger than 9999.




When input X000 is ON, the data of register V000 (timer T000 set value) is converted into the BCD data and stored in register Y03W (Y03F ~ Y030).




When the binary data of register D2 is larger than 9999, a code other than BCD is stored in the highest-order position of the BCD, and normal conversion is not performed.

- When registers D1 and D2 are the byte registers,




One (1)-byte binary data of X00L is converted into the BCD code and stored in Y01L.


Note: If the X00L value exceeds 99, the third (3rd) digit and above are ignored.



- When register D1 is the word register and register D2 is the byte register,




One (1)-byte binary data of X00H is converted into the BCD data and stored in D003.




F*011 BCD → BIN Conversion (Unsigned)


Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*011	d1 D1	d2 D2	—
Function	Converts the unsigned BCD data of register specified by Ag.2 into the BIN data and stores in the register specified by Ag.1.			
Content of operation	BCD $\binom{D2}{d2}$ → BIN $\binom{D1}{d1}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Flag	 Operation result Unchanged Unchanged			




When input X000 is ON, the BCD data of register X02W is converted into the BIN data and stored in D050.




- When registers D1 and D2 are the byte registers,




One (1)-byte BCD data of X02H is converted into the BIN data and stored in R05L.



- When register D1 is the word register and register D2 is the byte register,




Two (2)-byte BCD data of X03W is converted into the BIN data and the low-order one (1) byte is stored in R04H.




Note: If the X03W value exceeds 256, the low-order eight (8) bits that were converted into the BIN data are stored in R04H.

F*012 BIN → BCD Conversion (Signed)

Symbol BCD	Code	Argument Ag.1	Ag.2	Ag.3
	F*012	d1 D1	d2 D2	—
Function	Converts the signed BIN data of register specified by Ag.2 into the BCD data and stores in the register specified by Ag.1.			
Content of operation	BIN (D2 / d2) → BCD (D1 / d1), (D1+1 / d1+1)			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Flag	Operation result Unchanged Unchanged			




When input X000 is ON, the signed BIN data of register D070 is converted into the signed BCD data, and the low-order four (4)-digit data is stored in register D055 and the high-order one (1)digit and a sign are stored in register D056.



When the high-order four (4)-bit data of register D1+1 is 1101, it signifies the negative value. If 0000, it represents the positive value.


- When registers D1 and D2 are the byte registers,



The register D1 data is four (4) bytes if it is the byte register or word register.

R03L								→	Y06H		Y06L		Y05H		Y05L	
195									0	0	0	0	0	1	9	5
1	1	0	0	0	0	1	1		0 0 0 0 0 0 0 0		0 0 0 0 0 0 0 0		0 0 0 0 0 0 0 1		1 0 0 1 0 1 0 1	


- When register D1 is the word register and register D2 is the byte register,




R04H								→	D011				D010			
195									0	0	0	0	0	1	9	5
1	1	0	0	0	0	1	1		0 0 0 0 0 0 0 0		0 0 0 0 0 0 0 0		0 0 0 0 0 0 0 1		1 0 0 1 0 1 0 1	

F*013 BCD → BIN Conversion (Signed)

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*013	d1 D1	d2 D2	
Function	Converts the signed BCD data of register specified by Ag.2 into the BIN data and stores in the register specified by Ag.1.			
Content of operation	BCD (D2 / d2) (D2+1 / d2+1) → BIN (D1 / d1)			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Flag	 Operation result Unchanged Unchanged			




When input X000 is ON, the signed BCD data of registers D200 and D201 is converted into the signed BIN data and stored in register D010.



MSB: 1 when negative and 0 when positive.
If the BCD data of registers D2, D2+1 is larger than +32767 or smaller than –32768, the data is not converted into the BIN code legally.


- When registers D1 and D2 are the byte registers,



The signed BCD data of X02L, X02H, X03L and X03H are converted into the signed BIN data and stored in register R05L.

X03H				X03L				X02H				X02L					R05L							
–			0	0				0				0			1	→	–103							
1	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0		1	0	0	1	1	0	0	1

- When register D1 is the word register and register D2 is the byte register,



X04H				X04L				X03H				X03L			
0				0				0				0			
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1
0	0	0	0	1	0	0	1								


↓

D00A															
709															
0	0	0	0	0	0	1	0	1	1	0	0	0	1	0	1

Even if register D2 is the byte register or word register, four (4)-byte data is converted.


F*020 BIN Addition

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*020	d1 D1	K2 d2 D2	K3 d3 D3




Function	Adds the BIN data of register specified by Ag.2 and BIN data of register specified by Ag.3 and stores the sum in register specified by Ag.1.
Content of operation	BIN (D2, d2, K2) + BIN (D3, d3, K3) → BIN (D1, d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Carry flag • Zero flag • Sign flag	 Operation result Unchanged Unchanged A000: Turned ON when a carry takes place as a result of operation. A006: Turned ON when the operation result is zero (0). A007: Turned ON when the MSB is 1 as a result of operation.

When input X000 is ON, the BIN data of register D001 is added to the BIN data of register D002, which is then stored in register D000.



If the word register is used for either register D2 or D3 and the byte register is used for register D1, the sum of low-order eight (8) bits is stored in D1 and the high-order eight (8) bits are ignored.

- When registers D1 and D2 are the byte registers,



The BIN data of R04L and X01L are added and the low-order one (1) byte is stored in E03L.


If a carry takes place (i.e., the data exceeds 256), the carry flag will not turn ON.

R04L		X01L		E03L
198	+	211	→	153
1 1 0 0 0 1 1 0		1 1 0 1 0 0 1 1		1 0 0 1 1 0 0 1

If the registers D2 and D3 are the byte registers, they are operated as the word register whose high-order eight (8) bits are zero (0).


F*021 Carried BIN Addition

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*021	d1 D1	K2 d2 D2	K3 d3 D3




Function	Adds the BIN data of register specified by Ag.2, BIN data of register specified by Ag.3 and carry flag and stores the sum in register specified by Ag.1.
Content of operation	BIN (D2 / d2 / K2) + BIN (D3 / d3 / K3) + C → BIN (D1 / d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Carry flag • Zero flag • Sign flag	 Operation result Unchanged Unchanged A000: Turned ON when a carry takes place as a result of operation. A006: Turned ON when the operation result is zero (0). A007: Turned ON when the MSB is 1 as a result of operation.

When input X000 is ON, the BIN data of register D00F, BIN data of register D120 and carry flag (A000) are added, which is then stored in register D110.



If the word register is used for either register D2 or D3 and the byte register is used for register D1, the sum of low-order eight (8) bits is stored in D1 and the high-order eight (8) bits are ignored.

- When adding the binary data of one (1) word or over,




← Addition of low-order one (1) word data.

← Addition of high-order one (1) word data.

In the above circuit, BIN data of 0 ~ 4294967295 is stored in D100 (low-order word) and D101 (high-order word).


F*022 BIN Subtraction

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*022	d1 D1	K2 d2 D2	K3 d3 D3




Function	Figures out the difference between the BIN data of register specified by Ag.2 and BIN data of register specified by Ag.3 and stores the result in register specified by Ag.1.
Content of operation	BIN (D2 / d2 / K2) – BIN (D3 / d3 / K3) → BIN (D1 / d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Carry flag • Zero flag • Sign flag	 Operation result Unchanged Unchanged A000: Turned ON when a borrow takes place as a result of operation. A006: Turned ON when the operation result is zero (0). A007: Turned ON when the MSB is 1 as a result of operation.

When input X000 is ON, the BIN data of register D020 is subtracted from the BIN data of register D112, which is then stored in register D030.



If the word register is used for either register D2 or D3 and the byte register is used for register D1, the low-order eight (8) bits of the result are stored in D1 and the high-order eight (8) bits are ignored.

- When registers D1 and D2 are the byte registers,




The BIN data of X04L is subtracted from the BIN data of R03H, and the difference is stored in R20L.

If a borrow takes place as a result of operation, the carry flag turns ON.

R03H									X04L									R20L								
57								–	108								→	–51								
0	0	1	1	1	0	0	1		0	1	1	0	1	1	0	0		1	1	0	0	1	1	0	1	


- When obtaining the absolute operation result,



← When a borrow takes place, the value is changed to a positive one using the complement of 2 of the result.


F*023 Borrowed BIN Subtraction

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*023	d1 D1	K2 d2 D2	K3 d3 D3




Function	Subtracts the BIN data of register specified by Ag.3 and carry flag from the BIN data of register specified by Ag.2 and stores the difference in register specified by Ag.1.
Content of operation	BIN (D2 / d2 / K2) – BIN (D3 / d3 / K3) – C → BIN (D1 / d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Carry flag • Zero flag • Sign flag	 Operation result Unchanged Unchanged A000: Turned ON when a borrow takes place as a result of operation. A006: Turned ON when the operation result is zero (0). A007: Turned ON when the MSB is 1 as a result of operation.

When input X000 is ON, the BIN data of register D044 and carry flag (A000) are subtracted from the BIN data of register D051, and the difference is stored in register D003.



If the word register is used for either register D2 or D3 and the byte register is used for register D1, the low-order eight (8) bits of the result are stored in D1 and the high-order eight (8) bits are ignored. Data of 0 ~ 65535 is also available.

- When subtracting the binary data of one (1) word or over,




← Subtraction of low-order one (1)-word data.

← Subtraction of high-order one (1)-word data.

It should be noted that if a borrow takes place in the subtraction of high-order one (1)-word data, the data is illegal.


F*024 Unsigned BIN Multiplication

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*024	d1 D1	K2 d2 D2	K3 d3 D3




Function	Figures out the product of the BIN data of register specified by Ag.2 and BIN data of register specified by Ag.3 and stores the result in register specified by Ag.1.
Content of operation	BIN (D2 / d2 / K2) * BIN (D3 / d3 / K3) → BIN (D1 / d1), (D1+1 / d1+1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65535
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65535
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Operation result Unchanged Unchanged Unchanged


When input X000 is ON, the BIN data of register D04F is multiplied by the BIN data of register D01B, and the low-order 1-word data is stored in register D105 and the high-order 1-word data in register D106.



Mixed use of byte register and word register is possible. However, even if either register (byte register or word register) is specified for register D1, four (4)-byte data is stored in register D1. Data of 0 ~ 65535 are available.


- When all registers are the byte registers,






F*025 Unsigned BIN Division

Symbol BIN	Code	Argument Ag.1	Ag.2	Ag.3
	F*025	d1 D1	d2 D2	K3 d3 D3




Function	Divides the BIN data of registers specified by Ag.2 by the BIN data of register specified by Ag.3 and stores the quotient and remainder in registers specified by Ag.1.
Content of operation	$\binom{D2}{d2}\ \binom{D2+1}{d2+1} \div \binom{D3}{d3}{K3}$ → $\binom{D1}{d1}$, $\binom{D1+1}{d1+1}$ (remainder)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65535
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65535
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Operation result Unchanged Unchanged Unchanged

When input X000 is ON, the four (4)-byte BIN data of register D101 and register D102 is divided by the two (2)-byte BIN data of register D05F, and the quotient and remainder are stored in registers D005 and D006, respectively.



Even if either register (byte register or word register) is specified for registers D1 and D2, they are operated as the two (2) word data.
Data of 0 ~ 65535 are available.

- Values of dividends D2, D2+1 can exceed 16 bits, but quotient D1 must be less than 16 bits.
- When all registers D1, D2, D3 are the byte registers,



Two (2)-word BIN data of X04H, X04L, X03H and X03L is divided by the data of R01H, and the quotient is stored in Y05H and Y05L and the remainder in Y06H and Y06L.

X04H	X04L	X03H	X03L
		6735	
0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 1 1 0 1 0	0 1 0 0 1 1 1 1

÷

R01H
197
1 1 0 0 0 1 0 1

Y05H	Y05L
34	
0 0 0 0 0 0 0 0	0 0 1 0 0 0 1 0


Quotient

Y06H	Y06L
37	
0 0 0 0 0 0 0 0	0 0 1 0 0 1 0 1


Remainder

F*032 Logical Product (AND)

Symbol AND	Code	Argument Ag.1	Ag.2	Ag.3
	F*032	d1 D1	K2 d2 D2	K3 d3 D3
Function	Figures out the logical product (AND) of BIN data of registers specified by Ag.2 and Ag.3 and stores the result in register specified by Ag.1.			
Content of operation	$\begin{pmatrix}D2\\d2\\K2\end{pmatrix} \wedge \begin{pmatrix}D3\\d3\\K3\end{pmatrix} \rightarrow \begin{pmatrix}D1\\d1\end{pmatrix}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767			
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767			
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Operation result Unchanged Unchanged Unchanged			




When input X000 is ON, the logical product of BIN data of registers D001 and D002 is figured out and the result is stored in register D000.




When either register D2 or D3 is the word register and register D1 is the byte register, the logical product of low-order eight (8) bits is figured out and stored in register D1. The high-order eight (8) bits are ignored.


AND truth table



- When registers D1, D2 and D3 are the byte registers,




The logical product of X02L and Y05H is figured out and stored in R03H.




F*033 Logical Sum (OR)

Symbol OR	Code	Argument Ag.1	Ag.2	Ag.3
	F*033	d1 D1	K2 d2 D2	K3 d3 D3




Function	Figures out the logical sum (OR) of BIN data of registers specified by Ag.2 and Ag.3 and stores the result in register specified by Ag.1.
Content of operation	$\begin{pmatrix}D2\\d2\\K2\end{pmatrix} \vee \begin{pmatrix}D3\\d3\\K3\end{pmatrix} \rightarrow \begin{pmatrix}D1\\d1\end{pmatrix}$
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Operation result Unchanged Unchanged Unchanged

When input X000 is ON, the logical sum of BIN data of registers D110 and D112 is figured out and the result is stored in register D10F.




When either register D2 or D3 is the word register and register D1 is the byte register, the logical sum of low-order eight (8) bits is figured out and stored in register D1. The high-order eight (8) bits are ignored.

OR truth table



A	B	C
0	0	0
1	0	1
0	1	1
1	1	1


- When registers D1, D2 and D3 are the byte registers,



E00H									X04L									R03L							
1	0	0	1	0	0	1	0	∨	0	0	0	1	0	1	0	1	→	1	0	0	1	0	1	1	1


F*034 Exclusive Logical Sum (XOR)

Symbol XOR	Code	Argument Ag.1	Ag.2	Ag.3
	F*034	d1 D1	K2 d2 D2	K3 d3 D3




Function	Figures out the exclusive logical sum (XOR) of BIN data of registers specified by Ag.2 and Ag.3 and stores the result in register specified by Ag.1.
Content of operation	(D2, d2, K2) ⩛ (D3, d3, K3) → (D1, d1)
Range of argument 1	Direct register: Entire range Indirect register: Entire range
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
Range of argument 3	Direct register: Entire range Indirect register: Entire range Constant: –32768 ~ 32767
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	Operation result Unchanged Unchanged Unchanged

When input X000 is ON, the exclusive logical sum of BIN data of registers D103 and D102 is figured out and the result is stored in register D10D.




XOR truth table



A	B	C
0	0	0
1	0	1
0	1	1
1	1	1


- When registers D1, D2 and D3 are the byte registers,




X01L									R03H									Y05H							
1	0	1	1	0	1	1	1	⩛	1	0	0	1	1	0	0	1	→	0	0	1	0	1	1	1	0

F*035 Increment

Symbol INC	Code	Argument Ag.1	Ag.2	Ag.3
	F*035	d1 D1		
Function	Increments the BIN data of register specified by Ag.1 and stores in register specified Ag.1.			
Content of operation	$\binom{D1}{d1} + 1 \rightarrow \binom{D1}{d1}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Flag	Low-order four (4) digits of operation result Unchanged			




When input X000 has turned ON from OFF, the BIN data of register D015 is incremented and stored in register D015.




The data ranges from –32768 to 32767.

F*036 Decrement

Symbol DEC	Code	Argument Ag.1	Ag.2	Ag.3
	F*036	d1 D1		
Function	Decrements the BIN data of register specified by Ag.1 and stores in register specified Ag.1.			
Content of operation	$\binom{D1}{d1} - 1 \rightarrow \binom{D1}{d1}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Flag	Low-order four (4) digits of operation result Unchanged			




When input X000 has turned ON from OFF, the BIN data of register D070 is decremented and stored in register D070.



The data ranges from –32768 to 32767.


- Forward/backward counter as per increment or decrement (signed BIN data)



When X000 is ON, the counter value increments. Likewise, when X001 is ON, the counter value decrements. The data ranges from –32768 to 32767.


F*037 Unsigned Comparison

Symbol CMP	Code	Argument Ag.1	Ag.2	Ag.3
	F*037	K1 d1 D1	K2 d2 D2	B3



Function	Compares the BIN data of register specified by Ag.1 with the BIN data of register specified by Ag.2, then stores the result in relay B3.
Content of operation	$\begin{pmatrix}D1\\d1\\K1\end{pmatrix} \leftrightarrow \begin{pmatrix}D2\\d2\\K2\end{pmatrix} \rightarrow B3$
Range of argument 1	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65534
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: 0 ~ 65534
Range of argument 3	Relay: Entire range
After operation • Ag.1 content • Ag.2 content • Ag.3 content	 Unchanged Unchanged
• Flag	Unchanged


When input X000 is ON, the BIN data of register D100 is compared with the BIN data of register D005, and the result is output into relay R050, R051.



When the BCD data are compared, both are regarded as the BIN data.
If either register D1 or D2 is the byte register, the data of the byte register is taken as the 16-bit data whose high-order eight (8) bits are zero (0) and compared.

Relay address: When B3 is even number	Relay address: When B3 is odd number	Ag.1 = Ag.2	Ag.1 < Ag.2	Ag.1> Ag.2
B3	B3–1	1	1	0
B3+1	B3	1	0	0


- Comparison of byte register with word register (BIN data)



D000	R02H	Result	R104	R105
(72) 0 0 0 0 | 0 0 0 0 | 0 1 0 0 | 1 0 0 0	(202) 1 1 0 0 | 1 0 1 0	<	1	0
(202) 0 0 0 0 | 0 0 0 0 | 1 1 0 0 | 1 0 1 0	(202) 1 1 0 0 | 1 0 1 0	=	1	1
(2304) 0 0 0 0 | 1 0 0 1 | 0 0 0 0 | 0 0 0 0	(174) 1 0 1 0 | 1 1 1 0	>	0	0

F*038 Signed Comparison

Symbol CMP	Code	Argument Ag.1	Ag.2	Ag.3
	F*038	K1 d1 D1	K2 d2 D2	B3




Function	Compares the BIN data of register specified by Ag.1 with the BIN data of register specified by Ag.2, then outputs the result into relay B3.
Content of operation	(D1, d1, K1) (s) ↔ (D2, d2, K2) (s) → B3
Range of argument 1	Direct register: Entire range Indirect register: Entire range Constant: –327678 ~ 32767
Range of argument 2	Direct register: Entire range Indirect register: Entire range Constant: –327678 ~ 32767
Range of argument 3	Relay: Entire range
After operation • Ag.1 content • Ag.2 content • Ag.3 content	 Unchanged Unchanged

Relay address		Ag.1 = Ag.2	Ag.1 < Ag.2	Ag.1> Ag.2
When B3 is even number	When B3 is odd number			
B3	B3–1	1	1	0
B3+1	B3	1	0	0

• Flag	Unchanged


When input X000 is ON, the BIN data of register D105 is compared with the BIN data of register D005, and the result is output into relay R046, R047.



When the BCD data are compared, they are regarded as the BIN data.

If either register D1 or D2 is the byte register, the data of the byte register is taken as the 16-bit data whose high-order eight (8) bits are zero (0) and compared.


- Comparison of byte register with word register (BIN data)



D180	R03H	Result	R010	R011
(–73) 1 1 1 1 | 1 1 1 1 | 1 0 1 1 | 0 1 1 1	(153) 1 0 0 1 | 1 0 0 1	<	1	0
(–174) 1 1 1 1 | 1 1 1 1 | 0 1 0 1 | 0 0 1 0	(184) 1 0 1 1 | 1 0 0 0	=	1	1
(–3140) 1 1 1 1 | 0 0 1 1 | 1 0 1 1 | 1 1 0 0	(83) 0 1 0 1 | 0 0 1 1	>	0	0
(206) 0 0 0 0 | 0 0 0 0 | 1 1 0 0 | 1 1 1 0	(206) 1 1 0 0 | 1 1 1 0	=	1	1
(456) 0 0 0 0 | 0 0 0 1 | 1 1 0 0 | 1 0 0 0	(226) 1 1 1 0 | 0 0 1 0	>	0	0


F*040 Arithmetic Left Shift

Symbol SLA	Code	Argument Ag.1	Ag.2	Ag.3
	F*040	d1 D1		




Function	Shifts the data of register specified by Ag.1 by one (1) bit to the left and sets the most significant bit (MSB) in the carry flag.
Content of operation	$C \leftarrow \begin{pmatrix} D1 \\ d1 \end{pmatrix} \leftarrow 0$
Range of argument 1	Direct register: Entire range Indirect register: Entire range
After operation • Ag.1 content • Carry flag • Other flags	Data shifted by one (1) bit to the left. A000: Status of MSB of Ag.1 before shifted. A006, A007: Unchanged

When input X000 has turned ON from OFF, the data of register D070 is shifted by one (1) bit to the left, the MSB is set in A000 and LSB is set to zero (0).




When register D1 is the byte register, the high-order eight (8) bits are brought into zero (0) and shifted. As a result, the carry flag is turned OFF.


- When register D1 is the byte register,



- Example of using register as one (1)-word length shift register:




<Time chart>




F*041 Left rotation

Symbol RL	Code	Argument Ag.1	Ag.2	Ag.3
	F*041	d1 D1		

Function	Shifts the data of register specified by Ag.1 by one (1) bit to the left and sets the carry flag in the least significant bit (LSB), then the MSB in the carry flag.
Content of operation	C ← (D1 / d1) ← C
Range of argument 1	Direct register: Entire range Indirect register: Entire range
After operation • Ag.1 content • Carry flag • Other flags	Data shifted by one (1) bit to the left. LSB is the value of carry flag before shifted. A000: Status of MSB of Ag.1 before shifted. A006, A007: Unchanged




When input X000 has turned ON from OFF, the data of register D007 is shifted by one (1) bit to the left, the A000 data is set in the LSB , then the MSB in A000.




When register D1 is the byte register, the high-order eight (8) bits are brought into zero (0) and shifted. After operation, the carry flag data turns OFF.

- When register D1 is the byte register,



- When shifting one (1) word or more to the left,




SLA D000 C ←← 0 = Left shift of low-order one (1) word.


RL D001 C ←← 0 = Left rotation of high-order one (1) word.

□ A carry is executed by the carry flag.

- Example of using register as two (2)-word shift register:



<Time chart>



F*042 Right Shift


Symbol SRA	Code	Argument Ag.1	Ag.2	Ag.3
	F*042	d1 D1		

Function	Shifts the data of register specified by Ag.1 by one (1) bit to the right and sets the LSB in the carry flag.
Content of operation	$0 \rightarrow \begin{pmatrix} D1 \\ d1 \end{pmatrix} \rightarrow C$
Range of argument 1 (BIN)	Direct register: Entire range Indirect register: Entire range
After operation • Ag.1 content • Carry flag • Other flags	Data shifted by one (1) bit to the right. A000: Status of LSB of Ag.1 before shifted. A006, A007: Unchanged

X000 FE042 SRL D011

SRL { } 0 → → C

When input X000 has turned ON from OFF, the data of register D011 is shifted by one (1) bit to the right, the LSB is set in A000 and MSB is set to zero (0).




When register D1 is the byte register, the high-order eight (8) bits are brought into zero (0) and shifted to the right.


- When register D1 is the byte register,

X000 FE042 SRL R04H 0 → → C


SRL { }



- Example of using register as bi-directional one (1)-word length shift register:



<Time chart>




X000: Data signal
X001: Shift signal
X002: Forward/reverse signal
X003: Reset signal


F*043 Right Rotation

Symbol RR	Code	Argument Ag.1	Ag.2	Ag.3
	F∗043	d1 D1		

Function	Shifts the data of register specified by Ag.1 by one (1) bit to the right and sets the carry flag data in the MSB, then sets the LSB in the carry flag.
Content of operation	$C \rightarrow \begin{pmatrix} D1 \\ d1 \end{pmatrix} \rightarrow C$
Range of argument 1	Direct register: Entire range Indirect register: Entire range
After operation • Ag.1 content • Carry flag • Zero flag • Sign flag	Data shifted by one (1) bit to the right. MSB is the value of carry flag before shifted. A000: Status of LSB of Ag.1 before shifted. A006: Status of LSB of Ag.1 before shifted. A007: Unchanged




When input X000 has turned ON from OFF, the data of register D010 is shifted by one (1) bit to the right, the A000 data is set in the MSB , then the LSB in A000.




When register D1 is the byte register, the high-order eight (8) bits are brought into zero (0) and shifted. Therefore, the carry flag data in MSB has no meaning.

- When register D1 is the byte register,



- When shifting one (1) word or more to the right,




SRL D001 0 →→ C = Right shift of high-order one (1) word.

RR D000 C →→ C = Right rotation of low-order one (1) word.


□ A borrow is executed by the carry flag.

- Example of using register as bi-directional two (2)-word length shift register:




F*045 4 → 16 Decoder


Symbol DCD	Code	Argument Ag.1	Ag.2	Ag.3
	F*045	d1 D1	d2 D2	
Function	Decodes the low-order four (4) bits of register specified by Ag.2 into 16 bits and stores in register specified by Ag.1.			
Content of operation	$\binom{D2}{d2}$ DCD → $\binom{D1}{d1}$			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Direct register: Entire range Indirect register: Entire range			
After operation • Ag.1 content • Ag.2 content • Flag	Operation result Unchanged Unchanged			



When input X000 is ON, the low-order four (4)-bit data of register D00F is decoded and stored in register D010 as the 16-bit data.




When register D1 is the byte register, the low-order eight (8) bits of the decoded result are stored in register D1.
If the data of register D2 is 8 or over, zero (0) is stored.




F*047 Bit Test (Constant Designation)

Symbol TST	Code	Argument Ag.1	Ag.2	Ag.3
	F*047	d1 D1	K2	B3
Function	Stores in relay specified by Ag.3 the bit of the data in register specified by Ag.1, which is at a position specified by constant K2.			
Content of operation	$\binom{D1}{d1}$ (K2) → B3			
Range of argument 1	Direct register: Entire range Indirect register: Entire range			
Range of argument 2	Constant: 0 ~ 15			
Range of argument 3	Relay: Entire range			
After operation • Ag.1 content • Ag.2 content • Ag.3 content • Flag	 Unchanged Unchanged Status of specified bit Unchanged			




When input X000 is ON, the status of Bit 11 of the data in register D022 is stored in relay R015.



When register D1 is the byte register, the high-order eight (8) bits are brought into zero (0) and tested.

F*049 Subroutine Start


Symbol	Code	Argument		
		Ag.1	Ag.2	Ag.3
SBR	F*049	K1		
Function	Defines the top of the subroutine program specified by constant K1.			
Range of argument 1	Constant: 0 ~ 32			
After operation • Ag.1 content • Flag	 Unchanged Unchanged			



The top of the subroutine program is indicated.
A subroutine program can be written in any area of program.

Note: When programming a subroutine program, include the subroutine start instruction at the top and the subroutine return instruction at the end of a program.

Example:



When you have to repeat the same processing in the program, register it beforehand as a subroutine, and you can execute it by calling this subroutine, when necessary. Thus, you can reduce the number of program steps and make the program easy-to-see.


Data from the subroutine start instruction (F*049) to the subroutine return instruction (F*059) is registered as one (1) subroutine. Up to thirty-two (32) subroutines can be registered.
Set a subroutine number in the argument of subroutine start instruction. Likewise, set the subroutine number in the argument of subroutine return instruction.
To call a registered subroutine, use the subroutine call instruction (F*058).

Cautions on use of subroutine:
Though there is not any limitation on the call of another subroutine from one subroutine (i.e., nesting), DO NOT execute the same subroutine. Otherwise, the system will operate incorrectly.

F*058 Subroutine Call

Symbol	Code	Argument		
		Ag.1	Ag.2	Ag.3
CAL	F*058	K1		
Function	Executes the subroutine program defined by the constant specified by Ag.1.			
Content of operation	CAL K1			
Range of argument 1	Constant: 0 ~ 32			
After operation • Ag.1 content • Flag	 Unchanged Unchanged			


When input X000 is ON, the subroutine program 010 is executed.



F*059 Subroutine Return/Program End


Symbol	Code	Argument		
		Ag.1	Ag.2	Ag.3
RET	F*059	K1		
Function	Specifies the end of the subroutine program designated by the constant of Ag.1.			
Content of operation	RET			
Range of argument 1	Constant: 0 ~ 32			
After operation • Ag.1 content • Flag	 Unchanged Unchanged			

The end of subroutine program 20 is executed.




F*063 1-Scan ON


Symbol	Code	Argument		
		Ag.1	Ag.2	Ag.3
EDG	FE063	B1		
Function	Turns ON the relay specified by Ag.1 during one (1) scan.			
Content of operation	B1: ON			
Range of argument 1	Relay: Entire range			
After operation • Ag.1 content • Flag	Turned ON relay B1 for one (1) scan. Unchanged			



When input X000 has turned ON from OFF, relay E000 is turned ON, which is turned OFF after this instruction is executed in the next scan.



Note: This instruction works exactly in the same manner as differentiating relay E***.



In terms of the processing speed, differentiating relay E*** is faster than this instruction. It is recommended, therefore, to use differentiating relay E*** where possible.


This instruction cannot be used as F L 063.

7.6 Programming


The PLC may perform the operation slightly different from the actual relay circuit because it successively reads data from the program memory and performs instructions one by one. Additionally, a run-around preventing diode is not required, which is needed for the relay board, and the number of auxiliary contacts is unlimited.
Design the circuit efficiently by fully understanding the difference in circuit design between the PLC and relay board.

7.6.1 Limitation on Creating Circuit

(1) One (1) circuit must consist of (11 columns × 1 output) × 11 lines or less as shown below.





(2) Current in the same circuit only flows from left to right. It will not flow from right to left. That is, the circuit includes a one-way diode at each contact.




→ Current flows in the direction shown by
⇠ the full-line arrow mark, but not in the dotted-line arrow mark direction.


For the current below, the current in the dotted-line arrow mark direction is not existent.










(3) No limitation is imposed on the circuit if items (1) and (2) are considered.



(4) The pair coil is considered as one (1) circuit.
The counter and latch are considered as one (1) circuit, including the reset condition. It is not possible to include another coil between the pair coil.







(Pair coil error occurs.)

7.6.2 Influence by Program Sequence


The PLC performs operation from the top to the end (P. END instruction) of the program repeatedly. (Cyclic scanning operation system)

For this reason,

(a) The operation is performed from the top to bottom of the program for each circuit (i.e., each circuit block with AND and OR connections).


(b) The operation is performed from the left to right for each column in one (1) circuit. (The operation of the input part is performed before the operation of the output part.)

(1) When the program sequence is changed, the operation may differ.




In program [1] above, R000 and R100 are turned ON within the same scan when X000 is turned ON. In program [2], however, R100 is turned ON one (1) scan later. This is because the status of contact R000 is changed one (1) scan later due to the presence of contact R000 before coil R000.
Generally, the status of the contact programmed before the coil is changed at the next scan to the one in which the coil state changed. There is a programming technique to use such scan delay constructively.

Example:




This is an oscillation circuit which repeats ON and OFF every scan.

(2) If an interlock is made in one (1) circuit, malfunction may result in.




Even if an interlock is made mutually in the above circuit, SOL1 and SOL2 repeat ON and OFF every scan when PB1 and PB2 are pressed at the same time.
This is because the operation is performed from the left to right in the same circuit according to the principle in Item (b) of Para. 7.6.2. To prevent malfunction, the circuit must be divided into the two (2) parts.




When PB1 and PB2 are pressed at the same time, the circuit in which priority is given to SOL1 is formed.

(3) If an application instruction with change in flag status is used together with a flag contact in the same circuit, the flag result is incorrectly reflected.



The above is the circuit to output an error as a result of operation (overflow) to R000. As the input part is operated before the output part according to the principle in Item (b) of Para. 7.6.2, the carry result after addition is not reflected. It is necessary to divide the circuit into the two (2) parts.



For the application instruction that performs operation with carry, however, multi-output circuits pose no problem because the flag is processed automatically and internally.

7.6.3 Influence by Input/Output Processing

The input/output relay can be used as a byte or word register. When it is used as a source or destination, however, all data are read and written in and out of the data memory. At the time when the application instruction has been executed, the result will not be output to the I/O device.


The final result of the operation is processed in batch and exchanged between the I/O device and data memory. At this time, the result is actually output to the I/O device.

7.6.4 Promoting Programming Efficiency

The TCmini need not consider stacks unlike the PLC with serial Boolean algebra processing system, because it has the special direct ladder-diagram input system. When the characteristics are fully understood, however, a program becomes more efficient with fewer instruction words.


(1) How to count the number of instruction words

The following sections necessary for constructing a circuit are counted as one (1) word.




Each section enclosed by dotted line is counted as one (1) word. The line required for constructing a circuit as marked "*" is also counted as one (1) word. In the above example, there are 13 words.


(2) Generally, if the circuit is left-down, a program becomes efficient with fewer number of instruction words.



[1] Left-down circuit, 7 words




[2] Middle-down circuit, 8 words



[3] Right-down circuit, 10 words

Left-down circuit [1] shown above is more efficient than circuits [2] and [3].
The number of instruction words of circuit [1], [2] and [3] is seven (7), eight (8) and ten (10), respectively.
All input instructions including the contact and connection ones are counted as one (1) word or two (2) words.
The output (coil) instructions including the application instruction are counted as one (1) word to five (5) words. For details, see Para. 7.2.

The following circuits require fewer words when formed left-down.



Section 8 TCPRGOS


TCPRGOS–W(E) is the sequence program development tool which operates on your personal computer.

8.1 Operating Environment of TCPRGOS

Items	Conditions
CPU	Personal computer incorporating CPU whose capacity is Pentium 200 MHz or over (Use of Pentium 233 MHz or over is recommended.)
Hard disk capacity	Free space of 10 M byte or over
Floppy disk drive	One (1) drive or more that can read the 1.44 format data.
Minimum available memory	Windows98: 16 MB or over (Use of 32 MB or over is recommended.) WindowsNT: 32 MB or over
Operating system	Windows98 or WindowsNT 4.0
Display	Display that can be connected with computer and designed for Windows98 or WindowsNT with resolution of 640 × 480 dots or over. (Recommendable resolution is 1024 × 768 dots or over.)
RS232C serial communication port	One (1) port
Others	Keyboard, mouse, printer, FD, modem (for remote maintenance system) that can be connected with computer and designed for Windows98 or WindowsNT.

8.2 Connection

Connect the TS1000 TCPRG port with the COM port of your personal computer, using a 9-pin cross cable.



TS1000 TCPRG port　　COM port of personal computer

Cross cable

TS1000 D–sub 9-pin female		DOS/V D–sub 9-pin female
1		1
RXD 2	⟋	2 RXD
TXD 3	⟍	3 TXD
DTR 4	⟋	4 DTR
FG 5	—	5 FG
6	⟍	6 DSR
RTS 7	⟋	7 RTS
CTS 8	⟍	8 CTS
9		9
Frame	—	Frame


8.3 How to Install the TCPRGOS

⚠ **CAUTION**	Before performing the setting given below, back up the TCPRGOS–W(E) floppy disks.


⚠ **CAUTION**	Before upgrading, be sure to uninstall the TCPRGOS–W(E) of the previous version. For details, see Para. 8.11 of this manual.


This paragraph describes the setup procedures when the floppy drive is set as the "A" drive.

- Start up the Explorer and double-click "SETUP.EXE" in the "A" drive.





- The TCPRGOS–W(E)V□.□□ Installer starts. Press the [Next] button.






- Now, execute the operation according to the directions of the Installer.








- Click the [Finish] button, and the TCPRGOS–W(E) has been installed.



8.4 Starting the TCPRGOS

- Starting TCPRGOS–W
  - Double-click the TCPRGOS–W icon on the desktop.
  - The TCPRGOS–W starts.



Status bar:

Information on current system connection status, message from application to user, etc. is displayed.

- Connected PLC model is displayed.
- Connection method is displayed, which is specified in communication setup.
- Connection/disconnection status is displayed.
- Connected PLC number is displayed.
- RUN/STOP status of PLC is displayed.

8.5 Creating a Circuit


- Creating a New Ladder Program and Saving in a File

  - Program to be created.




8.5.1 Start of New Ladder Editor


- Click [New] from the [File] menu.



- As the [New] dialog box appears, click [Ladder Program] from the [New] box.




- The ladder editor starts newly.




8.5.2 Creation of Circuit


- Point [Normal Open Contact] from the [Insert] menu, then click [AND].




- The symbol of normal open contact is entered at the cursor position and the contact address input dialog box appears.




- Move the cursor to the contact address edit box and enter “X000”. Then click the [OK] button.




- The normal open contact of address X000 is entered.




- Click [Coil] from the [Insert] menu.




- The symbol of coil is entered and the coil input dialog box appears.



- Enter “Y100” in the coil address edit box and click the [OK] button.



- One (1) circuit is created as shown below.




One Point Advice

- Cursor movement
  If a desired position is clicked by means of the mouse, the cursor moves to that position. The cursor can also move vertically and horizontally by means of the arrow keys. The symbol other than coil is entered at the cursor position.


- Address change
  When the mouse is moved to an already entered contact or coil and double-clicked, the address input dialog box appears. Move the cursor to the edit box where the address is to be entered , modify the address, then click the [OK] button.

8.5.3 Input of Perpendicular Line Symbol

- Point [Connecting Line] from the [Insert] menu and click [Perpendicular].




- The symbol of perpendicular line is entered.




8.5.4 Input of Timer in Coil

- Click [Coil] from the [Insert] menu.




- The symbol of coil is entered and the coil address input dialog box appears.


- Enter “T000” in the coil address.




- Click the first argument edit box to move the cursor.



- Enter “32” in the first argument and click the [OK] button.




- The following circuit is created.




8.5.5 Input of Function Command in Coil


- Point [Normal Close Contact] from the [Insert] menu and click [AND].




- The symbol of normal close contact is entered and the contact address input dialog box appears. Enter the contact address “R000”.



- The normal close contact of R000 is entered.




- Click [Coil] from the [Insert] menu.




- The symbol of coil is entered and the coil address input dialog box appears.


- Enter “FL035” in the coil address, and move the cursor to the first argument edit box.



- Enter “D000” in the first argument.




- The following circuit is created.



One Point Advice


- Coil input dialog box
  After “FL020” is entered, the coil input dialog box is as follows:




In this way, the status of the coil input dialog box differs with the type of the coil.

8.5.6 Input of Pair Coil


- Point [Normal Open Contact] from the [Insert] menu and click [AND].




- The symbol of normal open contact is entered and the contact address input dialog box appears. Enter “X200” in the contact address.




- The normal open contact of X200 is entered.




- Click [Coil] from the [Insert] menu.



- The symbol of coil is entered and the coil address input dialog box appears.
  Enter “L000” in the coil address.




- The following circuit is created.




8.5.7 Change of Connecting Cine with Contact


- Move the mouse to the head of the latch reset and click. The cursor moves to the head position.



- Point [Normal Close Contact] from the [Insert] menu and click [AND].



- The symbol of normal close contact is entered and the contact address input dialog box appears. Enter “R100” in the contact address.




- The normal close contact is inserted at a place where the connecting line was input and the circuit is changed as shown below.




8.5.8 Renumber of Circuits

- Click [Renumber] from the [View] menu.




- Words [NEW] are cleared and the circuits are renumbered.




8.5.9 Saving in File


- Click [Close] from the [File] menu.



- As the following message box appears, click the [YES] button.




 The following file saving dialog box appears.




 Click the [Save] button. The ladder editor is closed and the created circuit is saved in the file of “test.tsq”.

8.5.10 Opening of Existing File


- Click [Open] from the [File] menu.




- The following [Open] dialog box appears.



- Change the type of file to “Ladder Program”.



- Select “test.tsq” among the displayed ladder programs.




- Click the [Open] button, and the file of “test.tsq” is opened.

8.5.11 Modifying and Saving of Existing Circuit


- Move the cursor to the circuit of the latch reset.



- Point [Delete] from the [Edit] menu and click [Line].




- The specified line is deleted.




- Move the mouse pointer to circuit number 0002 and click (circuit selection).


- Point [Delete] from the [Edit] menu and click [Circuit].




- The circuit of circuit number 0002 is deleted.



- Click [Save] from the [File] menu.




- The file of “test.tsq” is overwritten.




8.6 Transferring Circuit

8.6.1 Check for Communication Setup

- Click [Option] from the [Communication] menu.



- The following communication setup dialog box appears.




Caution !

The baudrate is changed over automatically.
Select the connection method alone. Normally, the property need not be changed.

8.6.2 Connection

- Click [Connect] from the [Communication] menu, and the PLC is connected with the personal computer.

Check for the status bar on the bottom of the window.




Caution !


Baudrate that can be connected is recognized automatically, and the connected baudrate is displayed on the status bar.

8.6.3 Transfer


- Click [Transfer] from the [File] menu.




 When the following transfer dialog box appears, click the [OK] button.



 Transfer starts. During the transfer, the following transfer progress dialog box appears.




 When the transfer has finished, the transfer finish message box appears. Click the [OK] button then.



Caution !


While the TCmini is running, the following message box appears. Select [No] because data change is not possible while the TCmini is running.




8.7 Online Operation

8.7.1 Start Online Ladder Editor


- Click [Ladder Editor] from the [Tool] menu.



- Data transfer from the PLC to the personal computer starts and transfer progress dialog box is displayed.




- When the transfer has finished, the transfer progress dialog box disappears and the online ladder editor starts.




8.7.2 Change of Online Ladder Editor Circuit

- Modification can be made in the same manner as the offline ladder editor. To change the coil address, observe the following steps.


1) Move the cursor to the coil (Z100) of circuit number 0000.



2) Click [Input Address] from the [Edit] menu.




3) As the coil address input dialog box appears, change the coil address to "Y200".




4) The coil address is changed.

5) Click [Write to PLC] from the [Operation] menu.




6) As the following message box appears, click the [YES] button.




7) The transfer progress dialog box is displayed and writing to PLC starts. When it has finished, the transfer progress dialog box is cleared.

8) Click [Reload] from the [Operation] menu.



9) As the following message dialog box appears, click the [YES] button.




10) The online ladder editor is closed and the transfer progress dialog box appears. Then the transfer starts.

11) When the transfer has finished, the transfer progress dialog box is closed and the online ladder editor starts again.


8.8 Monitor

8.8.1 Selection of Monitor Mode

- Click [Monitor Mode] from the [View] menu.




- The monitor mode replaces the edit mode.




8.8.2 Designation of PLC RUN or STOP and Compulsive Setting of Contact


1) Click [RUN] from the [Operation] menu.




2) As the following message box appears, click the [YES] button to run the PLC.




3) Make sure that the cursor is located at the normal open contact of “Z000” in circuit number 0000. Then click [Force Set] from the [Operation] menu.




4) As the following message box appears, click the [YES] button.




5) The normal open contact of “Z000” in circuit number 0000 is compulsively set.




6) Click [STOP] from the [Operation] menu to stop the PLC.




7) The normal close contact is set and monitored as shown below.




8) Click [RUN] from the [Operation] menu.



9) As the following message box appears, click the [YES] button to run the PLC.




10) Monitoring is performed as shown below.



8.8.3 Quit of Monitor Mode

- Click [Edit Mode] from the [View], and the monitor mode terminates with the edit mode selected.



Caution !

In the monitor mode, editing of a circuit (modification, addition, deletion, etc.) is not allowed. Edit after selecting the edit mode. Modified circuit cannot be monitored unless written to the PLC. After writing it to the PLC, read and call the latest online ladder editor.


One Point Advice

- Changeover of decimal/hexadecimal notation

  The notation comes in two (2) types; decimal notation and hexadecimal notation.

  To change over the notation, click [Decimal] or [Hexadecimal] from the [View] menu. The menu item marked with "√" on the left side is the currently selected notation.


  Example of hexadecimal notation:




8.9 Monitoring Register Data

8.9.1 Start of Online Register Editor

- Click [Register Editor] from the [Tool] menu.




- The online register editor starts.




8.9.2 Compulsive Setting of Device


- Click Bit E of D002 by means of the mouse and move the cursor.




- Click [Set] from the [Edit] menu.



- As the following message dialog appears, click the [OK] button.




- Bit E of D000 is set compulsively.




8.9.3 Modification of Word Data Specified by Address


- Move the mouse pointer to the hexadecimal data area of D002, then click.




- Click [Change Data] from the [Edit] menu.



- The following [Change Data] dialog box appears. Change the data to "FFFF" and click the [OK] button.




- The data are changed.



8.10 Quitting the TCPRGOS

8.10.1 Exit from Active Editor

 Click [Close] from the [File] menu. The active editor terminates.




 Repeat Step above and quit all editors (online ladder editor, online register editor, offline ladder editor (“test.tsq”)).

One Point Advice


 Active editor

Indicates the editor which is operated currently. It is located on the forefront among the TCPRGOS–W windows. To change over the active editor, click the editor name shown in the “Window” menu.



8.10.2 Quit of TCPRGOS

- Click [Quit Application] from the [File] menu. The TCPRGOS–W terminates to close the window.



Caution !

You need not quit the TCPRGOS–W after closing all active editors. You can quit by only clicking [Quit Application] from the [File] menu with the editors opened. When change was made in any editor, appropriate message box appears to ask whether each change should be saved or not.

8.11 How to Uninstall

Before uninstalling the TCPRGOS–W(E), delete the registered OCX file. Otherwise, unnecessary key is left in the registry.

Deletion of registered OCX file

Double-click and execute "Unregist.bat" in the install directory.


When the system displays a message box, register or deletion of OCX file has finished.

Uninstall the TCPRGOS–W(E) by selecting [Control panel] – [Add or delete application].

Section 9 Advice of Sequence Program Creation


This section describes some sample circuits which you can refer to when creating a sequence program. Refer to the appendix system sequence also.

9.1 Turning ON/OFF External Output by DOUT Command




R400 turns on and off by the DOUT(1) and DOUT(–) commands, respectively.
As Y100 operates, interlocked with R400 ON/OFF, the R400 state can be output to an external device, interlocked with the DOUT command.
(The R400 state can be output to any destination by changing the output relay address.)

9.2 Input of External Signal by DIN Command




The R200 state is read by means of DIN(1) and DIN(–) commands.
As R200 operates, interlocked with X000 ON/OFF, the X000 state can be read by the robot's DIN1 command.
(Any input destination can be ready by the DIN(1) command by changing the input relay address.)

9.3 Output of AUTORUN Signal to External Device




R538 is the interface relay indicating that the robot is working in the automatic operation. This state is output to an external device. (It can be output to any output designation by changing the output relay address.)

9.4 Generating Alarm in TS1000 by External Signal




When external input IN3 (X002) turns on, R310 turns on accordingly. When R310 turns on, an alarm (1–037) is generated in the robot controller.
(The alarm can be generated by any input by changing the input relay address.)

9.5 Output of Value to Control Panel




The content of D170 is transferred to D150 by extension instruction (or command) FL006. The FL command executes a command as per the signal state. In this example, as the signal is always ON, data is transferred in each scanning.
In D170, a value written to system variable PLCDTAW1 (robot language) by the robot program is stored. In the above program, this value is transferred to D150 which is the exclusive register indicating a 7-segment value of the control panel.
By changing the source register, any data such as constant and sequence operation result can be displayed.

9.6 Change of Output Destination by Sequence Parameter




R510 is the relay which can be turned on and off by user parameter of TS1000.
When "1" (ON) is specified for appropriate parameter, DOUT(1) turns on Y100.
When "0" (OFF) is set, DOUT(1) turns on Y101. When SEQPARA* of R510 ~ R517 is used, you can change the sequence motion by the robot parameter without changing the ladder sequence

9.7 Circuit Generating 1 Pulse at Power ON



Just after the power is turned on, R000 turns on in the initial scanning. As R001 is ON in the 2nd scanning, R000 turns off.
This can be realized by one (1) command when F*63 is used.


9.8 Circuit Generating 1 Pulse at Start



At the start of input X000, one (1) pulse is generated.

Note: If the PLC starts running while X000 is ON, R000 turns on in the 1st scanning.


9.9 Circuit Generating 1 Pulse at Fall (1)



With the fall of input X000, one (1) pulse is generated.


Caution: When X000 is OFF, R000 turns on in the 1st scanning after power ON. (Necessary measures are taken in Para. 9.10.)
If the PLC starts running while X000 is OFF, R000 turns on in the 1st scanning.

9.10 Circuit Generating 1 Pulse at Fall (2)




With the fall of input X000, one (1) pulse is generated. R000 will not turn on at power ON.

9.11 Self-Holding Circuit (Priority Is Given to Reset)




When X000 is turned on once while X001 is OFF, output R000 turns on, which is kept even after X000 is OFF. When X001 turns on, R000 turns off.

9.12 Self-Holding Circuit (Priority Is Given to Set)




When X000 is turned on once while X001 is OFF, output R000 turns on, which is kept even after X000 is OFF. When X001 turns on, R000 turns off.
If X000 is ON while X001 is ON, R000 turns on.

9.13 Interlock Circuit




Either X000 or X001 whose circuit turns on first is ON, and the other circuit will not turn on. When both circuits are turned on at the same time, the upper circuit (Y100) turns on by the scanning system. Useful for the motor CW/CCW circuit.

9.14 Alternate Circuit




Every time input X000 has turned on, output R001 is reversed. Thus, an alternate output can be given, using the normal open contact of the momentary switch.

9.15 Non-Modal Timer Circuit




When input X000 turns on, R000 turns on for the time set on the timer.
If the ON time of input X000 is shorter than the timer-set value, the ON time of R000 is identical with the ON time of X000.

9.16 Non-Modal Start Timer Circuit



When input X000 turns on, R000 turns on for the time set on the timer.


9.17 Circuit Turning ON and OFF at Predetermined Intervals



A050 is the special auxiliary relay which repeats ON and OFF at one (1)-second intervals.

A051 is the special auxiliary relay which repeats ON and OFF at two (2)-second intervals.

9.18 Step Sequence Circuit




When X000 turns on, R000 turns on accordingly.
When X001 is ON, R001 is ON with R000 OFF.
When X002 is ON, R002 is ON with R001 OFF.

Section 10 Troubleshooting

10.1 Robot Servo Will Not Turn ON

[1] Is interface relay SVOFF (R33C) turned on?
When the SVOFF signal turns off, the servo turns off. Design the sequence and external circuit, therefore, so that interface relay SVOFF can be turned on.

[2] Is the alarm (8–014 Emergency Stop SW ON) generated?
If this alarm is generated, make sure that the EMERGENCY stop pushbutton switch is not pressed.
Wiring of the EMERGENCY stop switch is the special line. Perform check on the wiring between EMS1B and EMS1C, EMS2B and EMS2C connected to the INPUT connector.



10.2 Program Cannot Run

[1] Is the program selected?

[2] Is the servo ON?

[3] Is interface relay STOP (R338) ON?
When the STOP signal turns off, the robot stops. Design the sequence and external circuit, therefore, so that interface relay STOP can be turned on.

[4] Is interface relay BREAK (R33B) ON?
Like the STOP signal, when the BREAK signal turns off, the robot slows down and stops.

10.3 Sequence Program Cannot Be Transferred by TCPRGOS

The sequence program areas which can be used by the user are areas 1 and 2. Change the sequence area, referring to Para. 2.4.

10.4 Sequence Program Is Cleared at Power ON

Sequence program area 1 is the RAM area for debugging. The sequence program is cleared after the power is turned off, then on again. To use the sequence program after debugging (check of operation), transfer it to program area 2 beforehand.

10.5 TCPRGOS Will Not Start

Are the specifications of your personal computer identical with those of the TCPRGOS? (See Para. 8.1.)

If the TCPRGOS will not operate just after it is installed, the DLL file version may be old. When this is the case, install the newest DLL file according to the following procedures.

[1] Quit all other applications, then make sure that the following files are present in the system directory.

MFC42.DLL MFC42LOC.DLL MSVCRT.DLL
CMCTLJP.DLL COMCTL32.OCX

[2] Confirm the version of each file. If it is older than the version below, delete the file.

File name	Version
MFC42.DLL	5.0.000
MFC42LOC.DLL	5.0.000
MSVCRT.DLL	5.00.7303
CMCTLJP.DLL	5.01.4319
COMCTL32.OCX	5.01.4319

Right-click a relevant file and select [Property]. When the dialog window is displayed, select the version information tag and check for the version.

[3] Install the TCPRGOS software again, referring to Para. 8.3.

10.6 Sequence-Related Alarm Occurred in TS1000

8–227 PLC STOP

Possible Cause: The sequence of the PLC remains stopped.

Remedies: If the sequence program has been stopped intentionally from the TCPRGOS, there is no problem at all. Turn the power off, then on again, or start the sequence program from the TCPRGOS.
This alarm may occur if the hardware went wrong or an error was found in the sequence program. When this happens, the following alarm (1–***) is also generated at the same time. Identify and remove the cause of the error to start the PLC.

1–164 PLC Backup data error

Possible Cause: The sequence program of TCmini has been destroyed.

Remedy: Transfer the program again, using the TCPRGOS.

1–166 PLC Remote unit error

Possible Causes:
[1] The setting of connecting the extension I/O unit is not identical with the user parameter setting.
[2] Wiring of the cable is done incorrectly.
[3] The connected I/O unit will not operate normally.

Remedies:
[1] Perform check on the user parameter setting. (See Para. 3.7.3.)
[2] Connect the cable. (See Para. 3.7.2.)
[3] If the external power supply is used, turn on the power of the extension I/O unit before the controller power.
If the I/O unit has malfunctioned, contact our after-sale service agent in your territory.

1–169 PLC Undefine label

Possible Cause: The label used in the sequence program is not defined.

Remedy: Correct the sequence program, using the TCPRGOS.

1–170 PLC Invalid command

Possible Cause: An illegal command (i.e., instruction word) is used in the sequence program.

Remedy: Correct the sequence program, using the TCPRGOS.

1–173 PLC Overlap label

Possible Cause: Duplicate definition of the label used in the sequence program.

Remedy: Correct the sequence program, using the TCPRGOS.

Section 11 Appendix

List of Relays

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
X00W	IN16	IN15	IN14	IN13	IN12	IN11	IN10	IN9	IN8	IN7	IN6	IN5	IN4	IN3	IN2	IN1
X01W				HI5	HI4	HI3	HI2	HI1	UFI2	UFI1		IN21	IN20	IN19	IN18	IN17
X02W	Reserved for the system								Reserved for the system							
X03W																
X04W	EI16	EI15	EI14	EI13	EI12	EI11	EI10	EI9	EI8	EI7	EI6	EI5	EI4	EI3	EI2	EI1
X05W	EI32	EI31	EI30	EI29	EI28	EI27	EI26	EI25	EI24	EI23	EI22	EI21	EI20	EI19	EI18	EI17
X06W	EI48	EI47	EI46	EI45	EI44	EI43	EI42	EI41	EI40	EI39	EI38	EI37	EI36	EI35	EI34	EI33
X07W	EI64	EI63	EI62	EI61	EI60	EI59	EI58	EI57	EI56	EI55	EI54	EI53	EI52	EI51	EI50	EI49
Y10W	OUT 16	OUT 15	OUT 14	OUT 13	OUT 12	OUT1 1	OUT 10	OUT 9	OUT 8	OUT 7	OUT 6	OUT 5	OUT 4	OUT 3	OUT 2	OUT 1
Y11W					HO4	HO3	HO2	HO1	UFO 2	UFO 1						OUT 17
Y12W	Reserved for the system								Reserved for the system							
Y13W																
Y14W	EO16	EO15	EO14	EO13	EO12	EO11	EO10	EO9	EO8	EO7	EO6	EO5	EO4	EO3	EO2	EO1
Y15W	EO32	EO31	EO30	EO29	EO28	EO27	EO26	EO25	EO24	EO23	EO22	EO21	EO20	EO19	EO18	EO17
Y16W	EO48	EO47	EO46	EO45	EO44	EO43	EO42	EO41	EO40	EO39	EO38	EO37	EO36	EO35	EO34	EO33
Y17W	EO64	EO63	EO62	EO61	EO60	EO59	EO58	EO57	EO56	EO55	EO54	EO53	EO52	EO51	EO50	EO49
X20W	FI16	FI15	FI14	FI13	FI12	FI11	FI10	FI9	FI8	FI7	FI6	FI5	FI4	FI3	FI2	FI1
X21W	FI32	FI31	FI30	FI29	FI28	FI27	FI26	FI25	FI24	FI23	FI22	FI21	FI20	FI19	FI18	FI17
X22W	FI48	FI47	FI46	FI45	FI44	FI43	FI42	FI41	FI40	FI39	FI38	FI37	FI36	FI35	FI34	FI33
X23W	FI64	FI63	FI62	FI61	FI60	FI59	FI58	EI57	FI56	FI55	FI54	FI53	FI52	FI51	FI50	FI49
X24W	Reserved for the system								Reserved for the system							
X25W																
X26W																
X27W																
Y30W	FO16	FO15	FO14	FO13	FO12	FO11	FO10	FO9	FO8	FO7	FO6	FO5	FO4	FO3	FO2	FO1
Y31W	FO32	FO31	FO30	FO29	FO28	FO27	FO26	FO25	FO24	FO23	FO22	FO21	FO20	FO19	FO18	FO17
Y32W	FO48	FO47	FO46	FO45	FO44	FO43	FO42	FO41	FO40	FO39	FO38	FO37	FO36	FO35	FO34	FO33
Y33W	FO64	FO63	FO62	FO61	FO60	FO59	FO58	FO57	FO56	FO55	FO54	FO53	FO52	FO51	FO50	FO49
Y34W	Reserved for the system								Reserved for the system							
Y35W																
Y36W																
Y37W																

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R00W																
R01W																
R02W																
R03W																
R04W																
R05W																
R06W																
R07W																
R10W																
R11W																
R12W																
R13W																
R14W																
R15W																
R16W																
R17W																

TCmini → Main unit of robot controller (R200 ~ R37F)

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R20W	DIN 16	DIN 15	DIN 14	DIN 13	DIN 12	DIN 11	DIN 10	DIN 9	DIN 8	DIN 7	DIN 6	DIN 5	DIN 4	DIN 3	DIN 2	DIN 1
R21W	DIN 32	DIN 31	DIN 30	DIN 29	DIN 28	DIN 27	DIN 26	DIN 25	DIN 24	DIN 23	DIN 22	DIN 21	DIN 20	DIN 19	DIN 18	DIN 17
R22W	DIN 48	DIN 47	DIN 46	DIN 45	DIN 44	DIN 43	DIN 42	DIN 41	DIN 40	DIN 39	DIN 38	DIN 37	DIN 36	DIN 35	DIN 34	DIN 33
R23W	DIN 64	DIN 63	DIN 62	DIN 61	DIN 60	DIN 59	DIN 58	DIN 57	DIN 56	DIN 55	DIN 54	DIN 53	DIN 52	DIN 51	DIN 50	DIN 49
R24W	DIN 116	DIN 115	DIN 114	DIN 113	DIN 112	DIN 111	DIN 110	DIN 109	DIN 108	DIN 107	DIN 106	DIN 105	DIN 104	DIN 103	DIN 102	DIN 101
R25W	DIN 132	DIN 131	DIN 130	DIN 129	DIN 128	DIN 127	DIN 126	DIN 125	DIN 124	DIN 123	DIN 122	DIN 121	DIN 120	DIN 119	DIN 118	DIN 117
R26W	DIN 148	DIN 147	DIN 146	DIN 145	DIN 144	DIN 143	DIN 142	DIN 141	DIN 140	DIN 139	DIN 138	DIN 137	DIN 136	DIN 135	DIN 134	DIN 133
R27W	DIN 164	DIN 163	DIN 162	DIN 161	DIN 160	DIN 159	DIN 158	DIN 157	DIN 156	DIN 155	DIN 154	DIN 153	DIN 152	DIN 151	DIN 150	DIN 149
R30W						LMIT OFF	MLT RST	OFS MOD	HAND IN8	HAND IN7	HAND IN6	HAND IN5	HAND IN4	HAND IN3	HAND IN2	HAND IN1
R31W	AL1-044	AL1-043	AL1-042	AL1-041	AL1-040	AL1-039	AL1-038	AL1-037	AL4-080	AL4-079	AL4-078	AL4-077	AL8-272	AL8-271	AL8-270	AL8-269
R32W									J_AXIS3	J_AXIS2	J_AXIS1	J_DIRECT	J_COOD	J_SPEED	J_REMOTE	J_MOVE
R33W			I_TEACH	SV OFF	BREAK	LOW_SPD	CYCLE	STOP	EX_SVON	RUN	ALM_RST	DO_RST	CYC_RST	STEP_RST	PRG_RST	STROBE
R34W	DIN 316	DIN 315	DIN 314	DIN 313	DIN 312	DIN 311	DIN 310	DIN 309	DIN 308	DIN 307	DIN 306	DIN 305	DIN 304	DIN 303	DIN 302	DIN 301
R35W	DIN 332	DIN 331	DIN 330	DIN 329	DIN 328	DIN 327	DIN 326	DIN 325	DIN 324	DIN 323	DIN 322	DIN 321	DIN 320	DIN 319	DIN 318	DIN 317
R36W	DIN 348	DIN 347	DIN 346	DIN 345	DIN 344	DIN 343	DIN 342	DIN 341	DIN 340	DIN 339	DIN 338	DIN 337	DIN 336	DIN 335	DIN 334	DIN 333
R37W	DIN 364	DIN 363	DIN 362	DIN 361	DIN 360	DIN 359	DIN 358	DIN 357	DIN 356	DIN 355	DIN 354	DIN 353	DIN 352	DIN 351	DIN 350	DIN 349

Main unit of robot controller → TCmini (R400 ~ R57F)

Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
R40W	DOUT 16	DOUT 15	DOUT 14	DOUT 13	DOUT 12	DOUT 11	DOUT 10	DOUT 9	DOUT 8	DOUT 7	DOUT 6	DOUT 5	DOUT 4	DOUT 3	DOUT 2	DOUT 1
R41W	DOUT 32	DOUT 31	DOUT 30	DOUT 29	DOUT 28	DOUT 27	DOUT 26	DOUT 25	DOUT 24	DOUT 23	DOUT 22	DOUT 21	DOUT 20	DOUT 19	DOUT 18	DOUT 17
R42W	DOUT 48	DOUT 47	DOUT 46	DOUT 45	DOUT 44	DOUT 43	DOUT 42	DOUT 41	DOUT 40	DOUT 39	DOUT 38	DOUT 37	DOUT 36	DOUT 35	DOUT 34	DOUT 33
R43W	DOUT 64	DOUT 63	DOUT 62	DOUT 61	DOUT 60	DOUT 59	DOUT 58	DOUT 57	DOUT 56	DOUT 55	DOUT 54	DOUT 53	DOUT 52	DOUT 51	DOUT 50	DOUT 49
R44W	DOUT 116	DOUT 115	DOUT 114	DOUT 113	DOUT 112	DOUT 111	DOUT 110	DOUT 109	DOUT 108	DOUT 107	DOUT 106	DOUT 105	DOUT 104	DOUT 103	DOUT 102	DOUT 101
R45W	DOUT 132	DOUT 131	DOUT 130	DOUT 129	DOUT 128	DOUT 127	DOUT 126	DOUT 125	DOUT 124	DOUT 123	DOUT 122	DOUT 121	DOUT 120	DOUT 119	DOUT 118	DOUT 117
R46W	DOUT 148	DOUT 147	DOUT 146	DOUT 145	OUT 144	DOUT 143	DOUT 142	DOUT 141	DOUT 140	DOUT 139	DOUT 138	DOUT 137	DOUT 136	DOUT 135	DOUT 134	DOUT 133
R47W	DOUT 164	DOUT 163	DOUT 162	DOUT 161	DOUT 160	DOUT 159	DOUT 158	DOUT 157	DOUT 156	DOUT 155	DOUT 154	DOUT 153	DOUT 152	DOUT 151	DOUT 150	DOUT 149
R50W							MLT END	OFS END	HAND OUT8	HAND OUT7	HAND OUT6	HAND OUT5	HAND OUT4	HAND OUT3	HAND OUT2	HAND OUT1
R51W									SEQ PAR8	SEQ PAR7	SEQ PAR6	SEQ PAR5	SEQ PAR4	SEQ PAR3	SEQ PAR2	SEQ PAR1
R52W	O16_ SEL	O15_ SEL	O14_ SEL	O13_ SEL	O12_ SEL	O11_ SEL	O10_ SEL	O9_ SEL	I16_S EL	I15_S EL	I14_S EL	I13_S EL	I12_S EL	I11_ SEL	I10_S EL	I9_ SEL
R53W			ALAR M	BT_ ALM	CYC _ST	LOW _ST	CYC _END	AUTO RUN	SYS_ RDY	EST HOST	EXT SIG	INT	TEAC H	ACK	SV_ RDY	EMG_ ST
R54W	DOUT 316	DOUT 315	DOUT 314	DOUT 313	DOUT 312	DOUT 311	DOUT 310	DOUT 309	DOUT 308	DOUT 307	DOUT 306	DOUT 305	DOUT 304	DOUT 303	DOUT 302	DOUT 301
R55W	DOUT 332	DOUT 331	DOUT 330	DOUT 329	DOUT 328	DOUT 327	DOUT 326	DOUT 325	DOUT 324	DOUT 323	DOUT 322	DOUT 321	DOUT 320	DOUT 319	DOUT 318	DOUT 317
R56W	DOUT 348	DOUT 347	DOUT 346	DOUT 345	OUT 344	DOUT 343	DOUT 342	DOUT 341	DOUT 340	DOUT 339	DOUT 338	DOUT 337	DOUT 336	DOUT 335	DOUT 334	DOUT 333
R57W	DOUT 364	DOUT 363	DOUT 362	DOUT 361	DOUT 360	DOUT 359	DOUT 358	DOUT 357	DOUT 356	DOUT 355	DOUT 354	DOUT 353	DOUT 352	DOUT 351	DOUT 350	DOUT 349


Bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
E00W																
E01W					Edge relays											
E02W																
E03W																
L00W					Latch relays											
L01W																
T/C00W																
T/C01W					Timers (100 ms)/counters											
T/C02W																
T/C03W																
T/C04W					Timers (10 ms)/counters											
T/C05W																
A00W																
A01W																
A02W					Special auxiliary relays											
A03W																
A04W																
A05W																

List of Registers


Register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
D00*																
D01*																
D02*							Data registers									
D03*																
D04*																
D05*																
D06*																
D07*						Data registers (backup)										
D10*																
D11*																
D12*																
D13*	AL10	AL09	AL08	AL07	AL06	AL05	AL04	AL03	AL02	AL01	AL NO					STEP
D14*																
D15*																USER
D16*			PSN_W6	PSN_W5	PSN_W4	PSN_W3	PSN_W2	PSN_W1	PLC DATA R8	PLC DATA R7	PLC DATA R6	PLC DATA R5	PLC DATA R4	PLC DATA R3	PLC DATA R2	PLC DATA R1
D17*			PSN_J6	PSN_J5	PSN_J4	PSN_J3	PSN_J2	PSN_J1	PLC DATA W8	PLC DATA W7	PLC DATA W6	PLC DATA W5	PLC DATA W4	PLC DAT AW3	PLC DAT AW2	PLC DAT AW1
P00*																
P01*					Timer (100 ms) current values/counter current values											
P02*																
P03*																
P04*																
P05*					Timer (10 ms) current values/counter current values											
V00*																
V01*					Timer (100 ms) set values/counter set values											
V02*																
V03*																
V04*																
V05*					Timer (10 ms) set values/counter set values											

Standard ladder sequence program

File Name: TS1KSEQ01.tld Page: 1 / 3



File Name: TS1KSEQ01.tld



File Name: TS1KSEQ02.tld Page: 3 / 3

