Station Equipment Maintenance Manual

Sample document for testing PDF import in Metro Fix Assist. Not an official procedure.

3.1 Ventilation Damper Fails to Open

Symptoms: damper position alarm on the BMS, airflow low in the concourse, damper actuator humming. Fault code VDM-E14.

WARNING: Isolate the actuator supply before touching the damper blades.

1. Read the alarm and damper number on the BMS screen.
2. Check the actuator supply fuse in the local control panel.
3. Operate the manual override lever and check the blades move freely.
4. Clean debris from the blade linkage and lubricate the pivot points.
5. Restore supply, command OPEN from the BMS and confirm the end-switch indication.

3.2 Smoke Extract Fan Fails to Start

Symptoms: fan does not start on test, fire mode command not acknowledged, motor contactor not pulling in. Fault code SEF-E62.

CAUTION: Smoke extract fans are life-safety equipment. Inform the station controller before testing.

1. Check the fan isolator is ON and not locked out.
2. Check the control voltage (230 V AC) at the starter panel.
3. Reset the motor protection relay and attempt a local start.
4. If the contactor does not pull in, check the fire alarm interface relay.
5. Record the result in the life-safety test log.

3.3 Platform Lighting Flickering

Symptoms: LED fittings flicker or go dark along the platform edge, emergency lights on battery.

1. Identify the affected lighting circuit from the distribution board schedule.
2. Check the MCB and the RCD for the circuit and reset if tripped.
3. Measure the supply voltage at the first fitting of the circuit.
4. Replace failed LED drivers and log the fitting numbers.

3.4 ભૂગર્ભ સ્ટેશનમાં પાણી લીકેજ

લક્ષણો: છત અથવા દીવાલમાંથી પાણી ટપકે છે, પ્લેટફોર્મ પર પાણી ભરાય છે.

1. વિસ્તારને બેરિકેડ કરો અને લપસણી સપાટીની ચેતવણી લગાવો.
2. પાણીનો સ્રોત શોધો અને નજીકનાં ઇલેક્ટ્રિકલ સાધનો આઇસોલેટ કરો.
3. સમ્પ પંપ ચાલુ છે તે તપાસો અને સ્ટેશન કંટ્રોલરને જાણ કરો.