

IDENTIFICATION

PRODUCT CODE: MAINDEC-08-DHKMA-D-D
PRODUCT NAME: PDP-8E EXTENDED MEMORY DATA & CHECKERBOARD TEST
RELEASE DATE MAY 1978
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: VERNON FREY
D. MACOMBER
BRUCE HANSEN

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1970, 1978

BY DIGITAL EQUIPMENT CORPORATION

1. **ABSTRACT**

MODIFIED TO RUN ON APT SYSTEMS, APRIL 1975.
SEE NOTES AT END OF DOCUMENT.

MODIFIED TO RUN ON CLASSIC 8 SYSTEMS (CONSOLE PACKAGE).
SEE SECTION 10.

MODIFIED TO RUN ON SYSTEMS WITH NO CONSOLE TERMINAL.
REFER TO SECTIONS STARTING AT SECTION 11 FOR PROGRAM INITIALIZATION,
OPERATING PROCEDURES, SWITCH REGISTER SETTINGS AND ERROR REPORTING.

THE DIAGNOSTIC HAS BEEN MODIFIED TO ACCOMMODATE THE KT8-A
MEMORY MANAGEMENT OPTION WITH MEMORY ADDRESSING OF UP TO 128K
WORD OF READ WRITE MEMORY.

THE PDP-8E EXTENDED MEMORY DATA & CHECKERBOARD TEST IS
DESIGNED TO DETECT MEMORY FAILURE DUE TO SENSE-LINE
NOISE UNDER WORST CASE CONDITIONS. THE FOUR WORST CASE
PATTERNS PROVIDED WILL GENERATE WORST CASE
NOISE CONDITIONS IN ALL STANDARD AND SPECIALLY PURCHASED
PDP-8E CORE STACKS, AND WILL TEST SYSTEMS EQUIPPED WITH
FROM 8K TO 128K WORDS OF CORE MEMORY. THE ALL 0'S AND ALL
1'S PATTERNS ARE PROVIDED TO IDENTIFY BASIC MEMORY FAILURES.
AUTOMATIC PROGRAM RELOCATION IS PROVIDED IN ORDER TO TEST
ALL MEMORY FIELDS FROM EACH MEMORY FIELD. TELETYPE PRINTOUTS
ARE PROVIDED FOR ERROR IDENTIFICATION, AND THE OPERATOR
IS GIVEN A DEGREE OF CONTROL OVER THE PROGRAM BY VARIOUS
SWITCH REGISTER SETTINGS.

2. **REQUIREMENTS**

2.1 **EQUIPMENT**

A PDP-8E COMPUTER EQUIPPED WITH AT LEAST 8K OF CORE MEMORY.

2.2 **STORAGE**

THE PROGRAM OCCUPIES CORE LOCATIONS 0000 TO 7577 IN THE PRESENT FIELD.

2.3 **PRELIMINARY PROGRAMS**

THE BINARY LOADER MUST BE IN MEMORY. ALSO, ALL DIAGNOSTICS
FOR A BASIC 4K PDP-8E MUST HAVE BEEN PREVIOUSLY RUN
SUCCESSFULLY. IF A KT8-A IS AVAILABLE, THE KT8-A DIAGNOSTIC
MUST BE RUN SUCCESSFULLY.

3. **LOADING PROCEDURE**

LOAD THE PROGRAM WITH THE BINARY LOADER (BIN). THE PROGRAM
MAY BE LOADED INTO ANY FIELD.

4. **OPERATING PROCEDURE**

SR00-02 SR02, IF SET, WILL RING THE TTY BEL'. ONCE FOR EACH ERROR. SR00 AND SR01 HAVE NO EFFECT WITH SR02 SET.

SR03 SR03 MAY BE SET OR RESET AT ANY TIME AND THE PROGRAM
WILL ACT ACCORDINGLY.
SR04 SR04 ALLOWS THE OPERATOR TO CHANGE THE FIELD LIMITS
AS DEFINED BY SR06-11.
SR05 SR05 IS NORMAL HALT FOR PROGRAM.
SR06-08 THESE SWITCHES DEFINE THE STARTING FIELD LIMIT

4.2 EXAMPLE OF SELECTING FIELDS FOR TEST

EXAMPLE 1: SR = 0037, 28K SYSTEM
FIELDS SELECTED FOR TESTING ARE 0:6543210

EXAMPLE 2: SR = 0004, 28K SYSTEM
FIELDS SELECTED FOR TESTING ARE 0:43210

EXAMPLE 3: SR = 0202, 28K SYSTEM
FIELDS SELECTED FOR TESTING ARE 0:2 (NO RELOCATION
WILL OCCUR).

EXAMPLE 4: SR = 0401, 28K SYSTEM
FIELDS SELECTED FOR TESTING ARE 0:64310

NOTE 1: FIELDS NOT IN THE SYSTEM ARE AUTOMATICALLY
DESELECTED AS IN EXAMPLE 1. FIELD 7 IS NOT
PRESENT, THEREFORE, NOT SELECTED.

NOTE 2: DO NOT SELECT A FIELD THAT CONTAINS A ROM.

NOTE 3: A SINGLE FIELD CAN BE SELECTED FOR TESTING
PROVIDING THE PROGRAM IS NOT IN THAT FIELD
AS IN EXAMPLE 3.

NOTE 4: ANY FIELD OR GROUP OF FIELDS CAN BE BY-PASSED
AS IN EXAMPLE 4. FIELDS 2 AND 3 ARE NOT SELECTED,
FIELD 7 IS NOT PRESENT.

NOTE 5: THE ABOVE INFORMATION ALSO APPLIES TO SYSTEMS WITH UPTO
128K WORDS OF READ WRITE MEMORY. FOR EACH ADDITIONAL
BANK OF MEMORY THE PROGRAM WILL PRINT THE FOLLOWING DEPENDING
ON THE AMOUNT OF MEMORY AVAILABLE.

"FIELDS SELECTED FOR TESTING 3:76543210 2:76543210 :76543210 0:76543210"

5. ERRORS

A TEST ERROR WILL OCCUR ANYTIME THE DATA WRITTEN DOES NOT
MATCH THE DATA READ. A RELOCATION ERROR WILL OCCUR IF THE
RELOCATION COMPARISON CHECK FAILS.

5.1 TEST ERROR TYPEOUTS

FOR THE FIRST ERROR ENCOUNTERED A HEADER WILL BE TYPED OUT
FOLLOWED BY THE PERTINENT DATA. FOR ALL SUBSEQUENT ERRORS,
ONLY THE PERTINENT DATA WILL BE TYPED. THE FORMAT IS AS
FOLLOWS:

PR.LOC.. FAIL. ADR..GOOD..BAD..PATTERN

PR LOC = THE PROGRAM ADDRESS WHERE THE ERROR JMS OCCURRED.
(INCLUDES FIELD).

FAIL ADR = THE ADDRESS OF THE LOCATION IN ERROR.
(INCLUDES FIELD).

GOOD = THE DATA THAT WAS WRITTEN.

BAD = THE DATA THAT WAS READ.

PATTERN= THE PRESENT TEST PATTERN AND THE NUMBER
OF TIMES IT WAS COMPLEMENTED.
NC (NOT COMPLEMENTED).
1C (ONE COMPLEMENT).
2C (TWO COMPLEMENTS).

5.2 RELOCATION ERROR TYPEOUTS

ALL RELOCATION ERRORS ARE IN THE FOLLOWING FORMAT:

XXXXXX RELOCATION ERROR AT LOCATION YYYYYY

XXXXXX = THE PROGRAM ADDRESS WHERE THE ERROR JMS OCCURRED.
(INCLUDES FIELD).

YYYYYY = THE ADDRESS OF THE LOCATION IN ERROR.
(INCLUDES FIELD).

NOTE: AFTER EACH ERROR PRINT-OUT THE PROGRAM CONTINUES
ON WITH THE NEXT SEQUENTIAL MEMORY LOCATION.

5.3 PARITY ERROR TYPEOUTS

IF THE BE SYSTEM CONTAINS A PARITY OPTION THE INTERRUPT WILL
BE TURNED ON TO ALLOW PARITY ERRORS WHEN THE PROGRAM IS
EXECUTING FROM FIELD 0. THE FOLLOWING 3 TYPEOUTS CAN OCCUR
WITH A PARITY OPTION:

A. PARITY ERROR, LOC 0=XXXX TSTAD=XXXXXX (PRESENT PATTERN)

B. INTERRUPT FROM KEYBOARD

C. UNWANTED INTERRUPT OCCURRED

6. RESTRICTIONS

6.1 STARTING RESTRICTIONS

THE PROGRAM MAY BE RESTARTED AT ANY TIME FROM LOCATION 0200
OR 0202 OF THE FIELD THE PROGRAM IS PRESENTLY IN.

6.2 OPERATING RESTRICTIONS

THE PARITY ERROR TYPEOUT CAN NOT BE INHIBITED.

7. EXECUTION TIME

THE TIME TO WRITE AND READ ALL SIX PATTERNS IN ONE FIELD IS APPROXIMATELY 6 SECONDS.

DURING PROGRAM EXECUTION A 15 WILL BE TYPED ON THE TTY APPROXIMATELY EVERY 15 MINUTES OF PROGRAM RUN TIME. THIS ALLOWS THE OPERATOR TO DETERMINE APPROXIMATE RUN TIME BEFORE A FAILURE OCCURRED.

NOTE: IT SHOULD BE NOTED THAT IF THE PROGRAM IS RELOCATING THE DIAGNOSTIC WILL PRINT AN END OF PASS MESSAGE AT THE COMPLETION OF ALL FIELDS SELECTED FOR RELOCATION. THE MESSAGE WILL BE 'S FOLLOWS:

"END OF PASS XXXX"

WHERE XXXX= THE OCTAL VALUE OF THE NUMBER OF TIMES THE PROGRAM HAS RELOCATED THROUGH ALL SELECTED FIELDS.

8. SCOPE LOOPS

8.1 SCOPE LOOP 1

THIS SCOPE LOOP DOES A READ, COMPLEMENT, WRITE ON THE ADDRESS SPECIFIED BY THE SR. THE ADDRESS BEING LOOPED ON CAN BE CHANGED SIMPLY BY CHANGING THE SWITCH SETTING. THE PREVIOUS ADDRESS WILL BE LEFT WITH ITS ORIGINAL CONTENT.

- A. SET THE SR TO THE INSTRUCTION FIELD THAT THE PROGRAM IS IN AND THE DATA FIELD WANTED TO TEST.
- B. PRESS KEY EXTD ADDR LOAD.
- C. SET THE SR EQUAL TO 5200.
- D. PRESS KEY ADDR LOAD.
- E. SET THE SR EQUAL TO THE ADDRESS TO TEST.
- F. PRESS KEYS CLEAR, AND CONT.

8.2 SCOPE LOOP 2

THIS SCOPE LOOP DOES A READ, COMPLEMENT, WRITE ON THE TWO ADDRESSES INPUT VIA THE SR. TO CHANGE THE ADDRESSES, THE LOOP MUST BE RESTARTED.

- A. SET THE SR TO THE INSTRUCTION FIELD THAT THE PROGRAM IS IN THE DATA FIELD WANTED TO TEST.
- B. PRESS KEY EXTD ADDR LOAD.
- C. SET THE SR EQUAL TO 5400.
- D. PRESS KEYS ADDR LOAD, CLEAR, AND CONT.

E. FOLLOW DIRECTIONS THAT ARE TYPED OUT.

8.3 SCOPE LOOP 3

THIS SCOPE LOOP DOES A READ, COMPLEMENT, WRITE ON THE GROUP OF ADDRESSES INPUT VIA THE SR. THE STARTING ADDRESS SPECIFIED MUST BE LESS THAN THE ENDING ADDRESS SPECIFIED.

- A. SET THE SR TO THE INSTRUCTION FIELD THAT THE PROGRAM IS IN AND THE DATA FIELD WANTED TO TEST.
- B. PRESS KEY EXT D ADL. LOAD.
- C. SET THE SR EQUAL TO 5600.
- D. PRESS KEYS ADDR LOAD, CLEAR, AND CONT.
- E. FOLLOW DIRECTIONS THAT ARE TYPED OUT.

8.4 SCOPE LOOP 4

THIS SCOPE LOOP DOES A READ, COMPLEMENT, WRITE ON THE ADDRESS INPUT VIA THE SR USING THE DATA SPECIFIED BY THE SR. THE DATA CAN BE CHANGED SIMPLY BY CHANGING THE SWITCH SETTING.

- A. SET THE SR TO THE INSTRUCTION FIELD THAT THE PROGRAM IS IN AND THE DATA FIELD WANTED TO TEST.
- B. PRESS KEY EXT D ADDR LOAD.
- C. SET THE SR EQUAL TO 6000.
- D. PRESS KEYS ADDR LOAD, CLEAR, AND CONT.
- E. A MESSAGE WILL BE TYPED OUT TO SET THE SR TO THE SELECTED ADDRESS.
- F. SET SR TO THE SELECTED ADDRESS AND DEPRESS CONT.
- G. SET S: TO SELECTED DATA (SCOPE LOOP IS CYCLING).

8.5 SCOPE LOOP 5

THIS SCOPE LOOP DOES A READ, COMPLEMENT, WRITE ON THE GROUP OF ADDRESSES INPUT VIA THE SR USING THE DATA SPECIFIED BY THE SR. THE STARTING ADDRESS SPECIFIED MUST BE LESS THAN THE ENDING ADDRESS SPECIFIED.

- A. SET THE SR TO THE INSTRUCTION FIELD THAT THE PROGRAM IS IN AND THE DATA FIELD WANTED TO TEST.
- B. PRESS KEY EXT D ADDR LOAD.
- C. SET THE SR EQUAL TO 5700.
- D. PRESS KEYS ADDR LOAD, CLEAR, AND CONT.

E. FOLLOW THE TYPED OUT MESSAGE THAT INPUTS THE ADDRESS
SELECTION.

F. SET SR TO SELECTED DATA (SCOPE LOOP IS CYCLING).

NOTE 1: THE ADDRESS(S) SPECIFIED WILL BE LOOPED UNTIL STOPPED
BY THE OPERATOR WITH KEY HALT. NO ERROR CHECKING IS DONE.
TO RESUME NORMAL OPERATION, RESTART PROGRAM AT
ADDRESS 0200 OR 0202 OF THE CURRENT INSTRUCTION FIELD.

9. PROGRAM DESCRIPTION

9.1 TEST PATTERNS

THE FOLLOWING TEST PATTERNS ARE EMPLOYED BY THE PROGRAM:

- A. BASIC ALL 0'S PATTERN.
- B. BASIC ALL 1'S PATTERN.
- C. 0000-7777 WORST CASE CHECKERBOARD PATTERN.
- D. 7777-0000 WORST CASE CHECKERBOARD PATTERN.
- E. 2525-5252 WORST CASE CHECKERBOARD PATTERN.
- F. 5252-2525 WORST CASE CHECKERBOARD PATTERN.

9.2 PROGRAM RELOCATION

PROGRAM RELOCATION IS GOVERNED BY THE STATUS OF SR BIT 3 OR BY THE FACT THAT ONLY ONE FIELD IS SELECTED FOR TESTING. WITH SR BIT 3 DOWN (0 POSITION) PROGRAM RELOCATION OCCURS EACH TIME THE TEST PATTERN AND ITS COMPLEMENT HAVE BEEN COMPLETELY TESTED IN EACH SELECTED FIELD. THE PROGRAM FIRST RELOCATES TO THE HIGHEST ORDER 4K FIELD UNDER TEST. THE PROGRAM KEEPS RELOCATING TO THE NEXT LOWER FIELD UNDER TEST UNTIL IT REACHES THE LOWEST ORDER FIELD UNDER TEST. THE TESTING AND RELOCATION CYCLE IS THEN REPEATED. THE CONTENTS OF THE ENTIRE FIELD ARE RELOCATED WHICH ENABLES ANY OTHER INFORMATION (RIM-BIN) TO BE CARRIED WITH THE PROGRAM.

THE PROGRAM PROVIDES A DEGREE OF PROTECTION FOR ITSELF BY REMEMBERING ALL FIELDS WHERE ERRORS OCCUR. WHEN A FAULTY FIELD IS NEXT IN SEQUENCE TO CONTAIN THE PROGRAM, THE PROGRAM WILL SKIP THE FAULTY FIELD AND RELOCATE TO THE FIRST LOWER ORDER FIELD WHICH IS ERROR FREE. IF ALL OTHER SELECTED FIELDS ARE FAULTY, PROGRAM RELOCATION WILL NOT TAKE PLACE.

DURING RELOCATION A COMPARISON CHECK IS MADE TO INSURE NO PROGRAM LOSS.

9.3 TEST PROCEDURE

- A. WRITE THE PATTERN IN ALL SELECTED FIELDS (EACH LOCATION IS THEN TREATED AS FOLLOWS):

- B. READ-WRITE THE LOCATION 11 TIMES.
- C. READ-WRITE-TEST THE LOCATION (NC).
- D. READ-WRITE THE LOCATION 11 TIMES.
- E. READ-COMPLEMENT-WRITE THE LOCATION.
- F. READ-WRITE THE LOCATION 11 TIMES.
- G. READ-WRITE-TEST THE LOCATION (1C).
- H. READ-WRITE THE LOCATION 11 TIMES.
- I. READ-COMPLEMENT-WRITE THE LOCATION.
- J. READ-WRITE THE LOCATION 11 TIMES.
- K. READ-WRITE-TEST THE LOCATION (2C).
- L. GO ON TO NEXT LOCATION REPEATING B-K.
- M. GO ON TO NEXT PATTERN REPEATING A-L WHEN ALL LOCATIONS OF ALL SELECTED FIELDS ARE COMPLETED.

FOR FURTHER UNDERSTANDING OF HOW THE TEST IS PERFORMED, REFER TO THE LISTING.

THE WORST CASE CHECKERBOARD PATTERN CONSISTS OF ALTERNATING 4 MEMORY CORES CONTAINING 0000 AND 4 MEMORY CORES CONTAINING 1111 ON A MEMORY PLANE. THIS PATTERN IS REVERSED EVERY 400 OCTAL LOCATIONS. (THIS TEST PATTERN IS GENERATED ACCORDING TO THE STRINGING OF THE STACK AND THE WIRING OF THE MEMORY SYSTEM. IT IS THE SAME PATTERN FOR ALL 8K STACKS).

Y LINES (MA6L THRU MA11L)

		ADDRESS BIT 9 HIGH				ADDRESS BIT 9 LOW							
		00	01	02	03	04	05	06	07	10	11	→ 76	77
ADDRESS BIT 3 HIGH	00	1	1	1	1	0	0	0	0	1	1	0	0
	01	1	1	1	1	0	0	0	0	1	1	0	0
	02	1	1	1	1	0	0	0	0	1	1	0	0
	03	1	1	1	1	0	0	0	0	1	1	0	0
		04	0	0	0	0	1	1	1	1			
ADDRESS BIT 3 LOW	05	0	0	0	0	1	1	1	1				
	06	0	0	0	0	1	1	1	1				
	07	0	0	0	0	1	1	1	1				
		10	1	1	1	1							
		11	1	1	1	1							
		76	0	0	0	0							
		77	0	0	0	0							
		176	0	0	0	0							
		177	0	0	0	0							

EMA2L USED IF AN 8K MEMORY

X
L
I
N
E
S
M
A
O
L
T
H
R
U
M
A
S

THE ABOVE REPRESENTS ONE MEMORY PLANE.

8102400 1.01

1010000 1.01

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

1000000

10. CONSOLE PACKAGE ADDENDUM

10.1. DESCRIPTION

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL. THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE - THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER, BEFORE CONTINUING WITH EXECUTION OF THE DIAGNOSTIC. ALL ERRORS AND PASS COMPLETES WILL BE PRINTED AT THE TERMINAL. NO HALTS WILL BE EXECUTED. 2) CONSOLE PACKAGE NOT ACTIVE-THIS WILL RESULT IN THE NORMAL STANDALONE OPERATION OF THE PROGRAM AS DISCRIBED IN SECTIONS 1 THROUGH 9 OF THIS DOCUMENT.

10.2 RESTRICTIONS

- 1) WHEN RUNNING THE CONSOLE PACKAGE SOME SUBTESTS MAY NOT BE EXECUTED.
- 2) THE CONSOLE PACKAGE WILL USE EITHER THE HARDWARE OR PSEUDOSWITCH REGISTER DEPENDING UPON THE CONDITION OF BIT 0 OF ADDRESS 21(HCW1). (SEE SECTION 10.8 FOR EXPLANATION)
- 3) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE. ONE MUST RELOAD THE DIAGNOSTIC AND INITILIZE FOR A ACTIVE CONSOLE PACKAGE.

10.3 INITIALIZATION

FOR A ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 22 BIT3=1 TO INDICATE CONSOLE PACKAGE ACTIVE.
- 2.) SET LOCATION 21 BIT0=0 TO INDICATE USE PSEUDO SWITCH REGISTER.
- 3.) SET LOCATION 21 BIT0=1 TO INDICATE NOT TO USE PSEUDO SWITCH REGISTER, BUT TO USE HARDWARE SWITCHES.

10.4 CONTROL CHARACTERS

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.

NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C

THIS RESETS THE LOADER (PGS 37 OF FLD 0 & 1) AND STARTS IT AT LOC 7600 OF FLD 0.

CONTROL S

THIS WILL STOP ANY OUTPUT TO A CONSOLE TERMINAL. THE ONLY WAYS TO CONTINUE IS TO TYPE CONTROL Q TO RESUME PRINTING OR CONTROL C TO ABORT THE PROGRAM COMPLETELY. THIS IS A NONPRINTING CHARACTER.

CONTROL Q

THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL S IS TYPED. THIS IS A NONPRINTING CHARACTER.

CONTROL G

THE CONTROL G ALLOWS THE OPERATOR TO CHANGE THE VALUE OF THE PSEUDO SWITCH REGISTER. UPON TYPING "CTRL" AND A "G" SIMULTANEOUSLY THE KEYBOARD WILL RESPOND WITH "G" AND PRINT THE SWITCH REGISTER QUESTION. (SEE SECTION 10.5 FOR DETAILS) AT THIS POINT THE OPERATOR MAY CHANGE THE VALUE OF THE PSEUDO SWITCHES OR TYPE A TERMINATING CHARACTER. IN ANY EVENT ONLY THE PSEUDO SWITCH REGISTER IS CHANGED. IT HAS NO EFFECT UPON THE HARDWARE SWITCHES.

10.5 SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER BEFORE PROGRAM EXECUTION TAKES PLACE OR TYPING A CONTROL G. THE PSEUDO SWITCH REGISTER IS SET UP UPON TYPING A TERMINATOR. THE TERMINATORS ARE AS FOLLOWS:

<CR> CARRIAGE RETURN: THIS CAUSES THE PROGRAM TO RESUME TESTING FROM WHERE IT LEFT OFF.

<LF> LINEFEED: THIS CAUSES THE PROGRAM TO RESTART THE TESTING FROM THE BEGINNING.

SR=0000 4000<CR> CARRIAGE RETURN
PROGRAM RESUMES TESTING FROM
POINT OF INTERRUPTION.

SR=0000 4000<LF> LINEFEED
CAUSES PROGRAM TO RESTART.

UNDER SCORING INDICATES OPERATOR RESPONSE

10.6 ERRORS

THE STANDARD ERROR REPORTS AS DESCRIBED IN SECTION 6 OF THIS DOCUMENT WILL BE USED.

10.7 SWITCH REGISTER SETTINGS

THE STANDARD SWITCH SETTINGS AS DESCRIBED IN SECTION 5 OF THIS DOCUMENT WILL BE USED.

10.8 PARAMETER CONTROL WORDS

THE CONSOLE PACKAGE USES THE LOCATIONS 20 21 22 FOR THE FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22
HARDWARE IDENTIFIER 2

LOCATION 002

<u>BIT</u>	<u>OCTAL VALUE</u>	<u>FUNCTION WHEN 0</u>	<u>FUNCTION WHEN 1</u>
0	4000	USE PSEUDO SWITCHES	USE HARDWARE SWITCHES
1	2000	NO OPTION 1	HAS OPTION 1
2	1000	NO OPTION 2	HAS OPTION 2
3	400	NO 8A SIMULATOR	HAS 8A SIMULATOR
4	200	NO OPTION SIMULATOR	HAS OPTION SIMULATOR
5	100	NOT ON 8A XOR	ON 8A XOR
6	40	NOT PDP8-E TYPE CPU	PDP8-E TYPE CPU
7-11		8A MEMORY SIZE EX. 1K=00 2K=01 7K=06 32K=31	

LOCATION 0022

<u>BIT</u>	<u>OCTAL VALUE</u>	<u>FUNCTION WHEN 0</u>	<u>FUNCTION WHEN 1</u>
0	4000	NOT ON ACT8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

11.0. NON CONSOLE TERMINAL SYSTEM ADDENDUM

11.1. DESCRIPTION

THE PROGRAM HAS BEEN MODIFIED TO RUN WITHOUT A CONSOLE TERMINAL BY MEANS OF A SPECIAL STARTING ADDRESS AND OPERATING PROCEDURES. THIS ALLOWS THE DIAGNOSTIC TO BE RUN ON THOSE SYSTEMS WITHOUT A CONSOLE TERMINAL. ALL ERRORS AND FIELD LIMIT CHANGES WILL RESULT IN A HALT OR HALTS INSTEAD OF TYPEOUTS ON THE CONSOLE TERMINAL.

11.2. RESTRICTIONS

1. IF THE CONSOLE PACKAGE WAS ENABLED, THE PROGRAM WILL DISABLE IT AT THE START OF THE PROGRAM.
2. FIELD LIMITS MUST BE SET AT PROGRAM START, OTHERWISE, THE PROGRAM WILL HALT TO ALLOW THE OPERATOR TO SET THE FIELD

LIMITS IN THE SWITCH REGISTER.

3. TO RUN THIS PROGRAM, A MINIMUM OF 8K OF MEMORY IS REQUIRED.
4. MEMORIES TO BE TESTED MUST BE IN SEQUENTIAL ORDER STARTING AT FIELD 0.

11.3 INITIALIZATION

THE PROGRAM WHEN LOADED IS INITIALIZED TO USE THE HARDWARE SWITCH REGISTER. IF NO HARDWARE SWITCH REGISTER IS AVAILABLE, DO THE FOLLOWING TO DISABLE THE SWITCH REGISTER SELECTION FROM HARDWARE TO A SOFTWARE PSEUDO SWITCH REGISTER (LOCATION 0020).

1. SET BIT 0 EQUAL TO A 0 IN LOCATION 21 TO INDICATE TO THE PROGRAM THAT LOCATION 20 WILL BE USED AS THE PSEUDO SWITCH REGISTER. THE PROGRAM WHEN STARTED WILL THEN SET THE PSEUDO SWITCH REGISTER TO FIELD LIMITS FOR A NORMAL SYSTEM STARTUP. PSEUDO SWITCH REGISTER WILL EQUAL XX00 WHERE XX EQUALS SWITCH REGISTER BITS, PREVIOUSLY SET, 0 EQUALS STARTING FIELD LIMIT AND 7 EQUALS ENDING FIELD LIMITS.

IF IT IS DESIRED TO INITIALIZE THE FIELD LIMITS TO OTHER THAN THE ABOVE DO THE NEXT STEP.

2. SET LOCATION 0021 TO 00XX WHERE XX IS THE MEMORY SIZE IN 4K INCREMENTS.

11.4 OPERATING PROCEDURES

TO START THE PROGRAM:

- A. SET THE IF AND DF TO THE FIELD THAT CONTAINS THE PROGRAM
- B. LOAD ADDRESS TO 0201
- C. IF THE HARDWARE SWITCH REGISTER IS USED, SET THE SWITCH REGISTER TO 0037.
- D. PRESS "INIT" AND THEN "RUN".
- E. THE PROGRAM WILL AGAIN HALT. AT THIS TIME SELECT THE DESIRED TEST PARAMETERS.
- F. PRESS "INIT" AND "RUN".
- G. THE PROGRAM WILL NOW RUN UNTILL AN ERROR IS ENCOUNTERED OR A SWITCH REGISTER OPTION IS SELECTED TO CAUSE THE PROGRAM TO HALT REFER TO LISTING FOR ALL HALTS.
- H. SETTING THE SWITCH REGISTER TO 0100, WILL CAUSE THE PROGRAM TO HALT AFTER THE CURRENT TEST-REFER TO LISTING FOR HALT.
- I. SETTING THE SWITCH REGISTER TO 0200 WILL CAUSE THE PROGRAM TO HALT FOR FIELD LIMIT CHANGES VIA THE SWITCH REGISTER. REFER TO LISTING FOR ADDRESS OF THE HALT.

11.5 SWITCH REGISTER SETTINGS

SR0=1	HALT AFTER ERROR
SR1=1	INHIBIT ERROR HALTS EXCEPT HALT AFTER ERROR SWITCH
SR2=1	INHIBIT OPERATION OF SR0 AND SR1
SR3=1	INHIBIT PROGRAM RELOCATION
SR4=1	HALT PROGRAM FOR FIELD LIMIT CHANGES
SR5=1	HALT AFTER CURRENT TEST

11.6 ERRORS

ALL ERRORS ENCOUNTERED WILL RESULT IN A ERROR HALT WITH ERROR INFORMATION IN THE AC. REFER TO THE LISTING FOR THE TYPE OF ERROR HALT AND GO TO THE APPROPRIATE PARAGRAPH BELOW.

A TEST ERROR WILL OCCUR ANYTIME THE DATA WRITTEN DOES NOT MATCH THE DATA READ. A RELOCATION ERROR WILL OCCUR IF THE RELOCATION COMPARISON CHECK FAILS.

11.7 TEST ERROR HALTS

FOR ERRORS ENCOUNTERED TESTING MEMORIES, THE PROGRAM WILL HALT WITH PERTINENT INFORMATION IN THE AC. REFER TO THE STEPS BELOW FOR THE TEST ERROR INFORMATION

- A. PRESS "CONT". THE PROGRAM WILL HALT AT 3115 WITH THE AC EQUAL TO THE PROGRAM ADDRESS OF THE ERROR JMS.
- B. PRESS "CONT". THE PROGRAM WILL HALT AT 3121 WITH THE CONTENTS OF AC BITS 7,8,9,10 AND 11 EQUAL TO THE FIELD BEING TESTED.
- C. PRESS "CONT". THE PROGRAM WILL HALT AT 3124 WITH THE AC EQUAL TO THE FAILING ADDRESS IN THE FIELD BEING TESTED.
- D. PRESS "CONT". THE PROGRAM WILL HALT AT 3127 WITH THE AC EQUAL TO THE EXPECTED DATA THAT WAS PUT INTO THE FAILING ADDRESS.
- E. PRESS "CONT". THE PROGRAM WILL HALT AT 3132 WITH THE AC EQUAL TO THE ACTUAL DATA THAT WAS READ FROM THE FAILING ADDRESS.
- F. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 3136 WITH THE PATTERN NUMBER IN THE AC. THE PATTERN NUMBER CORRESPONDS TO THE PATTERNS BELOW.

AC=0	-	NO TEST PATTERN
AC=1	-	BASIC ALL 0'S PATTERN
AC=2	-	BASIC ALL 1'S PATTERN
AC=3	-	0000-7777 WCP PATTERN
AC=4	-	7777-0000 WCP PATTERN
AC=5	-	2525-5252 WCP PATTERN
AC=6	-	5252-2525 WCP PATTERN

- H. PRESS "CONT" TO CONTINUE THE PROGRAM ON TO THE NEXT SEQUENTIAL TEST MEMORY ADDRESS.
- I. ERROR HALTS MAY BE INHIBITED BY SETTING SR1 TO A 1

11.8 RELOCATION ERROR HALTS

ALL RELOCATION ERRORS WILL RESULT IN A HALT WITH PERTINENT INFORMATION IN THE AC. REFER TO THE STEPS BELOW FOR THE ERROR INFORMATION.

- A. THE PROGRAM WILL HALT AT ADDRESS 2735 WITH THE CONTENTS OF THE AC EQUAL TO THE PROGRAM LOCATION OF THE ERROR JMS.
- B. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 2741 WITH THE CONTENTS OF AC BITS 7,8,9,10, AND 11 EQUAL TO THE FIELD THAT PROGRAM TRIED TO PUT THE INSTRUCTION INTO.
- C. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 2744 WITH THE CONTENTS OF AC EQUAL TO THE LOCATION IN THE FAILING FIELD IN ERROR.
- D. PRESSING "CONTINUE" AGAIN WILL RESULT IN THE PROGRAM CONTINUING WITH THE NEXT SEQUENTIAL MEMORY LOCATION.

11.9 PARITY ERROR HALTS

IF THE SYSTEM CONTAINS A PARITY OPTION, THE INTERRUPT WILL BE TURNED ON TO ALLOW PARITY ERRORS WHEN THE PROGRAM IS EXECUTING FROM FIELD 0. THERE ARE 3 TYPES OF FAILURES UNDER THIS ERROR, REFER TO THE APPROPRIATE PARAGRAPH BELOW FOR THE FAILING ADDRESS.

11.9.1 PARITY ERROR

- A. THE PROGRAM WILL HALT AT ADDRESS 3355 WITH THE CONTENTS OF THE AC EQUAL TO THE INTERRUPTED PC.
- B. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 3361 WITH THE CONTENTS OF THE AC EQUAL TO THE DATA FIELD AT THE TIME OF THE PARITY ERROR.
- C. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 3364 WITH THE CONTENTS OF THE AC EQUAL TO THE ADDRESS IN THE TEST FIELD BEING TESTED.
- D. PRESS "CONT". THE PROGRAM WILL HALT AT ADDRESS 3136 WITH THE CONTENTS OF THE AC EQUAL TO THE PATTERN NUMBER. REFER TO STEP G FOR PATTERN BEING EXECUTED IN SECTION 11.7.
- E. PRESS "CONT". THE PROGRAM WILL CONTINUE UNTIL ANOTHER ERROR IS ENCOUNTERED OR THE PROGRAM IS STOPPED.

11.9.2 INTERRUPT FROM KEYBOARD

THE PROGRAM WILL HALT AT ADDRESS 3404. THIS SIGNIFIES THAT THE PROGRAM DETECTED A PARITY OPTION AND TURNED THE INTERRUPT ON. UPON TURNING THE INTERRUPT ON, A INTERRUPT WAS RECEIVED FROM THE CONSOLE TERMINAL. TO COVER FROM THIS ERROR PRESS CONTINUE.

11.9.3 UNWANTED INTERRUPT OCCURRED

THE PROGRAM WILL HALT AT ADDRESS 3425 FOR THIS ERROR. THIS
ERROR SIGNIFIES THAT AN INTERRUPT OCCURED FROM SOME
OTHER DEVICE THAN THE PARITY OPTION OR THE CONSOLE
KEYBOARD. PRESS "CONTINUE" TO RECOVER FROM THIS ERROR.

12.0 APT HOOKS

12.1 DESCRIPTION

THE APT INTERFACES PROVIDES A MEANS OF COMMUNICATING WITH THE APT MOTHER AND THE SYSTEM UNDER TEST. IT FURTHER PROVIDES A MEANS OF LOADING DIAGNOSTICS.

TWO INTERFACES ARE PROVIDED FOR THIS COMMUNICATION. THEY ARE:

1. TIMING
2. ERROR REPORTING

EACH WILL BE DESCRIBED AT A LATER TIME.

12.2 APT INITIALIZATION

SHOULD BIT ZERO OF HCW2(ADDRESS 22) BE SET TO A ONE(1), APT IS ASSUMED TO BE PRESENT. THE PROGRAM WILL SET THE PSEUDO-SWITCH REGISTER TO 0037 AND THE NOTTY INDICATOR IS SET SO AS TO DISABLE ALL TERMINAL COMMUNICATION. AT THIS POINT AN EXIT BACK TO MAIN LINE C: E TO DETERMINE IF A KT8-A IS PRESENT IN THE SYSTEM. AFTER DETERMINING THIS THE PROGRAM WILL AUTO-SIZE MEMORY AND SET UP THE APPROPRIATE FIELD STATUS BITS. AFTER AUTO-SIZING MEMORY THE CONTENTS OF FIELD 7, ADDRESSES 6000-7777 ARE MOVED TO FIELD ZERO.

SHOULD LESS THAN 32K OF MEMORY BE FOUND BANK ZERO FIELD 7 OF THE FIELD STATUS WORDS IS SET SO AS NOT TO ENABLE TESTING FIELD 7 OF BANK ZERO.

FROM THIS POINT ON ALL APT INTERFACING IS DONE FROM THE PROGRAM FIELD. THIS ALLOWS TEST OF A FULL 32 K SYSTEM. IT ALSO PROVIDES A MEANS OF TESTING UP TO 128K OF MEMORY.

12.3 APT INTERFACES

12.3.1 TIMING

THE TIMING INTERFACE PROVIDES THE NECESSARY INFORMATION TO THAT THE DIAGNOSTIC IS RUNNING ERROR FREE. THE TIME INTERVAL IS BETWEEN 2 AND 5 SECONDS.

12.3.2 ERRORS

THE ERROR INFORMATION THAT IS PASSED TO THE APT HOST CONSISTS OF THE FIELD THE PROGRAM IS CURRENTLY IN AND THE PC OF THE ERROR CALL.

NOTE:

IT SHOULD BE NOTED THAT THIS PROGRAM NO LONGER SUPPORTS THE APT PROM. THE NEW INTERFACE MUST BE USED. THE NEW INTERFACE CONSISTS OF A BOOT ROM TO LOAD IN THE ACTUAL ROM CODE FOR APT INTO MEMORY. IF FIELD 7 IS NOT PRESENT THEN THE MS8-A MUST BE USED IN PLACE OF MEMORY.

```

1 /POP-BE EXTENDED MEMORY DATA AND CHECKERBOARD TEST
2
3 /MAINDEC-08-D-WA-C-L
4
5
6 /COPYRIGHT (C) 1972, 1975, 1976 DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS. 01754
7 /PROGRAMMER, VERNON FREY
8
9
10 /
11
12 /SR00=1      HLT AFTER ERROR
13 /SR01=1      INHIBIT ERROR REPORT
14 /SR02=1      CALL ON ERROR (USEFUL FOR MAINTENANCE)
15 /SR03=1      INHIBIT PROGRAM RELOCATION
16 /SR04=1      CHANGE FIELD LIMITS
17 /SR05=1      HLT AFTER CURRENT TEST
18
19 /
20 /PROGRAM STARTING ADDRESS
21 /C0300
22 /
23 /
24 /V-CRO
25 /
26 /
27 /DEFINE NPAGE
28 /<      JMP I      (..+20087800>
29 /
30 /POP-BE IOT COMMANDS & MICRO INSTRUCTIONS
31 /
32 /EXPANDED MODE COMMANDS USED IN THIS TEST
33 6284  CUF=6204
34 6274  SLF=6274
35 6001  K10A=1
36 8200  LHM=      82C0      /LOAD EXPANDED MODE REGISTER.
37 8230  PEM=      8230
38 8280  LLS1=      82C0
39 8240  LRR=      8240
40 8250  RRR=      825C
41 6203  CDI=6203      /CHANGE TO DF & IF 0
42 6107  SPO=8107      /SKIP ON PARITY OPTION
43 8101  SNP=8101      /SKIP IF NO PARITY ERROR
44 8104  CVP=8104      /CLEAR PARITY ERROR FLAG
45 6004  GIF=6004      /GET INTERRUPT FLAGS
46 6005  RIF=6005      /RESTORE INTERRUPT FLAGS
47 7701  ACL=77C1      /LOAD W0 IN W0 AC
48 7002  BSA=7002      /SWAP BYTES IN AC
49 7421  UOL=7421      /LOAD W0 FROM AC THEN CLR AC
50 7521  SNA=7F31      /SWAP AC AND W0
51 6000  SKNO=6000      /SKIP IF INTERRUPT ON, & TURN OFF
52 8007  CAF=8007      /CLEAR ALL FLAGS
53
54
55 0000  *0

```

/POP-8E EXTENDED MEMORY DATA AND CHECKERBOARD TEST

PAL10 V142A 17-JAN-78

9:53 PAGE 1-1

SEQ 0021

```

56 0000 0304 'D /INTERRUPT ADDRESS
57 0001 3074 DCA /SAVE AC
58 0002 7701 ACL
59 0003 3075 DCA SMC /SAVE MQ
60 0004 8777' CND INTRCU
61
62
63 0005 5600 IAPTR, APTER /APT/
64 0006 8C52 IAPTRC, APTCK /APT/
65
66
67 0020 *-20
68
69
70 0020 0007 PSR, 7 /APT/
71 0021 4000 MCW1, 4000 /APT/
72 0022 00C9 MCW2, 0 /APT/
73
74 0023 00C0 INMODE, 0
75 /
76 /PAGE 0 CONSTANTS AND POINTERS
77 /
78 0024 00C0 BANK, 0
79 0025 0000 ENTFLO, 0
80 0026 4000 $400, 4000 /HALT AFTER ERROR
81 7027 20C3 $401, 20C0 /INHIBIT ERROR TYPEOUT
82 0030 10C0 $42, 10C0 /BELL ON ERROR
83 0031 C429 $423, 400 /INHIBIT PROGRAM RELOCATION
84 0032 0209 $424, 2C3 /CHANGE FIELD LIMITS
85 0033 C-00 $425, 1C0 /HALT AFTER CURRENT TEST
86 0034 3070 $488, 70 /STARTING FIELD (0-7)
87 0035 0037 $8911, 7 /ENDING FIELD (0-7)
88 0036 00C0 CS, C /COMPLEMENT STATUS
89 /CCCC=NC (NO COMPLEMENT)
90 /BIT 1=IC (ONE COMPLEMENT)
91 /BIT 2=CC (TWO COMPLEMENTS)
92 0037 2000 TS, C /TEST STATUS
93 /CCCC=ND TEST
94 /BIT 0=ALL ZEROS TEST
95 /BIT 1=ALL ONES TEST
96 /BIT 2 = 0050-7777 WCP TEST
97 /BIT 3 = 7777-CCCC WCP TEST
98 /BIT 4 = 2525-5252 WCP TEST
99 /BIT 5 = 5252-2525 WCP TEST
100 /BIT 6= WARD-1 PATTERN
101 0040 0030 FS, 0 /FIELD STATUS BANK0
102 0041 00C0 FS1, C /FIELD STATUS BANK 1
103 0042 C-70 FS2, 0 /FIELD STATUS BANK 2
104 0043 -30 FS3, 0 /FIELD STATUS BANK 3
105 /BITS 0-7 COINCIDE WITH FIELDS
106 /0-7 FOR EACH FIELD NOT IN
107 /THE SYSTEM THE EQUIVALENT BIT
108 /IS SET.
109 0044 0030 RS, 0 /RELOCATION STATUS BANK 0
110 0045 00C0 RS1, 0 /RELOCATION STATUS BANK1

```

```

111 0046 0000 RS2, 0
112 0047 0000 RS3, 0
113
114
115
116
117
118 0050 0000 CRELO, 0
119 0051 0000 PROF, 0
120 0052 0000 TSTFLD, 0
121 0053 0000 COUNT, 0
122 0054 0000 MOVE, 0
123 0055 0000 HEAD1, 0
124 0056 0000 TEMP, 0
125 0057 0000 TSTAC, 0
126 0060 0000 FCNT, 0
127 0061 0000 RELCNT, 0
128 0062 0000 STARTF, 0
129 0063 0000 ENDF, 0
130 0064 0000 INSAME, 0
131 0065 0000 LEGALD, 0
132 0066 0000 A, 0
133 0067 0000 B, 0
134 0070 0000 P2, 0
135 0071 0000 W4, 0
136 0072 0000 CDATA, 0
137 0073 0000 BDATA, 0
138 0074 0000 SAC, 0
139 0075 0000 SMQ, 0
140 0076 0000 NOTTY, 0
141 0077 0000 NUMFLD, 0
142 0100 0000 FIVE, 0
143 0101 0570 MINS, 0570
144
145
146
147
148
149 0102 0341 KENDHL
150 0103 5400 KPRINT
151 0104 4747 XGETSR
152 0105 4723 XCBCAL
153 0106 0522 XSETFS
154 0107 0532 XSETRS
155 0110 5117 XRACA
156 0111 5142 XRACB
157
158 0200 *200

```

```

/RELOCATION STATUS BANK 2
/RELOCATION STATUS BANK 3
/BITS 0-7 COINCIDE WITH FIELDS
/G-7. FS IS XFERRED INTO RS.
/EACH FIELD THAT FAILS SETS THE
/EQUIVALENT BIT SO THAT PROGRAM
/WILL NOT RELOCATE TO A FAILING FIELD.
/O = INHIBIT PROGRAM RELOCATION
/PROGRAM IN FIELD 00X0
/TESTING FIELD 00X0
/MOVE ERROR COUNTER
/MOVE ADDRESS COUNTER
/7777 MEANS TYPEOUT ERROR HEADING
/TEMP STORAGE LOCATION
/TEST ADDRESS COUNTER
/COUNT # OF FIELDS PRESENT
/END OF PASS COUNTER.
/STARTING FIELD 00X0
/ENDING FIELD 00X0
/PROGRAM IN SELECTED FIELD
/LEGAL FIELD SELECTION CONTROL
/A REG TO WRITE/READ
/B REG TO WRITE/READ
/CONTROLS 2 PAGES
/CONTROLS 4 WORDS
/GOOD DATA = DATA WRITTEN
/BAD DATA = DATA READ
/SAVE AC (INT)
/SAVE SO (INT)
/PROGRAM FLAG FOR NO TELETYPE TO AVOID PRINTOUTS
/NUMBER OF FIELDS BEING TESTED.
/THIS IS NOW 15 MINUTE COUNTER

```

/END OF TEST LAS

```

166
167
168 0200 5325 JMP START+1
169 0201 5324 JMP START
170
171 0202 4251 JMS DFEIF
172 0203 7410 SKP
173
174 0204 4771 JMS TITLE
175 0205 6002 PATA, IOF
176 0206 1376 TAD (7200)
177 0207 6200 LXM
178 0210 7200 CLA
179 0211 6230 REM
180 0212 7710 SPA CLA
181 0213 7340 CLL CLA CMA
182 0214 3025 DCA EMNFLG
183 0215 4775 JMS PNTOPT
184 0216 4774 JMS SETSW
185 0217 3036 DCA CS
186 0220 3037 DCA TS
187 0221 3040 DCA FS
188 0222 3044 DCA RS
189 0223 7240 STA
190 0224 3050 DCA CRELO
191 0225 3057 DCA TSTAD
192 0226 1101 TAD MINS
193 0227 3100 DCA FIVE
194 0230 7240 STA
195 0231 3055 DCA HEAD1
196 0232 4773 JMS FSSET
197 0233 4772 JMS APFL
198 0234 7240 STA
199 0235 1060 TAD FCNT
200 0236 3060 DCA FCNT
201 0237 4771 JMS LEGAL
202 0240 1077 TAD NUMFLD
203 0241 7041 CIA
204 0242 3061 DCA RELCNT
205 0243 1050 TAD CRELO
206 0244 7650 SNA CLA
207 0245 5261 JMP PATN
208 0246 4770 JMS CSRO3
209 0247 5301 JMP PATO
210 0250 5270 JMP PATN
211
212
213
214
215
216 0251 0000 DFEIF, 0
217 0252 6002 IOF
218 0253 7300 CLA CLL
219 0254 6224 RIF
220 0255 1176 TAD (6201)

```

```

/APT/200 = START ADDRESS.
/STARTING ADDRESS IF NO TTY AVAILABLE
/202 = RESTART ADDRESS
/TYPOUT PROG TITLE
/LOAD EXPANDED MODE REGISTER
/MAKE SURE AC CLEAR
/SKIP IF KDBA NOT ENABLED
/SET KDBA ACTV
/SETUP SR
/CLEAR INH RELO
/CLEAR TEST ADDRESS COUNTER
/SET UP COUNTER
/RESET ERROR HEADING
/SET FIELD STATUS & TYPE SELECTION
/AC=-:
/-1 TO FIELDS IN SYSTEM
/CHECK FOR LEGAL FIELD SELECTION
/SET UP PASS COUNTER
/NEGATE IT
/SAVE IT.
/NO RELOCATE & TEST ONLY 1 FIELD
/RELOCATION PROGRAM
/INHIBIT PROGRAM RELOCATION

```

/MAKE DF = IF

```

/
DFEIF, 0
IOF
CLA CLL
RIF
TAD (6201)

```

```
221 0256 3257 DCA .+1
222 0257 6301 CDF 0
223 0260 5651 JMP 1 DFEIF
224
225
226
227 /
228 /NO PROGRAM RELOCATION AND TEST ONLY 1 FIELD
229
230 0261 6224 PATM, RIF PROFLD
231 0262 3051 DCA
232 0263 4767 JMS PAREL /TYPEOUT NO RELOCATION
233 0264 4766 PATMO, JMS TEST
234
235 0265 4502 ENDMLT /TEST FOR END OF PASS INFORMATION
236 0266 5205 JMP PATA /YES
237
238
239 0267 9264 JMP PATMO /NO
240
241
242 /
243 /NO PROGRAM RELOCATION BUT TEST ALL SELECTED FIELDS
244 /
245 0270 6224 PATN, RIF PROFLD
246 0271 3051 DCA
247
248 0272 4767 JMS PAREL /TYPEOUT NO RELOCATION
249 0273 4766 PATNO, JMS TEST
250
251 0274 4502 ENDMLT /TEST FOR END OF PASS INFORMATION
252 0275 5205 JMP PATA /YES
253
254 0276 4770 JMS CSRO3 /NO
255 0277 9301 JMP PATO /RELOCATE PROGRAM
256 0300 5273 JMP PATNO /CONTINUE
257
258
259 /
260 /CHECK ALL SELECTED FIELDS FROM EACH SELECTED FIELD
261 /
262 0301 6224 PATO, RIF PROFLD
263 0302 3051 DCA
264 0303 1040 TAD FS
265 0304 3044 DCA RS /SETUP RELO STATUS
266 0305 1041 TAD FS1
267 0306 3045 DCA RS1
268 0307 1042 TAD FS2
269 0310 1046 DCA RS2
270 0311 1043 TAD FS3
271 0312 3047 DCA RS3
272
273 0313 4785 JMS PREL /TYPEOUT RELOCATION
274 0314 4786 PATOO, JMS TEST
275
```

```
276 0315 4502 ENDMLT /TEST FOR END OF PASS INFORMATION
277 0316 5205 JMP PATA /YES
278
279 0317 4770 JMS CSRO3 /NO
280 0320 7410 SKP
281 0321 9270 JMP PATH /INHIBIT PROGRAM RELOCATION
282 0322 4764 JMS SETREL /GO TEST RELOCATION
283 0323 5314 JMP PATOO /CONTINUE
284
285
286 0324 5334 START, JMP .+13
287 0325 3076 DCA NOTTY /SAVE TTY FLAG STATUS
288 0326 4763 JMS APTIZ /GO SETUP MEMORY SIZE FROM PSR OR SR
289 0327 1076 TAD NOTTY /GET TTY FLAG
290 0330 7650 SNA CLA /TTY AVAILABLE
291 0331 5204 JMP PATA-1 /YES GO PRINT TITLE
292 0332 6002 IOF /NO, TURN THE INTERRUPT OFF
293 0333 5205 JMP PATA /GO START WITHOUT TITLE
294 0334 1022 TAD MCW2 /GET HARDWARE WORD 2
295 0335 0362 AND (7377 /MASK OUT CLB BIT
296 0336 3022 DCA MCW2
297 0337 7240 CLA CMA
298 0340 5325 JMP START+1 /GO SET FLAG FOR NO TELETYPE
299
300
301 /
302 /THIS ROUTINE DETERMINES IF HALT AFTER TEST SELECTED
303 /AND/OR CHANGE FIELD LIMITS SELECTED
304 /IF FIELD LIMITS ARE TO CHANGE RETURN CALL +1 IF THEY ARE NOT TO
305 /CHANGE RETURN CALL +2.
306
307 0341 0000 XENDML, 0
308 0342 4504 GETSR /GET CURRENT SWITCH VALUE
309 0343 0033 AND SRO5 /HALT AFTER TEST
310 0344 7650 SNA CLA /SKIP IF HALT AFTER TEST SELECTED
311 0345 4505 JMP .+3 /DON'T HALT
312 0347 7402 MLT /TEST FOR ACTIVE CONSOLE
313 0350 4504 GETSR /NON ACTIVE CONSOLE, JUST HALT
314 0351 0032 AND SRO4 /GET SWITCHES AGAIN
315 0352 7330 SNA CLA /ISOLATE CHANGE FIELD LIMITS SWITCH
316 0353 2341 ISZ XENDML /SKIP IF FIELD LIMITS ARE TO CHANGE
317 0354 5741 JMP I XENDML
318
319 0362 7377 /
320 0363 5622
321 0364 0600
322 0365 4154
323 0366 0600
324 0367 4115
325 0370 1607
326 0371 1470
327 0372 5704
328 0373 1615
329 0374 4071
330 0375 1726
```

```
331 0376 7200
332 0377 4043
      0400
      PAGE
      /DETERMINE WHICH RELOCATION ROUTINE TO USE.
333
334
335 0400 0000
336 0401 1025
337 0402 7110
338 0403 1034
      SETREL, 0
      TAD EXWFLD
      SZA CLA /SKIP IF EXPANDED MODE NOT ENABLED
      JMP KTBREL
340
341
342 /SETUP TO RELOCATE THE PROGRAM
343
344 /THIS ROUTINE IS USED ONLY IF KTB OR KTB8 FUNCTIONS ARE TO BE TESTED
345
346 0404 7200
347 0405 6224
348 0406 3151
349 0407 1051
350 0410 7112
351 0411 7010
352 0412 3777
353 0413 7240
354 0414 1777
355 0415 0035
356 0416 3777
357 0417 1777
358 0420 1376
      KTBREL, CLA /MAKE SURE AC IS CLEAR
      RIF /GET INSTRUCTION FIELD OF PROGRAM
      DCA PROFLD /SAVE THE VALUE
      TAD PROFLD
      CLL RTR
      RAR
      FLOCNT /MOVE INTO PROPER POSITION
      STA
      TAD FLOCNT
      AND SR911
      DCA FLOCNT
      TAD FLOCNT
      TAD (TRSTAB
      /ESTABLISH POINTER OF STATUS
      /ROUTINE
      DCA TEMP /SAVE THE POINTER
      TAD I TEMP /GET ROUTINE TO EXECUTE
      DCA TRS /AND SAVE IT
      JMS I TRS /GO TEST STATUS
      JMP KTBREL+7
      TAD FLOCNT /SET UP FIELD TO GO
      AND SR911 /ISOLATE BITS 0-11
      CLL RTR
      RAL /SET UP FOR INSTRUCTION
      JMP CSAME /GO TEST FOR SAME FIELD
360 0421 3056
361 0422 1456
362 0423 3272
363 0424 4672
364 0425 5213
365 0426 1777
366 0427 0035
367 0430 7106
368 0431 7004
369 0432 5263
      /
      JMP KTBREL+7
371 0433 5213
372
373
374 /THIS ROUTINE WILL TEST THE KTB8 FUNCTIONS.
375
376 0434 7200
377 0435 6224
378 0436 3051
379 0437 1051
380 0440 4510
381 0441 3777
382 0442 7240
383 0443 1777
384 0444 0375
      KTBREL, CLA /MAKE SURE AC IS CLEAR
      RIF /GET PROGRAM FIELD
      DCA PROFLD /AND SAVE IT
      TAD PROFLD
      RACA
      DCA FLOCNT /SAVE THE BINARY COUNT VALUE OF FIELD
      STA
      TAD FLOCNT
      AND (37
```

```
385 0445 3777
386 0446 1777
387 0447 0035
388 0450 1376
389 0451 3056
390 0452 1456
391 0453 3272
392 0454 4672
393 0455 5242
394 0456 1777
395 0457 0375
396 0460 4511
397 0461 5263
398 0462 5242
      DCA FLOCNT
      TAD FLOCNT /ADD IN OFFSET
      AND SR911
      TAD (TRSTAB /GET STARTING ADDRESS OF ROUTINE POINTER
      DCA TEMP /SAVE THE POINTER ADDRESS
      TAD I TEMP /GET ACTUAL ROUTINE ADDRESS
      DCA TRS /SAVE THE ROUTINE ADDRESS
      JMS I TRS /GO TEST FOR PROPER FIELD SELECTION
      JMP KTBREL+6
      TAD FLOCNT /DECREMENT FIELD VALUE
      AND (37 /ISOLATE 5 BITS
      RACB /REARRANGE INTO PROPER FORMAT
      JMP CSAME /GO TEST FOR VALID FIELD SELECTION
      KTBREL+6
400 0463 3052
401 0464 4774
402 0465 5800
403 0466 4773
404 0467 6224
405 0470 3051
406 0471 5600
      CSAME, DCA TESTFLD /SAVE FIELD VALUE TO TEST
      JMS SAME /PCFLD=TESTFLD
      JMS I SETREL /YES
      JMS RELO /GO RELOCATE PROGRAM
      RIF /GET PROGRAM LOCATION
      DCA PROFLD
      JMP I SETREL /EXIT RELOCATION ROUTINE
407
408 0472 0000
409 0473 3703
410 0474 3712
411 0475 3722
412 0476 3732
413 0477 3743
414 0500 3754
415 0501 3765
416 0502 4000
      TRS, 0
      TRSTAB, TRS0
      TRS1
      TRS2
      TRS3
      TRS4
      TRS5
      TRS6
      TRS7
417
418
419 /TEST COMPLEMENT STATUS
420 /RETURN IF 0C, RETURN+1 IF 1C, RETURN+2 IF 2C
421
422 0503 0000
423 0504 7200
424 0505 1030
425 0506 7450
426 0507 5703
427 0510 2303
428 0511 7106
429 0512 7430
430 0513 5703
431 0514 2303
432 0515 7710
433 0516 1113
434 0517 7000
      TCS, 0
      CLA
      TAD CS
      SNA
      JMP I TCS /NC
      ISZ TCS
      CLL RTR
      SZL
      JMP I TCS /1C
      ISZ TCS
      SPA CLA
      JMP I TCS /2C
      APTEOB, NOP /APY/
435
436 0520 7402
437 0521 5320
      HLT
      JNZ -1 /ERRONEOUS STATUS BITS SET
438
439 /SET UP PROPER FIELD STATUS BITS
```

```
440
441 0522 0000 /
442 0523 1777' XSETFS, 0 FLDONT /GET FIELD 10 CO
443 0524 7112 CLL RTR
444 0525 7010 RAR /MOVE BANK SELECT INTO POSITION
445 0526 0372 AND 13
446 0527 1371 TAD 1FS /ESTABLISH POINTER TO ADDRESS OF STATUS
447 0530 3056 DCA TEMP /AND SAVE THE POINTER
448 0531 5722 JMP I XSETFS /AND EXIT
449
450 /ESTABLISH RELOCATION STATUS POINTER
451
452 0532 0000 XSETFS, 0
453 0533 1777' TAD FLDONT /GET FIELD 11 CO
454 0534 7112 CLL RTR
455 0535 7010 RAR
456 0536 0372 AND 13
457 0537 1371 TAD 1FS /SAVE THE POINTER
458 0540 3056 DCA TEMP
459 0541 5722 JMP I XSETFS
460
461 /
462 0571 0040
463 0572 0003
464 0573 4200
465 0574 1600
466 0575 0037
467 0576 0073
468 0577 : -6
469
470 PAGE
471
472 /TEST PATTERN CONTROL
473
474 0600 0000 TEST, 0
475 0601 4777' JMS PAR
476 0602 7200 CLA
477 0603 3056 DCA A
478 0604 3047 DCA B
479 0605 4776' JMS STS0 /ALL ZEROS TEST
480 0606 4253 JMS TEST0
481 0607 7240 STA
482 0610 3056 DCA A
483 0611 7240 STA
484 0612 3057 DCA B
485 0613 4775' JMS STS1 /ALL ONES TEST
486 0614 4253 JMS TEST0
487 0615 7240 STA
488 0616 3057 DCA B
489 0617 3056 DCA A
490 0620 4774' JMS STS2 /0000-7777 MCP TEST
491 0621 4253 JMS TEST0
492 0622 7240 STA
493 0623 3056 DCA A
```

```
494 0624 3057 DCA B
495 0625 4773' JMS STS3 /7777-0000 MCP TEST
496 0626 4253 JMS TEST0
497 0627 7200 CLA
498 0630 1175 TAD [2525
499 0631 3056 DCA A
500 0632 1174 TAD [5252
501 0633 3057 DCA B
502 0634 : 72 JMS STS4 /2525-5252 MCP TEST
503 0635 4253 JMS TEST0
504 0636 7200 CLA
505 0637 1174 TAD [5252
506 0640 3056 DCA A
507 0641 1175 TAD [2525
508 0642 3057 DCA B
509 0643 4771' JMS STS5 /5252-2525 MCP TEST
510 0644 4253 JMS TEST0
511 0645 7200 CLA
512 0646 3057 DCA TS /CLEAR TEST STATUS
513 0647 6002 IOF
514 0650 4770' JMS M0STST /GO PERFORM MARCH PATTERN
515 0651 5600 JMP I TEST
516
517 /TEST ALL FIELDS SELECTED FOR TEST
518
519
520 0652 5653 KTEST, JMP I TEST0
521 0653 0000 TEST0, 0
522 0654 3767' DCA FLDONT /CLEAR FIELD INDICATOR
523 0655 3054 DCA BANK /CLEAR BANK VALUE
524 0656 4307 JMS N0FLD /GO TEST FOR VALID SELECTION
525 0657 5261 JMP T0LPO /NO A VALID FIELD, UPDATE AND TRY AGAIN
526 0660 4766' JMS N0FLD /GO WRITE SELECTED FIELD
527 0661 1767' TAD FLDONT
528 0662 7041 CIA /COMPLEMENT CURRENT VALUE
529 0663 1060 TAD FCNT /SEE IF AT MAXIMUM FOUND
530 0664 7550 SNA CLA /SKIP IF NO AT MAX AVAILABLE
531 0665 5270 JMP TEST1
532 0666 2767' ISZ FLDONT /UPDATE FIELD TO DO
533 0667 8256 JMP TEST0+3 /GO BACK AND TRY NEXT FIELD
534
535 /
536
537
538 0670 3767' TEST1, DCA FLDONT /CLEAR FIELD INDICATOR
539 0671 3024 DCA BANK /CLEAR BANK INDICATOR
540 0672 4307 JMS N0FLD
541 0673 5500 JMP TIUPD
542 0674 4765' JMS R0FLD /READ PATTERN WRITTEN
543 0675 1053 TAD CCUNT /TEST FOR ANY READ ERRORS
544 0676 7640 SZA CLA
545 0677 4784' JMS SETERR /GO SET UP PROPER ERROR ROUTINE
546 0700 1767' TIUPD, TAD FLDONT /SET UP TO TEST FOR MAX FIELDS
547 0701 7041 CIA
548 0702 1060 TAD FCNT /GET NUMBER OF FIELDS FOUND
```

```
549 0703 7650 SNA CLA /SKIP IF NOT AT MAX
550 0704 5763 JNO TEST8 /GO CMTD NEXT TEST
551 0705 2767 ISZ FLOCNT
552 0706 5272 JNP TEST1+2 /GO BACK AND DO NEXT VALUE
553 /
554 /
555 /
556 /
557 /
558 /
559 /THIS ROUTINE DETERMINES IF A VALID FIELD IS SELECTED.
560 /A VALID SELECTION RETURNS+2
561 /NON-VALID SELECTION RETURNS +1
562 /
563 0707 0000 NUFLO, 0
564 0710 1767 TAD FLOCNT /GET FIELD TO TEST
565 0711 0035 AND SR911 /ISOLATE FIELD
566 0712 1262 TAD (TFSTAB /GET TO POINTER OF FIELD STATUS
567 0713 3337 DCA TFS /SAVE THE VALUE
568 0714 1737 TAD I TFS /GET ROUTINE TO EXECUTE
569 0715 3337 DCA TFS /AND SAVE IT
570 0716 4737 JMS I TFS /GO TEST FOR VALID FIELD SELECTION
571 0717 5707 JMP I NUFLO /NOT A VALID FIELD
572 0720 1025 TAD ENVFLG
573 0721 7650 SNA CLA /SKIP IF EXPANDED MODE ENABLED
574 0722 5232 JNP NCEMM
575 0723 1767 TAD FLOCNT
576 0724 4811 RACB /REARRANGE AC INTO PROPER FORMAT
577 0725 3052 SETFLD, DCA TSTFLD
578 0726 4761 JMS SAME /PROFLD=TSTFLD
579 0727 7410 SKP
580 0730 2307 ISZ NUFLO
581 0731 5707 JMP I NUFLO /GET A VALID FIELD
582 /
583 0732 1767 NCEMM, TAD FLOCNT
584 0733 0035 AND SR911 /ISOLATE FIELD TO DO
585 0734 7106 CLL RTL
586 0735 7604 RAL
587 0736 5325 JMP SETFLD /MOVE INTO BITS 6-8
588 /
589 0737 0000 TFS, 0 /GO TEST FOR FIELD SELECTION
590 /
591 0740 3600 TFSTAB, TFS0
592 0741 3607 TFS1
593 0742 3617 TFS2
594 0743 3627 TFS3
595 0744 3640 TFS4
596 0745 3651 TFS5
597 0746 3662 TFS6
598 0747 3672 TFS7
599 /
600 /
601 0761 1600
602 0762 0743
603 0763 1000
```

```
604 0764 4510
605 0765 1200
606 0766 1005
607 0767 2346
608 0770 5200
609 0771 3262
610 0772 2255
611 0773 3250
612 0774 3243
613 0775 3237
614 0776 3233
615 0777 4267
616 /
617 /
618 1000 4504 PAGE
619 1001 0032 /TEST8, GETSR
620 1002 7640 AND SR04 /CHANGE FIELD LIMITS?
621 1003 5777 SZA CLA /YES
622 /
623 1004 5778 JMP PAT1
624 /
625 /
626 /
627 /WRITE A & B REG PATTERN INTO SELECTED FIELD/
628 /
629 1005 0000 NUFLO, 0
630 1006 1773 TAD [-40
631 1007 1770 DCA P2 /WRITE 2 PAGES
632 1010 241 JMS WRA /WRITE 4 WORDS FROM A REG
633 1011 4263 JMS WRB /WRITE 4 WORDS FROM B REG
634 1012 2070 ISZ P2
635 1013 5210 JMP -3
636 1014 1773 TAD [-40
637 1015 3070 DCA P2
638 1016 4263 JMS WRB
639 1017 4241 JMS WRA
640 1020 2070 ISZ P2
641 1021 5216 JMP -3
642 1022 1757 TAD TSTAD
643 1023 7640 SZA CLA
644 1024 5206 JMP NUFLO+1
645 /
646 1025 2100 ISZ FIVE /SEE IF READY TO PRINT IS YET
647 1026 5605 JMP I NUFLO
648 1027 1076 TAD NOTTY /GET THE TELETYPE FLAG
649 1030 7710 SPA CLA /IS THERE ONE AVAILABLE
650 1031 5605 JMP I NUFLO /NO-ABORT THE FIVE MINUTE TYPEOUT
651 1032 1101 TAD MINS /RESET FIFTEEN MINUTE COUNTER
652 1033 3100 DCA FIVE
653 /
654 1034 4775 JMS MES
655 1035 4543
656 1036 6165 /TYPE A 15
657 1037 0000 0000
```

```

658 1040 5605      JMP I  WRFLO      /END OF MEMORY REACHED
659 1041 0000      WRA, 0
660 1042 1172      TAD  [-4
661 1043 3071      DCA  W4      //WRITE 4 WORDS FROM A REG
662 1044 1052      TAD  TSTFLD
663 1045 1176      TAD  [6201
664 1046 3247      DCA  .-1
665 1047 8711      CDF  0      /TEST DF
666 1050 1138      WRA1, TAD  A
667 1051 3457      DCA I  TSTAD
668 1052 2057      ISZ  TSTAD
669 1053 7000      NOP
670 1054 2071      ISZ  W4
671 1055 5250      JMP  W4A1
672 1056 1051      TAD  PROFLD      /4 WORDS ARE WRITTEN
673 1057 1176      TAD  [6201
674 1060 3261      DCA  .-1
675 1061 6201      CDF  0      /PROGRAM DF
676 1062 5441      JMP I  WRA
677 1063 0000      WRB, 0
678 1064 1172      TAD  [-4
679 1065 3071      DCA  W4      /WRITE 4 WORDS FROM B REG
680 1066 1052      TAD  TSTFLD
681 1067 1176      TAD  [6201
682 1070 3271      DCA  .-1
683 1071 6201      CDF  0      /TEST DF
684 1072 1067      WRB1, TAD  B
685 1073 3457      DCA I  TSTAD
686 1074 2057      ISZ  TSTAD
687 1075 7000      NOP
688 1076 2071      ISZ  W4
689 1077 5272      JMP  WRB1
690 1100 1051      TAD  PROFLD      /4 WORDS ARE WRITTEN
691 1101 1176      TAD  [6201
692 1102 3303      DCA  .-1
693 1103 6201      CDF  0      /PROGRAM DF
694 1104 5683      JMP I  WRB
695
696
697 /TYPEOUT FIELDS SELECTED FOR TESTING
698
699 1105 0000      TOSEL, 0
700 1106 7346      CLL  CLA  CMA  RTL      /AC=-3
701 1107 3024      DCA  BANK      /SAVE BANK VALUE
702 1110 1024      TAD  BANK
703 1111 7041      CIA
704 1112 7106      CLL  RTL      /MAKE BANK VALUE POSITIVE
705 1113 7004      RAL
706 1114 3774      DCA  FLD CNT      /SHIFT OVER FOR OTHER ROUTINES
707 1115 1024      TAD  BANK
708 1116 7041      CIA
709 1117 1171      TAD  [PS
710 1120 3056      DCA  TEMP      /ESTABLISH STATUS CONTROL WORD
711 1121 1456      TAD I  TEMP      /GET ADDRESS OF CONTROL WORD
712 1122 1170      TAD  [-7760      /SEE IF THERE IS A FIELD TO DO

```

```

713 1123 7650      SNA  CLA
714 1124 5336      JMP  TOSEL1      /IS THIS BANK TO BE TESTED
715 1125 1024      TAD  BANK      /UPDATE BANK SELECT VALUE
716 1126 7041      CIA
717 1127 1167      TAD  [280
718 1130 4773      JMS  TYPE
719 1131 1372      TAD  [-1
720 1132 4773      JMS  TYPE
721 1133 4771      JMS  FLDSEL
722 1134 1370      TAD  [240
723 1135 4773      JMS  TYPE
724 1136 2024      TOSEL1, ISZ  BANK      /UPDATE BANK VALUE
725 1137 7000      NOP
726 1140 1024      TAD  BANK
727 1141 7740      SNA  SZA  CLA      /SKIP IF LAST BANK NOT DONE
728 1142 5705      JMP I  TOSEL      /EXIT ROUTINE
729 1143 5310      JMP  TOSEL+3      /GO BACK AND TRY AGAIN
730
731 1170 0240
732 1171 2102
733 1172 0272
734 1173 5035
735 1174 2346
736 1175 2240
737 1176 0652
738 1177 0205
739 1200
740
741
742 /
743 1200 0000      RDFLD, 0
744
745 1201 4406      JMS I  IAPTRK      /APT/
746
747 1202 7200      CLA
748 1203 1052      TAD  TSTFLD
749 1204 1176      TAD  [6201
750 1205 3210      DCA  RDA2
751 1206 1210      TAD  RDA2
752 1207 3263      DCA  RCB2
753 1210 6201      RDA2, CDF  0      /TEST DF
754 1211 1166      TAD  [-100
755 1212 3070      DCA  P2
756 1213 1172      RDFLDA, TAD  [-4
757 1214 3071      DCA  W4
758 1215 3036      RDAC,  OCA  CS      /READ & TEST 4 WORDS
759 1216 4777      JMS  READ      /NO COMPLEMENT
760 1217 1141      CIA
761 1220 1066      TAD  A
762 1221 7440      SZA
763
764 1222 4777      JMS  ERRA      /A REG ERROR - NC
765 1223 4327      JMS  READ
766 1224 7040      CMA

```

```
767 1225 3457 DCA I TSTAD
768 1226 4778 JMS SC51 /1 COMPLEMENT
769 1227 4327 JMS READ
770 1230 7001 IAC
771 1231 1066 TAD A
772 1232 7440 SZA
773
774 1233 4775 JMS ERROR1
775 1234 4327 JMS READ
776 1235 7040 CMA
777 1236 3457 DCA I TSTAD
778 1237 4774 JMS SC52 /2 COMPLEMENTS
779 1240 4327 JMS READ
780 1241 7041 CIA
781 1242 1166 TAD A
782 1243 7440 SZA
783
784 1244 4777 JMS ERROR1 /A REG ERROR - 2C
785 1245 2057 ISZ TSTAD
786 1246 7000 NOP
787 1247 2071 ISZ W4
788 1250 5215 JMP RDAC /COMPLETE 4 WORDS
789 1251 2070 ISZ P2
790 1252 5266 JMP RDFLODB /COMPLETE CURRENT 2 PAGES
791 1253 1061 TAD PROFLO
792 1254 1176 TAD [6201
793 1255 3256 DCA -1
794 1256 6111 CDF 3 /PROGRAM OF
795 1257 1107 TAD TSTAD
796 1260 1640 SZA CLA
797 1261 5210 JMP PCA2 /READ ANOTHER 2 PAGES
798 1262 5600 JMP I RDFLO /END OF MEMORY REACHED
799
800 1263 6201 RDB2, CCF 0 /TEST OF
801 1264 1166 TAD [-100
802 1265 3070 DCA P2 /READ & TEST 2 PAGES
803 1266 1172 RDFLODB, TAD [-4
804 1267 3071 DCA -1 /READ & TEST 4 WORDS
805 1270 3036 RDB2, DCA CS /NO COMPLEMENT
806 1271 4327 JMS READ
807 1272 7041 CIA B
808 1273 1067 TAD
809 1274 7440 SZA
810
811 1275 4773 JMS ERROR1 /B REG ERROR - NC
812 1276 4327 JMS READ
813 1277 7040 CMA
814 1300 3457 DCA I TSTAD
815 1301 4778 JMS SC51 /1 COMPLEMENT
816 1302 4327 JMS READ
817 1303 7001 IAC
818 1304 1067 TAD B
819 1305 7440 SZA
820
821 1306 4772 JMS ERROR1 /B REG ERROR - 1C
```

```
822 1307 4327 JMS READ
823 1310 7040 CMA
824 1311 3457 DCA I TSTAD
825 1312 4774 JMS SC52 /2 COMPLEMENTS
826 1313 4327 JMS READ
827 1314 7041 CIA
828 1315 1067 TAD B
829 1316 7110 SZA
830
831 1317 4773 JMS ERROR1 /B REG ERROR - 2C
832 1320 2057 ISZ TSTAD
833 1321 7000 NOP
834 1322 2071 ISZ A1
835 1323 5270 JMP RDB2 /COMPLETE 4 WORDS
836 1324 2070 ISZ P2
837 1325 5213 JMP RFLDA /COMPLETE CURRENT 2 PAGES
838 1326 5263 JMP RDB2
839
840 /READ TEST ADDRESS SUBROUTINE
841 /
842 1327 0000 READ, 0
843 1330 1457 TAD I TSTAD
844 1331 1457 TAD I TSTAD
845 1332 1457 TAD I TSTAD
846 1333 1457 TAD I TSTAD
847 1334 1457 TAD I TSTAD
848 1335 1457 TAD I TSTAD
849 1336 1457 TAD I TSTAD
850 1337 1457 TAD I TSTAD
851 1340 1457 TAD I TSTAD
852 1341 1457 TAD I TSTAD
853 1342 1457 TAD I TSTAD
854 1343 7000 CLA
855 1344 1457 TAD I TSTAD
856 1345 5727 JMP I READ
857
858
859
860 /KEYBOARD INTERRUPT OCCURRED
861 /
862 1346 0000 KBINT, 0
863 1347 1276 TAD NOTI /GET THE TELETYPE FLAG
864 1350 7000 SZA CLA /IS THERE A TELETYPE AVAILABLE
865 1351 5134 JMP -3 /YES GO PREPARE THE ERROR
866 1352 7002 RLT /NO, -LT- INTERRUPTED FROM THE KEY BOARD
867 1353 5164 JMP KBINTC /GO CLEAR FLAG AND CONTINUE
868 1354 4771 JMS YES
869 1355 4543 JMS YES
870 1356 1116 TEXT "KBINT FROM KB"
871 1357 2440
872 1358 0000
873 1359 1115
874 1362 4013
875 1363 0000
876 1364 6232 KBINTC, ACC
```

```
071 1365 7240 STA
072 1366 7255 DCA -EAD1
073 1367 5745 JWP I KEINT
074
075 1371 2243
076 1372 1437
077 1373 1425
078 1374 3272
079 1375 1411
080 1376 3266
081 1377 1410
082
083 1401 3002 ERRA, 0
084 1401 7041 CIA
085 1402 1065 TAD A
086 1403 3073 DCA BDATA /DATA READ
087 1404 1066 TAD A
088 1405 4254 JWS GERRC /GO TO ERRC SETUP ROUTINE
089 1406 1066 TAD I
090 1407 3457 DCA I TSTAD /RE-WRITE BAD LOCATION
091 1408 5623 JWP I ERRA
092 1411 3000 ERRA1, 0
093 1412 3056 DCA TEMP
094 1413 1066 TAD A
095 1414 7040 CMA
096 1415 1056 TAD TEMP
097 1416 3073 DCA BDATA /DATA READ
098 1417 1066 TAD A
099 1420 7040 CMA
100 1421 4254 JWS GERRC /GO TO ERRC SETUP ROUTINE
101 1422 1066 TAD A
102 1423 7040 CMA
103 1424 3457 DCA I TSTAD /RE-WRITE BAD LOCATION
104 1425 5611 JWP I ERRA1
105 1426 3000 ERRA, 0
106 1427 7041 CIA
107 1430 1067 TAD B
108 1431 3073 DCA BDATA /DATA READ
109 1432 1067 TAD B
110 1433 4254 JWS GERRC /GO TO ERRC SETUP ROUTINE
111 1434 1067 TAD B
112 1435 3457 DCA I TSTAD /RE-WRITE BAD LOCATION
113 1436 5626 JWP I ERRA
114 1437 3000 ERRA1, 0
115 1440 3056 DCA TEMP
116 1441 1067 TAD B
117 1442 7040 CMA
118 1443 36 TAD TEMP
119 1444 1073 DCA BDATA /DATA READ
120 1445 1067 TAD B
121 1446 7040 CMA
122 1447 4254 JWS GERRC /GO TO ERRC SETUP ROUTINE
123 1450 1067 TAD L
124 1451 7040 CMA
```

```
925 1452 3457 DCA I TSTAD
926 1453 5637 JWP I ERRA1
927 1454 3000 GERRC, 0 /GO TO ERRC
928 1455 3072 DCA BDATA /DATA WRITTEN
929 1456 1051 TAD PROFLO
930 1457 1176 TAD 16201
931 1460 3261 DCA -1
932 1461 6201 CCF 0 /PROGRAM OF
933 1462 4777 JWS ERRC /DATA OR CHPBD ERROR
934 1463 1052 TAD TSTFLO
935 1464 1176 TAD 16201
936 1465 3268 DCA -1
937 1466 6201 CCF 0 /TEST OF
938 1467 5654 JWP I GERRC
939
940
941 /CHECK FOR LEGAL FIELD SELECTION
942 /
943 1470 3000 LEGAL, 0
944 1471 7330 CMA CLL
945 1472 3064 DCA INSAME /SAVE FIELD CONTROL
946 1473 7344 CLL CMA RAL /AC--2
947 1474 3065 DCA LEGALO /LEGAL SELECTION CONTROL
948 1475 3052 DCA TSTFLO
949 1476 1025 TAD 000FLG /GET ATBA INDICATOR
950 1477 7650 SNA CLA /SKIP IF ACTIVE
951 1500 5123 JWP NOEMB
952 1501 3776 DCA FLOCONT /START WITH FIELD 0
953 1502 1051 JWS 000FLD
954 1503 1340 JWS LEGALO /VALID FIELD SELECTION
955 1504 4776 JWS 152 FLOCONT /UPDATE PATTERN
956 1505 1778 TAD FLOCONT
957 1506 4611 TAD 000B /REARRANGE INTO PROPER CONFIGURATION
958 1507 3052 DCA TSTFLO /AND THE NEW VALUE
959 1510 1776 TAD FLOCONT
960 1511 0375 AND 137 /ISOLATE FIELD
961 1512 7440 SZA CLA /SKIP IF RETURNED TO ZERO
962 1513 5302 JWP -1 /GO BACK AND TRY AGAIN
963 1514 2085 JWS LEGALO /NO FIELD SELECTION
964 1515 5774 JWP NOFLD
965 1516 1064 TAD INSAME
966 1517 7040 SZA CLA
967 1520 5773 JWP BINT /PRG IN SELECTED FIELD
968 1521 3056 DCA 000FLD /ONLY 1 FIELD SELECTED
969 1522 5370 JWP I LEGAL
970
971 /AND FUNCTIONS
972 /
973 1522 3776 NOEMB, DCA FLOCONT /START WITH FIELD ZERO
974 1524 4351 JWS 000FLD /GO TEST FOR VALID SELECTION
975 1525 4342 JWS LEGALO
976 1526 2776 JWS FLOCONT /UPDATE FIELD NUMBER
977 1527 1778 TAD FLOCONT /GET BACK FIELD SELECTION
978 1530 0035 AND 5901 /ISOLATE FIELD
979 1531 7106 CLL RTL
```

```

980 1532 7004      PAL      /MOVE INTO POSITION
981 1532 5052      DCA      /SAVE NEW VALUE
982 1534 1052      TAD      /TSTFLD
983 1535 7640      SZA CLA  /COME BACK TO ZERO?
984 1536 5324      JMP      /GO BACK AND TRY AGAIN
985 1537 5314      JMP      /INVALID SELECTIONS OR NOT ENOUGH
986
987
988
989
990
991 1540 0000      LEGALA, 0
992 1541 2065      ISZ      LEGALO      /FIELD SELECTED
993 1542 7410      SKP
994 1543 5670      JMP I     LEGAL      /AT LEAST 2 FIELDS SELECTED
995 1544 6224      RIF
996 1545 3251      DCA      PROFLO
997 1546 4772      JMS      SAME      /PROGRAM IN SELECTED FIELD?
998 1547 2064      ISZ      SAME      /YES
999 1550 5140      JMP I     LEGALA
1000
1001
1002 1551 0000      /SET UP FOR TESTING FIELD STATUS FOR LEGAL SELECTION
1003 1552 7200      LG.FLD, C
1004 1553 1776      CLA
1005 1554 0035      TAD      FLD CNT      /MAKE SURE FC IS CLEAR
1006 1555 1371      AND      SR3:1      /GET FIELD TO TEST
1007 1556 3050      TAD      /ISOLATE FIELDS
1008 1557 1456      DCA      TEMP
1009 1558 3056      TAD I     TEMP      /SAVE ROUTINE POINTER
1010 1559 4456      DCA      TEMP      /GET POINTER
1011 1562 2351      JMS I     TEMP      /EXECUTE FS ROUTINE
1012 1563 5751      ISZ      LGFLD      /INVALID FIELD
1013
1014
1015 1571 0740
1016 1572 1600
1017 1573 5044
1018 1574 4600
1019 1575 0037
1020 1576 2546
1021 1577 2600
1022
1023
1024
1025
1026
1027
1028 1600 0000      /
1029 1601 1051      SAME, 0
1030 1602 7041      TAD      PROFLO
1031 1603 1052      CIA
1032 1604 7640      TAD      TSTFLD
1033 1605 2200      SZA CLA  /PROG NOT IN SEL FIELD
1034
1035
1036
1037
1038 1607 0000
1039 1610 4504
1040 1611 0031
1041 1612 7640
1042 1613 2207
1043 1614 5607
1044
1045
1046
1047
1048
1049 1615 0000      /
1050 1616 7200      FSSET, 0
1051 1617 2260      CLA
1052 1620 3077      DCA      FCNT      /CLEAR FIELD COUNT
1053 1621 1076      DCA      NUMFLD
1054 1622 7700      TAD      NOTTY
1055 1623 5233      SZA CLA  /SKIP IF NO TTY AVAILABLE
1056 1624 1021      JMP      21
1057 1625 7710      TAD      21
1058 1626 5233      SPA CLA  /SKIP IF NO HARDWARE SWITCHES
1059 1627 1020      JMP      15
1060 1630 0377      TAD      PSR
1061 1631 3063      AND      137
1062 1632 5247      DCA      ENDF      /GET PSEUDO SWITCH REGISTER
1063 1633 4505      JMP      15
1064 1634 7402      /SET UP LAST FIELD TO 00
1065 1635 4504      CBCLAL  /BYPASS SETUP
1066 1636 0377      HLT
1067 1637 3063      GETSR
1068 1640 4504      AND      137
1069 1641 7002      DCA      ENDF      /GET NEW SWITCH VALUE
1070 1642 0377      AND      137
1071 1643 3062      /ISOLATE FIELD WIN
1072 1644 4776      DCA      STARTF      /SAVE THE STARTING FIELD
1073 1645 4505      JMS      SETPAR      /GET NEW SWITCH VALUE
1074 1646 7402      CBCLAL
1075
1076
1077
1078 1647 3040      /
1079 1650 3041      /NOW DETERMINE WHICH FIELDS TO TEST
1080 1651 3042      DCA      FS
1081 1652 3043      DCA      FS1
1082 1653 25      DCA      FS2
1083 1654 1550      TAD      EXMPFLG
1084
1085 1655 5274      SZA CLA  /TEST TO SEE IF EXPANDED MODE FEATURES
1086 1656 3775      JMP      8040      /ARE AVAILABLE TO BE USED.
1087 1657 1775      DCA      FLD CNT      /NOT ENABLED. TEST AS THOUGH A KMBE/A
1088 1660 4511      TAD      FLD CNT      /GET BACK VALUE TO DO
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
3000
3001
3002
3003
3004
3005
3006
3007
3008
3009
3010
3011
3012
3013
3014
3015
3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045
3046
3047
3048
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3
```

```
1089 1681 1176 TAD [6201 /ESTABLISH DATA FIELD
1090 1682 3263 DCA -1
1091 1683 7402 MVT
1092 1684 4774 JVS CFP /CHANGED TO DATA FIELD TO TEST
1093 1685 4314 JVS SPFLD /GO TEST FIELD FOR PRESENCE
1094 1686 2775 ISZ FLOCNT /SET APPROPRIATE BIT
1095 1687 1775 TAD FLOCNT /UPDATE PATTERN
1096 1670 0377 AND 127 /GO BACK TO ZERO YET
1097 1671 7640 SZA CLA /SKIP IF BACK TO FIELD ZERO
1098 1672 5257 JVP -13
1099 1673 5307 JVP FSELO
1100 1674 1373 BANKO, TAD (7760
1101 1675 3041 DCA FS1
1102 1676 1373 TAD (7760
1103 1677 3042 DCA FS2
1104 1700 1373 TAD (7760
1105 1701 3043 DCA FS3
1106 1702 7200 BANKO, CLA
1107 1703 6240 LRR /CLEAR RELOCATION
1108 1704 6250 RRR
1109 1705 2775 DCA FLOCNT
1110 1706 4772 JVS TESBVK /TEST BANK ZERO
1111
1112 1707 1076 FSEND, TAD NOTTY /GET TTY FLAG
1113 1710 7710 SPA CLA /IS TTY AVAILABLE
1114 1711 5615 JMP I FSSET /NO, ABORT TTY MESSAGE AND RETURN
1115 1712 4771 JVS PNTFLD
1116 1713 5715 JMP I FSSET
1117
1118 /SET UP ROUTINE TO SET STATUS BIT
1119 /
1120 1714 0000 SPFLD, 0
1121 1715 1775 TAD FLOCNT
1122 1716 0035 AND SAG11 /ISOLATE FIELD
1123 1717 1370 TAD (SFSTAB
1124 1720 3056 DCA TEMP /SAVE POINTER
1125 1721 1458 TAD I TEMP
1126 1722 3056 DCA TEMP /SAVE THE POINTER
1127 1723 4458 JMS I TEMP /GO PERFORM SET FUNCTION
1128 1724 7130 NOP
1129 1725 5714 JMP I SPFLD
1130
1131 /
1132 /
1133 /PRINT SELECTED OPTION FOR TESTING WHETHER KMB OR KTB
1134 /
1135 1726 0000 PNTOPT, 0
1136 1727 1076 TAD NOTTY /TEST FOR NOTTY TO USE
1137 1730 7640 SZA CLA
1138 1731 5726 JMP I PNTOPT /NO TTY AVAILABLE
1139 1732 1025 TAD EMFLG
1140 1733 7640 SZA CLA /SKIP IF KT NOT ENABLED
1141 1734 1367 TAD (7
1142 1735 1366 TAD (1315
1143 1736 3341 DCA OPT /SAVE OPTION VALUE
```

```
1144 1737 4755 JMS MES
1145 1740 4543 4543 /CRLF
1146 1741 0000 OPT, 0000
1147 1742 7040 TEXT *B SELECTED FOR TESTING *
1743 2305
1744 1405
1745 0324
1746 0174
1747 1106
1750 1722
1751 4024
1752 3523
1753 2411
1754 1807
1755 4000
1756 5726
1148
1149
1150 1755 2240
1151 1756 1715
1152 1757 0007
1153 1770 3352
1154 1771 4654
1155 1772 2314
1156 1773 7760
1157 1774 2500
1158 1775 2348
1159 1776 5000
1160 1777 3037
1161 2000
1162
1163
1164 /RETURN+1 IF FIELD PRESENT IN SYSTEM & IS SELECTED
1165 /
1166 2000 0000 CFP, 0
1167 2001 7300 CLA CLL
1168 2002 6224 RIF
1169 2003 1176 TAD [6201
1170 2004 3212 DCA CFPD
1171 2005 1165 TAD [-1
1172 2006 3677 DCA I CHECK
1173 2007 1677 TAD I CHECK
1174 2010 7640 SZA CLA /SKIP IF NO" PRESENT
1175 2011 5214 JMP -3
1176 2012 8201 CFPD, 0 /PROGRAM DP
1177 2013 5600 JMP I CFP
1178 2014 2060 ISZ PCNT /FIELD IS PRESENT
1179 2015 6214 RIF /START = ENDP
1180 2016 3301 DCA CFTMP /SAVE TEST FIELD
1181 2017 1025 TAD EMFLG
1182 2020 7650 SNA CLA /SKIP IF EXPANDED MODE ACTIVE
1183 2021 5228 JMP -5
1184 2022 1301 TAD CFTMP /GET BACK SELECTED FIELD
1185 2023 4510 RACA /CHANGE INT. BINARY COUNT
1186 2024 3301 DCA CFTMP /RESTORE IT FOR TESTING
```

```
1107 2025 5000 JWP L+5
1108 2025 1201 TAD CFP1MP /GET BACK FIELD VALUE
1109 2027 7112 CLL RTR
1110 2030 7210 JWP
1111 2031 5001 DCA CFP1MP /CHANGE TO BINARY COUNT NUMBER
1112 2032 1003 TAD /SAVE NUMBER FOR TESTING
1113 2033 7041 CIA
1114 2034 1002 TAD STARTF
1115 2035 7000 SNA
1116 2036 5046 JWP CFP2
1117 2037 1301 TAD CFP1MP /GET BACK NUMBER
1118 2040 7041 CIA
1119 2041 1002 TAD STARTF
1200 2042 7000 SNA CLA
1201 2043 7000 CFP1, ISZ CFP /FIELD IS PRESENT & SELECTED
1202 2044 2077 ISZ /FIELD PRESENT AND SELECTED
1203 2045 5212 JWP CFPD
1204 2046 7110 CFP2, SPA CLA /STARTF < ENDF
1205 2047 5207 JWP CFP4
1206 2050 1301 TAD CFP1MP
1207 2051 7041 CIA
1208 2052 1002 TAD STARTF
1209 2053 7000 SNA
1210 2054 5243 JWP CFP1 /DF = STARTF (SELECTED)
1211 2055 7710 SPA CLA
1212 2056 5243 JWP CFP1 /DF > STARTF (SELECTED)
1213 2057 1301 CFP3, TAD CFP1MP /DF < STARTF ***
1214 2058 7041 CIA
1215 2061 1003 TAD ENDF
1216 2062 7000 SNA
1217 2063 5243 JWP CFP1 /DF = ENDF (SELECTED)
1218 2064 7110 SPA CLA
1219 2065 9312 JWP CFPD /DF > ENDF (NOT SELECTED)
1220 2066 5243 JWP CFP1 /DF < ENDF (SELECTED)
1221 2067 1301 CFP4, TAD CFP1MP /STARTF < ENDF
1222 2070 7041 CIA
1223 2071 1002 TAD STARTF
1224 2072 7000 SNA
1225 2073 5243 JWP CFP1 /DF = STARTF (SELECTED)
1226 2074 7710 SPA CLA
1227 2075 5207 JWP CFP3 /DF > STARTF THIS TIME ***
1228 2076 5212 JWP CFPD /DF < STARTF (NOT SELECTED)
1229 2077 2100 CHECK, CHECKNO
1230 2100 0000 CHECKNO, 0
1231 2101 0000 CFP1MP, 0
1232
1233
1234
1235
1236
1237
1238 2102 0000 /
1239 2103 4777' /FIND OUT WHICH FIELDS HAVE BEEN SELECTED FOR TESTING
1240 2104 5307 FLDSEL, 0
1241 2105 1164 JWS TFS7
JWP . 3
TAD [267
```

```
1242 2106 4776' JWS TYPE /FIELD 7
1243 2107 4775' JWS TFS6
1244 2110 5313 JWP .-3
1245 2111 1163 TAD [266
1246 2112 4776' JWS TYPE /FIELD 6
1247 2113 4774' JWS TFS5
1248 2114 5317 JWP .-3
1249 2115 1162 TAD [265
1250 2116 4776' JWS TYPE /FIELD 5
1251 2117 4773' JWS TFS4
1252 2120 5323 JWP .-3
1253 2121 1161 TAD [264
1254 2122 4776' JWS TYPE /FIELD 4
1255 2123 4772' JWS TFS3
1256 2124 5327 JWP .-3
1257 2125 1160 TAD [263
1258 2126 4776' JWS TYPE /FIELD 3
1259 2127 4771' JWS TFS2
1260 2130 5333 JWP .-3
1261 2131 1157 TAD [262
1262 2132 4776' JWS TYPE /FIELD 2
1263 2133 4770' JWS TFS1
1264 2134 5337 JWP .-3
1265 2135 1156 TAD [261
1266 2136 4776' JWS TYPE /FIELD 1
1267 2137 4767' JWS TFS0
1268 2140 5343 JWP .-3
1269 2141 1157 TAD [260
1270 2142 1164' JWS TYPE /FIELD 0
1271 2143 5702 JWP I FLDSEL
1272
1273
1274 2167 3000 /
1275 2170 3007
1276 2171 3011
1277 2172 3027
1278 2173 3040
1279 2174 3051
1280 2175 3062
1281 2176 3075
1282 2177 3072
2200 PAGE
1283
1284
1285
1286
1287
1288 2200 0000 /
1289 2201 7000 SIXTY, 0
1290 2202 1000 CLA CLL
1291 2203 3005 TAD : SIXTY /ADDRESS OF OPERAND
1292 2204 1000 DCA :
1293 2205 1000 ISZ SIXTY
1294 2206 3036 TAD I SIXTY /STORE ADDRESS
1295 2207 2200 DCA 51
ISZ SIXTY
```

```
1296 2210 1155 TAD [77
1297 2211 7140 CMA
1298 2212 0635 AND I 50 /AC=7700
1299 2213 7002 BSW /FIRST 2 DIGITS OF OPERAND
1300 2214 4222 JMS CNV /CONVERT DIGITS FOR TYPEOUT
1301 2215 2236 ISZ 51 /INC STORAGE ADDRESS
1302 2216 1155 TAD [77
1303 2217 0735 AND I 52 /SECOND 2 DIGITS OF OPERAND
1304 2220 1122 JMS CNV
1305 2221 1600 JMP I SIXTY /CODE
1306 2222 0000 0
1307 2223 3237 DCA 52
1308 2224 1237 TAD 52
1309 2225 7106 CLL RTL
1310 2226 7004 RAL
1311 2227 0154 AND [707 /LEFT DIGIT
1312 2230 1237 TAD 52
1313 2231 0154 AND [707 /RIGHT DIGIT
1314 2232 1153 TAD [0000
1315 2233 3036 DCA I 51 /STORE CONVERTED DIGITS
1316 2234 5622 JMP I CNV
1317 2235 0000 SO, 0
1318 2236 0000 SI, 0
1319 2237 0000 S2, 0
1320 /
1321 /TELETYPE OUTPUT WITH BELL
1322 /
1323 2240 0000 MES, 0
1324 2241 7240 STA
1325 2242 3023 DCA INCODE /SET PRINTER ACTIVE INDICATOR /-CB-/
1326 2243 7240 STA
1327 2244 1240 TAD MES /FIRST WORD -1
1328 2245 3010 DCA 10
1329 /
1330 2246 1410 TAD I 10
1331 2247 3113 DCA M0
1332 2250 1313 TAD M0
1333 2251 7002 BSW
1334 2252 4256 JMS TYPCH /TYPEOUT FIRST CHARACTER
1335 2253 1313 TAD M0
1336 2254 4256 JMS TYPCH /TYPEOUT SECOND CHARACTER
1337 2255 5248 JMP MES+6 /CONTINUE
1338 /
1339 2256 0000 TYPCH, 0
1340 2257 0155 AND [77
1341 2260 7440 SZA
1342 2261 5264 JMP -+3
1343 2262 3023 DCA INCODE /CLEAR MESSAGE ACTIVE INDICATOR /-CB-/
1344 2263 5410 JMP I 10 /END OF MESSAGE RETURN
1345 2264 1152 TAD -134
1346 2265 7440 SZA
1347 2266 5271 JMP -+3
1348 2267 1151 TAD [207 /CODE IS BELL
1349 2270 5311 JMP MTP
1350 2271 1172 TAD [-4
```

```
1351 2272 7500 SMA
1352 2273 5276 JMP -+3 /CODE LESS THAN 40?
1353 2274 1150 TAD [340 /NO
1354 2275 5311 JMP MTP /YES, ADD 300. CODE IS ALPHA
1355 2276 1147 TAD [-3
1356 2277 7440 SZA
1357 2300 5303 JMP -+3
1358 2301 1146 TAD [212 /CODE IS LINE FEED
1359 2302 5311 JMP MTP
1360 2303 1145 TAD [-2
1361 2304 7440 SZA
1362 2305 5310 JMP -+3
1363 2306 1144 TAD [215 /CODE IS CR
1364 2307 7410 SKP
1365 2310 1143 TAD [245 /ADD 200 TO OTHERS > 40
1366 2311 4777 MTP, JMS TYPE
1367 2312 5656 JMP I TYPCH
1368 2313 0000 NO, 0
1369 /
1370 /
1371 /TEST THE SELECTED BANK FOR FIELDS AVAILABLE
1372 /
1373 2314 0000 TESTBANK, 0
1374 2315 6271 CDF 70
1375 2316 4776 JMS CFP /CHECK FIELD PRESENT
1376 2317 4775 JMS SFS7 /SET FIELD STATUS BIT 7
1377 2320 6261 CDF 60
1378 2321 4776 JMS CFP
1379 2322 4774 JMS SFS6
1380 2323 6251 CDF 50
1381 2324 4776 JMS CFP
1382 2325 4773 JMS SFS5
1383 2326 6241 CDF 40
1384 2327 4776 JMS CFP
1385 2330 4772 JMS SFS4
1386 2331 6231 CDF 30
1387 2332 4776 JMS CFP
1388 2333 4771 JMS SFS3
1389 2334 6221 CDF 20
1390 2335 4776 JMS CFP
1391 2336 4770 JMS SFS2
1392 2337 6211 CDF 10
1393 2340 4776 JMS CFP
1394 2341 4767 JMS SFS1
1395 2342 6201 CDF 00
1396 2343 4776 JMS CFP
1397 2344 4766 JMS SFS0
1398 2345 5714 JMP I TESTBANK
1399 2346 1140 FIDONT, 0
1400 /
1401 /MARCH TEST IN ERROR
1402 /
1403 2347 0000 TVAR, 0
1404 2350 4240 JMS 115
1405 2351 1501 TEXT MARCH -
```

```
2352 2203
2353 1042
2354 5548
2355 0000
2356 5747
1406 JWP I TWAR
1407
1408 2366 3277
1409 2367 3317
1410 2370 3340
1411 2371 3412
1412 2372 3432
1413 2373 3452
1414 2374 3472
1415 2375 3512
1416 2376 2000
1417 2377 5025
2400
PAGE
1418 /
1419 /TYPEOUT CHARACTER IN AC AND A SPACE
1420 /
1421 2400 0000 TYPSP, 0
1422 2401 4777 JMS TYPE
1423 2402 1142 TAD 1240
1424 2403 4777 JMS TYPE
1425 2404 5600 JWP I TYPSP
1426
1427
1428
1429 /ERROR ROUTINE (BELL ON ERROR HAS PRIORITY)
1430 /
1431 2405 0000 RETURN, 0 /PROGRAM RETURN ADDRESS
1432 2406 4405 CODERR, JMS I 1AFTER
1433 2407 4504 GETSR
1434 2410 0030 AND SMO2 /BELL ON ERROR?
1435 2411 7650 SNA CLA
1436 2412 5221 JWP 1
1437 2413 1076 TAD NOTTY /GET TTY FLAG
1438 2414 7710 SPA CLA
1439 2415 5605 JWP I RETURN /NO TELETYPE AVAILABLE DO NOT RING BELL
1440 2416 1151 TAD 1207
1441 2417 4777 JMS TYPE /RING BELL
1442 2420 5605 JWP I RETURN
1443 2421 4504 GETSR
1444 2422 0027 AND SMO1
1445 2423 7640 SZA CLA
1446 2424 5267 JWP STOP /INHIBIT TYPEOUT
1447 2425 1025 TAD ENWFLG /TEST FOR W'BA
1448 2426 7650 SNA CLA
1449 2427 5234 JWP 1
1450 2430 6224 RIF /GET PROGRAM FIELD
1451 2431 4510 RACA /BINARY COUNT NUMBER
1452 2432 3056 DCA TEMP
1453 2433 5240 JWP 1
1454 2434 6224 RIF
1455 2435 7112 CLL RTR
```

```
1456 2436 7010 RAR
1457 2437 3356 DCA TEMP /MAKE A BINARY NUMBER
1458 2440 4776 JMS SIXTY /SAVE CHARACTER
1459 2441 0056 TEMP
1460 2442 2457 ERROR0-1
1461 2443 1141 TAD 14543
1462 2444 3257 DCA ERROR0-1
1463 2445 1115 TAD RETURN
1464 2446 1165 TAD [-1]
1465 2447 3056 DCA TEMP
1466 2450 4776 JMS SIXTY
1467 2451 0056 TEMP
1468 2452 2461 ERROR1
1469 2453 1076 TAD NOTTY /GET TTY FLAG
1470 2454 7710 SPA CLA /IS THERE A TTY ON SYSTEM
1471 2455 5656 JWP I ADDER /NO, SO HALT ON ERRORS INSTEAD-INFO IN AC
1472 2456 4775 JMS YES
1473 2457 4543 4543
1474 2460 0000 ERROR0, 0 /FIELD
1475 2461 0000 ERROR1, 0
1476 2462 0000
1477 2463 4040 4040 /PROGRAM LOCATION OF ERROR JMS
1478 2464 0000 0
1479 2465 5656 JWP I 1
1480 2466 0000 ADDER, 0 /TYPEOUT ERROR
1481 2467 4504 STOP, GETSR /ADDRESS OF ERROR TYPEOUT
1482 2470 0026 AND SMO0 /HALT AFTER ERROR?
1483 2471 7650 SNA CLA
1484 2472 5276 JWP LIMIT /INHIBIT ERROR HALT
1485 2473 1205 TAD RETURN
1486 2474 1165 TAD [-1]
1487
1488 2475 7402 HLT /HALT WITH AC = ERROR JMS
1489 2476 4504 LIMIT, GETSR
1490 2477 0032 AND SMO4 /CHANGE FIELD LIMITS?
1491 2500 7640 SZA CLA
1492 2501 5774 JWP DATA /YES
1493 2502 5605 JWP I RETURN /NO
1494
1495
1496 /
1497 /RELOCATION MOVE ERROR
1498 /
1499 2503 0000 ERRN, 0
1500
1501 2504 2053 ISZ COUNT /MOVE ERROR OCCURRED
1502 2505 7410 SKP
1503 2506 5304 JWP 1
1504 2507 7200 CLA
1505 2510 1303 TAD EPRN
1506 2511 3205 DCA RETURN /RETURN ADDRESS
1507 2512 1373 TAD DEPRN
1508 2513 3266 CCA ADDER /ERROR TYPEOUT ADDRESS
1509 2514 5206 JWP CODERR
1510 2515 4772 PERM, JMS FLDAT /SET UP FIELD VALUE TO PRINT
```

```
1511 2516 2536 Z10 /WHERE TO PUT IT
1512 2517 4776 JMS SIXTY
1513 2520 0054 MOVE
1514 2521 2537 Z11
1515 2522 1076 TAD NOTTY /GET TTY FLAG
1516 2523 7710 SPA /IS THERE A TELETYPE AVAILABLE?
1517 2524 5345 JMP ERRNO /NO-MALT CN ERRORS INSTED-INFO IN AC
1518 2525 4775 JMS MES
1519 2526 2205 TEXT *RELO ERR AT *
      2527 1417
      2530 4005
      2531 2222
      2532 4001
      2533 2440
      2534 0000
1520 2535 4775 JMS MES
1521 2536 0000 Z10. 0
1522 2537 0000 Z11. 0
1523 2540 0000 0
1524 2541 0000 0
1525 2542 7240 STA
1526 2543 3055 DCA HEAD1
1527 2544 5267 JMP STOP
1528
1529
1530 //RELOCATION ERROR ROUTINE ON A SYSTEM WITHOUT A TELETYPE
1531
1532
1533 2545 7240 ERRNO, CLA CMA
1534 2546 1205 TAD RETURN /
1535 2547 7402 MLY /AC=PROGRAM LOCATION OF ERROR JMS
1536 2550 7200 CLA
1537 2551 1771 TAD FLD0CNT /GET TEST FIELD
1538 2552 0370 AND 137 /MASK TO FIELD BITS
1539 2553 7402 MLY /AC=FIELD BEING TESTED IN BITS 7-11
1540 2554 7200 CLA
1541 2555 1054 TAD MOVE
1542 2556 7402 MLY /AC=ADDRESS OF LOCATION IN ERROR
1543 2557 7240 CLA CMA
1544 2560 3055 DCA HEAD1
1545 2561 5267 JMP STOP /GO CHECK FOR MALT AFTER ERROR SWITCH
1546
1547 2570 0037
1548 2571 2346
1549 2572 5067
1550 2573 2515
1551 2574 0205
1552 2575 2710
1553 2576 1000
1554 2577 5025
      2600
      PAGE
1555
1556
1557
1558 /DATA OR CHECKERBOARD ERROR OCCURRED
```

```
1559 /
1560 2600 0000 ERRNO, 0
1561
1562 2601 2053 ISZ COUNT /ERROR OCCURRED
1563 2602 7410 SKP
1564 2603 5001 JMP -2
1565 2604 7200 CLA
1566 2605 1200 TAD ERRNO
1567 2606 3777 DCA RETURN /RETURN ADDRESS
1568 2607 1376 TAD IPERRNO
1569 2610 3775 DCA ADDR /ERROR TYPEOUT ADDRESS
1570 2611 4504 GETSR
1571 2612 0000 AND SR02 /BELL CN ERROR
1572 2613 7640 SZA CLA
1573 2614 5774 JMP RBELL /RING BELL
1574 2615 4504 GETSR
1575 2616 0027 AND SR01
1576 2617 7640 SZA CLA
1577 2620 5773 JMP STOP /INHIBIT TYPEOUT
1578 2621 205E ISZ HEAD1
1579 2622 7410 SKP
1580 2623 4772 JMS ERRNO /TYPEOUT ERROR HEADING
1581 2624 5771 JMP CODERR
1582
1583 2625 4770 PERRC, JMS FLD0DAT /SET UP FIELD INFORMATION
1584 2626 2644 Z1 /LOCATION TO PUT IT IN
1585 2627 4767 JMS SIXTY
1586 2630 0047 TSTAD
1587 2631 1045 Z2
1588 2632 4767 JMS SIXTY
1589 2633 0072 GOATA
1590 2634 2651 Z3
1591 2635 4767 JMS SIXTY
1592 2636 0073 BOATA
1593 2637 2654 Z4
1594 2640 1076 TAD NOTTY /GET TTY FLAG
1595 2641 7710 SPA /IS THERE A TELETYPE AVAILABLE
1596 2642 5307 JMP ERRNO /NO GO MALT CN ERRORS INSTEAD
1597 2643 4766 JMS MES
1598 2644 0000 Z1. 0
1599 2645 0000 Z2. 0 /FAIL ADR
1600 2646 0000 0
1601 2647 4040 4040
1602 2650 4040 4040
1603 2651 0000 Z3. 0 /GOOD
1604 2652 0000 0
1605
1606
1607 2653 4040 4040
1608 2654 0000 Z4. 0 /BAD
1609 2655 0000 0
1610 2656 4000 4000
1611 2657 4765 PARORC, JMS TTS
1612 2660 4135 JMS TN /NONE
1613 2661 5773 JMP STOP
```

/PDP-8E EXTENDED MEMORY DATA AND CHECKERBOARD TEST PAL10 V142A 17-JAN-78 9:53 PAGE 1-21

SEO 0051

```
1710 3222 6110 TEXT *0000-7777 WCP - *
      3223 2210
      3224 5257
      3225 6787
      3226 6740
      3227 7703
      3230 2640
      3231 5540
      3232 6600
1711 3233 5620 JKP I TC7
1712 3234 0000 T70, 0
1713 3235 4777 JMS MES
1714 3236 6767 TEXT *7777-0000 WCP - *
      3237 6767
      3240 5660
      3241 6060
      3242 6340
      3243 2703
      3244 2040
      3245 5540
      3246 0000
1715 3247 5634 JMP I T70
1716
1717 3250 0000 T25, 0
1718 3251 4777 JMS MES
1719 3252 0205 TEXT *2525-5252 WCP - *
      3253 6105
      3254 5145
      3255 1 35
      3256 1340
      3257 2703
      3260 2040
      3261 5540
      3262 0000
1720 3263 5650 JMP I T25
1721
1722 3264 0000 T52, 0
1723 3265 4777 JMS MES
1724 3266 6562 TEXT *5252-2525 WCP - *
      3267 6182
      3270 5562
      3271 6562
      3272 6540
      3273 2703
      3274 2040
      3275 5540
      3276 0000
1725 3277 5664 JKP I T52
1726
1727
1728 /
1729 /PARITY ERROR
1730 /
1731 3100 7200 PARINT. CLA
1732 3101 1376 TAD (INTR
```

```
1733 3102 3775 JCA RETURN
1734 3103 4774 JMS SIXTY
1735 3104 0000 0
1736 3105 3131 Z20
1737 3106 4774 JMS SIXTY
1738 3107 0057 TSTAD
1739 3110 3145 Z21
1740 3111 1 76 TAD NOTTY
1741 3112 1 10 SPA CLA
1742 3113 5354 JUP PARERR
1743 3114 4777 JMS MES
1744 3115 4543 TEXT *%PARITY ERR, LOC 0*
      3116 2001
      3117 2211
      3120 2431
      3121 4005
      3122 2122
      3123 5440
      3124 1 17
      3125 6340
      3126 6075
      3127 0000
1745 3130 4777 JMS YES
1746 3131 0000 Z20, 0
1747 3132 0000 0
1748 3133 4040 4040 /CONTENT OF LOC 0
1749 3134 2423 2423
1750 3135 2401 2401
1751 3136 0475 0475 /TSTAD=
1752 3137 0000 0000
1753 3140 6004 GTF
1754 3141 0136 AND 17
1755 3142 1 67 TAD 1260
1756 3143 4773 JMS TYPE
1757 3144 4777 JMS MES
1758 3145 0000 Z21, 0
1759 3146 0000 0
1760 3147 4000 4000
1761 3150 0104 JUP
1762 3151 7540 STA
1763 3152 3555 JCA
1764 3153 5772 JUP HEAD1
1765 PARERR
1766 /PARITY ERROR ON A NON TTY SYSTEM- ERROR INFO IN THE AC FOR EACH HALT
1767
1768
1769 3154 1000 PARERR. TAD 0
1770 3155 7402 RLT /GET THE INTERRUPTED PAC
1771 3156 7402 CLA /AC=INTERRUPTED PC (LOCATION 0)
1772 3157 6004 GTF
1773 3160 3371 AND 17
1774 3161 7402 RLT /GET THE FLAGS
1775 3162 7200 CLA /MASK TO DATA FIELD
1776 3163 1657 TAD /AC+DATA FIELD AT TIME OF PARITY ERROR
1777 3164 7402 RLT /AC+ADDRESS IN FIELD BEING TESTED
```

```
1778 3165 7200 CLA
1779 3166 6104 CMP
1780 3167 5772 JMP PARCRC /CLEAR MEMORY PARITY ERROR BIT
1781 /GO GET PATTERN BEING TESTED
1782 3171 C007
1783 3172 2657
1784 3173 5025
1785 3174 2200
1786 3175 2405
1787 3176 4256
1788 3177 2240
1789 3200 PAGE
1790 /
1791 /UNWANTED INTERRUPT OCCURRED
1792 /
1793 3200 1377 BADINT, TAD (BADINT
1794 3201 4405 JMS I IAPTR /GO TO APT IF NEED BE
1795 3202 1076 TAD NOTTY /GET THE TELETYPE FLAG
1796 3203 7700 SHA CLA /IS THERE A TELETYPE ON THE SYSTEM
1797 3204 5207 JWP -43 /YES GO PRINT THE MESSAGE
1798 3205 7402 HLT /UNWANTED INTERRUPT OCCURRED
1799 3206 5227 JWP BINTC /GO CLEAR THE WORLD AND CONTINUE
1800 3207 4776 JMS MES
1801 3210 4543 TEXT *XUNWANTED INTERRUPT OCCURRED*
3211 2516
3212 2701
3213 1624
3214 0504
3215 4011
3216 1624
3217 0522
3220 2225
3221 2624
3222 4017
3223 0303
3224 2522
3225 2205
3226 0400
1802 3227 6007 BINTC, CAF
1803 3230 7240 STA
1804 3231 3056 DCA HEAD1
1805 3232 5775 JWP INTR
1806 /
1807 /SET ONLY STATUS BIT SPECIFIED
1808 /
1809 3233 0000 STS0, 0 /SET TS0 (ALL 0 TEST)
1810 3234 7710 CLA STL RAR
1811 3235 1137 DCA TS
1812 3236 5633 JWP I STS0
1813 3237 0000 STS1, 0 /SET TS1 (ALL 1 TEST)
1814 3240 7332 CLA STL RTR
1815 3241 3037 DCA TS
1816 3242 5637 JWP I STS1
1817 3243 0000 STS2, 0 /SET TS2 (0000 - 7777 MCP TEST)
```

```
1818 3244 7332 CLA STL RTR
1819 3245 7010 RAR
1820 3246 3037 DCA TS
1821 3247 5643 JWP I STS2
1822
1823
1824 3250 0000 STS3, 0 /SET TS3 (7777 - 0000 MCP TEST)
1825 3251 7332 CLA STL RTR
1826 3252 7010 RTR
1827 3253 2037 DCA TS
1828 3254 5650 JWP I STS3
1829 3255 0000 STS4, 0 /SET TS4 (2525 - 5252 MCP TEST)
1830 3256 7203 CLA IAC BSW
1831 3257 7104 CLL RAL
1832 3260 3037 DCA TS
1833 3261 5655 JWP I STS4
1834 3262 0000 STS5, 0 /SET TS5 (5252 - 2525 MCP TEST)
1835 3263 7203 CLA IAC BSW
1836 3264 3037 DCA TS
1837 3265 5662 JWP I STS5
1838
1839 3266 0000 SCS1, 0 /SET CS1 (1 COMPLEMENT)
1840 3267 7332 CLA STL RTR
1841 3270 3036 DCA CS
1842 3271 5666 JWP I SCS1
1843 3272 0000 SCS2, 0 /SET CS2 (2 COMPLEMENTS)
1844 3273 7332 CLA STL RTR
1845 3274 7010 RAR
1846 3275 1136 DCA CS
1847 3276 1672 JWP I SCS2
1848 /
1849 /SET ALSO STATUS BIT SPECIFIED
1850 /
1851 3277 0000 SF50, 0 /SET FS0 (DON'T TEST FIELD 0)
1852 3300 7200 CLA
1853 3301 4506 SETFS /SETUP BANK POINTER
1854 3302 1456 TAD I T_LWP
1855 3303 7004 RAL
1856 3304 7130 STL RAR
1857 3305 3436 DCA I TEMP /SAVE STATUS WORD
1858 3306 5677 JWP I SF50
1859 3307 0000 SRS0, 0 /SET RS0 (DON'T RELO TO FIELD 0)
1860 3310 7200 CLA
1861 3311 4507 SETRS /SETUP BANK POINTER
1862 3312 1456 TAD I TEMP
1863 3313 7004 RAL
1864 3314 7130 STL RAR
1865 3315 3456 DCA I TEMP /SAVE NEW WORD
1866 3316 5707 JWP I SRS0
1867 3317 0000 SFS1, 0 /SET FS1 (DON'T TEST FIELD 1)
1868 3320 7200 CLA
1869 3321 4506 SETFS /SETUP BANK POINTER
1870 3322 1456 TAD I TEMP
1871 3323 7006 RTL
1872 3324 7132 STL RTR
```

1873	3325	3456	DCA I	TEMP	
1874	3326	5717	JMP I	SFS1	
1875	3327	0000	SRS1,	0	
1876	3330	7200	CLA		
1877	3331	4507	SETRS		
1878	3332	1456	TAD I	TEMP	
1879	3333	1044	TAD	RS	
1880	3334	7116	RTL		
1881	3335	132	STL RTR		
1882	3336	1456	DCA I	TEMP	
1883	3337	5727	JMP I	SRS1	/SAVE NEW WORD
1884	3340	0000	SFS2,	0	
1885	3341	7200	CLA		/SET FS2 (DON'T TEST FIELD 2)
1886	3342	4506	SETFS		
1887	3343	1456	TAD I	TEMP	/SETUP BANK POINTER
1888	3344	7006	RTL		
1889	3345	7500	SMA		
1890	3346	1135	TAD	[4000]	
1891	3347	7112	RTR		
1892	3350	3456	DCA I	TEMP	/SAVE NEW WORD
1893	3351	5740	JMP I	SFS2	
1894			/		
1895	3352	3277	SFS3,	SFS3	
1896	3353	3317	SFS1		
1897	3354	3340	SFS2		
1898	3355	2412	SFS3		
1899	3356	3432	SFS4		
1900	3357	3452	SFS5		
1901	3360	3472	SFS6		
1902	3361	3512	SFS7		
1903	3375	4256			
1904	3376	2240			
1905	3377	3200			
		3400	PAGE		
1906	3400	0000	SRS2,	0	/SET RS2 (DON'T RELO TO FIELD 2)
1907	3401	7200	CLA		
1908	3402	4507	SETRS		/SETUP BANK POINTER
1909	3403	1456	TAD I	TEMP	
1910	3404	7006	RTL		
1911	3405	7500	SMA		
1912	3406	1135	TAD	[4000]	
1913	3407	7012	RTR		
1914	3410	3456	DCA I	TEMP	/SAVE NEW WORD
1915	3411	5800	JMP I	SRS2	
1916			/		
1917			/		
1918	3412	0000	SFS3,	0	/SET FS3 (DON'T TEST FIELD 3)
1919	3413	7200	CLA		
1920	3414	4506	SETFS		/SETUP BANK POINTER
1921	3415	1456	TAD I	TEMP	
1922	3416	0134	AND	[7360]	
1923	3417	1133	TAD	[400]	
1924	3420	3456	DCA I	TEMP	/SAVE NEW WORD
1925	3421	5612	JMP I	SFS3	
1926	3422	0000	SRS3,	0	/SET RS3 (DON'T RELO TO FIELD 3)

1927	3423	7200	CLA		
1928	3424	4507	SETRS		/SETUP BANK POINTER
1929	3425	1456	TAD I	TEMP	
1930	3426	0134	AND	[7360]	
1931	3427	1133	TAD	[400]	
1932	3430	3456	DCA I	TEMP	/SAVE NEW WORD
1933	3431	5622	JMP I	SRS3	
1934	3432	0000	SFS4,	0	/SET FS4 (DON'T TEST FIELD 4)
1935	3433	7200	CLA		
1936	3434	4506	SETFS		/SETUP BANK POINTER
1937	3435	1456	TAD I	TEMP	
1938	3436	0132	AND	[7560]	
1939	3437	1131	TAD	[200]	
1940	3440	3456	DCA I	TEMP	/SAVE NEW WORD
1941	3441	5632	JMP I	SFS4	
1942					
1943					
1944					
1945	3442	0000	SRS4,	0	/SET RS4 (DON'T RELO TO FIELD 4)
1946	3443	7200	CLA		
1947	3444	4507	SETRS		/SETUP BANK POINTER
1948	3445	1456	TAD I	TEMP	
1949	3446	0132	AND	[7560]	
1950	3447	1131	TAD	[200]	
1951	3450	3456	DCA I	TEMP	/SAVE NEW WORD
1952	3451	5642	JMP I	SRS4	
1953	3452	0000	SFS5,	0	/SET FS5 (DON'T TEST FIELD 5)
1954	3453	7200	CLA		
1955	3454	4506	SETFS		/SETUP BANK POINTER
1956	3455	1456	TAD I	TEMP	
1957	3456	0130	AND	[7660]	
1958	3457	1127	TAD	[100]	
1959	3460	3456	DCA I	TEMP	/SAVE NEW WORD
1960	3461	5652	JMP I	SFS5	
1961	3462	0000	SRS5,	0	/SET RS5 (DON'T RELO TO FIELD 5)
1962	3463	7200	CLA		
1963	3464	4507	SETRS		/SETUP BANK POINTER
1964	3465	1456	TAD I	TEMP	
1965	3466	0130	AND	[7660]	
1966	3467	1127	TAD	[100]	
1967	3470	3456	DCA I	TEMP	/SAVE NEW WORD
1968	3471	5662	JMP I	SRS5	
1969	3472	0000	SFS6,	0	/SET FS6 (DON'T TEST FIELD 6)
1970	3473	7200	CLA		
1971	3474	4506	SETFS		/SETUP BANK POINTER
1972	3475	1456	TAD I	TEMP	
1973	3476	0126	AND	[7720]	
1974	3477	1171	TAD	[30]	
1975	3500	136	DCA I	TEMP	/SAVE NEW WORD
1976	3501	5672	JMP I	SFS6	
1977	3502	0000	SRS6,	0	/SET RS6 (DON'T RELO TO FIELD 6)
1978	3503	7200	CLA		
1979	3504	4507	SETRS		/SETUP BANK POINTER
1980	3505	1456	TAD I	TEMP	
1981	3506	0126	AND	[7720]	

```
1982 3507 1171 TAD [40
1983 3510 3456 DCA I TEMP /SAVE NEW WORD
1984 3511 5732 JMP I SR56 /SET FS7 (DON'T TEST FIELD 7)
1985 3512 0000 SFS7, 0
1986 3513 7200 CLA /SETUP BANK POINTER
1987 3514 4508 SETFS
1988 3515 1456 TAD I TEMP
1989 3516 0173 AND [7740
1990 3517 1170 TAD [20
1991 3520 3456 DCA I TEMP /SAVE NEW WORD
1992 3521 5712 JMP I SFS7 /SET RS7 (DON'T RELO TO FIELD 7)
1993 3522 0000 SRS7, 0
1994 3523 7200 CLA /SETUP BANK POINTER
1995 3524 4507 SETRS
1996 3525 1456 TAD I TEMP
1997 3526 0173 AND [7740
1998 3527 1170 TAD [20
1999 3530 3456 DCA I TEMP /SAVE NEW WORD
2000 3531 5722 JMP I SRS7
2001
2002 /TEST TEST STATUS
2003 /RETURN IF NO TEST
2004 /RETURN +2 IF ALL 0 TEST
2005 /RETURN +4 IF ALL 1 TEST
2006 /RETURN +6 IF 0000 - 7777 WCP
2007 /RETURN +8 IF 7777 - 0000 WCP
2008 /RETURN +10 IF 2525 - 5252 WCP
2009 /RETURN +12 IF 5252 - 2525 WCP
2010 /RETURN +14 IF MARCH PATTERN
2011
2012 3532 0000 TTS, 0
2013 3533 7200 CLA /CLEAR PATTERN NUM FOR NON TTY SYSTEMS
2014 3534 3355 DCA TSNUM
2015 3535 1037 TAD [0
2016 3536 0125 AND [7770
2017 3537 7450 SNA
2018 3540 5356 JMP TTYCHK /NO TEST
2019 3541 2355 ISZ TSNUM
2020 3542 2332 ISZ TTS
2021 3543 2332 ISZ TTS
2022 3544 7104 TTSO, CLL RAL
2023 3545 7421 ROL
2024 3546 7430 SLL /CHECK THIS TEST BIT
2025 3547 5356 JMP TTYCHK
2026 3550 2355 ISZ TSNUM
2027 3551 2332 ISZ TTS
2028 3552 2332 ISZ TTS
2029 3553 7521 SWP
2030 3554 5344 JMP TTSO /CHECK NEXT TEST BIT
2031
2032
2033 3555 0000 TSNUM, 0
2034
2035 3556 7200 TTYCHK, CLA
2036 3557 1076 TAD NOTTY /GET PROGRAM FLAG
```

```
2037 3560 7710 SPA CLA /WAS THERE A TELETYPE AVAILABLE
2038 3561 5777 JMP PATERR /NO, GO HALT ON ERROR
2039 3562 5732 JMP I TTS /RETURN TO ERROR PRINTOUT
2040
2041 3577 2731 PAGE
2042 3600
2043
2044 /TEST FIELD STATUS
2045 /RETURN IF FIELD STATUS BIT SET (DON'T TEST FIELD)
2046 /RETURN +1 IF FIELD STATUS BIT RESET (TEST THIS FIELD)
2047
2048
2049 3600 0000 TFSO, 0
2050 3601 7200 CLA /SETUP BANK POINTER
2051 3602 4506 SETFS
2052 3603 1456 TAD I TEMP /FIELD 0
2053 3604 7200 SVA CLA
2054 3605 2700 ISZ TFSO
2055 3606 5600 JMP I TFSO
2056
2057 3607 0000 TFS1, 0
2058 3610 7200 CLA /SETUP BANK POINTER
2059 3611 4506 SETFS
2060 3612 1456 TAD I TEMP
2061 3613 7200 RAL /FIELD 1
2062 3614 7700 SVA CLA
2063 3615 2207 ISZ TFS1
2064 3616 5607 JMP I TFS1
2065
2066 3617 0000 TFS2, 0
2067 3620 7200 CLA /SETUP BANK POINTER
2068 3621 4506 SETFS
2069 3622 1456 TAD I TEMP
2070 3623 7200 RAL /FIELD 2
2071 3624 7700 SVA CLA
2072 3625 2217 ISZ TFS2
2073 3626 5617 JMP I TFS2
2074
2075 3627 0000 TFS3, 0
2076 3630 7200 CLA /SETUP BANK POINTER
2077 3631 4506 SETFS
2078 3632 1456 TAD I TEMP
2079 3633 7200 RAL /FIELD 3
2080 3634 7700 SVA CLA
2081 3635 2227 ISZ TFS3
2082 3636 5627 JMP I TFS3
2083
2084
2085 3640 0000 TFS4, 0
2086 3641 7200 CLA /SETUP BANK POINTER
2087 3642 4506 SETFS
2088 3643 1456 TAD I TEMP
2089 3644 7200 RAL
2090 3645 7000 RAL
```

```
2291 3656 7700 SWA CLA /FIELD 4
2092 3647 2243 ISZ TFS4
2093 3650 5640 JMP I TFS4
2094 3651 0000 TFS5, 0
2095 3652 7200 CLA
2096 3653 4506 SETFS /SETUP BANK POINTER
2097 3654 1456 TAD I TEMP
2098 3655 7002 BSW
2099 3656 7010 RAL
2100 3657 7620 SWA CLA /FIELD 5
2101 3660 2251 ISZ TFS5
2102 3661 5651 JMP I TFS5
2103
2104 3662 0000 TFS6, 0
2105 3663 7200 CLA
2106 3664 4506 SETFS /SETUP BANK POINTER
2107 3665 1456 TAD I TEMP
2108 3666 7002 BSW
2109 3667 7700 SWA CLA /FIELD 6
2110 3670 2262 ISZ TFS6
2111 3671 5662 JMP I TFS6
2112
2113
2114 3672 0000 TFS7, 0
2115 3673 7200 CLA
2116 3674 4506 SETFS /SETUP BANK POINTER
2117 3675 1456 TAD I TEMP
2118 3676 7002 BSW
2119 3677 7004 RAL
2120 3700 7700 SWA CLA /FIELD 7
2121 3701 2272 ISZ TFS7
2122 3702 5672 JMP I TFS7
2123
2124 /
2125 /TEST RELOCATION STATUS
2126 /RETURN IF RELO STATUS BIT SET (DON'T RELO TO FIELD)
2127 /RETURN+1 IF RELO STATUS BIT RESET (RELO TO THIS FIELD)
2128 /
2129 3703 0000 TRS0, 0
2130 3704 7200 CLA
2131 3705 4507 SETRS /SETUP BANK POINTER
2132 3706 1456 TAD I TEMP
2133 3707 7700 SWA CLA /FIELD 0
2134 3710 2303 ISZ TRS0
2135 3711 5703 JMP I TRS0
2136
2137 3712 0000 TRS1, 0
2138 3713 7200 CLA
2139 3714 4507 SETRS /SETUP BANK POINTER
2140 3715 1456 TAD I TEMP
2141 3716 7004 RAL
2142 3717 7700 SWA CLA /FIELD 1
2143 3720 2312 ISZ TRS1
2144 3721 5712 JMP I TRS1
2145
```

```
2146 3722 0000 TRS2, 0
2147 3723 7200 CLA
2148 3724 4507 SETRS /SETUP BANK POINTER
2149 3725 1456 TAD I TEMP
2150 3726 7006 RTL
2151 3727 7700 SWA CLA /FIELD 2
2152 3730 2322 ISZ TRS2
2153 3731 5722 JMP I TRS2
2154
2155 3732 0000 TRS3, 0
2156 3733 7200 CLA
2157 3734 4507 SETRS /SETUP BANK POINTER
2158 3735 1456 TAD I TEMP
2159 3736 7004 RAL
2160 3737 7006 RTL
2161 3740 7700 SWA CLA /FIELD 3
2162 3741 2332 ISZ TRS3
2163 3742 5732 JMP I TRS3
2164
2165 3743 0000 TRS4, 0
2166 3744 7200 CLA
2167 3745 4507 SETRS /SETUP BANK POINTER
2168 3746 1456 TAD I TEMP
2169 3747 7006 RTL
2170 3750 7006 RTL
2171 3751 7700 SWA CLA /FIELD 4
2172 3752 2343 ISZ TRS4
2173 3753 5743 JMP I TRS4
2174
2175 /*CB*/ PAGE
2176
2177
2178 3754 0000 TRS5, 0
2179 3755 7200 CLA
2180 3756 4507 SETRS /SETUP BANK POINTER
2181 3757 1456 TAD I TEMP
2182 3760 7202 BSW
2183 3761 7010 RAL
2184 3762 7620 SWA CLA /FIELD 5
2185 3763 2251 ISZ TRS5
2186 3764 5754 JMP I TRS5
2187
2188 3765 0000 TRS6, 0
2189 3766 7200 CLA
2190 3767 4507 SETRS /SETUP BANK POINTER
2191 3770 1456 TAD I TEMP
2192 3771 7202 BSW
2193 3772 7700 SWA CLA /FIELD 6
2194 3773 2365 ISZ TRS6
2195 3774 5765 JMP I TRS6
2196
2197 /PAGE
2198 /
2199
2200 4000 0000 TRS7, 0
```

```
2201 4001 7200 CLA
2202 4002 4507 SETRS /SETUP BANK POINTER
2203 4003 1456 TAD I TEMP
2204 4004 7002 BSW
2205 4005 7004 RAL
2206 4006 7700 SMA CLA /FIELD 7
2207 4007 2200 ISZ TRS7
2208 4010 5700 JMP I TRS7
2209
2210
2211
2212
2213 /TYPEOUT ERROR HEADING
2214
2215 4011 0000 ERRND, 0
2216 4012 1076 TAD NOTTY /GET TTY FLAG
2217 4013 7710 SPA CLA
2218 4014 5611 JMP I ERRND /NO TELETYPE AVAILABLE DON'T PRINT
2219 4015 4777 JMS MES
2220 4016 4543 TEXT '*PR LOC FAIL ADR GOOD BAD PATTERN*'
2221 4017 2022
2222 4020 4014
2223 4021 1703
2224 4022 4040
2225 4023 0601
2226 4024 1114
2227 4025 4001
2228 4026 0422
2229 4027 4040
2230 4030 0717
2231 4031 1704
2232 4032 4040
2233 4033 0201
2234 4034 0440
2235 4035 4020
2236 4036 0124
2237 4037 2405
2238 4040 2216
2239 4041 0000
2240 4042 5611 JMP I ERRND
2241
2242
2243 /TYPEOUT PROGRAM TITLE
2244
2245 4043 0000 TITLE, 0
2246 4044 1076 TAD NOTTY /GET TTY FLAG
2247 4045 7710 SPA CLA /TTY AVAILABLE ?
2248 4046 5643 JMP I TITLE /NO. ABORT MESSAGE
2249 4047 4777 JMS MES
2250 4050 4543 TEXT '*PDP-0E EXT MEM DATA & CHKBD*'
2251 4051 4320
2252 4052 0420
2253 4053 5570
2254 4054 0540
2255 4055 0530
```

```
4056 2440
4057 1505
4060 1540
4061 0401
4062 2401
4063 4046
4064 4003
4065 1013
4068 0204
4069 4300
2232 4070 5643 JMP I TITLE
2233
2234
2235 /TYPEOUT TO SET SWITCHES
2236
2237 4071 0000 SETSW, 0
2238 4072 1076 TAD NOTTY /GET TTY FLAG
2239 4073 7710 SPA CLA /IS THERE A TTY AVAILABLE
2240 4074 5671 JMP I SETSW
2241 4075 4777 JMS MES
2242 4076 4543 TEXT '*SELECT FIELD PARAMETERS*'
2243 4077 2309
2244 4100 1405
2245 4101 0324
2246 4102 4006
2247 4103 1105
2248 4104 1404
2249 4105 4020
2250 4106 0122
2251 4107 0115
2252 4110 0524
2253 4111 0522
2254 4112 2345
2255 4113 4300
2243 4114 5671 JMP I SETSW
2244
2245
2246
2247 /TYPEOUT 'NO RELOCATION'
2248
2249 4115 0000 PNDREL, 0
2250 4116 1076 TAD NOTTY /GET TTY FLAG
2251 4117 7710 SPA CLA /IS THERE A TTY ON SYSTEM
2252 4120 5715 JMP I PNDREL /NO. GO RUN TEST
2253 4121 4777 JMS MES
2254 4122 4543 TEXT '*NO RELOCATION, PROG IN FIELD*'
2255 4123 1217
2256 4124 22
2257 4125 0514
2258 4126 1703
2259 4127 0124
2260 4130 1117
2261 4131 1654
2262 4132 4020
```

```
4133 2217
4134 0740
4135 1118
4136 4008
4137 1105
4140 1404
4141 4000
2256 4142 6224 RIF
2257 4143 7106 CLL RTL
2258 4144 7004 RAL
2259 4145 1124 TAD [6000
2260 4146 3350 DCA ZB
2261 4147 4777 JMS MES
2262 4150 0000 ZB. 0
2263 4151 7240 STA HEAD1
2264 4152 3055 DCA
2265 4153 5715 JMP I PNOREL
2266
2267 /
2268 /TYPEOUT 'RELOCATION'
2269 /
2270 4154 0000 PREL. 0
2271 4155 1076 TAD NOTTY /GET TELETYPE FLAG
2272 4156 7710 SPA CLA /PRINT MESSAGE 7
2273 4157 5754 JMP I PREL /NO TTY - DO NOT PRINT
2274 4160 4777 JMS MES
2275 4161 4543 TEXT *$PRCG WILL RELOCATE*
4162 3772
4163 07
4164 4027
4165 1114
4166 1440
4167 2205
4170 1417
4171 0301
4172 2405
4173 0000
2276 4174 7240 STA
2277 4175 3055 DCA HEAD1
2278 4176 5.54 JMP I PREL
2279
2280
2281
2282 /
2283 4177 2240 PAGE
4200
2284
2285 /
2286 /
2287 /
2288 /
2289 /
2290 /
2291 /RELOCATE THE PROGRAM
2292 /
```

```
2293 4200 0000 RELO. 0
2294 4201 7200 CLA
2295 4202 3053 DCA COUNT /CLEAR ERROR COUNTER
2296 4203 3054 DCA MOVE /CLEAR MOVE COUNTER
2297 4204 2061 ISZ RELCNT /SEE IF ALL FIELDS DONE
2298 4205 5212 JMP .+5
2299 4206 1077 TAD NUMFLO
2300 4207 7711 CIA
2301 4210 0061 DCA RELCNT
2302 4211 4777 JMS ENDPAS
2303 4212 1176 TAD [6201
2304 4213 1051 TAD PROFLO
2305 4214 3225 DCA RELO2
2306 4215 1176 TAD [6201
2307 4216 1052 TAD TSTFLO
2308 4217 3227 DCA RELO3
2309 4220 1225 TAD RELO2
2310 4221 3232 DCA RELO4
2311 4222 7705 CLL CLA IAC RAL /AC+2
2312 4223 1227 TAD RELO3
2313 4224 3544 DCA RELO5
2314 4225 6201 RELO2, CDF 0 /MOVE FROM CF
2315 4226 1454 TAD 1 MOVE
2316 4227 6201 RELO3, CDF 0 /MOVE TO DF
2317 4230 3454 DCA 1 MOVE
2318 4231 1454 TAD 1 MOVE
2319 4232 6201 RELO4, CDF 0 /MOVE FROM DF
2320 4233 7041 CIA
2321 4234 1454 TAD 1 MOVE
2322 4235 7640 SZA CLA
2323 4236 4776 JMS ERRN /MOVE ERROR
2324 4237 2054 ISZ MOVE
2325 4240 5225 JMP RELO2
2326 4241 1053 TAD COUNT
2327 4242 7640 SZA CLA /SKIP IF MOVE ERROR
2328 4243 5600 JMP I RELO
2329 4244 6203 RELO5, CDF 0 /NEW PROGRAM FIELD
2330 4245 5600 JMP I RELO
2331
2332 /
2333 /INTERRUPT ROUTINE
2334 /
2335 4246 4300 INTROU, JMS SAVINT
2336 4247 6107 SPO /SKIP IF PARITY OPTION
2337 4250 5253 JMP .+3
2338 4251 6101 SWP
2339 4252 5775 JMP PARINT /PARITY ERROR
2340 4253 6031 KGF
2341 4254 5774 JMP EADINT /UNWANTED INTERRUPT
2342 4255 4773 JMS KBINT /KEYBOARD INTERRUPT
2343 4256 4772 INTR. JMS RESINT
2344 4257 7200 CLA
2345 4260 1075 TAD SMO
2346 4261 7421 MQL
2347 4262 6004 GTF /RESTORE MQ
```

```
2348 4263 8005 RTF
2349 4264 7200 CLA
2350 4265 1974 TAD SAC /RESTORE AC
2351 4266 5400 JMP I C
2352
2353
2354 /TURN INTERRUPT ON IF FIELD 0 AND PARITY OPTION INSTALLED
2355
2356
2357 4267 0000 PAR, 0
2358 4270 7300 CLA CLL
2359 4271 6007 CAF
2360 4272 6107 SPD /SKIP ON PARITY OPTION
2361 4273 5657 JMP I PAR
2362 4274 6224 RIF
2363 4275 7850 SNA CLA /SKIP IF NOT FIELD 0
2364 4276 6001 ICN
2365 4277 5687 JMP I PAR
2366 4300 0000 SAVINT, 0
2367 4301 7200 CLA
2368 4302 1771 TAD SIXTY
2369 4303 3335 DCA A1
2370 4304 1770 TAD CNV
2371 4305 3336 DCA A2
2372 4306 1787 TAD S0
2373 4307 3337 DCA A3
2374 4310 1766 TAD S1
2375 4311 3340 DCA A4
2376 4312 1765 TAD S2
2377 4313 3341 DCA A5
2378 4314 1764 TAD YES
2379 4315 3342 DCA A6
2380 4316 1783 TAD TYPCH
2381 4317 3343 DCA A7
2382 4320 1762 TAD NO
2383 4321 3344 DCA A8
2384 4322 1761 TAD TYPE
2385 4323 3345 DCA A9
2386 4324 1760 TAD TYPSP
2387 4325 3346 DCA A10
2388 4326 1757 TAD RETURN
2389 4327 3347 DCA A11
2390 4330 1756 TAD ERRD90
2391 4331 3350 DCA A12
2392 4332 1755 TAD ERROR1
2393 4333 3351 DCA A13
2394
2395 4334 5754 JMP C80000 /CB/
2396
2397 4335 0000 A1, 0 /CB/
2398 4336 0000 A2, 0 /CB/
2399 4337 0000 A3, 0 /CB/
2400 4340 0000 A4, 0 /CB/
2401 4341 0000 A5, 0 /CB/
2402 4342 0000 A6, 0 /CB/
```

```
2403 4343 0000 A7, 0 /CB/
2404 4344 0000 A8, 0 /CB/
2405 4345 0000 A9, 0 /CB/
2406 4346 0000 A10, 0 /CB/
2407 4347 0000 A11, 0 /CB/
2408 4350 0000 A12, 0 /CB/
2409 4351 0000 A13, 0 /CB/
2410
2411 4354 2400
2412 4355 2461
2413 4356 2460
2414 4357 2405
2415 4360 2400
2416 4361 5025
2417 4362 2313
2418 4363 2256
2419 4364 2240
2420 4365 2237
2421 4366 2236
2422 4367 2235
2423 4370 2222
2424 4371 2200
2425 4372 2192
2426 4373 1546
2427 4374 3200
2428 4375 3100
2429 4376 2503
2430 4377 5726
2431 PAGE /CB/
2432 C80000, /CB/
2433
2434
2435 4400 1777 TAD ERROR1+1
2436 4401 3315 DCA A14
2437 4402 1778 TAD A14
2438 4403 3316 DCA A15
2439 4404 1775 TAD A15
2440 4405 3317 DCA A16
2441 4406 1774 TAD A16
2442 4407 3320 DCA A17
2443 4410 1773 TAD A17
2444 4411 3321 DCA A18
2445 4412 1772 TAD A18
2446 4413 3322 DCA A19
2447 4414 1771 TAD A19
2448 4415 3323 DCA A20
2449 4416 1770 TAD A20
2450 4417 3324 DCA A21
2451 4420 1767 TAD A21
2452 4421 3325 DCA A22
2453 4422 1766 TAD A22
2454 4423 3326 DCA A23
2455 4424 1765 TAD A23
2456 4425 3327 DCA A24
```

```
2457
2458 4428 1754' TAD SAVINT /CB/
2459 4427 3231 DCA CBCCD1 /CB/
2460 4430 5831 JMP : CBCCD1 /CB/
2461
2462 4431 0000 CB00D1, 0 /CB/
2463
2464
2465
2466
2467 4432 0000 RESINT, 0
2468 4433 1200 CLA
2469 4434 1763' TAD A1
2470 4435 3782' DCA SIXTY
2471 4436 1761' TAD A2
2472 4437 3750' DCA C5V
2473 4440 1757' TAD A3
2474 4441 3755' DCA SC
2475 4442 1755' TAD A4
2476 4443 3754' DCA S1
2477 4444 1753' TAD A5
2478 4445 3752' DCA S2
2479 4446 1751' TAD A6
2480 4447 3750' DCA SES
2481 4450 1747' TAD A7
2482 4451 3746' DCA T/PCN
2483 4452 1745' TAD A8
2484 4453 3744' DCA WC
2485 4454 1743' TAD A9
2486 4455 3742' DCA TYPE
2487 4456 1741' TAD A10
2488 4457 3740' DCA TYPSP
2489 4460 1737' TAD A11
2490 4461 3736' DCA RETURN
2491 4462 1735' TAD A12
2492 4463 3734' DCA ENFCRD
2493 4464 1733' TAD A13
2494 4465 3732' DCA ERROR1
2495 4466 1315 T/D A14
2496 4467 3777' DCA ERROR1+1
2497 4470 1316 TAD A15
2498 4471 3776' DCA ADDER
2499 4472 1317 TAD A16
2500 4473 3775' DCA TN
2501 4474 1323 TAD A17
2502 4475 3774' DCA T0
2503 4476 1321 TAD A18
2504 4477 3773' DCA T1
2505 4500 1322 TAD A19
2506 4501 3772' DCA T07
2507 4502 1323 TAD A20
2508 4503 3771' DCA T70
2509 4504 1324 TAD A21
2510 4505 3770' DCA T25
2511 4506 1325 TAD A22
```

```
2512 4507 3767' DCA T52
2513 4510 1326 TAD A23
2514 4511 3766' DCA TCS
2515 4512 1327 TAD A24
2516 4513 3765' DCA T13
2517 4514 5832 JMP : RESINT
2518
2519 4515 0000 A14, 0 /CB/
2520 4516 0000 A15, 0 /CB/
2521 4517 0000 A16, 0 /CB/
2522 4520 0000 A17, 0 /CB/
2523 4521 0000 A18, 0 /CB/
2524 4522 0000 A19, 0 /CB/
2525 4523 0000 A20, 0 /CB/
2526 4524 0000 A21, 0 /CB/
2527 4525 0000 A22, 0 /CB/
2528 4526 0000 A23, 0 /CB/
2529 4527 0000 A24, 0 /CB/
2530
2531 /
2532 4532 2461
2533 4533 4351
2534 4534 2460
2535 4535 4350
2536 4536 2465
2537 4537 4347
2538 4540 2463
2539 4541 4348
2540 4542 4349
2541 4543 4345
2542 4544 2313
2543 4545 4344
2544 4546 2256
2545 4547 4343
2546 4550 2240
2547 4551 4342
2548 4552 2237
2549 4553 4341
2550 4554 2226
2551 4555 4340
2552 4556 2235
2553 4557 4337
2554 4558 1102
2555 4561 4336
2556 4562 2200
2557 4563 4335
2558 4564 4330
2559 4565 1332
2560 4566 13
2561 4567 1064
2562 4570 3050
2563 4571 3034
2564 4572 3020
2565 4573 3010
2566 4574 3000
```

```
2507 4575 2735
2508 4576 2466
2509 4577 2462
      4600
2570
2571 /
2572 /TYPEOUT 'NONE' FOR NO LEGAL FIELD SELECTION.
2573 /
2573 4600 1076 NOFLD, TAD NOTTY /GET THE TTY FLAG
2574 4601 7710 SPA CLA /WAS IT SET
2575 4602 5777 JMP PATA /YES NO TELETYPE DO NOT PRINT
2576 4603 4776 JMS MES
2577 4604 1617 TEXT "NONE"
      4605 1605
      4606 0000
2578 4607 5777 JMP PATA /SETUP SWITCHES AGAIN
2579
2580 /THIS ROUTINE ESTABLISHES THE PROPER ERROR ROUTINE TO GO TO
2581 /
2582
2583 4610 0000 SETERR, 0
2584 4611 7200 CLA
2585 4612 1775 TAD FLD CNT
2586 4613 0035 AND SR911
2587 4614 1374 TAD (ERRTAB /GET TO ERROR ROUTINE TO EXECUTE
2588 4615 3253 DCA SRS
2589 4616 1653 TAD I SRS /GET ROUTINE TO EXECUTE
2590 4617 3253 DCA SRS /SAVE IT
2591 4620 4F53 JMS I SRS /GO EXECUTE ROUTINE
2592 4621 1100 STA /ACA-1
2593 4622 1060 TAD FCNT /-1 TO NUMBER OF FIELDS TO DO
2594 4623 3060 DCA FCNT /SAVE NEW VALUE
2595 4624 1060 TAD FCNT
2596 4625 7640 SZA CLA /ANY FIELDS LEFT TO DO
2597 4626 8610 JMP I SETERR /YES CONTINUE TESTING
2598 4627 4776 JMS MES
2599 4630 4543 TEXT "X#DISCONNECTED"
      4631 0411
      4632 2303
      4633 1716
      4634 1005
      4635 0324
      4636 0504
      4637 0000
2600 4640 7402 HLT
2601 4641 5240 JMP -1
2602 4642 5610 JMP I SETERR /DON'T CONTINUE
2603
2604 4643 3307 /
2605 4644 3327 ERRTAB, SR50
2606 4645 3400 SR51
2607 4646 3422 SR52
2608 4647 3442 SR53
2609 4650 3462 SR54
2610 4651 3502 SR55
2611 4652 3522 SR56
      SR57
```

```
2612
2613 4653 0000 SRS, 0
2614
2615 /
2616 4654 0000 PNTFLD, 0
2617 4655 4776 JMS MES
2618 4656 4543
2619 4657 1100 0
2620 4660 1060 TAD FCNT
2621 4661 0034 AND SR68 /ISOLATE BANK INFORMATION
2622 4662 7112 CLL RTR
2623 4663 7010 RAR /MOVE INTO POSITION
2624 4664 1167 TAD [760
2625 4665 4773 JMS TYPE /TYPE BANK SELECTION
2626 4666 1060 TAD FCNT /GET FLD CNT
2627 4667 0035 AND SP911
2628 4670 1167 TAD [260 /SET UP ASCII FOR FIELDS
2629 4671 4772 JMS TYPSP /TYPEOUT # OF FIELDS IN THIS SYSTEM
2630 4672 4776 JMS MES
2631 4673 0611 TEXT "FIELDS IN THIS SYSTEM"
      4674 0514
      4675 0423
      4676 4011
      4677 1640
      4700 2410
      4701 1123
      4702 4023
      4703 3123
      4704 2405
      4705 1500
2632 4706 4776 JMS MES
2633 4707 4543 TEXT "X#FIELDS SEL'D ARE "
      4710 0611
      4711 0514
      4712 0423
      4713 4023
      4714 0514
      4715 4703
      4716 4001
      4717 2205
      4720 4000
2634 4721 4771 JMS TQSEL
2635 4722 5654 JMP I PNTFLD
2636
2637 /
2638 /ROUTINE TO CHECK FOR CONSOLE PACKAGE ACTIVE
2639 /
2640 /IF CONSOLE PACKAGE ACTIVE, GO TO CONSOLE PACKAGE
2641 /RETURN CALL + 2
2642 /
2643 /IF CONSOLE PACKAGE NOT ACTIVE, RETURN CALL + 1
2644 /
2645 4723 0000 XCBAL, 0
2646 4724 3346 DCA CHRTMP /SAVE AC
2647 4725 1022 TAD 22 /GET MCW2
```

```
2648 4726 0345 AND K100 /TEST FOR BIT 3=1 CONSOLE ACTIVE
2649 4727 7640 SZA CLA /SKIP IF CONSOLE NOT ACTIVE
2650 4730 5333 JMP .+3 /CONSOLE IS ACTIVE.
2651 4731 1348 TAD CHRTMP /GET BACK THE CHARACTER
2652 4732 5723 JMP I XCBAL /AND EXIT.
2653 4733 6224 RIF /READ INSTRUCTION FIELD
2654 4734 1370 TAD [OFFSET /ADD CONSOLE PACKAGE FIELD OFFSET
2655 4735 1367 TAD [CIF /ADD CIF INSTRUCTION CODE
2656 4736 3537 DCA .+1 /SAVE MODIFIED CIF FOR EXECUTION
2657 4737 7402 HLT /MODIFIED CIF TO CONSOLE PACKAGE FIELD
2658 4740 1348 TAD CHRTMP /RESTORE AC
2659 4741 4744 JMS I CBLOC /GO TO CONSOLE PACKAGE
2660 4742 2323 ISZ XCBAL /INCREMENT RETURN ADDRESS
2661 4743 5723 JMP I XCBAL /RETURN CALL + 2 CONSOLE WAS ACTIVE
2662
2663 4744 7222 /CBLOC. CENR /POINTER TO CONSOLE PACKAGE ENTRY
2664 4745 0400 K100. 0400 /CONSTANT
2665 4746 0000 CHRTMP. 0 /TEMPORARY AC SAVE AREA
2666
2667 /THIS ROUTINE REPLACES THE LAS INSTRUCTION. IF CONSOLE ACTIVE
2668 /THE PSEUDO SWITCH REGISTER WILL BE READ INSTEAD OF
2669 /GOING A LAS
2670
2671 4747 0000 XGETSR. 0
2672 4750 7300 CLL CLA
2673 4751 1621 TAD 21
2674 4752 7710 SPA CLA /SKIP IF PSLUDO SWITCH REGISTER TO BE USED
2675 4753 7614 CLA QSR SKP /GET SWITCHES AND SKIP
2676 4754 1020 TAD 20 /THIS WILL BE ZERO IF CONSOLE NOT ACTIVE
2677 4755 5747 JMP I XGETSR /EXIT WITH VALUE IN THE AC
2678 4767 6202
2679 4770 0000
2680 4771 1105
2681 4772 2400
2682 4773 5025
2683 4774 4643
2684 4775 2346
2685 4776 2240
2686 4777 0205
2687 5000
2688
2689
2690 5000 0000
2691 5001 7200
2692 5002 1076
2693 5003 7710
2694 5004 5770
2695 5005 7771
2696 5006 345
2697 5007 2305
2698 5010 1405
2699 5011 0324
2700 5012 4024
2701 5013 0523
```

PAGE

/PRINT "SELECT TEST PARAMETERS"

SETPAR. 0

CLA

TAD NOTTY

SPA CLA

/SKIP IF TTY AVAILABLE

JMP I SETPAR

JMS MES

TEXT "XSELECT TEST PARAMETERSX"

```
5014 2440
5015 2001
5016 2201
5017 1505
5020 2405
5021 2223
5022 4345
5023 0000
5024 5000
2697 5024 5000 JMP I SETPAR
2698
2699
2700 /TYPEOUT CHARACTER IN AC
2701
2702 5025 0000 TYPE. 0
2703 5026 3056 DCA TEMP /SAVE THE CHARACTER
2704 5027 1022 TAD 22 /GET HCW2
2705 5030 7710 SPA CLA /SKIP APT NOT ACTIVE
2706 5031 5025 JMP I TYPE /EXIT IF APT ACTIVE
2707 5032 1056 TAD TEMP /GET BACK CHARACTER
2708 5033 6000 SKON
2709 5034 5241 JMP TYPEOFF
2710 5035 4503 PPRINT
2711 5036 6001 ICN
2712 5037 7200 CLA
2713 5040 5625 JMP I TYPE
2714 5041 4503 TYPEOFF. PRINT
2715 5042 7200 CLA
2716 5043 5025 JMP I TYPE
2717
2718 /TYPEOUT "PROGRAM IN SELECTED FIELD"
2719
2720
2721 5044 1076 PINF. TAD NOTTY /GET THE TELETYPE PROGRAM FLAG
2722 5045 7710 SPA CLA /IS THERE A TELETYPE AVAILABLE
2723 5046 5776 JMS PATA /NO TTY- DO NOT PRINT
2724 5047 4777 JMS MES /GO PRINT MESSAGE
2725 5050 4E43 TEXT "XPROGRAM IN SELECTED FIELD"
2726 5051 2022
2727 5052 1707
2728 5053 2401
2729 5054 1540
2730 5055 1116
2731 5056 4023
2732 5057 0514
2733 5058 0503
2734 5059 2405
2735 5060 3440
2736 5061 0511
2737 5062 0514
2738 5063 0400
2739 5064 5776 JMP PATA /GO SETUP SWITCHES AGAIN
2740
```

```
/SET UP THE FIELD IN ERROR FOR TYPEOUT
/LOCATION FOLLOWING CALL IS WHERE TO STORE INFORMATION
/
```

```
2731 5067 0000 FLD0AT, 0
2732 5070 1667 TAD I FLD0AT /GET LOCATION TO STORE IT IN
2733 5071 3016 DCA DATTMP /SAVE IT
2734 5072 2267 ISZ FLD0AT /UPDATE RETURN
2735 5073 1275 TAD EMMFLG
2736 5074 7650 SNA CLA /SKIP IF KTB ACTIVE
2737 5075 5002 JAP -5
2738 5076 112 TAD TSTFLD /GET FIELD BEING DONE
2739 5077 1110 RACA /BINARY NUMBER
2740 5100 3056 DCA TEMP /SAVE IT
2741 5101 5056 JAP -5 /PROCESS IT
2742 5102 1052 TAD TSTFLD
2743 5103 7112 CLL RTR
2744 5104 7010 RAR
2745 5105 3056 DCA TEMP /SAVE IT
2746 5106 4775 JMS SIXTY
2747 5107 0656 TEMP /LOCATION TO 00
2748 5110 5114 QQ /WHERE TO PUT IT
2749 5111 1115 TAD YY /GET DECODED VALUE
2750 5112 3716 DCA I DATTMP
2751 5113 5067 JMP I FLD0AT /AND EXIT
2752
2753 /
2754 5114 0000 CC, 0
2755 5115 0000 YY, 0
2756 5116 0000 DATTMP, 0
2757 /
2758
2759 /
2760 /MAKE A BINARY NUMBER OUT OF A FIELD CHANGE
2761 /
2762 5117 0000 XRACA, 0
2763 5120 3360 DCA RTEMP
2764 5121 1060 TAD RTEMP
2765 5122 0365 AND K104
2766 5123 3361 DCA RTEMP1 /SAVE BANK VALUE
2767 5124 1361 TAD RTEMP1
2768 5125 7002 SSW /5 INTO 11
2769 5126 7106 CLL RTL /MOVE INTO 9
2770 5127 7004 RAL /NOW 8
2771 5130 1261 TAD RTEMP1
2772 5131 7004 RAL
2773 5132 0374 AND 130 /ISOLATE BANK
2774 5133 3361 DCA RTEMP1
2775 5134 1360 TAD RTEMP
2776 5135 0373 AND 170 /ISOLATE FIELD
2777 5136 7112 CLL RTR
2778 5137 7010 RAR /INTO BIT 9-11
2779 5140 1361 TAD RTEMP1
2780 5141 5717 JMP I XRACA /EXIT WITH BINARY NUMBER IN THE AC
2781 /
2782 /MAKE A FIELD CHANGE OUT OF A BINARY NUMBER
2783 /
2784 5142 0000 XRACS, 0
2785 5143 3360 DCA RTEMP
```

```
2786 5144 1360 TAD RTEMP
2787 5145 7112 CLL RTR
2788 5146 7010 RAR /BANK IN 10-11
2789 5147 0372 AND 13
2790 5150 1371 TAD (BANKR /MAKE A POINTER
2791 5151 3217 DCA XRACA /SAVE THE POINTER
2792 5152 1360 TAD RTEMP
2793 5153 0370 AND 17 /ISOLATE FIELD
2794 5154 7106 CLL RTL
2795 5155 7004 RAL /NOW IN POSITION
2796 5156 1717 TAD I XRACA
2797 5157 5742 JMP I XRACS
2798 /
2799 5160 0000 RTEMP, 0
2800 5161 0000 RTEMP1, 0
2801 5162 0000 BANKR, 0
2802 5163 0004 4
2803 5164 0100 100
2804 5165 0104 K104, 104
2805 /
2806 5170 0007
2807 5171 5132
2808 5172 0003
2809 5173 0070
2810 5174 0030
2811 5175 0000
2812 5176 0005
2813 5177 2240
2814
2815 /
2816 /
2817 /
2818 /THE FOLLOWING TEST IS A MARCH PATTERN DEVELOPED FOR TESTING
2819 /THE MSB-C MOS MEMORY.
2820 /
2821 /
2822 /THE TEST SELECTED FOR THE MOS MEMORY TESTING IS A TYPICAL MARCH
2823 /PATTERN. THE TEST BEGINS BY LOADING THE ENTIRE MEMORY WITH
2824 /A 2525 PATTERN. THEN STARTING AT ADDRESS ZERO OF LOWEST POSSIBLE
2825 /FIELD THE TEST READS THE CONTENTS, COMPARES IT, AND THEN WRITES BACK
2826 /THE COMPLEMENT VALUE. THE PROCESS IS REPEATED THROUGHOUT THE ENTIRE
2827 /MEMORY.
2828 /
2829 /NEXT THE PROCESS REPEATS FROM MAXIMUM TO MINIMUM, COMPLEMENTING
2830 /AS IT IS BEING DONE.
2831 /
2832 /THE ENTIRE SEQUENCE IS THEN REPEATED USING A BACKGROUND OF
2833 /0122. THIS INSURES THAT A ONE AND A ZERO CAN BE WRITTEN INTO
2834 /EACH MEMORY CELL.
2835 /
2836 /
2837 /
2838 5200 0000 POSTST, 0
2839 5201 7244 CLL CLA CVA RAL /AC=2
```

```
2840 5202 3364 DCA PATCNT
2841 5203 7344 CLL CLA CVA RAL /AC=-2
2842 5204 3362 DCA TSTCNT
2843 5205 7336 CLL CLA
2844 5206 3777 DCA FLOCNT
2845 5207 3624 DCA BANK /CLEAR INDICATORS
2846 5210 7301 CLL CLA IAC
2847 5211 3360 DCA ADDINC
2848 5212 7301 CLL CLA IAC
2849 5213 3361 DCA FLDINC
2850 5214 4778 MOSLOD, JMS MUFLD /TEST FOR VALID FIELD SELECTION
2851 5215 5232 JVP MUUPD /GO UPDATE FIELD VALUE
2852 5216 1051 TAD MUFLD /GET CURRENT FIELD
2853 5217 1176 TAD [6201 /MAKE IT A CDF
2854 5220 3227 DCA MUFLD /SAVE FOR RETURN
2855 5221 1052 TAD TSTFLD
2856 5222 1176 TAD [6201 /MAKE TEST FIELD A CDF
2857 5223 3225 DCA -2
2858 5224 1385 VENLOD, TAD PAT1 /FILL MEMORY WITH BACKGROUND
2859 5225 6201 CDF /CHANGED TO LOAD FIELD
2860 5226 3457 DCA I TSTAD
2861 5227 6201 MOSFLD, CDF /MAKE DF=PROFLD
2862 5230 3057 ISZ TSTAD /SEE IF ALL DONE
2863 5231 5224 JMP MUFLD /GO BACK AND TRY IT AGAIN
2864 /UPDATE TEST FIELD VALUE AND TEST AGAIN
2865 /
2866 5232 7200 MUUPD, CLA
2867 5233 1177 TAD FLOCNT
2868 5234 1141 CIA
2869 5235 1060 TAD FCNT /TEST FOR MAX VALUE
2870 5236 7850 SNA CLA /SKIP IF NOT AT MAX
2871 5237 5242 JMP -3 /AT MAX START READING
2872 5240 2777 ISZ FLOCNT /UPDATE FIELD TO DO
2873 5241 5214 JMP MUFLD /GO BACK AND TEST THIS FIELD VALUE
2874 /
2875 /AT THIS POINT ALL MEMORY IS FILLED WITH BACKGROUND 2525
2876 /
2877 5242 4406 JMS I IAPTOX /NOTIFY APT IF REQUIRED.
2878 5243 3777 DCA FLOCNT
2879 5244 3624 DCA BANK /CLEAR INDICATORS AGAIN FOR READ CYCLE
2880 5245 4778 MOSRED, JMS MUFLD
2881 5246 5300 JMP MUUPD /NOT A VALID SELECTION.
2882 5247 1365 TAD PAT1 /SET UP COMPARISON
2883 5250 3672 DCA GOATA
2884 5251 1051 TAD PROFLD /GET CURRENT FIELD LOCATION
2885 5252 1176 TAD [6201 /MAKE IT A CDF
2886 5253 3264 DCA REDFLD /SET UP RETURN
2887 5254 1052 TAD TSTFLD /GET FIELD TO READ
2888 5255 1176 TAD [6201 /MAKE IT A CDF
2889 5256 3257 DCA -1 /AND SAVE IT FOR USE
2890 5257 6201 REDLUR, CDF /CHANGE TO TEST FIELD CDF
2891 5260 1457 TAD I TSTAD /GET VALUE IN SELECTED FIELD
2892 5261 3073 DCA BOATA /SAVE IT FOR COMPARISON
2893 5262 1365 TAD PAT2 /NOW WRITE BACK COMPLIMENT VALUE
2894 5263 3457 DCA I TSTAD /BACK INTO SELECTED FIELD
```

```
2895 5264 6201 REDFLD, CDF /CHANGED TO CURRENT CDF
2896 5265 1072 TAD GOATA
2897 5266 7041 CIA
2898 5267 1073 TAD BOATA /SET UP COMPARISON
2899 5270 7640 SZA CLA /SKIP IF EQUAL
2900 5271 4775 JMS MOSERR /GO REPORT ERROR
2901 5272 1057 TAD TSTAD
2902 5273 1176 TAD ADDINC /ADD IN ADDRESS OFFSET.
2903 5274 1176 DCA TSTAD /AND RESTORE NEW VALUE
2904 5275 1057 TAD TSTAD
2905 5276 7640 SZA CLA
2906 5277 5257 JMP REDLUR /GO BACK AND DO THE NEXT
2907 5300 1361 MUUPD, TAD FLDINC
2908 5301 7710 SPA CLA /SKIP IF READING LOW TO HIGH
2909 5302 5305 JMP -3 /BY PASS COMPARISON
2910 5303 1060 TAD FCNT
2911 5304 7641 CIA
2912 5305 1777 TAD FLOCNT
2913 5306 7750 SNA CLA /SKIP IF NOT AT MAX
2914 5307 5314 JMP -5
2915 5310 1361 TAD FLDINC /ADD IN FIELD OFF SET VALUE
2916 5311 1777 TAD FLOCNT /TO THE CURRENT FIELD POSITION
2917 5312 3777 DCA FLOCNT
2918 5313 5245 JMP MOSRED /GO BACK AND READ NEXT FIELD
2919 /
2920 /NOW UPDATE PATTERN TO LOAD AND READ BACK VALUE
2921 /
2922 5314 1361 TAD FLDINC
2923 5315 7041 CIA /NEGATE CURRENT FIELD INCREMENT VALUE
2924 5316 3261 DCA FLDINC /AND RESTORE IT
2925 5317 1360 TAD ADDINC /NOW DO SAME FOR THE ADDRESS OFFSET
2926 5320 7041 CIA
2927 5321 3360 DCA ADDINC
2928 5322 1360 TAD ADDINC
2929 5323 7700 SNA CLA /SKIP IF READING HIGH TO LOW
2930 5324 3231 JMP -5
2931 5325 7240 STA /AC TO -1
2932 5326 3257 DCA TSTAD /START AT ADDRESS 7777 OF HIGH FIELD
2933 5327 1563 TAD FCNT /START AT HIGHEST FIELD
2934 5330 3777 DCA FLOCNT
2935 5331 1265 TAD PAT1 /COMPLIMENT PATTERN
2936 5332 7640 DCA
2937 5333 3233 DCA PAT1
2938 5334 1366 TAD PAT2
2939 5335 7640 DCA
2940 5336 3266 DCA PAT2
2941 5337 4406 JMS I IAPTOX
2942 5340 2562 ISZ TSTCNT /ALL DONE ?
2943 5341 7610 SNA
2944 5342 5246 JMP -4
2945 5343 7336 CLL CLA CVA RTR /SET BIT ONE OF CS WORD
2946 5344 3236 DCA CS /ONES COMPLIMENT
2947 5345 5243 JMP MOSRED
2948 5346 3236 DCA CS
2949 5347 1365 TAD PAT1
```

```
2950 5350 7040 CMA
2951 5351 3385 DCA PAT1
2952 5352 1386 TAD PAT2
2953 5353 7040 CMA
2954 5354 3386 DCA PAT2
2955 5355 2384 ISZ PATCNT /SEE IF ALL PATTERNS DONE
2956 5356 5203 JMP MOSTST+3
2957 5357 5600 JMP I MOSTST
2958
2959 5360 0000 /
2960 5361 0000 ADDINC, 0
2961 5362 0000 FLDINC, 0
2962 5363 0000 TSTCNT, 0
2963 5364 0000 ADDCNT, 0
2964 5365 0000 PATCNT, 0
2965 5365 2525 PAT1, 2525
2966 5366 5252 PAT2, 5252
2967
2967 5375 5415 /
2968 5376 0707
2969 5377 2348
2970 5400 PAGE
2971 5400 0000 /
2972 5401 6040 XPRINT, 0
2973 5402 6041 TLS
2974 5403 5202 JMP -1
2975 5404 6042 TCF
2976 5405 7200 CLA
2977 5406 6031 NSF /IS KEY BOARD VIATING
2978 5407 5600 JMP I XPRINT /GET CHARACTER
2979 5410 6036 MRB /TEST FOR ACTIVE CONSOLE
2980 5411 4505 CBCL /NOT ACTIVE JUST IGNORE CHARACTER
2981 5412 7200 CLA /CLEAR FLAG
2982 5413 6032 NCC
2983 5414 5600 JMP I XPRINT
2984
2985
2986 /
2987 /
2988
2989 5415 0000 MOSERR, 0
2990 5416 2053 ISZ COUNT /UPDATE ERROR COUNT
2991 5417 1377 TAD (40
2992 5420 3037 DCA TS /SAVE TEST STATUS FOR PRINTOUT
2993 5421 3036 DCA CS
2994 5422 1072 TAD QDATA /DATA WRITTEN
2995 5423 4776 JMS GERRC
2996 5424 3053 DCA COUNT
2997 5425 1115 JMP I MOSERR
2998
2999
3000
3001 /
3002 /
3003 /PRINT END OF PASS MESSAGE
```

```
3004
3005 5426 0000 /
3006 5427 7200 ENDPAS, 0
3007 5430 1076 CLA
3008 5431 7710 TAD NOTTY
3009 5432 5626 SPA CLA /SKIP IF IT IS AVAILABLE
3010 5433 2255 JMP I ENDPAS
3011 5434 4775 ISZ PASSES
3012 5435 5455 JMS SIXTY
3013 5436 5451 PASSES
3014 5437 4774 ENDMES MES
3015 5440 4345 JMS TEXT *#END OF PASS *
3016 5441 0516
3017 5442 0440
3018 5443 1706
3019 5444 4020
3020 5445 0123
3021 5446 2340
3022 5447 0000
3023 5450 4774 JMS MES
3024 5451 0000 ENDMES, 0
3025 5452 0000 0
3026 5453 0000 0
3027 5454 5626 JMP I ENDPAS
3028
3029 /
3030 /
3031 /
3032 5600 0000 /
3033 5601 6002 APTER, 0 /APT/
3034 5602 3222 IDP /APT/
3035 5603 1122 DCA APTIZ /SAVE ANYTHING IN THE AC
3036 5604 7700 TAD 22 /GET MCW2
3037 5605 5600 SMA CLA /SKIP IF APT ALIVE
3038 5606 6224 JMP I APTER
3039 5607 1123 RIF /APT/
3040 5610 3021 TAD [G203 /APT/CREATES A CDF INST.
3041 5611 1621 DCA APTER1 /APT CDF IN PROM CODE
3042 5612 3218 TAD APTER1
3043 5613 1222 DCA APTIZ
3044 5614 7450 SNA
3045 5615 1777 TAD ADDER /APT/MODIFY NEXT CDF INST.
3046 5616 6201 CDF /SEE IF ANYTHING WAS IN AC
3047 5617 7000 NOP /SKIP IF THERE WAS
3048 5620 5776 JMP /APT/AC=ERROR PC.
3049 /
3050 5621 6523 APTER1, 6523 /APT/(MODIFIED CDF) DP=IF.
3051 /APT/CALL APT - 'ERROR'.
```

```

3051 /
3052 /APT/ THIS ROUTINE INITIALIZES PROGRAM FOR APT
3053 /
3054 APT12, 0
3055 5622 0000 /MAKE SURE INTERRUPT IS OFF
3056 5623 0002 /GET APT CONTROL WORD
3057 5624 1022 /SKIP IF APT ENABLED.
3058 5625 7700 /
3059 5626 5774 /AC=1
3060 5627 140 /NOP CONSOLE TERMINAL
3061 5630 5076 /SET UP FOR AUTO SIZE
3062 5631 1375 /
3063 5632 3020 /APT ENABLED
3064 5633 5251 /
3065 5634 1076 /
3066 5635 7700 /SKIP IF NO TTY ON SYSTEM
3067 5636 5250 /
3068 5637 1021 /GET CONFIGURATION WORD 1
3069 5640 7710 /SKIP IF SOFTWARE SWITCHES TO BE USED
3070 5641 5747 /
3071 5642 1020 /GET PSEUDO SWITCH REGISTER
3072 5643 7840 /SKIP IF NO VALUE IN PSEUDO SWITCHES
3073 5644 5247 /
3074 5645 1375 /SETUP DEFAULT FOR AUTO SIZING
3075 5646 3020 /
3076 5647 7610 /BYPASS SAVING OS/B MONITOR
3077 5650 4774 /SAVE OSB MONITOR IN FIELD 1
3078 5651 5622 /AND EXIT
3079 /
3080 /
3081 /
3082 /
3083 /APT/ ROUTINE TO 'NOTIFY' APT THAT THE PROGRAM IS RUNNING OK.
3084 /
3085 5652 0000 APTOK, 0 /APT/
3086 5653 7200 CLA /APT/
3087 5654 1022 TAD /APT/UNDER APT CONTROL?
3088 5655 7700 SNA CLA /APT/SKP IF YES.
3089 5656 5274 JMP APTOK0 /
3090 5657 0002 /APT/
3091 5660 6224 /APT/AC=IF.
3092 5661 1123 TAD [6203 /APT/CREATE A CDF INST.
3093 5662 3873 DCA APTOK1 /SET UP APT CODE CDF
3094 5663 1673 TAD APTOK1
3095 5664 3265 DCA /
3096 5665 6201 CDF /APT/MODIFY NEXT LOC.
3097 5666 7000 NOP /APT/INCDIF ED CDF OF CURRENT IF.
3098 5667 4773 JMS 6500 /APT/CALL APT - 'PRG CK'.
3099 5670 5652 JMP APTOK /APT/RTN FROM APT - RTN TO CALL+1.
3100 5671 0000 APTCT, 0
3101 5672 0000 APTCTY, 0
3102 5673 6505 APTOK1, 6505 /LOCATION TO OVERLAY FOR PROPER FIELD
3103 /
3104 /SEE IF KEY BOARD WAITING
3105 /

```

```

3106 5674 0000 APTOK0, 0
3107 5675 6031 KSF
3108 5676 5852 JMP I APTOK
3109 5677 6036 KRB
3110 5700 4505 CBCAL /TEST FOR CONSOLE
3111 5701 7200 CLA /IGNORE CHARACTER
3112 5702 6832 KCC
3113 5703 5652 JMP I APTOK /EXIT
3114 /
3115 /
3116 /THIS ROUTINE DETERMINES IF MEMORY IS CONTIGUOUS IS LOWER 32K
3117 /OF MEMORY. IF NOT FIELD 7 IS NOT TESTED.
3118 /
3119 5704 0000 APTFL, 0 /APT/
3120 5705 1022 TAD /GET APT CONTROL WORD
3121 5706 7700 SNA CLA /SKIP IF APT ENABLED
3122 5707 5704 JMP I APTFL /EXIT IF NOT
3123 5710 7333 CLL CLA CML IAD RTR /AC=6000
3124 5711 3337 DCA APTMOV /SET UP STARTING ADDRESS
3125 5712 6271 APTLUP, CDF 70 /POINTER TO PROM CODE
3126 5713 1737 TAD I APTMOV /GET AN ADDRESS
3127 5714 6201 CDF /FIELD ZERO
3128 5715 3737 DCA I APTMOV /SAVE THE VALUE
3129 5716 1737 TAD I APTMOV /GET BACK VALUE JUST MOVED
3130 5717 7041 CIA
3131 5720 6271 CDF 70 /BACK TO FIELD 7 FOR COMPARE
3132 5721 1737 TAD I APTMOV /GET BACK ORIGINAL VALUE
3133 5722 6201 CDF /BACK TO FIELD ZERO
3134 5723 7640 SZA CLA /SKIP IF EQUAL
3135 5724 4340 JMS MOVFAL /MOVE FAILURE. SOME BAD STUFF
3136 5725 2337 ISZ APTMOV /UP DATE ADDRESS POINTER
3137 5726 5312 JMP APTLUP /GO BACK AND TRY AGAIN
3138 /
3139 /AT THIS POINT THE APT PROM CODE IS SITTING IN THE PROGRAM
3140 /FIELD. FROM THIS POINT OUT ALL APT PROCESSING WILL BE DONE
3141 /IN THE FIELD BEING EXERCISED.
3142 /
3143 5727 1040 TAD FS /TEST TO SEE IF LOWER 32K CONTIGUOUS
3144 5730 7650 SNA CLA
3145 5731 5704 JMP I APTFL /ALL MEMORY CONTIGUOUS
3146 5732 1040 TAD FS /GET BACK FIELD STATUS
3147 5733 0072 AND 17740 /MASK OUT 7
3148 5734 1371 TAD 120 /NOP FIELD TESTING
3149 5735 3040 DCA FS /AND RESTORE FIELD STATUS WORD
3150 5736 5704 JMP I APTFL /AND EXIT.
3151 /
3152 5737 0000 APTMOV, 0
3153 /
3154 5740 30 MOVFAL, 0
3155 5741 240 STA
3156 5742 1340 TAD MOVFAL /ERROR PC
3157 5743 6201 CDF /ERROR FIELD
3158 5744 6272 CIF 70 /TO PROM CODE
3159 5745 5776 JMP 6220 /REPORT THE ERROR
3160

```

```
3161 /
3162 /
3163 /THE FOLLOWING LOCATIONS FROM 6000 TO 7777 ARE USED AS THE COMMUNICATIONS
3164 /INTERFACES FOR APT SHOULD APT BE AVAILABLE.
3165 /
3166 5771 5C23
3167 5772 7740
3168 5773 65CC
3169 5774 6036
3170 5775 6037
3171 5776 6620
3172 5777 2468
3173 5C00 /C6/
3174 6000 4777 LOOP1, JMS SAVCF
3175 6001 1076 TAD NGTTY /GET THE TELETYPE FLAG
3176 6002 7710 SPA CLA /IS THERE CN ON THE SYSTEM
3177 6003 5223 JMP LOOP1A-1 /NO ABORT MESSAGE AND GALT
3178 6004 4776 JMS WES
3179 6005 4542 TEXT *%LOOP ON ADDRESS SET IN SR*
6006 1417
6007 1720
6010 4017
6011 1640
6012 6164
6013 0422
6014 0523
6015 2740
6016 0005
6017 1440
6020 1116
6021 4023
6022 3200
3180 6023 4775 LOOP1A, JMS KLSDF
3181 6024 4504 GETSR
3182 6025 3235 DCA SR
3183 6026 1635 TAD I SR
3184 6027 7040 CMA
3185 6030 3635 DCA I SR
3186 6031 1035 TAD I SR
3187 6032 7040 CMA
3188 6033 3635 DCA I SR
3189 6034 5224 JMP LOOP1A
3190 6035 6000 SR, 0
3191 /
3192 /C6/ ROUTINE TO SAVE PAGE 37 OF FIELD 1
3193
3194 6036 0000 COSM, 0
3195 6037 7200 CLA
3196 6040 6224 RIF /READ THE INSTRUCTION FIELD
3197 6041 1374 TAD (6201 /ADD CDF 0 TO IT
3198 6042 3251 DCA COSM0 /MODIFY THE CDF INSTR AT LOC COSM0
3199 6043 1373 TAD (7577 /SET UP PAGE 37 POINTER -1
3200 6044 3010 DCA 10 /SAVE IN AUTO INDEX 10
3201 6045 1372 TAD (COSM-1 /GET ADDRESS -1 OF STORAGE AREA
```

```
3202 6046 3011 DCA 11 /SAVE IN AUTO INDEX 11
3203 6047 6211 COSM1, CDF 10 /CHANGE DATA FIELD TO 1
3204 6050 1410 TAD I 10 /GET THE WORD
3205 6051 6201 COSM0, CDF /CHANGE DATA FIELD TO PRG FIELD
3206 6052 3411 DCA I 11 /SAVE IN STORE AREA
3207 6053 1010 TAD 10 /CHECK TO SEE IF PAGE DONE
3208 6054 7040 CMA
3209 6055 7 0 SZA CLA /DONE SAVING PAGE
3210 6056 1447 JMP COSM1 /NO-DO NEXT WORD
3211 6057 5636 JMP I COSM /YES-RETURN TO CALL+1
3212
3213
3214 /C6/ ROUTINE TO RESTORE PAGES 37 OF FIELD 0 AND 1
3215
3216 6060 7200 COSM, CLA
3217 6061 6224 RIF /GET THE PRESENT DATA FIELD
3218 6062 1374 TAD (6201 /GET THE CDF INSTRUCTION
3219 6063 1367 DCA COSM0 /SAVE THE NEW CDF INSTRUCTION
3220 6064 1367 TAD COSM0
3221 6065 3276 DCA COSM01
3222 6066 1373 TAD (7577 /SET UP AUTO INDEX FOR RESTORE OF 0
3223 6067 3010 DCA 10 /SAVE IN AUTO INDEX 10
3224 6070 1372 TAD (COSM-1 /SETUP STORAGE POINTER
3225 6071 3011 DCA 11 /SAVE IN AUTO INDEX 11
3226 6072 1373 TAD (7577 /SETUP AUTO INDEX OF RESTORE OF FIELD 1
3227 6073 3012 DCA 12 /SAVE IN AUTO INDEX 12
3228 6074 1373 TAD (7577 /SETUP NEXT POINTER
3229 6075 3013 DCA 13 /SAVE IN AUTO INDEX 13
3230 6076 6201 COSM01, CDF
3231 6077 1013 TAD 13
3232 6100 7040 CMA
3233 6101 7652 SNA CLA /ALL DONE
3234 6102 5307 JMP COSM0
3235 6103 3411 TAD I 11 /GET DATA TO RESTORE
3236 6104 6211 CDF 10 /CHANGE DATA FIELD TO 1
3237 6105 3413 DCA I 13 /PUT IT IN FIELD 1
3238 6106 5175 JMS COSM01 /GO DO NEXT WORD
3239 6107 6201 COSM0, CDF /MODIFIED CDF INSTRUCTION TO PRG FIELD
3240 6110 1010 TAD 10 /RESTORATION DONE
3241 6111 7040 CMA
3242 6112 7650 SNA CLA /SKIP IF NO
3243 6113 5307 JMP COSM1 /DONE-GO TO MONITOR AT 7600
3244 6114 1410 TAD I 10 /GET DATA FROM PROGRAM FIELD
3245 6115 6201 CDF 00
3246 6116 3412 DCA I 12 /RESTORE 0
3247 6117 5307 JMP COSM0
3248 6120 6223 COSM1, CDF /CHANGE DATA AND INSTR FIELD TO 0
3249 6121 5722 JMP I 1
3250 6122 7650
3251
3252 6172 6177
3253 6173 7577
3254 6174 6201
3255 6175 5670
```

```
3257 6176 2240
3258 6177 6664
3259 6200 *C100 /C8/
3253 6200 4777 LCOP2, JMS SAYDF
3254 6201 1C76 TAD NCTTY /GET TELETYPE STATUS
3255 6202 7710 SPA CLA /IS THERE ONE ON THE SYSTEM
3256 6203 5234 JMP LCOP2A-2 /NO-ABORT MESSAGE AND HALT FOR INFO
3257 6204 4776 JMS MES
3258 6205 4543 TEXT *%LCOP ONLY THE 2 ADDRESSES INPUT FROM THE SR*
3259 6206 1417
3260 6207 1720
3261 6210 4017
3262 6211 1614
3263 6212 3140
3264 6213 2410
3265 6214 0540
3266 6215 6240
3267 6216 01C4
3268 6217 0422
3269 6220 0523
3270 6221 2305
3271 6222 2340
3272 6223 1116
3273 6224 0025
3274 6225 4440
3275 6226 0622
3276 6227 1715
3277 6230 4024
3278 6231 1035
3279 6232 4023
3280 6233 22C0
3281 6234 4245 JMS IN12
3282 6235 4775 JMS RESDF
3283 6236 1731 LCOP2A, TAD I FIRST
3284 6237 7040 CMA
3285 6240 3731 DCA I FIRST
3286 6241 1732 TAD I SECOND
3287 6242 7040 CMA
3288 6243 3732 DCA I SECOND
3289 6244 5236 JMP LCOP2A
3290 6245 0C00 IN12, 0
3291 6246 1076 TAD NCTTY /GET TELETYPE FLAG
3292 6247 7710 SPA CLA /IS THERE ONE ON THE SYSTEM
3293 6248 8274 JMP IN12A /NO-ABORT MESSAGE AND HALT FOR INFO
3294 6251 4776 JMS MES
3295 6252 4543 TEXT *%SET SR TO FIRST ADDRESS & CONT*
3296 6253 2175
3297 6254 1440
3298 6255 1322
3299 6256 4024
3300 6257 1740
3301 6260 0611
3302 6261 2223
3303 6262 2440
```

```
6263 0104
6264 0422
6265 0523
6266 2340
6267 4640
6270 0317
6271 1824
6272 0000
3281 6273 4505 IN12A, C8CAL
3282 6274 74C2 HLT
3283 6275 4504 GETSR
3284 6276 3331 DCA FIRST
3285 6277 0276 TAD NCTTY /GET FLAG STATUS AGAIN
3286 6278 7710 SPA CLA /TELETYPE AVAILABLE?
3287 6279 9325 JMP FIRST-4 /NO-ABORT MESSAGE AND HALT FOR INFO
3288 6282 4776 JMS MES
3289 6283 4543 TEXT *%SET SR TO SECOND ADDRESS & CONT*
3290 6284 2329
3291 6285 2440
3292 6286 2322
3293 6287 4024
3294 6290 1740
3295 6291 2005
3296 6292 0317
3297 6293 16C4
3298 6294 4001
3299 6295 0174
3300 6296 14C5
3301 6297 1323
3302 6298 4046
3303 6299 4023
3304 6300 1716
3305 6303 24C0
3306 6304 4105 C8CAL
3307 6305 74C2 HLT
3308 6306 4504 GETSR
3309 6307 3732 DCA SECOND
3310 6308 3145 JMP I IN12
3311 6309 0000 FIRST, 0
3312 6310 0000 SECOND, 0
3313 6311 0676
3314 6312 2240
3315 6316 6664
3316 6317 6400 *6400 /C8/
3317 6400 4777 LCOP3, JMS SAYDF
3318 6401 1C76 TAD NCTTY /GET THE TELETYPE STATUS
3319 6402 7710 SPA CLA /IS THERE A TELETYPE AVAILABLE?
3320 6403 5234 JMP LCOP3A-6 /NO-ABORT MESSAGE AND HALT FOR INFO
3321 6404 4776 JMS MES
3322 6405 4543 TEXT *%LOOP FROM FIRST ADDRESS "HRL" SECOND ADDRESS*
3323 6406 1417
```

```
6407 1720
6410 4008
6411 2217
6412 1540
6413 6611
6414 2223
6415 2440
6416 0 14
6417 6422
6420 0523
6421 2340
6422 2410
6423 2225
6424 4023
6425 0503
6426 1716
6427 6440
6430 0104
6431 0122
6432 0523
6433 2300
3310 6434 4775' JMS IN12
3311 6435 1774' TAD FIRST
3312 6436 3263 DCA SRL1
3313 6437 1773' TAD SECOND
3314 6440 3264 DCA SRL2
3315 6441 4772' JMS RESDF
3316 6442 1263 LOOP3A, TAD SRL1
3317 6443 3262 LOOP3B, DCA SRL
3318 6444 1662 TAD I
3319 6445 7040 CMA
3320 6446 3662 DCA I SRL
3321 6447 1662 TAD I SRL
3322 6450 7040 CMA
3323 6451 3662 DCA I SRL
3324 6452 1262 TAD SRL
3325 6453 7041 CIA
3326 6454 1264 TAD SRL2
3327 6455 7650 SNA CLA
3328 6456 5242 JMP LOOP3A
3329 6457 2262 ISZ SRL
3330 6460 5244 JMP LOOP3B
3331
3332
3333 6461 5200 JMP LOOP3
3334 6462 0000 SRL, 0
3335 6463 0000 SRL1, 0
3336 6464 0000 SRL2, 0
3337 6500 +6500 /CB/
3338
3339 8500 4777' LOOPS, JMS SAVDF
3340 8501 1076 TAD NOTTY
3341 8502 7710 SPA CLA
3342 8503 5336 JMP LOOP5A-6
3343 8504 4776' JMS MES
```

```
/GET TTY FLAG
/IS THERE A TELETYPE AVAILABLE
/NO-ABORT MESSAGE AND HALT FOR INFO
```

```
3344 6505 4543 TEXT *%LOOP DATA IN THE SR THRU THE ADDRESS SELECTION*
6506 1417
6507 1720
6510 4004
6511 0124
6512 0140
6513 1116
6514 4024
6515 1005
6516 4023
6517 2240
6520 2410
6521 2225
6522 4024
6523 1005
6524 4001
6525 0404
6526 2205
6527 2323
6530 4023
6531 0514
6532 0503
6533 2411
6534 1716
6535 0000
3345 6536 4775' JMS IN12
3346 6537 1774' TAD FIRST
3347 6540 3364 DCA SR5A
3348 6541 1773' TAD SECOND
3349 6542 3365 DCA SR5B
3350 6543 4772' JMS RESDF
3351 6544 1264 LOOP5A, TAD SR5A
3352 6545 3365 LOOP5B, DCA SR5C
3353 6546 4504 GETSR
3354 6547 3766 DCA I SR5C
3355 6550 1766 TAD I SR5C
3356 6551 3766 DCA I SR5C
3357 6552 1366 TAD SR5C
3358 6553 7041 CIA
3359 6554 1365 TAD SR5B
3360 6555 7650 SNA CLA
3361 6556 9344 JMP LOOP5A
3362 6557 2366 ISZ SR5C
3363 6560 9346 JMP LOOP5B
3364
3365 6561 4505 CBCL
3366 6562 7402 HLT
3367 6563 5700 JMP LOOP5
3368 6564 0 SR5A, 0
3369 6565 6000 SR5B, 0
3370 6566 0000 SR5C, 0
3371
3372 6572 6676
3373 6573 6332
3374 6574 6331
```

/START AGAIN WITH FIRST ADDRESS

/DO NEXT ADDRESS

/HALT RESULTED FROM ILLEGAL LIMITS

/FIRST ADDRESS OF GROUP

/LAST ADDRESS OF GROUP

/ADDRESS COUNTER

```
3375 6575 6245
3376 6576 2240
3377 6577 6664
3378 6600
3379 3800 4264 LQDP4, JMS SAVDF
3380 6601 1076 TAD NOTIFY /GET TTY STATUS
3381 6602 7710 SPA CLA /IS THERE CIE ON THE SYSTEM
3382 6603 5253 JMP LQDP4A-4 /NO-ABORT MESSAGE AND HALT FOR INFO
3383 6604 4777 JMS MES
3384 6605 4543 TEXT "X#LOOP DATA IN THE SR ON THE INPUT ADDRESS"
6606 1417
6607 1720
6608 4004
6609 0124
6610 0140
6611 1118
6612 4024
6613 1005
6614 4023
6615 2240
6616 1718
6617 4024
6618 1005
6619 4011
6620 1620
6621 2524
6622 4771
6623 034
6624 2205
6625 2223
6626 0000
3385 6627 4777 JMS MES
3386 6628 4543 TEXT "X#SET SR TO ADDRESS & CONT"
6629 2105
6630 2440
6631 2322
6632 4024
6633 1740
6634 0.04
6635 0422
6636 0523
6637 2340
6638 4640
6639 0317
6640 1624
6641 0000
3387 6652 4505 CBCAL
3388 6653 7402 HLT
3389 6654 4504 GETSR
3390 6655 3263 DCA SR4
3391 6656 4276 JMS RESDF /RESTORE DATA FIELD TO NEW
3392 6657 4504 LQDP4A, GETSR
3393 6660 3663 DCA I SR4
```

```
3395 6661 1663 TAD I SR4
3396 6662 5257 JMP LQDP4A
3397 6663 0000 SR4, 0
3398 6664 0000 SAVDF, 0
3399 6665 7200 CLA
3400 6666 6214 RDF
3401 6667 3275 DCA SAVE
3402 6670 6774 RIF
3403 6671 76 TAD [6201
3404 6672 3273 DCA .+1
3405 6673 6201 CDF 00 /PROGRAM DF
3406 6674 5664 JMP I SAVDF
3407 6675 0000 SAVE, 0
3408
3409 6676 0000 RESDF, 0
3410 6677 1275 TAD SAVE
3411 6700 76 TAD [6201
3412 6701 3302 DCA .+1
3413 6702 6701 CDF 00 /LOOP DF
3414 6703 5676 JMP I RESDF
3415
3416 6777 2240 /
3417 PAGE 7000
3418 COSA=.
3419
3420 /
3421 /
3422 /
3423 /IF ENTERED WITH AC=0000 THE SWITCH REGISTER
3424 /MODIFICATION ROUTINE IS ENTERED AUTOMATICALLY.
3425 /IF ENTERED WITH AC NOT EQUAL TO 0000, THE
3426 /KEYBOARD INPUT DECODER IS ENTERED AND IT IS ASSUMED
3427 /THAT THE AC CONTAINS THE ASCII CODE TO BE
3428 /CHECKED FOR A VALID CONTROL CHARACTER.
3429 /
3430 /
3431 /
3432 0205 RSTART-PATA
3433 0000 OFFSET=0
3434 /
3435 /
3436 7200 *7200
3437 /
3438 7200 0000 CBTEMP, 0 /TEMPORARY WORK AREA
3439 7201 6203 CBCDI, CIF CDF /USED TO CREATE CDI TO PROGRAM FIELD
3440 7202 6201 CBCDF, CDF /USED TO CREATE CDF TO CONSOLE FIELD
3441 7203 0000 CBSWR, 0 /SWITCH REGISTER SAVE AREA
3442 7204 0000 CBWDE, 0 /PRINT MODE SWITCH
3443 7205 0000 CBCNT, 0 /USED AS COUNTER
```

```
3444 7206 7775 CBW3. -3 /CONSTANT
3445 7207 7774 CBW4. -4 /CONSTANT
3446 7210 7773 CBW5. -5 /CONSTANT
3447 7211 7770 CS+10. -10 /CONSTANT
3448 7212 7520 CBW250. -250 /CONSTANT
3449 7213 0007 CBW7. 0007 /CONSTANT
3450 7214 0240 CBW240. 0240 /CONSTANT
3451 7215 0260 CBW260. 0260 /CONSTANT
3452 7216 0275 CBW275. 0275 /CONSTANT
3453 7217 0277 CBW277. 0277 /CONSTANT
3454 7220 0322 CBW322. 0322 /CONSTANT
3455 7221 0323 CBW323. 0323 /CONSTANT
3456 /
3457 /
3458 7222 0000 CBENR. 0
3459 7223 3200 DCA CBTEMP /SAVE AC
3460 7224 6214 RDF /READ PROGRAM FIELD
3461 7225 1201 TAD CBW3 /ADD CBI INSTRUCTION
3462 7226 3205 DCA CBENR /SAVE CBI TO PROGRAM FIELD TEMPORARILY
3463 7227 6224 RIF /READ CONSOLE FIELD
3464 7230 1202 TAD CBW3 /ADD CBI INSTRUCTION
```

```
3465 7231 3241 DCA CBFLD /SAVE CDF TO CONSOLE FIELD
3466 7232 1777 TAD 1 121 /GET MCM FROM PROGRAM FIELD
3467 7233 7710 SPA CLA /SKIP IF USING PSEUDO SWR
3468 7234 7614 LAS SWR /GET HARDWARE SWR AND SKIP
3469 7235 1776 TAD 1 120 /GET PSEUDO SWR
3470 7236 3203 DCA CBW3R /SAVE SWITCH REGISTER
3471 7237 1775 TAD 1 (INCODE) /GET MESSAGE ACTIVE FLAG
3472 7240 3204 DCA CBW3DE /SAVE MESSAGE ACTIVE FLAG
3473 7241 7602 CBFLD, MLT /MODIFIED CDF TO CONSOLE DATA FIELD
3474 7242 1222 TAD CBENR /GET RETURN ADDRESS
3475 7243 3774 DCA CBRTN /SAVE FOR EXIT
3476 7244 1205 TAD CBENR /GET CBI TO PROGRAM FIELD
3477 7245 3773 DCA CBPFLD /SAVE CBI TO PROGRAM FIELD FOR EXIT
3478 7246 1200 TAD CBTEMP /GET AC UPON ENTRY
3479 7247 7240 SZA /SKIP IF IT WAS ZERO
3480 7250 3772 JMP CBENR /AC NOT ZERO, GO CHECK CTRL CHAR
3481 /
3482 /PRINT OUT SR*XXXX WHERE XXXX IS THE CURRENT CONTENTS
3483 /OF THE SWITCH REGISTER BEING USED (EITHER PSEUDO OR HARDWARE)
3484 /
3485 7251 4771 CBPSW, JMS CBWRLF /DD A <CR> AND <LF>
3486 7252 1221 TAD CBW323 /GET ASCII CODE FOR "S"
3487 7253 4770 JMS CBWYP /PRINT "S"
3488 7254 1220 TAD CBW322 /GET ASCII CODE FOR "R"
3489 7255 4770 JMS CBWYP /PRINT "R"
3490 7256 1216 TAD CBW325 /GET ASCII CODE FOR "A"
3491 7257 4770 JMS CBWYP /PRINT "A"
3492 7258 1207 TAD CBW3 /AC--4
3493 7259 1206 DCA CBWYR /SET UP OCTAL DIGIT COUNTER
3494 7260 1203 TAD CBW3R /GET SWITCH REGISTER
3495 7263 7204 RAL /EXTRA ROTATE FOR LINK
3496 7264 7204 CBLOPA, RAL
3497 7265 7206 RAL
3498 7266 1203 DCA CBW3R /ROTATE OCTAL DIGITS FOR PRINTING
/SAVE ROTATED SWR
```

```
3499 7267 1203 TAD C85AR /GET ROTATED SWR
3500 7270 0213 AND C8K7 /MASK OFF DIGIT TO PRINT
3501 7271 1215 TAD C8A200 /ADD ASCII BASE CODE
3502 7272 4770 JMS C8TYP /PRINT AN OCTAL DIGIT
3503 7273 1203 TAD C85AR /GET SWR
3504 7274 2205 ISZ C8CNTR /INCREMENT LOOP COUNTER
3505 7275 5264 JMP C8LOPA /GO PRINT NEXT DIGIT
3506
3507 /ACCEPT KEYBOARD INPUT OF OCTAL DIGITS, <CR>, <LF>
3508 /CTRL/C OR CTRL/G. ALL OTHER CHARACTERS ARE INVALID
3509 /AND WILL BE ECHOED, FOLLOWED BY A "?".
3510 /A CARRIAGE RETURN, LINE FEED, AND A RESTART OF
3511 /THE SRXXXX ROUTINE
3512 /
3513
3514 7276 7300 CLA CLL
3515 7277 1210 TAD C875 /AC=5
3516 7300 3205 DCA C8CNTR /SET UP TO ACCEPT 5 CHARACTERS
3517 7301 3787 DCA C8BLD /CLEAR SWITCH REG. BUILD AREA
3518 7302 3786 DCA C8FLG /CLEAR SWR CHANGE SWITCH
3519 7303 1214 TAD C8K240 /GET ASCII CODE FOR SPACE
3520 7304 4770 JMS C8TYP /SPACE OVER ONE POSITION
3521 7305 4765 JMS C8TYP /GO WAIT FOR KEYBOARD INPUT
3522 7306 3200 DCA C8TEMP /SAVE INPUT CHARACTER
3523 7307 1200 TAD C8TEMP /GET CHARACTER
3524 7310 1564 TAD (-203
3525 7311 7490 SNA /SKIP IF NOT CTRL/C
3526 7312 5783 JMP C8CTLG /GO TO CTRL/C ROUTINE
3527 7313 1207 TAD C8M4 /AC=4
3528 7314 7450 SNA /SKIP IF NOT CTRL/G
3529 7315 5762 JMP C8CTLG /GO TO CTRL/G ROUTINE
3530 7316 1206 TAD C8M3 /SUBTRACT 3
3531 7317 7450 SNA /SKIP IF NOT LINE FEED
3532 7320 5761 JMP C8EXT1 /GO TO LINE FEED EXIT
3533 7321 1206 TAD C8M3 /SUBTRACT 3
3534 7322 7650 SNA CLA /SKIP IF NOT CARRIAGE RETURN
3535 7323 5760 JMP C8EXT2 /GO TO CARRIAGE RETURN EXIT
3536 7324 1200 TAD C8TEMP /GET CHARACTER
3537 7325 4770 JMS C8TYP /ECHO IT
3538 7326 1200 TAD C8TEMP /GET CHARACTER
3539 7327 1212 TAD C8M260
3540 7330 7510 SPA /SKIP IF >= TO ASCII CODE FOR ZERO
3541 7331 5351 JMP C8ERR /INVALID CHARACTER NOT OCTAL DIGIT
3542 7332 1211 TAD C8M10
3543 7333 7700 SNA CLA /SKIP IF <= ASCII CODE FOR SEVEN
3544 7334 5351 JMP C8ERR /INVALID CHARACTER NOT OCTAL DIGIT
3545 7335 7240 STA /AC=7777
```

```
3546 7336 3766 DCA C8FLG /SET SWR CHANGE FLAG
3547 7337 1200 TAD C8TEMP /GET CHARACTER
3548 7340 0213 AND C8K7 /MASK TO 3 BITS
3549 7341 3200 DCA C8TEMP /SAVE OCTAL DIGIT
3550 7342 1787 TAD C8BLD /GET SWR BUILD AREA CONTENTS
3551 7343 7108 CLL RTL
3552 7344 7004 RAL /ROTATE TO BUILD SWR
3553 7345 1200 TAD C8TEMP /ADD NEXT OCTAL DIGIT
3554 7346 3787 DCA C8BLD /SAVE NEW SWR
3555 7347 2205 ISZ C8CNTR /INCREMENT OCTAL DIGIT COUNTER
3556 7350 5305 JMP C8SRLP /CONTINUE ACCEPTING OCTAL DIGITS
3557
3558 7351 7300 C8ERR, CLA CLL
3559 7352 1217 TAD C8K277 /GET ASCII CODE FOR "?"
3560 7353 4770 JMS C8TYP /PRINT "?"
3561 7354 4771 JMS C8CRLF /DO A <CR> AND <LF>
3562 7355 5261 JMP C8PSW /GO START OVER
3563 /
3564 /
3565 7360 7536
3566 7361 7525
3567 7362 7457
3568 7363 7485
3569 7364 7575
3570 7365 7510
3571 7366 7703
3572 7367 7400
3573 7370 7476
3574 7371 7517
3575 7372 7420
3576 7373 7537
3577 7374 7402
3578 7375 7703
3579 7376 7703
3580 7377 7400
3581 /
3582 /
3583 /
3584 /
3585 /
3586 /
3587 /
3588 /
3589 /
3590 /
3591 /
3592 /
3593 /
3594 /
3595 /
3596 /
3597 /
3598 /
3599 /
3600 /
3601 /
3602 /
3603 /
3604 /
3605 /
3606 /
3607 /
3608 /
3609 /
3610 /
3611 /
3612 /
3613 /
3614 /
3615 /
3616 /
3617 /
3618 /
3619 /
3620 /
3621 /
3622 /
3623 /
3624 /
3625 /
3626 /
3627 /
3628 /
3629 /
3630 /
3631 /
3632 /
3633 /
3634 /
3635 /
3636 /
3637 /
3638 /
3639 /
3640 /
3641 /
3642 /
3643 /
3644 /
3645 /
3646 /
3647 /
3648 /
3649 /
3650 /
3651 /
3652 /
3653 /
3654 /
3655 /
3656 /
3657 /
3658 /
3659 /
3660 /
3661 /
3662 /
3663 /
3664 /
3665 /
3666 /
3667 /
3668 /
3669 /
3670 /
3671 /
3672 /
3673 /
3674 /
3675 /
3676 /
3677 /
3678 /
3679 /
3680 /
3681 /
3682 /
3683 /
3684 /
3685 /
3686 /
3687 /
3688 /
3689 /
3690 /
3691 /
3692 /
3693 /
3694 /
3695 /
3696 /
3697 /
3698 /
3699 /
3700 /
3701 /
3702 /
3703 /
3704 /
3705 /
3706 /
3707 /
3708 /
3709 /
3710 /
3711 /
3712 /
3713 /
3714 /
3715 /
3716 /
3717 /
3718 /
3719 /
3720 /
3721 /
3722 /
3723 /
3724 /
3725 /
3726 /
3727 /
3728 /
3729 /
3730 /
3731 /
3732 /
3733 /
3734 /
3735 /
3736 /
3737 /
3738 /
3739 /
3740 /
3741 /
3742 /
3743 /
3744 /
3745 /
3746 /
3747 /
3748 /
3749 /
3750 /
3751 /
3752 /
3753 /
3754 /
3755 /
3756 /
3757 /
3758 /
3759 /
3760 /
3761 /
3762 /
3763 /
3764 /
3765 /
3766 /
3767 /
3768 /
3769 /
3770 /
3771 /
3772 /
3773 /
3774 /
3775 /
3776 /
3777 /
3778 /
3779 /
3780 /
3781 /
3782 /
3783 /
3784 /
3785 /
3786 /
3787 /
3788 /
3789 /
3790 /
3791 /
3792 /
3793 /
3794 /
3795 /
3796 /
3797 /
3798 /
3799 /
3800 /
3801 /
3802 /
3803 /
3804 /
3805 /
3806 /
3807 /
3808 /
3809 /
3810 /
3811 /
3812 /
3813 /
3814 /
3815 /
3816 /
3817 /
3818 /
3819 /
3820 /
3821 /
3822 /
3823 /
3824 /
3825 /
3826 /
3827 /
3828 /
3829 /
3830 /
3831 /
3832 /
3833 /
3834 /
3835 /
3836 /
3837 /
3838 /
3839 /
3840 /
3841 /
3842 /
3843 /
3844 /
3845 /
3846 /
3847 /
3848 /
3849 /
3850 /
3851 /
3852 /
3853 /
3854 /
3855 /
3856 /
3857 /
3858 /
3859 /
3860 /
3861 /
3862 /
3863 /
3864 /
3865 /
3866 /
3867 /
3868 /
3869 /
3870 /
3871 /
3872 /
3873 /
3874 /
3875 /
3876 /
3877 /
3878 /
3879 /
3880 /
3881 /
3882 /
3883 /
3884 /
3885 /
3886 /
3887 /
3888 /
3889 /
3890 /
3891 /
3892 /
3893 /
3894 /
3895 /
3896 /
3897 /
3898 /
3899 /
3900 /
3901 /
3902 /
3903 /
3904 /
3905 /
3906 /
3907 /
3908 /
3909 /
3910 /
3911 /
3912 /
3913 /
3914 /
3915 /
3916 /
3917 /
3918 /
3919 /
3920 /
3921 /
3922 /
3923 /
3924 /
3925 /
3926 /
3927 /
3928 /
3929 /
3930 /
3931 /
3932 /
3933 /
3934 /
3935 /
3936 /
3937 /
3938 /
3939 /
3940 /
3941 /
3942 /
3943 /
3944 /
3945 /
3946 /
3947 /
3948 /
3949 /
3950 /
3951 /
3952 /
3953 /
3954 /
3955 /
3956 /
3957 /
3958 /
3959 /
3960 /
3961 /
3962 /
3963 /
3964 /
3965 /
3966 /
3967 /
3968 /
3969 /
3970 /
3971 /
3972 /
3973 /
3974 /
3975 /
3976 /
3977 /
3978 /
3979 /
3980 /
3981 /
3982 /
3983 /
3984 /
3985 /
3986 /
3987 /
3988 /
3989 /
3990 /
3991 /
3992 /
3993 /
3994 /
3995 /
3996 /
3997 /
3998 /
3999 /
4000 /
4001 /
4002 /
4003 /
4004 /
4005 /
4006 /
4007 /
4008 /
4009 /
4010 /
4011 /
4012 /
4013 /
4014 /
4015 /
4016 /
4017 /
4018 /
4019 /
4020 /
4021 /
4022 /
4023 /
4024 /
4025 /
4026 /
4027 /
4028 /
4029 /
4030 /
4031 /
4032 /
4033 /
4034 /
4035 /
4036 /
4037 /
4038 /
4039 /
4040 /
4041 /
4042 /
4043 /
4044 /
4045 /
4046 /
4047 /
4048 /
4049 /
4050 /
4051 /
4052 /
4053 /
4054 /
4055 /
4056 /
4057 /
4058 /
4059 /
4060 /
4061 /
4062 /
4063 /
4064 /
4065 /
4066 /
4067 /
4068 /
4069 /
4070 /
4071 /
4072 /
4073 /
4074 /
4075 /
4076 /
4077 /
4078 /
4079 /
4080 /
4081 /
4082 /
4083 /
4084 /
4085 /
4086 /
4087 /
4088 /
4089 /
4090 /
4091 /
4092 /
4093 /
4094 /
4095 /
4096 /
4097 /
4098 /
4099 /
4100 /
4101 /
4102 /
4103 /
4104 /
4105 /
4106 /
4107 /
4108 /
4109 /
4110 /
4111 /
4112 /
4113 /
4114 /
4115 /
4116 /
4117 /
4118 /
4119 /
4120 /
4121 /
4122 /
4123 /
4124 /
4125 /
4126 /
4127 /
4128 /
4129 /
4130 /
4131 /
4132 /
4133 /
4134 /
4135 /
4136 /
4137 /
4138 /
4139 /
4140 /
4141 /
4142 /
4143 /
4144 /
4145 /
4146 /
4147 /
4148 /
4149 /
4150 /
4151 /
4152 /
4153 /
4154 /
4155 /
4156 /
4157 /
4158 /
4159 /
4160 /
4161 /
4162 /
4163 /
4164 /
4165 /
4166 /
4167 /
4168 /
4169 /
4170 /
4171 /
4172 /
4173 /
4174 /
4175 /
4176 /
4177 /
4178 /
4179 /
4180 /
4181 /
4182 /
4183 /
4184 /
4185 /
4186 /
4187 /
4188 /
4189 /
4190 /
4191 /
4192 /
4193 /
4194 /
4195 /
4196 /
4197 /
4198 /
4199 /
4200 /
4201 /
4202 /
4203 /
4204 /
4205 /
4206 /
4207 /
4208 /
4209 /
4210 /
4211 /
4212 /
4213 /
4214 /
4215 /
4216 /
4217 /
4218 /
4219 /
4220 /
4221 /
4222 /
4223 /
4224 /
4225 /
4226 /
4227 /
4228 /
4229 /
4230 /
4231 /
4232 /
4233 /
4234 /
4235 /
4236 /
4237 /
4238 /
4239 /
4240 /
4241 /
4242 /
4243 /
4244 /
4245 /
4246 /
4247 /
4248 /
4249 /
4250 /
4251 /
4252 /
4253 /
4254 /
4255 /
4256 /
4257 /
4258 /
4259 /
4260 /
4261 /
4262 /
4263 /
4264 /
4265 /
4266 /
4267 /
4268 /
4269 /
4270 /
4271 /
4272 /
4273 /
4274 /
4275 /
4276 /
4277 /
4278 /
4279 /
4280 /
4281 /
4282 /
4283 /
4284 /
4285 /
4286 /
4287 /
4288 /
4289 /
4290 /
4291 /
4292 /
4293 /
4294 /
4295 /
4296 /
4297 /
4298 /
4299 /
4300 /
4301 /
4302 /
4303 /
4304 /
4305 /
4306 /
4307 /
4308 /
4309 /
4310 /
4311 /
4312 /
4313 /
4314 /
4315 /
4316 /
4317 /
4318 /
4319 /
4320 /
4321 /
4322 /
4323 /
4324 /
4325 /
4326 /
4327 /
4328 /
4329 /
4330 /
4331 /
4332 /
4333 /
4334 /
4335 /
4336 /
4337 /
4338 /
4339 /
4340 /
4341 /
4342 /
4343 /
4344 /
4345 /
4346 /
4347 /
4348 /
4349 /
4350 /
4351 /
4352 /
4353 /
4354 /
4355 /
4356 /
4357 /
4358 /
4359 /
4360 /
4361 /
4362 /
4363 /
4364 /
4365 /
4366 /
4367 /
4368 /
4369 /
4370 /
4371 /
4372 /
4373 /
4374 /
4375 /
4376 /
4377 /
4378 /
4379 /
4380 /
4381 /
4382 /
4383 /
4384 /
4385 /
4386 /
4387 /
4388 /
4389 /
4390 /
4391 /
4392 /
4393 /
4394 /
4395 /
4396 /
4397 /
4398 /
4399 /
4400 /
4401 /
4402 /
4403 /
4404 /
4405 /
4406 /
4407 /
4408 /
4409 /
4410 /
4411 /
4412 /
4413 /
4414 /
4415 /
4416 /
4417 /
4418 /
4419 /
4420 /
4421 /
4422 /
4423 /
4424 /
4425 /
4426 /
4427 /
4428 /
4429 /
4430 /
4431 /
4432 /
4433 /
4434 /
4435 /
4436 /
4437 /
4438 /
4439 /
4440 /
4441 /
4442 /
4443 /
4444 /
4445 /
4446 /
4447 /
4448 /
4449 /
4450 /
4451 /
4452 /
4453 /
4454 /
4455 /
4456 /
4457 /
4458 /
4459 /
4460 /
4461 /
4462 /
4463 /
4464 /
4465 /
4466 /
4467 /
4468 /
4469 /
4470 /
4471 /
4472 /
4473 /
4474 /
4475 /
4476 /
4477 /
4478 /
4479 /
4480 /
4481 /
4482 /
4483 /
4484 /
4485 /
4486 /
4487 /
4488 /
4489 /
4490 /
4491 /
4492 /
4493 /
4494 /
4495 /
4496 /
4497 /
4498 /
4499 /
4500 /
4501 /
4502 /
4503 /
4504 /
4505 /
4506 /
4507 /
4508 /
4509 /
4510 /
4511 /
4512 /
4513 /
4514 /
4515 /
4516 /
4517 /
4518 /
4519 /
4520 /
4521 /
4522 /
4523 /
4524 /
4525 /
4526 /
4527 /
4528 /
4529 /
4530 /
4531 /
4532 /
4533 /
4534 /
4535 /
4536 /
4537 /
4538 /
4539 /
4540 /
4541 /
4542 /
4543 /
4544 /
4545 /
4546 /
4547 /
4548 /
4549 /
4550 /
4551 /
4552 /
4553 /
4554 /
4555 /
4556 /
4557 /
4558 /
4559 /
4560 /
4561 /
4562 /
4563 /
4564 /
4565 /
4566 /
4567 /
4568 /
4569 /
4570 /
4571 /
4572 /
4573 /
4574 /
4575 /
4576 /
4577 /
4578 /
4579 /
4580 /
4581 /
4582 /
4583 /
4584 /
4585 /
4586 /
4587 /
4588 /
4589 /
4590 /
4591 /
4592 /
4593 /
4594 /
4595 /
4596 /
4597 /
4598 /
4599 /
4600 /
4601 /
4602 /
4603 /
4604 /
4605 /
4606 /
4607 /
4608 /
4609 /
4610 /
4611 /
4612 /
4613 /
4614 /
4615 /
4616 /
4617 /
4618 /
4619 /
4620 /
4621 /
4622 /
4623 /
4624 /
4625 /
4626 /
4627 /
4628 /
4629 /
4630 /
4631 /
4632 /
4633 /
4634 /
4635 /
4636 /
4637 /
4638 /
4639 /
4640 /
4641 /
4642 /
4643 /
4644 /
4645 /
4646 /
4647 /
4648 /
4649 /
4650 /
4651 /
4652 /
4653 /
4654 /
4655 /
4656 /
4657 /
4658 /
4659 /
4660 /
4661 /
4662 /
4663 /
4664 /
4665 /
4666 /
4667 /
4668 /
4669 /
4670 /
4671 /
4672 /
4673 /
4674 /
4675 /
4676 /
4677 /
4678 /
4679 /
4680 /
4681 /
4682 /
4683 /
4684 /
4685 /
4686 /
4687 /
4688 /
4689 /
4690 /
4691 /
4692 /
4693 /
4694 /
4695 /
4696 /
4697 /
4698 /
4699 /
4700 /
4701 /
4702 /
4703 /
4704 /
4705 /
4706 /
4707 /
4708 /
4709 /
4710 /
4711 /
4712 /
4713 /
4714 /
4715 /
4716 /
4717 /
4718 /
4719 /
4720 /
4721 /
4722 /
4723 /
4724 /
4725 /
4726 /
4727 /
4728 /
4729 /
4730 /
4731 /
4732 /
4733 /
4734 /
4735 /
4736 /
4737 /
4738 /
4739 /
4740 /
4741 /
4742 /
4743 /
4744 /
4745 /
4746 /
4747 /
4748 /
4749 /
4750 /
4751 /
4752 /
4753 /
4754 /
4755 /
4756 /
4757 /
4758 /
4759 /
4760 /
4761 /
4762 /
4763 /
4764 /
4765 /
4766 /
4767 /
4768 /
4769 /
4770 /
4771 /
4772 /
4773 /
4774 /
4775 /
4776 /
4777 /
4778 /
4779 /
4780 /
4781 /
4782 /
4783 /
4784 /
4785 /
4786 /
4787 /
4788 /
4789 /
4790 /
4791 /
4792 /
4793 /
4794 /
4795 /
4796 /
4797 /
4798 /
4799 /
4800 /
4801 /
4802 /
4803 /
4804 /
4805 /
4806 /
4807 /
4808 /
4809 /
4810 /
4811 /
4812 /
4813 /
4814 /
4815 /
4816 /
4817 /
4818 /
4819 /
4820 /
4821 /
4822 /
4823 /
4824 /
4825 /
4826 /
4827 /
4828 /
4829 /
4830 /
4831 /
4832 /
4833 /
4834 /
4835 /
4836 /
4837 /
4838 /
4839 /
4840 /
4841 /
4842 /
4843 /
4844 /
4845 /
4846 /
4847 /
4848 /
4849 /
4850 /
4851 /
4852 /
4853 /
4854 /
4855 /
4856 /
4857 /
4858 /
4859 /
4860 /
4861 /
4862 /
4863 /
4864 /
4865 /
4866 /
4867 /
4868 /
4869 /
4870 /
4871 /
4872 /
4873 /
4874 /
4875 /
4876 /
4877 /
4878 /
4879 /
4880 /
4881 /
4882 /
4883 /
4884 /
4885 /
4886 /
4887 /
4888 /
4889 /
4890 /
4891 /
4892 /
4893 /
4894 /
4895 /
4896 /
4897 /
4898 /
4899 /
4900 /
4901 /
4902 /
4903 /
4904 /
4905 /
4906 /
4907 /
4908 /
4909 /
4910 /
4911 /
4912 /
4913 /
4914 /
4915 /
4916 /
4917 /
4918 /
4919 /
4920 /
4921 /
4922 /
4923 /
4924 /
4925 /
4926 /
4927 /
4928 /
4929 /
4930 /
4931 /
4932 /
4933 /
4934 /
4935 /
4936 /
4937 /
4938 /
4939 /
4940 /
4941 /
4942 /
4943 /
4944 /
4945 /
4946 /
4947 /
4948 /
4949 /
4950 /
4951 /
4952 /
4953 /
4954 /
4955 /
4956 /
4957 /
4958 /
4959 /
4960 /
4961 /
4962 /
4963 /
4964 /
4965 /
4966 /
4967 /
4968 /
4969 /
4970 /
4971 /
4972 /
4973 /
4974 /
4975 /
4976 /
4977 /
4978 /
4979 /
4980 /
4981 /
4982 /
4983 /
4984 /
4985 /
4986 /
4987 /
4988 /
4989 /
4990 /
4991 /
4992 /
4993 /
4994 /
4995 /
4996 /
4997 /
4998 /
4999 /
5000 /
5001 /
5002 /
5003 /
5004 /
5005 /
5006 /
5007 /
5008 /
5009 /
5010 /
5011 /
5012 /
5013 /
5014 /
5015 /
5016 /
5017 /
5018 /
5019 /
5020 /
5021 /
5022 /
5023 /
5024 /
5025 /
5026 /
5027 /
5028 /
5029 /
5030 /
5031 /
5032 /
5033 /
5034 /
5035 /
5036 /
5037 /
5038 /
5039 /
5040 /
5041 /
5042 /
5043 /
5044 /
5045 /
5046 /
5047 /
5048 /
5049 /
5050 /
5051 /
5052 /
5053 /
5054 /
5055 /
5056 /
5057 /
5058 /
5059 /
5060 /
5061 /
5062 /
5063 /
5064 /
5065 /
5066 /
5067 /
5068 /
5069 /
5070 /
5071 /
5072 /
5073 /
5074 /
5075 /
5076 /
5077 /
5078 /
5079 /
5080 /
5081 /
5082 /
5083 /
5084 /
5085 /
5086 /
5087 /
5088 /
5089 /
5090 /
5091 /
5092 /
5093 /
5094 /
5095 /
5096 /
5097 /
5098 /
5099 /
5100 /
5101 /
5102 /
5103 /
5104 /
5105 /
5106 /
5107 /
5108 /
5109 /
5110 /
5111 /
5112 /
5113 /
5114 /
5115 /
5116 /
5117 /
5118 /
5119 /
5120 /
5121 /
5122 /
5123 /
5124 /
5125 /
5126 /
5127 /
5128 /
5129 /
5130 /
5131 /
5132 /
5133 /
5134 /
5135 /
5136 /
5137 /
5138 /
5139 /
5140 /
5141 /
5142 /
5143 /
5144 /
5145 /
5146 /
5147 /
5148 /
5149 /
5150 /
5151 /
5152 /
5153 /
5154 /
5155 /
5156 /
5157 /
5158 /
5159 /
5160 /
5161 /
5162 /
5163 /
5164 /
5165 /
5166 /
5167 /
5168 /
5169 /
5170 /
5171 /
5172 /
5173 /
5174 /
5175 /
5176 /
5177 /
5178 /
5179 /
5180 /
5181 /
5182 /
5183 /
5184 /
5185 /
5186 /
5187 /
5188 /
5189 /
5190 /
5191 /
5192 /
5193 /
5194 /
5195 /
5196 /
5197 /
5198 /
5199 /
5200 /
5201 /
5202 /
5203 /
5204 /
5205 /
5206 /
5207 /
5208 /
5209 /
5210 /
5211 /
5212 /
5213 /
5214 /
5215 /
5216 /
5217 /
5218 /
5219 /
5220 /
5221 /
5222 /
5223 /
5224 /
5225 /
5226 /
5227 /
5228 /
5229 /
5230 /
5231 /
5232 /
5233 /
5234 /
5235 /
5236 /
5237 /
5238 /
5239 /
5240 /
5241 /
5242 /
5243 /
5244 /
5245 /
5246 /
5247 /
5248 /
5249 /
5250 /
5251 /
5252 /
5253 /
5254 /
5255 /
5256 /
5257 /
5258 /
5259 /
5260 /
5261 /
5262 /
5263 /
5264 /
5265 /
5266 /
5267 /
5268 /
5269 /
5270 /
5271
```

```
3600 /
3601 /
3602 /
3603 7420 1377 CBCTL, TAD (-203
3604 7421 7450 SNA /SKIP IF NOT CTRL/C
3605 7422 5265 JMP CBCTLC /CTRL/C TYPED EXIT TO MONITOR
3606 7423 1376 TAD (-4
3607 7424 7450 SNA /SKIP IF NOT CTRL/G
3608 7425 5257 JMP CBCTLG /CTRL/G TYPED GO PRINT "G"
3609 7426 1375 TAD (-12
3610 7427 7450 SNA /SKIP IF NOT CTRL/O
3611 7430 5255 JMP CBCTLO /CTRL/O TYPED
3612 7431 1374 TAD (-2
3613 7432 7450 SNA /SKIP IF NOT CTRL/S
3614 7433 5237 JMP CBCTLS /CTRL/S TYPED
3615 7434 3773 DCA /SET MESSAGE ACTIVE FLAG
3616 7435 2204 ISZ /TEST CTRL/S ACTIVE FLAG
3617 7436 5273 JMP CBECNO /GO ICHO CHARACTER AND RETURN TO PROGRAM
3618 /
3619 /CTRL/S HANDLER
3620 /
3621 7437 7240 CBCTLS, STA /AC=7777
3622 7440 3204 DCA /SET CTRL/S ACTIVE FLAG
3623 7441 1773 TAD /GET MESSAGE ACTIVE FLAG
3624 7442 7650 SNA CLA /SKIP IF CTRL/S TYPED WHILE MESSAGE ACTIVE
3625 7443 5337 JMP CBPFLD /RETURN TO PROGRAM
3626 /
3627 7444 7240 CBWAIT, STA /SET CONTROL S ACTIVE INDICATOR
3628 7445 74 J4 DCA /WAIT FOR KEYBOARD INPUT
3629 7446 3310 JMS CBTTY
3630 7447 1377 TAD (-203
3631 7450 7450 SNA /SKIP IF NOT CTRL/C
3632 7451 5265 JMP CBCTLC /CTRL/C TYPED EXIT TO MONITOR
3633 7452 1372 TAD (-16
3634 7453 7640 SNA CLA /SKIP IF CTRL/O
3635 7454 5244 JMP CBWAIT /NOT CTRL/C OR CTRL/O CONTINUE WAITING
3636 7455 3204 CBCTLO, DCA /CLEAR CTRL/S ACTIVE FLAG
3637 7456 5337 JMP CBPFLD /RETURN TO MAIN PROGRAM
3638 /
3639 /CONTROL G HANDLER
3640 /
3641 7457 4317 CBCTLG, JMS CBCTLF /DO A <CR> AND <LF>
3642 7460 1216 TAD /GET ASCII CODE FOR UP ARROW
3643 7461 4276 JMS CBTYP /PRINT UP ARROW
3644 7462 1215 TAD /GET ASCII CODE FOR "G"
3645 7463 4276 JMS CBTYP /PRINT "G"
3646 7464 5771 JMP CBPSW /GO TO "SR=XXXX" ROUTINE
3647 /
3648 /CONTROL C HANDLER
3649 /
3650 7465 3204 CBCTLC, DCA /SET CTRL/S ACTIVE FLAG
3651 7466 1216 TAD /GET ASCII CODE FOR UP ARROW
3652 7467 4276 JMS CBTYP /PRINT UP ARROW
3653 7470 1214 TAD /GET ASCII CODE FOR "C"
3654 7471 4276 JMS CBTYP /PRINT "C"
```

```
3655 7472 5770 JMP CBPM /RESTORE MONITOR AND EXIT
3656 /
3657 7473 1767 CBECNO, TAD /GET CHARACTER
3658 7474 4276 JMS CBTYP /ECHO IT
3659 7475 5337 JMP CBPFLD /RETURN TO PROGRAM
3660 /
3661 /
3662 /
3663 /
3664 /PRINT ONE CHARACTER
3665 /
3666 7476 0000 CBTP, 0
3667 7477 2204 ISZ /TEST CTRL/S ACTIVE FLAG
3668 7500 7410 SKP /SKIP IF CTRL/S NOT ACTIVE
3669 7501 5244 JMP CBWAIT /GO WAIT FOR CTRL/O OR CTRL/C
3670 7502 6046 TIS /TRANSMIT CHARACTER
3671 7503 6041 TSF /TEST TTY FLAG
3672 7504 5303 JNP /WAIT FOR TTY FLAG
3673 7505 6042 TCF /CLEAR TTY FLAG
3674 7506 7200 CLA /CLEAR AC DO NOT CLEAR LINK
3675 /
3676 7507 5676 JMP I CBTYP /RETURN
3677 /
3678 /WAIT FOR KEYBOARD INPUT THEN EXIT WITH ASCII CODE IN AC
3679 /
3680 7510 0000 CBTTY, 0
3681 7511 6031 MSF /SKIP IF KEYBOARD FLAG SET
3682 7512 5311 JMP /WAIT FOR KEYBOARD INPUT
3683 7513 6036 KRB /READ KEYBOARD BUFFER CLEAR FLAG
3684 7514 0205 AND /MASK TO 7 BITS
3685 7515 1206 TAD /SET BIT 4
3686 7516 5710 JMP I CBTTY /RETURN
3687 /
3688 /EXECUTE A CARRIAGE RETURN AND LINE FEED
3689 /
3690 7517 0000 CBCTLF, 0
3691 7520 1212 TAD /GET ASCII CODE FOR CARRIAGE RETURN
3692 7521 4276 JMS CBTYP /GO EXECUTE THE CARRIAGE RETURN
3693 7522 1213 TAD /GET ASCII CODE FOR LINE FEED
3694 7523 4276 JMS CBTYP /GO EXECUTE THE LINE FEED
3695 7524 5717 JMP I CBCTLF /RETURN
3696 /
3697 /CONSOLE PACKAGE EXIT IF TERMINATED WITH LINE FEED
3698 /
3699 7525 4317 CBEXT1, JMS CBCTLF /DO A <CR> AND <LF>
3700 7526 1337 TAD /GET MODIFIED CDT TO PROGRAM FIELD
3701 7527 3330 DCA /SAVE FOR EXECUTION
3702 7530 7402 MLI /MODIFIED CDT TO PROGRAM FIELD
3703 7531 2203 ISZ /TEST SWR CHANGE FLAG
3704 7532 5601 JMP I CBSTR /RESTART PROGRAM WITHOUT CHANGE OF SWR
```

3705	7533	1200	TAD	CBELD	/GET NEW SWITCH REGISTER	
3706	7534	3768	CCA I	120	/SAVE IT IN PROGRAM FIELD	
3707	7535	5601	JMP I	CBSTRY	/RESTART PROGRAM WITH NEW PSEUDO SWR	
3708						
3709					/EXIT FROM CONSOLE PACKAGE IF TERMINATED WITH CARRIAGE RETURN	
3710					/	
3711	7536	4317	CBEXT2	JVS	C9CRLF	/ADD A KORN AND KLF
3712	7537	7402	CBPFLD	MLT		/MODIFIED CIL TO PROGRAM FIELD
3713	7540	7300	CLA	CLL		/CLEAR AC AND LINK FOR RETURN
3714	7541	2203	ISZ	CBPLG		/TEST SWR CHANGE FLAG
3715	7542	5602	JMP I	CBRTN		/RETURN TO PROGRAM WITHOUT CHANGE OF SWR
3716	7543	1200	TAD	CBELD		/GET NEW SWITCH REGISTER
3717	7544	3768	CCA I	120		/SAVE IT IN PROGRAM FIELD
3718	7545	5602	JMP I	CBRTN		/RETURN TO PROGRAM
3719						
3720						
3721						
3722	7566	0020				
3723	7567	7200				
3724	7570	6060				
3725	7571	7251				
3726	7572	7762				
3727	7573	7204				
3728	7574	7776				
3729	7575	7768				
3730	7576	7774				
3731	7577	7575				
3732		7600				
3733						
3734	0123	6203				
3735	0124	6000				
3736	0125	7770				
3737	0126	7720				
3738	0127	0100				
3739	0130	7650				
3740	0131	6203				
3741	0132	7560				
3742	0133	0400				
3743	0134	7360				
3744	0135	4000				
3745	0136	6007				
3746	0137	0323				
3747	0140	2235				
3748	0141	4513				
3749	0142	6240				
3750	0143	6245				
3751	0144	6115				
3752	0145	76				
3753	0146	6212				
3754	0147	7775				
3755	0150	0540				
3756	0151	6207				
3757	0152	7744				
3758	0153	6060				

PAGE
/
\$\$\$

3759	0154	0707
3760	0155	0077
3761	0156	0161
3762	0157	0262
3763	0160	0263
3764	0161	0164
3765	0162	0265
3766	0163	0266
3767	0164	0267
3768	0165	7777
3769	0166	7700
3770	0167	0260
3771	0170	0020
3772	0171	0040
3773	0172	7774
3774	0173	7740
3775	0174	5252
3776	0175	2325
3777	0176	6201
3778	0177	4246

A	0066	C8000	4431	C85A	7800	FCNT	0060
A1	4335	C8100	7417	C85FL3	7434	FIRST	6331
A10	4348	C89LD	7400	C85A	8034	FIVE	9100
A11	4347	C8CAL	4835	C85M0	8051	FLOCNT	2348
A12	4350	C8C3F	7202	C85M1	8047	FLODAT	8067
A13	4351	C8C21	7201	C85RLP	7301	FLOINC	5361
A14	4351	C8C4TL	7420	C85RTT	7401	FLOSEL	2102
A15	4351	C8C4T2	7425	C85WR	7200	FS	0040
A16	4357	C8C4LF	7417	C85TNP	7200	FS1	0041
A17	4350	C8C4LC	7465	C85TY	7510	FS2	0042
A18	4351	C8C4L3	7457	C85TP	7476	FS3	0043
A19	4352	C8C4LO	7455	C84AIT	7444	FSEND	1707
A2	4336	C8C4LS	7437	CAF	6007	FSSET	1615
A20	4323	C8ECM0	7473	CD:	6207	GOATA	0072
A21	4324	C8EXT1	7423	CFP	2020	GERRC	1454
A22	4325	C8EXT2	7351	CFP0	2012	GETSR	4504
A23	4326	C8EXT1	7525	CFP1	204J	GTF	6004
A24	4327	C8EXT2	7536	CFP2	2040	HCW1	0021
A3	4337	C8FLD	7241	CFP3	2057	HCW2	0022
A4	4340	C8FLG	7403	CFP4	2057	HEAD1	0055
A5	4341	C8K100	7411	CFPTNP	210	IAPTR	0005
A6	4342	C8K177	7405	CHECK	2077	IAPTRM	0006
A7	4343	C84200	7406	CHECK0	2100	LEGAL1	1514
A8	4344	C84212	7413	CMRTAP	4740	IN12	8245
A9	4345	C84215	7412	CMP	6104	IN12A	8274
ACL	7701	C84240	7214	CMV	2222	INMODE	0023
ADDCNT	5363	C84250	7215	COERR	2436	INNAME	0084
ADDER	2716	C84275	7216	COUNT	0053	INTR	4256
ADDINC	1160	C84277	7217	CRELQ	0030	INTROU	4246
APCTCX	1671	C84303	7414	CS	0036	K104	5165
APCTCY	5672	C84307	7415	CSANE	0462	K400	4745
APTE08	0817	C84322	7220	CSRO3	1607	KBINT	1346
APTR	5600	C84323	7221	CUF	6254	KBINTC	1384
APTR1	5621	C84356	7416	DATTNP	5116	KMBREL	0404
APTRX	5651	CMK7	7213	DFELF	0057	KTB	0001
APTRFL	5704	CMK7T	7207	ENWFLG	0020	KTBREL	0334
APTIZ	5622	C8LCC	4744	ENDF	0063	KTEST	0552
APTLUP	5712	C8LOPA	7264	ENDHLT	4502	LEGAL	1470
APTRVQ	5737	C8M10	7211	ENDNES	5457	LEGAL0	0085
APTRK	5652	C8M250	7212	ENDPAS	5420	LEGALA	1540
APTRK0	5674	C8M3	7208	ERRA	1400	LGLFLO	1551
APTRK1	5673	C8M4	7207	ERRA1	1417	LIMIT	2476
B	0067	C8M40	7410	ERRS	1420	LOOP1	6000
BADINT	3200	C8M5	7210	ERRB1	1437	LOOP1A	6024
BANK	0024	C8M5DE	7204	ERRC	2400	LOOP2	6200
BANK0	1674	C8FFLC	7537	ERRCC	2707	LOOP2A	6238
BANK0A	1702	C8PSW	7291	ERRPD	4017	LOOP3	6400
BANKR	5162	CFM	6060	ERRM	2503	LOOP3A	6442
BDATA	0073	C8RVO	6107	ERRM7	2645	LOOP3B	6444
BINTC	3227	C8RMO1	6076	ERRMO	2460	LOOP4	6600
B5W	7002	C8RM1	6120	ERRM1	2461	LOOP4A	6657
C80000	4400	C8RTN	7402	ERRTA	4843	LOOP5	6500

LOOP5A	6544	PNTOPT	1728	SETPAR	5000	ST55	3262
LOOP5B	6546	PREL	4194	SETREL	0400	SUF	8274
LRR	6240	PRINT	4503	SETAS	4537	SWP	7521
LUSR	6260	PROFLD	0351	SETSW	4077	TO	3000
LXW	8200	PSR	0020	SFSC	3277	T07	3020
MO	2313	QO	5114	SFS1	3317	TOUPD	0681
MOUPD	5232	RACA	4510	SFS2	3340	T1	3010
MIUPD	5710	RACE	4511	SFS3	3412	T1UPD	0700
MEMLOD	5124	RBELL	2413	SFS4	3432	T25	3050
MES	2240	RD42	1210	SFS5	3452	T52	3064
MINS	0101	RD4C	1215	SFS6	3472	T70	3034
MOSERR	5415	RD82	1283	SFS7	3512	TCS	0503
MOSFLD	9227	RD8C	1270	SFSTAB	3352	TEMP	0056
MOSLGD	5214	RDFLA	1200	SIATY	2230	TES9NK	2314
MOSRED	5245	RDFLCA	1213	SKCN	6000	TEST	0600
MOSTST	5200	RDFLCB	1258	SMP	6107	TEST0	0653
MOV	0054	RE4D	1327	SMQ	6076	TEST1	0670
NOVVAL	5740	REDFLD	5264	SPFLD	1714	TEST8	1000
NOL	7721	REOLUP	5257	SPO	6107	TFS	0737
NTP	2311	RELCNT	0061	SR	6035	TFS0	3600
NCEUB	1523	RELJ	4230	SRC0	0020	TFS1	3607
NCEM4	0732	RELQ2	4225	SRC1	0027	TFS2	3617
NDFLC	4600	RELQ3	4227	SRC2	0030	TFS3	3627
NOTAPT	5634	RELQ4	4232	SRC3	0037	TFS4	3640
NOTTY	0376	RELQ5	4244	SRC4	0030	TFS5	3651
MUFLD	0707	REM	6239	SRC5	0030	TFS6	3662
MUFLD	0077	RESDF	6376	SRC6	6663	TFS7	3672
OFFSET	0000	RESINT	4222	SRC8	6564	TFSTAB	0740
OPT	1741	RETURN	2403	SRC9	6565	TITLE	4043
P2	0070	RFR	6250	SRC	6566	TWAR	2347
PAR	4267	RS	0044	SRC1	0034	TN	2735
PARERR	3154	RS1	0045	SRC11	0035	TCSEL	1106
PARINT	3100	RS2	0046	SRL	6462	TOSEL1	1136
PARORC	2687	RS3	0047	SRL1	6463	TR	0472
PASSES	9455	RSTANT	6120	SRL2	6464	TR0	3703
PAT1	5365	RTEVP	5163	SRS	4953	TR1	3712
PAT2	5366	RTEVP1	5161	SRS0	3077	TR2	3722
PAT3	0025	RFF	2225	SRS1	3227	TR3	3732
PATCNT	5364	SC	2225	SRS2	3400	TR4	3743
PATERR	2731	S1	2225	SRS3	3422	TR5	3754
PATM	0081	S2	2237	SRS4	3442	TR6	3765
PATVO	0264	SAC	0074	SRS5	3462	TR7	4000
PATN	0270	SAVE	1803	SRS6	3500	TRSTAB	0473
PATNG	0073	SAVEF	6654	SRS7	3522	TS	0037
PATJ	0301	SAVE	6075	START	0324	TSNMJ	3155
PATCO	0314	SAVINT	4230	STARTF	0080	TSTAD	0057
PERIC	2625	SCS	3233	STCP	2487	TSTCNT	5362
PERCO	2677	SCS2	3272	STSC	3233	TSTFLD	0052
PERR	2616	SECCNT	6332	ST51	3237	T5	3532
PINF	8044	SETEPR	4210	ST52	3243	T50	3544
PNOREL	4115	SETFLD	0725	ST53	3250	TYCHK	3558
PNTFLD	4654	SETFS	4506	ST54	3256	TYPCN	2256

TYPE 5025
 TYP0FF 5041
 TYPSP 2400
 W4 0071
 WRA 1041
 WRA1 1050
 WRB 1063
 WRB1 1072
 WRFLD 1605
 XCDCAL 4723
 XENDML 0341
 XGTSR 4747
 XPRINT 5400
 XRACA 5117
 XRACB 5142
 XSETFS 0522
 XSETRS 0532
 YY 5115
 Z1 2644
 Z10 2538
 Z11 2537
 Z2 2645
 Z20 3131
 Z21 3145
 Z3 2651
 Z4 2654
 ZB 4150

ERRORS DETECTED: 0

LINKS GENERATED: 349

RUN-TIME: 8 SECONDS

3K CORE USED

A 132# 477 482 489 493 499 506 688 761 771 781 885 887 889 SEQ 0102
 A1 894 898 901
 A10 2389 2397# 2469
 A11 2387 2406# 2487
 A12 2389 2407# 2489
 A13 2391 2408# 2491
 A14 2393 2409# 2493
 A15 2436 2495 2519#
 A16 2438 2497 2520#
 A17 2440 2499 2521#
 A18 2442 2501 2522#
 A19 2444 2503 2527#
 A20 2446 2505 2524#
 A21 2371 2398# 2471
 A22 2448 2507 2525#
 A23 2450 2509 2526#
 A24 2452 2511 2527#
 A25 2454 2513 2528#
 A26 2456 2515 2529#
 A3 2373 2399# 2473
 A4 2375 2400# 2475
 A5 2377 2402# 2477
 A6 2379 2403# 2479
 A7 2381 2404# 2481
 A8 2383 2405# 2483
 A9 2385 2406# 2485
 ACL 47# 50
 ADDCNT 2962#
 ADDER 1471 1480# 1508 1568 2437 2498 3045
 ADDINC 2847 2902 2925 2937 2928 2959#
 APTCTX 3106#
 APTCTY 3101#
 APTCGB 434#
 APTER 63 3032# 3037
 APTER1 3040 3041 3050#
 APTX 3063 3077#
 APTFL 197 3119# 3122 3145 3150
 APTIZ 289 3034 3043 3054# 3077
 APTLUP 3125# 3137
 APTMOV 3124 3126 3128 3129 3132 3136 3152#
 APTOK 64 3085# 3099 3108 3113
 APTOKQ 3089 3106#
 APTCK1 3093 3094 3102#
 B 133# 478 484 488 494 501 508 684 808 816 828 907 909 911
 916 920 923
 BADINT 1793# 1793 2341
 BANK 78# 523 539 701 702 707 715 724 726 2845 2879
 BANKQ 1085 1100#
 BANKQA 1106#
 BANKR 2790 2801#
 BDATA 137# 886 897 908 919 1592 1853 2092 2098
 BINTC 1799 1802#
 BSW 48# 1069 1299 1333 1835 1835 2098 2108 2118 2182 2192 2204 2768

C80000	2395	2432#							
C80001	2459	24	2462#						
C87600	3537#								
C89LD	3517	3550	3554	3582#	3705	3716			
C8CAL	354#	311	1063	1073	2380	3110	3282	3292	3365 3388
C8CDF	3440#	3464							
C8CD1	3439#	3451							
C8CHTL	3400	3603#							
C8CHTR	3443#	3462	3476	3493	3504	3516	3555		
C8CRLF	3405	3561	3641	3670#	3695	3699	3711		
C8CTLG	3526	3509	3632	3650#					
C8CTLG	3529	3608	3641#						
C8CTLG	3611	3656#							
C8CTL5	3614	3621#							
C8ECMO	3617	3657#							
C8ENFR	3663	3458#	3474						
C8ERR	3541	3544	3558#						
C8EXT1	3532	3699#							
C8EXT2	3535	3711#							
C8FLD	3465	3473#							
C8FLG	3518	3546	3585#	3703	3714				
C8K100	3591#								
C8K177	3587#	3684							
C8K200	3560#	3685							
C8K212	3593#	3693							
C8K215	3592#	3691							
C8K240	3450#	3519							
C8K260	3451#	3501							
C8K275	3452#	3490							
C8K277	3453#	3559							
C8K303	3594#	3653							
C8K307	3595#	3644							
C8K322	3454#	3488							
C8K323	3455#	3466							
C8K336	3596#	3642	3651						
C8K7	3459#	3500	3548						
C8K77	3589#								
C8LCC	2659	2663#							
C8LOPA	3406#	3505							
C8M10	3447#	3542							
C8M260	3448#	3539							
C8M3	3444#	3530	3533						
C8M4	3445#	3492	3527						
C8M40	3590#								
C8MS	3446#	3515							
C8MODE	3442#	3472	3615	3623					
C8PFLD	3477	3625	3637	3659	3700	3712#			
C8PSW	3485#	3562	3646						
C8RM	3217#	3655							
C8RM0	3220	3221	3235	3240#	3248				
C8RM01	3222	3231#	3239						
C8RM1	3244	3249#							
C8RTN	3475	3584#	3715	3718					

SEQ 0104

C8SA	3201	3225	3417#						
C8SFLG	3586#	3616	3622	3628	3636	3650	3667		
C8SM	3076	3194#	3211						
C8SW0	3198	3205#							
C8SW1	3203#	3210							
C8SRLP	3521#	3556							
C8STRT	3583#	3704	3707						
C8SWR	3441#	3470	3494	3498	3499	3523	3538	3547	3549 3553 3657
C8TEMP	3438#	3459	3478	3522	3523	3536	3538	3547	3549 3553 3657
C8TTY	3521	3629	3680#	3686					
C8TYP	3467	3469	3431	3502	3520	3537	3560	3643	3645 3652 3654 3658 3666# 3676
C8WAIT	3692	3694							
C8WAIT	3627#	3635	3665						
CAF	52#	1802	2359						
CD1	41#	2329							
CFP	1092	1166#	1177	1201	1375	1378	1381	1384	1387 1390 1393 1396
CFP0	1170	1176#	1203	1219	1228				
CFP1	1201#	1210	1212	1217	1220	1225			
CFP2	1196	1204#							
CFP3	1213#	1227							
CFP4	1205	1221#							
CFPTMP	1180	1184	1186	1188	1191	1197	1206	1213	1221 1231#
CHECK	1172	1173	1229#						
CHECK0	1229	1230#							
CHRTMP	2646	2651	2658	2665#					
CHP	44#	1761	1779						
CHV	1300	1304	1306#	1316	2370	2472			
CODERR	1432#	1509	1531						
COUNT	1214	543	1501	1552	2795	2328	2990	2998	
CRELO	118#	190	205	958					
CS	88#	185	424	758	805	1841	1846	2046	2948 2993
CSAME	369	397	404#						
CSRO3	298	254	279	1036#	1042	1043			
CUF	33#								
DATTMP	2733	2750	2756#						
DEIF	171	216#	223						
ENXFLG	79#	182	335	572	949	1082	1139	1181	1447 2735
ENDF	129#	1661	1067	1192	1215				
ENDHLT	148#	235	251	276					
ENDMES	3013	3017#							
ENDPAS	2302	3005#	3009	3020					
ERRA	764	71	883#	891					
ERRA1	774	852#	904						
ERRB	811	831	845#	913					
ERRB1	821	914#	926						
ERRC	933	1560#	1586						
ERRCC	1586	1639#							
ERRHD	1580	2215#	2218	2221					
ERRM	1499#	1505	2223						
ERRM1	1517	1533#							
ERRORO	1460	1462	1474#	2390	2392	2394	2496		
ERROR1	1468	1475#	2392	2435	2494				
ERRTAB	2587	2604#							

SEQ 0105

FCNT	125	199	203	329	548	1051	1178	2193	2594	2595	2620	2626	2669	2910	SEQ 0106
FIRST	2933	3270	3235	3293	3297	3311	3346								
FIVE	142	193	646	652											
FLODNT	350	354	356	357	365	381	383	185	386	394	442	453	522	527	
	532	533	536	551	554	575	583	106	952	955	956	959	973	976	
	977	1004	1006	1067	1094	1095	1109	1121	1399	1537	1643	2585	2844	2867	
FLODNT	7872	2278	2912	2916	2917	2934									
FLODNT	1510	1593	2731	2732	2734	2751									
FLODNT	2849	2537	2915	2922	2924	2980									
FLODNT	72	1226	1271												
FS	121	187	254		457	709	1078	3143	3148	3149					
FS1	102	256	1070	1101											
FS2	103	258	1080	1103											
FS3	104	270	1081	1105											
FSND	1099	1112													
FSSET	106	1049	1114	1116											
GDATA	136	928	1559	1652	2593	2898	2994								
GERRC	860	500	310	522	927	9	2995								
GERRC	152	307	313	619	1039	1065	1038	1433	1443	1481	1489	1570	1574	3181	
GERRC	3284	3294	3353	3390	3393										
GTF	45	177	1772	2347											
HCW1	71	3267													
HCW2	72	294	296	3055	3087	3120									
HEAD1	123	195	872	1526	1544	1578	1763	1804	2264	2277					
IAPTR	63	1452	1794												
IAPTR	64	745	2877	2941											
LEGAL	963	985													
LEGAL	3266	3275	3296	3310	3345										
LEGAL	3278	3283													
LEGAL	74	1225	1343	3471											
LEGAL	130	945	965	998											
LEGAL	1732	1605	2343												
LEGAL	60	2335													
LEGAL	2765	2504													
LEGAL	2648	2504													
LEGAL	862	873	2342												
LEGAL	867	870													
LEGAL	346	354	371												
LEGAL	35														
LEGAL	338	376	393	398											
LEGAL	520	623													
LEGAL	201	943	969	994											
LEGAL	131	947	963	992											
LEGAL	954	975	991	999											
LEGAL	953	974	1002	1011	1012										
LEGAL	1484	1489													
LEGAL	3174														
LEGAL	3177	3181	3189												
LEGAL	3260														
LEGAL	3263	3268	3274												
LEGAL	3304	3333													
LEGAL	3307	3316	3328												

LOOP38	3318	3330														
LOOP38	3379															
LOOP38	3382	3393	3396													
LOOP38	3399	3367														
LOOP38	3442	3351	3361													
LOOP38	3353	3363														
LOOP38	39	1107														
LOOP38	36															
LOOP38	36	177														
LOOP38	133	1332	1335	1359	2382	2484										
LOOP38	2851	2856														
LOOP38	2881	2907														
LOOP38	2858	2863														
LOOP38	654	968	142	1323	1327	1337	1404	1472	1518	1520	1597	1668	1699	1704		
LOOP38	1709	1713	1718	1723	1743	1745	1757	1800	2219	2220	2241	2254	2261	2274		
LOOP38	2378	2480	2573	2538	2617	2630	2632	2695	2724	3014	3016	3178	3284	3279		
LOOP38	3299	3328	3343	3383	3385											
LOOP38	123	192	651													
LOOP38	2900	2839	2927													
LOOP38	2554	2851														
LOOP38	2250	2873														
LOOP38	2890	2878	2947													
LOOP38	514	2636	2958	2957												
LOOP38	122	1513	1541	2290	2315	2317	2318	2321	2324							
LOOP38	3135	3154	1158													
LOOP38	49	2023	2146													
LOOP38	1342	1354	1359	1368												
LOOP38	251	973	984													
LOOP38	574	552														
LOOP38	562	2573														
LOOP38	3258	3264														
LOOP38	140	227	259	643	363	1053	1112	1136	1437	1469	1515	1594	1740	1795		
LOOP38	2016	2210	2227	2228	2251	2271	2573	2692	2721	3007	3060	3064	3175	3281		
LOOP38	3278	3236	3221	3240	3250											
LOOP38	524	540	503	571	580	581	285	2680								
LOOP38	141	222	1052	1062	2299											
LOOP38	2654	3453														
LOOP38	1140	1146														
LOOP38	104	51	634	627	640	755	789	1102	836							
LOOP38	44	2827	2361	2365												
LOOP38	1742	1729														
LOOP38	1751	2339														
LOOP38	161	1754	1750													
LOOP38	3010	3012	3012													
LOOP38	2838	2842	2835	2837	2849	2851	2864									
LOOP38	2853	2858	2843	2852	2854	2865										
LOOP38	175	236	212	277	291	293	621	1492	2575	2578	2723	2726	3432			
LOOP38	2840	2855	2853													
LOOP38	1637	2139														
LOOP38	227	229														
LOOP38	233	239														
LOOP38	210	245	26													
LOOP38	249	256														

SEQ 0107

SEQ 0108

SEO 0109

[illegible]

TR54	413	2165#	2172	2173															
TR55	414	2176#	2185	2186															
TR56	415	2188#	2194	2195															
TR57	416	2200#	2207	2208															
TRSTAB	358	388	409#																
TS	92#	186	512	1811	1815	1820	1827	1832	1836	2015	2992								
TSNUM	1657	2014	2019	2026	2033#														
TSAD	125#	191	642	667	668	685	686	767	777	785	795	814	824	832					
	843	844	845	846	847	848	849	850	851	852	853	855	890	903					
	912	925	1586	1647	1739	1776	2860	2662	2891	2894	2901	2903	2904	2932					
TSTCNT	2842	2942	2961#																
TSTFLO	120#	400	577	662	680	748	934	948	958	981	982	1031	2307	2738					
	2742	2855	2887																
TTS	1611	1656	2012#	2020	2021	2027	2028	2039	2455	2516									
TT50	2022#	2030																	
TTVCHK	2018	2025	2035#																
TYPCM	1334	1336	1339#	1367	2380	2482													
TYPE	718	720	723	1242	1246	1250	1254	1258	1262	1266	1270	1366	1422	1424					
	1641	1631	1633	1756	2364	2486	2625	2702#	2706	2713	2716								
TYPOFF	2769	2714#																	
TYPSP	1421#	1425	2386	2488	2629														
W4	135#	661	670	679	688	757	787	804	834										
WRA	632	639	659#	676															
WRA1	666#	671																	
WRB	633	638	677#	694															
WRB1	684#	689																	
WRFLD	526	629#	644	647	650	650													
XC8CAL	155	2645#	2652	2660	2661														
XENOML	149	306#	316	317															
XGETSR	153	2671#	2677																
XPRINT	151	2971#	2976	2983															
XRACA	161	2762#	278#	2791	2796														
XRACB	163	278#	2797																
XSETFS	187	441#	448																
XSETRS	159	452#	459																
YY	2749	2755#																	

SEQ 0112

SEQ 0113

.L1777	1060	1066	1070	1096	1160#						
.L2167	1267	1274#									
.L2170	1263	1275#									
.L2171	1259	1276#									
.L2172	1255	1277#									
.L2173	1251	1278#									
.L2174	1247	1279#									
.L2175	1243	1280#									
.L2176	1242	1286	1250	1254	1258	1262	1266	1270	1281#		
.L2177	1235	1282#									
.L2366	1397	1403#									
.L2367	1394	1409#									
.L2370	1391	1410#									
.L2371	1368	1411#									
.L2372	1385	1412#									
.L2373	1352	1413#									
.L2374	1379	1414#									
.L2375	1376	1415#									
.L2376	1375	1378	1381	1384	1387	1350	1393	1398	1416#		
.L2377	1366	1417#									
.L2570	1538	1547#									
.L2571	1537	1548#									
.L2572	1510	1549#									
.L2573	1507	1550#									
.L2574	1492	1551#									
.L2575	1472	1510	1520	1552#							
.L2576	1458	1466	1512	1553#							
.L2577	1422	1424	1441	1554#							
.L2751	1617	1623#									
.L2752	1644	1674#									
.L2753	1643	1675#									
.L2754	1631	1633	1676#								
.L2755	1627	1677#									
.L2756	1626	1678#									
.L2757	1624	1679#									
.L2760	1622	1680#									
.L2761	1620	1681#									
.L2762	1618	1682#									
.L2763	1616	1683#									
.L2764	1614	1684#									
.L2765	1611	1656	1685#								
.L2766	1597	1686#									
.L2767	1585	1588	1591	1687#							
.L2770	1583	1689#									
.L2771	1581	1690#									
.L2772	1580	1691#									
.L2773	1577	1613	1634	1660	1691#						
.L2774	1575	1692#									
.L2775	1569	1693#									
.L2776	1568	1694#									
.L2777	1567	1640	1695#								
.L3171	1773	1782#									
.L3172	1764	1780	1783#								

SEQ 0114

.L3173	1756	1784#									
.L3174	1734	1757	1785#								
.L3175	1733	1766#									
.L3176	1732	1767#									
.L3177	1699	1704	1709	1713	1718	1723	1743	1745	1757	1788#	
.L3375	1805	1903#									
.L3376	1803	1904#									
.L3377	1793	1915#									
.L3577	2033	2041#									
.L4177	2219	2230	2241	2254	2261	2274	2283#				
.L4354	2395	2411#									
.L4355	2392	2412#									
.L4356	2390	2413#									
.L4357	2388	2414#									
.L4360	2356	2415#									
.L4361	2384	2416#									
.L4362	2382	2417#									
.L4363	2360	2418#									
.L4364	2378	2419#									
.L4365	2376	2420#									
.L4366	2374	2421#									
.L4367	2372	2422#									
.L4370	2370	2423#									
.L4371	2368	2424#									
.L4372	2343	2425#									
.L4373	2342	2426#									
.L4374	2341	2427#									
.L4375	2339	2428#									
.L4376	2327	2429#									
.L4377	2302	2431#									
.L4532	2494	2530#									
.L4533	2493	2533#									
.L4534	2492	2534#									
.L4535	2491	2535#									
.L4536	2490	2536#									
.L4537	2489	2537#									
.L4540	2469	2539#									
.L4541	2467	2539#									
.L4542	2466	2540#									
.L4543	2465	2541#									
.L4544	2464	2542#									
.L4545	2463	2543#									
.L4546	2462	2544#									
.L4547	2461	2545#									
.L4550	2450	2546#									
.L4551	2479	2547#									
.L4552	2478	2548#									
.L4553	2477	2549#									
.L4554	2476	2550#									
.L4555	2475	2551#									
.L4556	2474	2552#									
.L4557	2473	2553#									
.L4558	2472	2554#									

SEQ 0115

.L4561	2471	2555#							
.L4562	2470	25							
.L4563	2469	2557#							
.L4564	2456	2558#							
.L4565	2455	2516	2559#						
.L4566	2453	2514	2530#						
.L4567	2451	2512	2561#						
.L4570	2449	2510	2562#						
.L4571	2447	2508	2563#						
.L4572	2445	2506	2564#						
.L4573	2443	2504	2565#						
.L4574	2441	2502	2566#						
.L4575	2439	2500	2567#						
.L4576	2437	2498	2568#						
.L4577	2435	2496	2569#						
.L4767	2655	2678#							
.L4770	2654	2679#							
.L4771	2634	2680#							
.L4772	2629	2631#							
.L4773	2625	2682#							
.L4774	2587	2663#							
.L4775	2585	2664#							
.L4776	2576	2598	2617	2630	2632	2685#			
.L4777	2575	2578	2686#						
.L5170	2793	2806#							
.L5171	2790	2807#							
.L5172	2789	2808#							
.L5173	2776	2809#							
.L5174	2773	2810#							
.L5175	2746	2811#							
.L5176	2723	2726	2812#						
.L5177	2695	2724	2813#						
.L5375	2900	2967#							
.L5376	2850	2880	2968#						
.L5377	2844	2867	2872	2878	2912	2916	2917	2934	2969#
.L5574	3014	3016	3025#						
.L5575	3011	3026#							
.L5576	2995	3027#							
.L5577	2991	3028#							
.L5771	3148	3166#							
.L5772	3147	3167#							
.L5773	3098	3168#							
.L5774	3076	3169#							
.L5775	3061	3073	3170#						
.L5776	3048	3159	3171#						
.L5777	3045	3172#							
.L6172	3201	3225	3253#						
.L6173	3199	3223	3227	3229	3254#				
.L6174	3197	3219	3255#						
.L6175	3180	3256#							
.L6176	3178	3257#							
.L6177	3174	3258#							
.L6375	3267	3299#							

[illegible]

[illegible]

.V6202	2655	2678#						
.V6203	3539	3592	3734#					
.V6245	3310	3345	3375#					
.V6331	3311	3346	3374#					
.V6332	3313	3348	3373#					
.V6500	3098	3168#						
.V6520	3048	3159	3171#					
.V6664	3174	3258#	3361#	3304	3339	3377#		
.V6676	3180	3256#	3287	3395#	3315	3350	3372#	
.V6777	3201	3225	3253#					
.V7200	176	331#	3657	3723#				
.V7204	3615	3623	372#					
.V7251	3646	3725#						
.V7360	1922	1930	3743#					
.V7377	295	319#						
.V7400	3517	3550	3554	3572#				
.V7402	3475	3577#						
.V7403	3518	3546	3571#					
.V7420	3480	3579#						
.V7457	3529	3567#						
.V7465	3526	3568#						
.V7476	3487	34#	3491	3502	3520	3537	3550	3573#
.V7510	3521	3570#						
.V7517	3485	3561	3574#					
.V7525	3532	3566#						
.V7536	3535	3565#						
.V7537	3477	3576#						
.V7560	1936	1949	3741#					
.V7575	3524	3569#	3603	3630	3731#			
.V7577	3199	3223	3227	3229	3254#			
.V7660	1957	1965	3739#					
.V7700	754	801	3765#					
.V7720	1973	1981	3737#					
.V7740	630	636	1939	1997	3147	3167#	3774#	
.V7744	1345	3757#						
.V7760	1100	1102	1104	1156#				
.V7762	3633	3726#						
.V7766	3609	3729#						
.V7770	2016	3736#						
.V7774	660	678	756	803	1350	3606	3730#	3773#
.V7775	1355	3754#						
.V7776	1380	3612	3728#	3752#				

EQF1DHHKHAADSEQ

00010000

783425

PDP10 472