# Quick reference card

Tap tab boxes directly. Arrows show navigation steps; they are not button-press cycles.

## PAD PARAMETERS

SELECT PAD > INFO TWICE; SAMPLE TABS SHOWN

| Main | Pos | Tone | LFO/Spd | Gen | Cnf |
|---|---|---|---|---|---|
| Pitch, Filter and Resonance | Sends / Dry; Clip / Slice tools | Fidelity / Drive; Filter 2 / Res 2 | LFO + Sample Speed 50-200% | Per-pad patterns + fills | Pad settings; Dub source / tap |

## MODULATION

SUPPORTED DIALS ONLY; ROUTES SAVE WITH THE PAD

| Select a dial | → | INFO | → | Source + Amount |
|---|---|---|---|---|
| Touch its square; do not drag | | Open the modulation source / amount page | | Native + KEY / ENV; CHAOS / RAND / NET |

## DELAY

FX1 IS SHARED BY ALL PADS AND LIVE INPUT

| FX1 | → | INFO | → | Main / More |
|---|---|---|---|---|
| Select the effect on the Pads view | | Open delay controls; Purge clears old echoes | | Digital / Tape / BBD / Codec; flutter, drive, tone, return |

## REVERB

FX2 AND FX3 HAVE SEPARATE SETTINGS AND TAILS

| FX2 / FX3 | → | INFO | → | Main / More |
|---|---|---|---|---|
| Tap selected FX2 again to switch to FX3 | | Open the selected reverb controls | | Plate / Room / Hall / Chamber; FX3 Out is on Main or More |

## TOOLS

OPEN TOOLS FROM HOME MENU; TAP ANY TAB

| Main | Rec | MIDI | Disp | Comp | Mstr |
|---|---|---|---|---|---|
| Int BPM / Clock; Tools / FX reset | FX Out routing; CV In utilities | MIDI settings; Monitor | Brightness / Flip; Saver / Sig wake | Compressor; parallel Mix | Section selects master / GEN |

## CLOCK & GEN

TOOLS CONTROLS; STOP HOLDS TIME, NOT ALL AUDIO

| Main: Int BPM | Main: Clock | Mstr: GEN Run |
|---|---|---|
| Int BPM: fast turn = coarse; hold 3 s = 120 BPM | Run / Stop / Reset; CV and MIDI transport | Mstr > Section > GEN Run; enable Run On for patterns |

## LIVE INPUT FX

NO SAMPLE OR RECORDING REQUIRED

| Empty pad + INFO | → | In 1/2 + RecMon On | → | Input FX pad |
|---|---|---|---|---|
| Open the pad's Recorder settings | | Set input and monitoring; adjust input Gain | | Off (default), Follow, or fixed Pad 1-16 |

### GESTURES & PERFORMANCE

**Pads:** turn lower-right encoder for clipboard. Select pad; tap Cut / Copy / Paste / Clear (CLR). Turn back to restore EXT meters.

**Drag a dial** or turn its encoder to edit.
**Double-tap:** default value; routes stay intact.

**Hold a Trigger pad / Play button 2 s:** Stop. The initial touch still plays or retriggers.

**Waveform pinch:** vertical amplitude; horizontal time. Two-finger tap restores the stock view.

**Speed + Slicer Smooth:** one shared stretch voice. Native Pitch remains unrestricted.

### INPUT FX & RECORDING

**Input FX pad:** Main Filter / Resonance, Tone, Pos sends / Dry. Follow switches pad settings.

**Mon Output:** direct input. **FX Out / FX3 Out:** shared wet returns; routes do not follow pads.

**Input Filter/Tone:** set values only. Send / Dry modulation works; raw Rec stays dry.

**Recording:** tap its destination pad to Stop. To reopen: select with a left encoder + INFO.

Full setup, routing examples and installation steps are in the reference guide.