NAVIGATION / +C THROUGH +C7 BUGFIX RELEASE

Quick reference card

Select a pad and press **INFO twice** for parameters. **Select + INFO** opens supported modulation. Page numbers refer to the full guide.

Waveform / Stop · 2	Pinch vertically for amplitude or horizontally for time. Two-finger tap: 100% amplitude + stock horizontal view. Hold a Trigger grid pad or the Play button on waveform/parameter pages 2 s to stop [+c7].
Speed / Pitch · 3	**Sample > LFO/Spd > SPEED**: 50-200%. One stretch voice, shared with Smooth. Pitch is unrestricted. Waiting voices need restart or neutral-then-adjust.
Tone · 4	**Pad > Tone**: Fidelity, Drive, Filter 2, Res 2, Slope 1. Select + INFO on Drive, Filter 2 or Res 2 to modulate.
Clip / Slicer · 5-6	**Pos**: Clip timing, Live Flip and Fill every; Slicer Sync, Sync Grid and **Slice Fit > Cut / Tape / Smooth**.
GEN · 7-8	**Pad > Gen** for patterns; **Cnf** for extra controls. Enable **Tools > Mstr > Section > GEN Run > Run On**. Follows the musical clock.
Delay / reverb · 9-10	**FX1 > INFO > More**: extra delay controls. **FX2 > INFO**: reverb; More for detail. Tap selected FX2 again for FX3, then INFO.
Sends / Dry · 11, 19	**Pad > Pos**: FX1/2/3 Send and Dry Level; select + INFO to modulate. Dry 0% is wet only. **Tools > Rec > FX Out** routes returns; FX3 has its own Out.
Modulation · 11-12	KEY, ENV, CHAOS, RAND and NET join native sources. Up to 12 saved routes per pad. Double-tap numeric dials to reset base values while keeping routes.
CV / MIDI · 13, 16	**Tools > Rec > CV In**: Scale, Offset, Quantize, Root. **Tools > MIDI > Monitor**: messages, Freeze, channel filter, Clear.
Master · 14-15	**Tools > Comp**: compressor. **Mstr > Section**: Comp env, Master FX, Dist Ctrl, Sweep Mod. Main and Mstr share the same compressor switch.
Overdub · 17	Empty pad > **Cnf > Dub source**: Manual or Pad 1-16. **Dub tap**: Pre / Post pad / Post+FX. Use **In 1/2**; Length Custom ends at Stop.
Recording / Resam · 18	**Rec Input > Resam** prints the mix. Tap destination on Pads to Stop. To reopen without stopping: select with a left encoder + INFO. Right encoders adjust live Gain. Rec starts a stopped clock and restores its prior state after the take [+c7].
Display / mutes · 2, 22	**Tools > Disp**: Brightness, Flip UI, saver, Sig wake; header Gfx toggles lines. **Mixer** mutes now save with the preset. **Main > RESET** keeps pad and Display settings.
Clock [+c6] · 20-21	**Main > Int BPM**: turn faster for larger changes; hold 3 s for 120.0. **Clock**: Run / Stop / Reset, Run CV, Reset CV, Reset CC/Ch. HOME: main Menu. Back: Tools. Stop holds time, not all audio.
Install / recover · 23	Patch official 2.3.4. Back up the card. Name output **BITBOXMK2.bin**, copy to card root and power on holding INFO. Use the original file to return to stock.