

The fix ladder

1

Reconnect the device

Wi-Fi off, wait, on. Not airplane mode.

2

Move closer

and find out whether distance is the problem

3

Check the network

are you on the one you meant?

4

Get the box up and out

open, central, unobstructed

5

Reboot the right box, once

power cable, never the reset pinhole



Download the graphics
toolbox.wlanpros.com/graphics



Keith Parsons · CWNE #3