Operation Manual

Flux-tool cleaning system

PC Software

Production : ATK5 EE


S/W Engineer: Hyun-su Park

1. Run a program

Double-click the FluxTool_CleanerSystem_ATV.exe icon on the desktop to run it




2. Log-in



Log in after entering ID and password

Default ID: 000000Default Password: 1

3. Operation




(1) Close the front door of the equipment and press the start button

If the following window opens, press the check button



- (2) Select the Recipe file and press the OK button
- (3) If you want to stop the process, press the stop button
- Ch1, Ch2, Ch3 The same GUI and SEQ


4. Maintenance



If you press the Maintenance button, you will see the screen above The process can be carried out the same as the "Operation" screen

(1) Individual I/O operations are possible However, it is impossible to operate during the process

5. Recipe



- (1) New / Edit / Copy / Save / Delete / Cancel button
 - New: Create a new Recipe file
 - Edit: Modifying Recipe Content
 - Copy : Copy Recipe File
 - Save : Create or modify Recipe and save it as a file (csv file)
 - Delete : Delete Recipe File
 - Cancel: Cancel creating or modifying Recipe
- (2) Add / Insert / Delete
 - Ability to add, insert, or delete each step in Recipe

• One recipe can be created up to 50 steps in total

(3) Recipe Item

- Water: Whether to use water

- Air knife : Whether to use dry air

- Pin move : Whether to use pin


1) Up: Keep Pin up

2) Down: Keep Pin down

3) Up/Down: Repeat Pin up/down every 3 seconds


- Time : Each step process time (sec)

6. Configure




Cylinder fwd/bwd time out : Alarm if it does not operate within the set time when moving the cylinder

7. In/Output



Check I/O control and status


8. Alarm



Alarm history by channel


- Alarm list
- (1) Code. 1002: Failed to read recipe file
 - Alarm when the Recipe file fails to be loaded during the process
- (2) Code. 1005: Cylinder forward time out
 - Alarm if cylinder operation fails to reach forward position within set time
- (3) Code. 1006: Cylinder backward time out
 - Alarm if cylinder operation fails to reach backward position within set time
- (4) Code. 1007: Cylinder home time out
 - Alarm if cylinder operation fails to reach home position within set time

9. Event Log



Event history by channel (year/month/date)

10. User regist



New User registration and modify, delete function

- User regist
 - Employee number : Employee number or unique numbers
 - Name : Name
 - Authority : Setting permissions (screen access permission)
 - Password : Password
- User edit
 - Modify existing registered user information
- User delete
 - Delete registered users