Mudita Kompakt How-to Guides

98 how-to articles from Mudita's support site, plus the essentials of the printed manual, for reading offline in the E-Reader.

Collected from support.mudita.com and the Kompakt user manual, 10 Nov 2026. Unofficial collection; the support site has the latest versions.

Contents

1. The phone itself

1. Buttons and ports
2. Charging
3. Cleaning, storage and temperature
4. Getting help

2. First steps

1. How to add an eSIM
2. Mudita Kompakt initial setup
3. How to insert a physical SIM card
4. How to find your phone number

3. Calling

1. How to make a call on Kompakt
2. How to change the emergency call number

4. Messaging

1. How to delete conversations
2. How to create a new message group
3. How to send SMS messages to a contact
4. How to send SMS messages to a new number
5. How to send MMS messages to a contact
6. How to send MMS messages to a new number
7. How to send SMS and MMS messages on Mudita Kompakt

5. Managing contacts

1. How to delete contacts on Kompakt
2. How to block contacts on Kompakt
3. How to unblock contacts on Kompakt

4. How to merge duplicate contacts using Mudita Center
5. How to manually add contacts on Kompakt
6. How to import contacts from Google
7. How to import contacts from Outlook
8. How to import contacts from a CSV file or vCard
9. How to create a vCard (VCF file) using iCloud
10. How to create a CSV or vCard using a Google Account
11. How to create a CSV file using Outlook
12. How to delete contacts using Mudita Center

6. Connectivity

1. How to connect to Wi-Fi
2. How to use Offline+
3. How to connect devices using Bluetooth
4. How to create a hotspot
5. How to share a Wi-Fi password
6. How to switch between SIM 2 and eSIM mode
7. How to allow or stop downloads using data
8. How to allow or stop roaming
9. How to turn Airplane mode on or off

7. Updating Kompakt

1. How to update MuditaOS K on Kompakt
2. How to manually check for MuditaOS K updates

8. Privacy and security

1. How to add fingerprints
2. How to block numbers
3. How to block hidden or unrecognized numbers

4. How to manually add a number to your blocked list
5. How to block a number from an incoming call
6. How to stop Kompakt showing files when connecting via USB-C
7. How to delete fingerprints
8. How to manage location sharing
9. How to unblock numbers on Kompakt

9. Basic settings and customization

1. How to turn certain sounds on or off
2. How to change the system language
3. How to toggle automatic crash reporting
4. How to change the volume level
5. How to put Kompakt in silent mode
6. How to add a new keyboard layout
7. How to unhide or hide app icons
8. How to change the screen time-out delay

0. Managing the battery

1. How to toggle battery charging between 80% and 100%
2. How to check battery information

1. Accessibility

1. How to toggle ending calls using the power button
2. How to toggle ring or touch vibration
3. How to adjust the audio balance
4. How to toggle mono audio
5. How to change how long popups stay on screen

6. How to change the touch and hold delay

2. Troubleshooting

1. Low call volume or no data on US carriers
2. An OS update fails on Kompakt
3. Ghost message sound with no notification
4. How to do a factory reset on Kompakt
5. Files do not show when connecting Kompakt via USB-C
6. I forgot my Kompakt PIN or screen pattern
7. Kompakt is stuck in a loop when it starts up

3. Calendar app

1. How to create a calendar event

4. Alarm app

1. How to create an alarm
2. How to edit an alarm
3. How to delete an alarm
4. How to snooze an alarm
5. How to manage alarms on Mudita Kompakt

5. Camera app

1. How to take a photo
2. How to view photos
3. How to take a screenshot
4. How to use the camera and gallery on Mudita Kompakt

6. Notes app

1. How to delete notes
2. How to create notes

7. Maps app

1. How to plan a route
2. How to delete a map
3. How to change where maps are stored
4. How to download a map

8. Weather app

1. How to change the weather default location
2. How to open the weather app

9. Managing files

1. How to transfer photos to Kompakt
2. How to transfer music to Kompakt
3. How to transfer e-books to Kompakt
4. How to delete files from Kompakt
5. How do I transfer photos from Kompakt to my computer?
6. Meditation Cards for Kompakt

0. Backup and restore

1. How to create a backup for Kompakt
2. How to find the backup file to restore Kompakt
3. How to restore Kompakt from a backup

1. Voice recorder

1. How to record a voice recording
2. How to listen to a voice recording
3. How to delete voice recordings

2. Safety

1. Safety in brief

3. Appendix: networks and radios

1. Supported bands

1. The phone itself

Buttons and ports

> *Volume and power on the right, the Offline+ switch and SIM tray on the left, three keys below the screen, headphones on top, USB-C at the bottom.*

RIGHT SIDE

- **Volume up** and **volume down**: the two upper keys
- **Power key**: the lower key. Press it to turn Kompakt on, or touch it to scan your fingerprint.
- To turn Kompakt off, hold the power key for 2 seconds, then choose the power off option.

LEFT SIDE

- **SIM tray**: push the SIM key into the small hole to open it. It holds one or two nano-SIMs, gold chip facing down.
- **Offline+ switch**: up for the full phone, down for Offline+. Offline+ turns off the antenna, microphones, camera, Wi-Fi and Bluetooth. You can't make emergency calls in Offline+.

BELOW THE SCREEN, LEFT TO RIGHT

- **Back**: go back one step
- **Home**: go to the home screen
- **Control Center**: opens the Control Center, where Settings lives

TOP AND BOTTOM

- **Top**: headphone jack (headphones not included)
- **Bottom**: USB-C port for charging and for connecting to a computer

Charging

> *No charger comes in the box. Use a USB-C cable and an adapter that gives between 2.5 and 10 W, or a wireless charger.*

WIRED

- Most USB power adapters work with a USB-C cable.
- The adapter should deliver at least 2.5 W and no more than 10 W. 10 W gives the fastest charge. Using a different one may damage the battery.
- Use an adapter from a reputable maker, certified as a Limited Power Source (IEC 60950-1 / 62368-1) rated 5 V 1.5 A.

WIRELESS

Kompakt can charge on a wireless charger. It gets warmer, uses more energy and wears the battery more than charging by cable.

LOOKING AFTER THE BATTERY

- You can stop charging at 80% instead of 100% to help the battery last. The setting, the battery's maximum capacity, cycle count, date of manufacture and date of first use are under **Control Center > Settings > Battery > Battery Information**.
- Don't charge overnight, and don't leave it charging for long periods when you aren't using the phone.
- Charge somewhere with air around it, and don't cover the phone while it charges.
- If you put Kompakt away for a long time, charge it to 40% once every 3 months.
- The battery is lithium-polymer.

Cleaning, storage and temperature

> *Turn it off, wipe it with a soft, slightly damp cloth, and dry it. Use it between 0 and 50 °C.*

CLEANING

- Turn Kompakt off first.

- Wipe it with a soft, slightly damp cloth, then dry it.
- Never hold it under running water or put it in any liquid.
- Never use harsh cleaners, wire brushes, scourers or anything metal or sharp.

STORAGE

- Keep it dry, ideally in its original box, away from children and pets.
- Store it between −25 °C and 60 °C (−13 °F to 140 °F).

USING IT

- Use it between 0 °C and 50 °C (32 °F to 122 °F).
- Kompakt is not waterproof.

Getting help

> *Write to support@mudita.com. Mudita's support site has the latest version of every article in this book.*

- **Email:** support@mudita.com
- **Support site:** support.mudita.com
- **Quick start, videos and the printed manual:** mudita.com/products/phones/mudita-kompakt/quick-start/

- **Mudita Center**, the free desktop app for Windows, macOS and Linux (contacts, backups, music and books): mudita.com/center
- **Legal and regulatory information**, including the certificates and the software license: **Control Center > Settings > Legal and Regulatory**

When you write, say which model you have (Global or North American), your MuditaOS K version, and what you have tried.

Mudita sp. z o.o., Jana Czeczota 6, 02-607 Warsaw, Poland.

2. First steps

How to add an eSIM

> *Switch to eSIM mode, then Settings, Network & Internet, SIM Cards, Add eSIM, and scan your carrier QR code. Kompakt holds one physical SIM plus either a second SIM or an eSIM, not both.*

WHAT YOU NEED

An eSIM QR code or activation code from your carrier, and an internet connection. Kompakt must be in eSIM mode before you add the eSIM.

SWITCH TO ESIM MODE

Kompakt has one dedicated SIM slot and one hybrid slot that takes either a second nano-SIM or a microSD card. An eSIM replaces the second SIM, so you use SIM 2 or eSIM, never both. A microSD card keeps working with an eSIM.

1. Open the Control Center and tap **Settings**.
2. Tap **Network & Internet**, then **SIM Cards**.
3. Tap **Switch mode**, then **Switch mode** again to confirm. Kompakt restarts.

ADD THE ESIM

1. Open the Control Center and tap **Settings**.

2. Tap **Network & Internet**, then **SIM Cards**.
3. Tap **Add eSIM**, then **Continue**.
4. Scan the QR code, or tap **Insert code** and type the activation code.
5. Read the Profile Policy rules and tap **Accept**.
6. Tap **Add this eSIM**. Tick the check box if you want to turn the eSIM on straight away. Kompakt restarts.

MOVING YOUR NUMBER FROM ANOTHER PHONE

Ask your carrier to transfer your eSIM to a new device, or to convert your physical SIM to an eSIM.

> **US owners.** If the eSIM activates but calls are quiet or data is blocked, try a physical SIM. Several US owners fixed it this way. Details in Low call volume on US carriers.

Mudita Kompakt initial setup

> *Insert your SIM, press the power button, pick a language, join Wi-Fi, accept the licence, set a 6-digit passcode and add a fingerprint on the power button. Install any update the phone offers at the end.*

BEFORE YOU START

Have your SIM card (or your carrier's eSIM QR code), your Wi-Fi password and the USB-C cable from the box ready.

STEP BY STEP

1. **Insert the SIM.** Push the SIM key into the round hole, pull the SIM tray fully out, place a nano-SIM in the tray with the gold side facing down, and slide the tray back in. For eSIM, skip this and add it after setup.
2. **Power on.** Press the **power button**.
3. **Language.** Tap **Language setup** and pick your language.
4. **Connect to Wi-Fi.** Pick your network, enter the password and tap **Next**.
5. **Licence.** Read the End User Licence Agreement and tap **Accept**.
6. **Passcode.** Enter a new 6-digit passcode, tap **Confirm passcode**, enter it again and tap **Set passcode**.
7. **Fingerprint.** The scanner is in the power button. Rest your finger on it, lift when it vibrates, and repeat, moving your finger slightly each time. Tap **Done**. You can add more later under **Settings**, **Security**, **Manage Fingerprints**.
8. **Tutorial.** Tap **Quick Tutorial** to see the basics, or skip it. Skipping does not affect

setup.

9. **Update.** If an update is available, tap **Update**, then **Restart phone**.

Adding an eSIM. Open the Control Center, tap **Settings**, **Network & Internet**, **SIM Cards**, **Add eSIM**. See How to add an eSIM.

BRING YOUR CONTACTS

Use Mudita Center on your computer: import from Google or Outlook, or upload a CSV or vCard file (for iCloud, export a vCard first). Each route has its own guide under Managing contacts.

> **US carriers.** AT&T, Verizon and their resellers keep lists of approved phones and may limit service on Kompakt: quiet calls, blocked data or missing picture messages. T-Mobile and T-Mobile-based carriers work best. See Low call volume on US carriers before contacting us.

IF SOMETHING GOES WRONG

Kompakt does not power on: charge it for a while, then try again. SIM not recognised: take the tray out and check the SIM sits gold side down. Update fails: check your internet connection, try again, and restart the phone.

Still stuck? Write to us with your model, your MuditaOS K version and what you tried.

How to insert a physical SIM card

> *Open the tray with the SIM Key, put the SIM in with the gold side down, and slide the tray back into Kompakt.*

STEP BY STEP

1. Insert the **SIM Key** into the round hole
2. Fully remove the **SIM tray**
3. Insert a **SIM card** into the **SIM tray** - gold side of the SIM facing down
4. Insert the **SIM tray** into Kompakt

How to find your phone number

> *You can find the phone numbers for each of your installed SIM cards in the SIM status screen.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **About**
4. Tap **SIM status (sim slot #)** for the SIM you want to view

3. Calling

How to make a call on Kompakt

> *Tap Phone, then Contacts to call someone you know, or Dial to type a new number.*

TO CALL A CONTACT

1. Tap **Phone**
2. Tap **Contacts**
3. Select the contact you want to call
4. Tap **Call**

TO CALL A NEW NUMBER

1. Tap **Phone**
2. Tap **Dial**
3. Enter the number you want to call
4. Tap the **Call** icon

How to change the emergency call number

> *Warning! Your emergency call may not be answered if you change the default number!*

The default emergency number is for the emergency services in your state or country.

TO CHANGE THE EMERGENCY NUMBER

1. Press the **Control Center** button

2. Tap **Settings** icon
3. Tap **Safety and Emergency**
4. Tap **Emergency Call**
5. Tap **Call in case of Emergency**
6. Tap the **existing number**
7. Enter the new number
8. Tap **Save**

4. Messaging

How to delete conversations

> *In SMS, tap the Pencil icon, select the conversations and tap Delete.*

STEP BY STEP

1. Tap **SMS**
2. Tap the **Pencil** icon
3. Select the conversations you want to delete
4. Tap **Delete**
5. Tap **Delete**

How to create a new message group

> *Start a new conversation in the SMS app and add more than one contact or number. Kompakt supports group messaging from MuditaOS K 1.4.0.*

If you are on an older version, update first.

CREATE A GROUP CONVERSATION

1. Tap **SMS**
2. Tap the **Plus** icon
3. Select the first contact you want to message

4. Select more contacts, or type a number or a contact name to add more people
5. Write your message
6. Tap the **Send** icon

The conversation is saved once you send a message or leave a draft. If you go back before that, the selection is cleared.

GROUP CHAT OR SEPARATE TEXTS

In **SMS**, tap the **Settings** icon (sliders, top right), tap your SIM card (for example, SIM 2 and the carrier name), then tap **Group Messaging**. Choose how Kompakt sends messages to several people for that SIM card. The same screen also has **Download MMS content**, **Allow while roaming** and **SMS delivery reports**.

- **Single MMS group chat:** everyone in the group sees all replies. Messages go out as MMS, so mobile data and MMS need to work on your plan.
- **Separate SMS chats:** everyone gets the same text, but replies come back to you in one-to-one conversations and people do not see each other's answers.

GOOD TO KNOW

- If you have two SIM cards active, you can switch between them in the same group

conversation.

- If you block someone who is in a group, you can still send them messages, but you will not receive their replies.
- Group chats started on an iPhone may not come through. Owners on the forum report that a newly created group works better.

How to send SMS messages to a contact

> *Sending SMS messages on your Kompakt is simple and allows you to quickly start conversations with your contacts or new numbers*

STEP BY STEP

1. Tap SMS.
2. Tap the Pencil icon to create a new message.
3. Select the contact you want to message.
4. Enter your message in the text field.
5. Tap the Send icon to send the message.

If the keyboard does not appear, tap the blinking cursor to activate it.

How to send SMS messages to a

new number

> *Sending an SMS to a new number on your Kompakt is simple and only takes a few steps. You can start a conversation even if the number is not saved in your contacts*

STEP BY STEP

1. Open the SMS app.
2. Tap the Plus icon to start a new message.
3. Enter the phone number manually.
4. Tap Send to: [phone number] to confirm the recipient.
5. Type your message in the text field.
6. Tap the Send icon to send your SMS.

If the keyboard does not appear, tap the blinking cursor to activate it.

How to send MMS messages to a contact

> *In SMS, tap the Plus icon, pick the contact, tap the Image icon and choose the picture to send.*

1. Tap **SMS**
2. Tap the **Plus** icon
3. Select the contact you want to message
4. Tap the **Image** icon

5. Select the image you want to send
6. Tap **Send**

SEND MMS MESSAGE TO A NEW NUMBER

1. Tap **SMS**
2. Tap the **Plus** icon
3. Enter the phone number
4. Tap **send to: xxxxxxxxxxx**
5. Tap the **Image** icon
6. Select the image you want to send
7. Tap **Send**

How to send MMS messages to a new number

> *In SMS, tap the Plus icon, type the number, tap the Image icon and choose the picture to send.*

STEP BY STEP

1. Tap **SMS**
2. Tap the **Plus** icon
3. Enter the phone number
4. Tap **send to: xxxxxxxxxxx**
5. Tap the **Image** icon
6. Select the image you want to send
7. Tap **Send**

How to send SMS and MMS messages on Mudita Kompakt

> *Open SMS, tap the Pencil icon for a contact or the Plus icon for a new number, write your message and tap Send. The steps for MMS are below.*

SEND SMS MESSAGE TO A CONTACT

1. Tap **SMS**
2. Tap the **Pencil** icon
3. Select the contact you want to message
4. Enter your message*
5. Tap the **Send** icon

*If the keyboard does not appear, tap the blinking cursor

SEND SMS MESSAGE TO A NEW NUMBER

1. Tap **SMS**
2. Tap the **Plus** icon
3. Enter the phone number
4. Tap **send to: xxxxxxxxxxx**
5. Enter your message*
6. Tap the **Send** icon

*If the keyboard does not appear, tap the blinking cursor

SEND MMS MESSAGE TO A CONTACT

1. Tap **SMS**
2. Tap the **Plus** icon
3. Select the contact you want to message
4. Tap the **Image** icon
5. Select the image you want to send
6. Tap **Send**

SEND MMS MESSAGE TO A NEW NUMBER

1. Tap **SMS**
2. Tap the **Plus** icon
3. Enter the phone number
4. Tap **send to: xxxxxxxxxxx**
5. Tap the **Image** icon
6. Select the image you want to send
7. Tap **Send**

HOW TO DELETE CONVERSATIONS

1. Tap **SMS**
2. Tap the **Pencil** icon
3. Select the conversations you want to delete
4. Tap **Delete**
5. Tap **Delete**

5. Managing contacts

How to delete contacts on Kompakt

> *Open the contact in Phone, then Contacts, tap the Pencil icon, then the Bin icon.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Contacts**
3. Select the contact you want to delete
4. Tap the **Pencil** icon
5. Tap the **Bin** icon
6. Tap **Delete contact**

How to block contacts on Kompakt

> *Open the contact in Phone, then Contacts, tap the Pencil icon, then the Block icon.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Contacts**
3. Select the contact you want to block
4. Tap the **Pencil** icon
5. Tap the **Block** icon
6. Tap **Block contact**

How to unblock contacts on Kompakt

> *Open the contact in Phone, then Contacts, tap the Pencil icon, then the Block icon and choose Unblock contact.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Contacts**
3. Select the contact you want to block
4. Tap the **Pencil** icon
5. Tap the **Block** icon
6. Tap **Unblock** contact

How to merge duplicate contacts using Mudita Center

> *Connect Kompakt to Mudita Center, open Contacts, then Manage Duplicates alongside All Contacts to merge them. You need Mudita Center 4.0.0 or newer and MuditaOS K 1.5.0 or newer.*

Connect Kompakt to Mudita Center, open **Contacts** and use **Manage Duplicates**, alongside **All Contacts** under **Contacts**, to merge them. This needs Mudita Center 4.0.0 or newer on your computer and MuditaOS K 1.5.0 or newer on Kompakt.

BEFORE YOU START

- Update Mudita Center and Kompakt to the versions above.
- Create a backup first, in case a merge does not turn out the way you expected: in Mudita Center, look under **Your Kompakt**, click **Overview**, then **Create backup**.

MERGE DUPLICATE CONTACTS

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** and click **Contacts**
3. Click **Manage Duplicates** alongside **All Contacts** under **Contacts**
4. Review each suggested duplicate, then delete or merge it one at a time
5. Check your contact list after merging

Do not disconnect Kompakt while Center is changing your contacts.

WHY DUPLICATES HAPPEN

Duplicates usually come from importing the same contacts twice, for example from Google and then again from a vCard file. If you plan to import again, delete the old copies first: select them in **Contacts** with the **Checkbox** and click **Delete**.

How to manually add contacts on Kompakt

> *Go to Phone, then Contacts, tap the Add contact icon, enter the details and tap Create.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Contacts**
3. Tap the **Add contact** icon
4. Enter the contact information
5. Tap **Create**

How to import contacts from Google

> *Connect Kompakt to Mudita Center, go to Contacts, click Import contacts and choose Google.*

STEP BY STEP

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Contacts**
3. Click **Import contacts**
4. Click **Google**
5. Log in to Google

6. Select the individual contacts to import or select **All contacts**
7. Click **Import selected contacts** to transfer contacts to phone*

*Important - do not disconnect your phone while the import is in progress

How to import contacts from Outlook

> *Connect Kompakt to Mudita Center, go to Contacts, click Import contacts and choose Outlook.*

STEP BY STEP

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Contacts**
3. Click **Import contacts**
4. Click **Outlook**
5. Log in to Outlook
6. Select the individual contacts to import or select **All contacts**
7. Click **Import selected contacts** to transfer contacts to phone*

*Important - do not disconnect your phone while the import is in progress

How to import contacts from a CSV file or vCard

> *Connect Kompakt to Mudita Center, go to Contacts, click Import contacts and upload your CSV or vCard file.*

STEP BY STEP

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Contacts**
3. Click **Import contacts**
4. Click **Upload CSV or vCard**
5. Select the CSV or Vcard file from your computer
6. Select the individual contacts to import or select **All contacts**
7. Click **Import selected contacts** to transfer contacts to phone*

*Important - do not disconnect your phone while the import is in progress

How to create a vCard (VCF file) using iCloud

> *On your computer, open iCloud Contacts, select the contacts and choose Export vCard.*

STEP BY STEP

1. On your computer, sign into your iCloud account using your Apple ID
2. Click **Contacts**
3. Select the contacts to export either by using **ctrl + click** or **shift + click***
4. Click the **Export** Icon
5. Click **Export vCard**
6. The vCard (VCF file) should appear in your downloads folder

*To quickly select all contacts, click the 3 dots in a circle icon > click Select All

How to create a CSV or vCard using a Google Account

> *On your computer, open Google Contacts, select the contacts and choose Export as CSV or vCard.*

1. On your computer, sign into your Gmail account using your Google ID
2. Click the **Grid** icon to show the apps list
3. Click **Contacts**
4. Select the contacts to export
5. Click the **3 dots** icon
6. Click **Export**

7. Select how you would like to export the contacts, either CSV or vCard
8. Click **Export**
9. The CSV or vCard should appear in your downloads folder

***TO QUICKLY SELECT ALL CONTACTS, CLICK THE DOWN ARROW ICON > CLICK ALL**

How to create a CSV file using Outlook

> *On your computer, open Outlook People, choose Manage contacts and click Export.*

STEP BY STEP

1. On your computer, sign into your Outlook account using your Microsoft ID
2. Click the **People** icon
3. Click the **Manage contacts**
4. Click **Export**
5. Click **Export**
6. The CSV should appear in your downloads folder

How to delete contacts using Mudita Center

> *In Mudita Center, open Contacts under Your Kompakt, tick the contacts and click Delete.*

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Contacts**
3. Hover the mouse pointer over contact you want to delete
4. Click the **Checkbox** to select the contact*
5. Select any other contacts you want to delete
6. Click **Delete**
7. Click **Delete**

***TO SELECT ALL, CLICK THE MINUS ICON NEAR THE TOP OF THE SCREEN**

6. Connectivity

How to connect to Wi-Fi

> *Go to Settings, then Network and Internet, then Wi-Fi, pick your network and enter the password.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Network and Internet**
4. Tap **Wi-Fi**
5. Select the Wi-Fi network you want to join
6. Enter the Wi-Fi network password
7. Tap **Connect**

How to use Offline+

> *Slide the Offline+ switch on the side of Kompakt down to go offline, and up to bring everything back.*

1. Slide the **Offline+ switch*** to the down position

TO ENABLE THE FULL PHONE FUNCTION

1. Slide the **Offline+ switch** to the up position

***THE OFFLINE+ SWITCH IS LOCATED ON THE LEFT SIDE OF KOMPAKT**

How to connect devices using Bluetooth

> *Before starting, ensure the device you want to connect to has Bluetooth turned on and is discoverable.*

TO CONNECT A DEVICE

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Connected Devices**
4. Tap **Pair new device**
5. If you see a notification “Bluetooth is on”, tap x to dismiss it
6. Select the device you want to pair with from the list
7. Tap **Pair**

How to create a hotspot

> *Hotspots allow other devices to use Kompakt’s Wi-Fi or data when they are tethered.*

TO CREATE A HOTSPOT

1. Press the **Control Center** button
2. Tap **Settings** icon

3. Tap **Network and Internet**
4. Tap **Hotspot and Tethering**
5. Tap **Wi-Fi Hotspot**
6. You can edit the name, password* and security settings for the hotspot
7. To turn on the hotspot Tap the **Toggle Switch** near the top of the screen

***THE PASSWORD MUST BE 8 OR MORE CHARACTERS LONG**

You can also turn the hotspot on and off from the Control Center:

1. Press the **Control Center** button
2. Tap **Hotspot icon** which is above the Airplane icon

How to share a Wi-Fi password

> *In the Wi-Fi settings, tap the network you are on and tap Share. The other device scans the QR code.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Network and Internet**
4. Tap **Wi-Fi**
5. Select the Wi-Fi network you are connected to

6. Tap **Share**
7. Touch the **power button** to scan your fingerprint or tap **USE PIN** > Enter PIN
8. Either scan the **QR code** with the other device, or copy the Wi-Fi passcode manually

How to switch between SIM 2 and eSIM mode

> *Go to Settings, then Network and Internet, then SIM Cards, and tap Switch mode. Kompakt restarts.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Network and Internet**
4. Tap **SIM Cards**
5. Tap **Switch mode**
6. Tap **Switch mode** and Komapkt will restart automatically

How to allow or stop downloads using data

> *If you stop Kompakt from using mobile data, downloads will need a Wi-Fi connection. This is useful if you have a limited data allowance or high cost for data.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Network and Internet**
4. Tap **Mobile Network**
5. Tap the Mobile data **Toggle switch** to stop or allow Kompakt using mobile data

How to allow or stop roaming

> *Roaming is when you use your device outside of your home country. Your network provider can charge you extra for this feature. Always check with your network provider before allowing roaming!*

TO ALLOW ROAMING

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Network and Internet**
4. Tap **Mobile Network**
5. Tap the Roaming **Toggle switch** to stop or allow roaming

How to turn Airplane mode on or off

> *Press the Control Center button and tap the Airplane icon.*

1. Press the **Control Center** button
2. Tap **Airplane** icon

Offline+ is more than Airplane mode as it disables the antenna, microphones, camera, Wi-Fi and Bluetooth.

TO USE OFFLINE+

1. Slide the **Offline+ switch*** to the down position

TO ENABLE THE FULL PHONE FUNCTION

1. Slide the **Offline+ switch** to the up position

***THE OFFLINE+ SWITCH IS LOCATED ON THE LEFT SIDE OF KOMPAKT**

7. Updating Kompakt

How to update MuditaOS K on Kompakt

> *When an update is ready, tap the notification at the top of the Control Center, then Update. To check yourself: Settings, Software Update. Updates are done on the phone, not in Mudita Center.*

BEFORE YOU UPDATE

Connect to the internet (Wi-Fi, or mobile data if you allow downloads over data). Updates keep your data and your MuditaOS K version only moves forward, but a recent backup in Mudita Center is good insurance.

UPDATE ON THE PHONE

1. When an update is available, you see **New MuditaOS K update is available** at the top of the Control Center. Tap it.
2. Tap **Update**.
3. If asked, read the licence agreement, tick the check box and tap **Agree**.
4. The update downloads and installs on its own. Tap **Restart phone** when asked.

To check manually: open the Control Center, tap **Settings**, **Software Update**. On

MuditaOS K 1.1.x and older, it is under **Settings**, **About**.

IF THE UPDATE FAILS

1. Try the update again.
2. Check that your internet connection is stable.
3. No Wi-Fi? Check that downloads over mobile data are allowed under **Settings**, **Network & Internet**, **Mobile Network**.
4. Restart the phone.
5. As a last resort, do a factory reset. Back up first.
6. If nothing works, contact us.

Mudita Center cannot install Kompakt updates. It only tells you that one is available.

WHAT IS IN THE LATEST VERSION

MuditaOS K 1.6 brings 38 keyboard languages, smarter text suggestions, easier Maps setup, voicemail on supported networks, task lists in Notes and per-alarm vibration. The version all Kompakt users received is 1.6.1; if your phone is on 1.6.0, update it to 1.6.1. Full list in the release notes. MuditaOS K 2.0 is planned for November 2026.

How to manually check for

MuditaOS K updates

> *Connect to the internet, then go to Settings, About, Software Update.*

STEP BY STEP

1. Make sure Kompakt is connected to the internet
2. Touch the **Control Center button**
3. Tap the **Settings** icon
4. Tap **About**
5. Tap **Software Update**
6. If an update is available, you can update MuditaOS K

An OS (Operating System) update fails on KompaktThere are a few things you can try if an update fails, a factory reset should be the last resort!

1. Try the update again
2. Check you have a stable internet connection
3. If you don't have Wi-Fi, check that you allow downloads using data
4. Restart the the device
5. Do a factory reset
6. If none of the above fix the problem, contact customer support

8. Privacy and security

How to add fingerprints

> *How to add fingerprintsKompakt's power button contains a fingerprint scanner, letting you unlock you phone quickly without the passcode.*

TO ADD A NEW FINGERPRINT

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Security**
4. Tap **Manage Fingerprints**
5. Type your passcode and tap **Enter** on the keypad
6. Tap the **Plus** icon
7. Follow the onscreen instructions*

*Make sure you place a slightly different part of your finger on the sensor after each vibration

HOW TO DELETE FINGERPRINTS

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Security**
4. Tap **Manage Fingerprints**

5. Type your passcode and tap **Enter** on the keypad
6. Tap the **Bin** icon next to the fingerprint you want to delete
7. Tap **Delete**

How to block numbers

> *Kompakt can block all hidden or unknown numbers, a number you add to a list, or a number while it is calling you.*

KOMPAKT GIVES YOU MANY WAYS TO BLOCK NUMBERS

1. You can choose to block all hidden or all unrecognized numbers
2. You can block individual numbers when you add a number to your blocked list
3. You can block a number during an incoming call

HOW TO BLOCK HIDDEN OR UNRECOGNIZED NUMBERS

You can block all incoming calls and messages from hidden numbers. You can also choose to block all numbers that you don’t recognize, you will only receive calls and messages from numbers in your contacts list.

TO BLOCK ALL HIDDEN OR UNRECOGNISED NUMBERS

1. Tap **Phone**
2. Tap **Recents**
3. Tap **App settings** icon in the topbar
4. Tap **Call Blocking**
5. Use the **Toggle switches** to select either Block hidden numbers or Block unrecognised numbers

HOW TO MANUALLY ADD A NUMBER TO YOUR BLOCKED LIST

1. Tap **Phone**
2. Tap **Recents**
3. Tap **App settings** icon in the topbar
4. Tap **Call Blocking**
5. Tap **Blocked Numbers**
6. Tap **Add to blocked** or the **Plus** icon
7. Enter the number you want to block
8. Tap **Block**

HOW TO BLOCK A NUMBER FROM AN INCOMING CALL

When you receive a call from the number you want to block:

1. Tap the **Block** icon
2. Tap **Block number**

HOW TO UNBLOCK NUMBERS ON KOMPAKT

1. Tap **Phone**
2. Tap **Contacts**
3. Tap the **App settings** icon
4. Tap **Call Blocking**
5. Tap **Blocked Numbers**
6. Tap the **Minus** icon for the number you want to unblock

How to block hidden or unrecognized numbers

> *You can block all incoming calls and messages from hidden numbers. You can also choose to block all numbers that you don’t recognize, you will only receive calls and messages from numbers in your contacts list.*

TO BLOCK ALL HIDDEN OR UNRECOGNISED NUMBERS

1. Tap **Phone**
2. Tap **Recents**
3. Tap **App settings** icon in the topbar
4. Tap **Call Blocking**
5. Use the **Toggle switches** to select either Block hidden numbers or Block unrecognised numbers

How to manually add a number to your blocked list

> *In Phone, go to Recents, open App settings, then Call Blocking and Blocked Numbers, and add the number.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Recents**
3. Tap **App settings** icon in the topbar
4. Tap **Call Blocking**
5. Tap **Blocked Numbers**
6. Tap **Add to blocked** or the **Plus** icon
7. Enter the number you want to block
8. Tap **Block**

How to block a number from an incoming call

> *While the unwanted number is calling you, you can block it straight from the call screen.*

STEP BY STEP

1. Tap the **Block** icon
2. Tap **Block number**

How to stop Kompakt showing files

when connecting via USB-C

> *While Kompakt is connected, go to Settings, then Connected Devices, then USB Preferences, and choose whether it shares files.*

FILES DON'T SHOW WHEN CONNECTING KOMPAKT VIA USB-C

If you connect Kompakt to your computer but can’t see your files, you’ll need to allow file transfer.

TO ALLOW FILE TRANSFER

1. Connect Kompakt to a computer with a USB-C cable
2. Press the **Control Center** button
3. Tap the **Settings** icon
4. Tap **Connected Devices**
5. Tap **USB Preferences***
6. Tap **File Transfer**

*If Kompakt isn’t connected to the computer, you won’t see this option!

HOW TO STOP KOMPAKT SHOWING FILES WHEN CONNECTING VIA USB-C

You can stop Kompakt from showing or accessing files when connected to a computer.

This may be useful if you connect to a computer that isn’t yours.

TO STOP SHOWING FILES

1. Connect Kompakt to a computer with a USB-C cable
2. Press the **Control Center** button
3. Tap the **Settings** icon
4. Tap **Connected Devices**
5. Tap **USB Preferences***
6. Tap **No data transfer**

*If Kompakt isn’t connected to the computer, you won’t see this option!

How to delete fingerprints

> *Go to Settings, then Security, then Manage Fingerprints, and tap the Bin icon next to the one to remove.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Security**
4. Tap **Manage Fingerprints**
5. Type your passcode and tap **Enter** on the keypad

6. Tap the **Bin** icon next to the fingerprint you want to delete
7. Tap **Delete**

How to manage location sharing

> *Kompakt allows you to either turn all location sharing off or on, or manage location sharing for individual apps.*

TO TURN ALL LOCATION SHARING OFF OR ON

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Location Sharing**
4. Tap the **Toggle switch** to turn location sharing for all apps off or on

To manage location sharing for individual apps:

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Location Sharing**
4. Select the app you want to manage
5. Select the level of sharing you want

How to unblock numbers on Kompakt

> *In Phone, open App settings, then Call Blocking and Blocked Numbers, and tap the*

> *Minus icon next to the number.*

STEP BY STEP

1. Tap **Phone**
2. Tap **Contacts**
3. Tap the **App settings** icon
4. Tap **Call Blocking**
5. Tap **Blocked Numbers**
6. Tap the **Minus** icon for the number you want to unblock

9. Basic settings and customization

How to turn certain sounds on or off

> *Go to Settings, then Sound, then Advanced, and use the toggles for dial pad, screen lock, charging and touch sounds.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Sound**
4. Tap **Advance**
5. Use the toggle to turn on or off sounds for:
    1. Dial pad presses
    2. Screen locking
    3. Charging (includes vibration)
    4. Touch sounds (button presses etc.)

How to change the system language

> *Go to Settings, then System, then Language and Keyboard, and tap System Language.*

STEP BY STEP

1. Press the **Control Center** button

2. Tap **Settings** icon
3. Tap **System**
4. Tap **Language and Keyboard**
5. Tap **System Language**
6. Select the language you want to use
7. Tap **Confirm**

How to toggle automatic crash reporting

> *Go to Settings, System, Crash Reporting and use the Automatic reporting toggle. The option is there from MuditaOS K 1.5.0.*

Go to **Settings**, **System**, **Crash Reporting** and use the **Automatic reporting** toggle. The option was added in MuditaOS K 1.5.0.

TURN AUTOMATIC CRASH REPORTING ON OR OFF

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **System**
4. Tap **Crash Reporting**
5. Tap the **Automatic reporting Toggle switch** to turn it off or on

WHAT IT DOES

When automatic reporting is on, Kompakt sends issue logs and bug reports to Mudita when an app crashes, which helps the team find and fix problems. Turn it off if you prefer that nothing is sent. The phone works the same either way.

If you want to report a problem yourself, you can still contact support from Mudita Center, which attaches a log file you can download and check first.

How to change the volume level

> *There are 2 ways to change the main volume level on Kompakt but you can also change the levels for certain functions like the alarm or ringtone too.*

To set the main volume though the Control Center:

1. Press the **Control Center** button
2. Swipe the **sound volume bar** below the **Bell** icon up or down

To set the main volume using the volume buttons:

1. Press or hold down the **volume up button** to raise volume

2. Press or hold down the **volume down button** to lower volume

TO CHANGE THE VOLUME FOR CERTAIN FUNCTIONS

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Sound**
4. Use the sliders to set the level you want

How to put Kompakt in silent mode

> *There are 2 main ways to put Kompakt into silent mode.*

TO SET SILENT MODE THOUGH THE CONTROL CENTER

1. Press the **Control Center** button
2. Tap the **Bell** icon or swipe the **sound volume bar** all the way down

TO SET SILENT MODE USING THE VOLUME BUTTON

1. Hold down the **volume down button** until the sound volume bar is all the way down

How to add a new keyboard layout

> *Go to Settings, then System, then Language and Keyboard, and add a layout under Keyboard Settings.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **System**
4. Tap **Language and Keyboard**
5. Tap **Keyboard Settings**
6. Tap **Languages and Styles**
7. Tap the **Plus** icon
8. Tap **Layout**
9. Select the Layout you want to add
10. Tap the **Back arrow** icon
11. Tap **Language**
12. Select the language you want to use
13. Tap the **Back arrow** icon
14. Tap **Add**

How to unhide or hide app icons

> *Some app icons like weather, calendar and alarm are hidden by default, but you can unhide them if you prefer.*

TO UNHIDE OR HIDE APPS

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **App layout**

4. Use the **Toggle switches** to unhide or hide the apps*
5. Tap the **Back arrow** icon to save the changes and exit

***TO SEE HOW YOUR APP SCREEN WILL LOOK, TAP PREVIEW**

How to change the screen time-out delay

> *To save power and to keep your phone secure, Kompakt's screen will sleep after set time delay.*

TO CHANGE THE SCREEN TIMEOUT DELAY

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Display**
4. Tap **Screen Timeout**
5. Select the time delay you want

10. Managing the battery

How to toggle battery charging between 80% and 100%

> *Limiting battery change to 80% can help maintain battery health.*

TO TOGGLE CHARGING BETWEEN 80% AND 100%

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Battery**
4. Tap **Battery Information**
5. Tap the **Stop charging at 80%** toggle switch

How to check battery information

> *You can get an idea of your battery's health by checking its maximum capacity, cycle count, date of manufacture and date of first use. To find battery information. See below.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Settings** icon
3. Tap **Battery**
4. Tap **Battery Information**

11. Accessibility

How to toggle ending calls using the power button

> *Go to Settings, Accessibility and turn Power button ends calls on or off. When it is on, pressing the power button during a call hangs up.*

Go to **Settings**, **Accessibility** and turn **Power button ends calls** on or off. When it is on, pressing the power button during a call hangs up.

TURN IT ON OR OFF

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Tap the **Power button ends calls Toggle switch**

BEFORE YOU TURN IT ON

With this setting on, any press of the power button during a call ends it. That includes pressing it to wake the screen, for example to reach the dial pad in a phone menu. If you often need the keypad during calls, leave it off and hang up with the end call button on the screen.

During a call the screen turns off when you hold Kompakt to your ear and should wake again when you move it away.

How to toggle ring or touch vibration

> *Go to Settings, Accessibility, Vibration and Haptic and use the Ring vibration or Touch vibration toggle.*

Go to **Settings**, **Accessibility**, **Vibration and Haptic** and use the **Ring vibration** or **Touch vibration** toggle. From MuditaOS K 1.6, the same screen also has **Notification vibration**.

TURN VIBRATION ON OR OFF

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Tap **Vibration and Haptic**
5. Tap the **Ring vibration Toggle switch** to feel a vibration when the phone rings or gets messages
6. Tap the **Touch vibration Toggle switch** to feel feedback when you long press or use the Back, Home and Control Center buttons

OTHER VIBRATION SETTINGS

- From MuditaOS K 1.6.0 there is also a **Notification vibration** toggle in the same section. It turns off vibration for text messages, calendar and third-party alerts in one go.
- Vibration can also be changed under **Settings**, **Sound**.
- Each alarm has its own vibration setting in the Alarm app.
- Touch vibration may not apply in every app.

How to adjust the audio balance

> *Go to Settings, Accessibility and move the Audio balance control towards left or right.*

Go to **Settings**, **Accessibility** and move the **Audio balance** control towards the left or right.

CHANGE THE BALANCE

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Find **Audio balance** in the audio section
5. Move the **Audio balance** control towards left or right until it sounds right to you

WHEN IT HELPS

Balance is useful if you hear better with one ear. You notice it most with headphones. To have the same sound in both ears, use **Mono audio** instead, or together with balance.

How to toggle mono audio

> *Go to Settings, Accessibility and turn Mono audio on. Both audio channels are combined, so each ear hears the same thing.*

Go to **Settings**, **Accessibility** and turn **Mono audio** on. Kompakt then combines both audio channels, so each ear hears the same thing.

TURN MONO AUDIO ON OR OFF

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Find **Mono audio** in the audio section
5. Tap the **Mono audio Toggle switch**

WHEN TO USE IT

Mono audio helps if you hear better with one ear, or if you often wear only one earbud. Music and calls that use separate left and right channels will then sound complete in either ear. You can also shift the sound towards one side with **Audio balance** in the same section.

How to change how long popups stay on screen

> *Go to Settings, Accessibility, Timing controls and change Popup duration. It sets how long certain notification popups stay before they disappear.*

Go to **Settings**, **Accessibility**, **Timing controls** and change **Popup duration**. It sets how long certain notification popups stay on screen before they disappear.

CHANGE THE POPUP DURATION

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Tap **Timing controls**
5. Tap **Popup duration**
6. Select how long you want popups to stay

GOOD TO KNOW

- A longer duration helps if popups vanish before you finish reading them.
- The setting may not apply to all apps, especially apps you installed yourself.

How to change the touch and hold

delay

> *Go to Settings, Accessibility, Timing controls and change Touch and hold delay.*

Go to **Settings**, **Accessibility** and change **Touch and hold delay** in the timing section. It sets how long you need to press the screen before a long press action happens.

CHANGE THE DELAY

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Accessibility**
4. Tap **Timing controls**
5. Tap **Touch and hold delay**
6. Select the delay you want

WHICH SETTING TO PICK

- Choose a longer delay if you open menus or select items by accident.
- Choose a shorter delay if long presses feel slow, for example when selecting messages or notes.

The delay applies to long press actions in apps.

12. Troubleshooting

Low call volume or no data on US carriers

> *Usually a carrier restriction, not a fault. Activate the SIM in another phone first, prefer a physical SIM, set the APN manually, or move to T-Mobile or a T-Mobile-based carrier (Mint Mobile, Tello, US Mobile).*

WHY THIS HAPPENS

Kompakt is PTCRB and FCC certified for US networks. AT&T, Verizon and resellers on their networks keep lists of approved phones and can limit service for devices that are not on them. Symptoms: quiet calls or speaker, one side cannot hear, blocked data, missing SMS or picture messages, weak signal in good coverage. We do not recommend Kompakt on AT&T or Verizon.

TRY THESE FIRST

1. **Activate the SIM in another phone.** Put it in an approved phone, make a call and send a text, then move it back to Kompakt. This fixes most cases, though some owners have to repeat it.
2. **Use a physical SIM instead of eSIM.** Several owners resolved it this way.

3. **Set the APN manually.** Ask your carrier for BYOD APN settings and enter them under **Settings**, **Network & Internet**, **Mobile Network**, **Access Point Names**.
4. **Tell your carrier it is an unlocked, certified BYOD phone** and ask them to make sure your line is not restricted. Ask about their unlock or whitelisting policy.

IF NONE OF THAT WORKS

T-Mobile and carriers that use its network, such as Mint Mobile, Tello or US Mobile GSM, have far fewer reports of this issue. If you switch and the problem stays, write to us with your carrier, plan and IMEI and we will look at the device.

An OS update fails on Kompakt

> *Try the update again on a stable connection, check that downloads over mobile data are allowed, then restart. A factory reset is the last resort.*

Try the update again on a stable internet connection, check that downloads over mobile data are allowed if you are not on Wi-Fi, then restart Kompakt. A factory reset is the last resort.

TRY THESE STEPS IN ORDER

1. Check for the update again

1. Make sure Kompakt is connected to the internet
2. Press the **Control Center** button
3. Tap the **Settings** icon
4. Tap **Software Update**
5. If an update is available, tap **Update**

On MuditaOS K 1.1.x and older, find **Software Update** under **Settings**, **About**. From 1.2.0, it is in the main **Settings** list.

2. Check your connection

Use a stable Wi-Fi network if you can. Updates are large, and a weak signal can stop the download.

3. Allow downloads over mobile data

If you have no Wi-Fi, Kompakt needs permission to use mobile data:

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **Network & Internet**
4. Tap **Mobile Network**
5. Tap the Mobile data **Toggle switch** to allow Kompakt to use mobile data

4. Restart Kompakt

Hold the power button for 2 seconds, select the power off option, then press the power button to turn it on again. Try the update once more.

5. Factory reset, only as a last resort

A factory reset deletes everything on your phone. Your MuditaOS K version stays the same. Back up first with Mudita Center: under **Your Kompakt**, click **Overview**, then **Create backup**.

1. Press the **Control Center** button
2. Tap the **Settings** icon
3. Tap **System**
4. Tap **Factory Reset**
5. Tap **Factory Reset**
6. If you are sure you want to delete all your data, tap **Factory Reset**

STILL NOT WORKING?

Contact customer support and tell us your MuditaOS K version and at which point the update stops.

Ghost message sound with no notification

> *Update Kompakt first: older versions could play the tone for group messages they could not show. If it continues, the sound may come from an app you installed yourself.*

Update Kompakt first. Before MuditaOS K 1.4.0, group messages were not fully supported, so the phone could play the message tone and show an unread badge for a message you could not open. After updating, owners found those old messages appeared and could be deleted.

1. UPDATE MUDITAOS K

1. Make sure Kompakt is connected to the internet
2. Press the **Control Center** button
3. Tap the **Settings** icon
4. Tap **Software Update**
5. If an update is available, tap **Update**

MuditaOS K 1.4.0 added full group messaging, and 1.6.0 fixed duplicate notifications for texts that arrived after a group message.

2. CHECK APPS YOU INSTALLED YOURSELF

Kompakt has no notification tray. Apps you sideloaded, such as WhatsApp or Signal, can still play a sound, but nothing appears on screen. One owner found the sound was a WhatsApp status like, not a message. Open those apps to see what arrived, or turn off their notification sounds inside each app.

3. OTHER CAUSES OWNERS HAVE FOUND

- A sound right after you turn the phone on can come from the SD card being detected.
- Receiving a file over Bluetooth plays a system sound with nothing to tap.
- Some owners fixed ghost sounds by removing numbers from their blocked list. This can let spam through again, so try it only if the steps above do not help.

STILL HAPPENING?

Restart Kompakt. If the sound keeps coming with no message, contact customer support and tell us your MuditaOS K version and whether you use sideloaded apps.

How to do a factory reset on

Kompakt

> *Back up in Mudita Center first. Then Settings, System, Factory Reset, and confirm Factory Reset. Everything on the phone is deleted; your MuditaOS K version stays the same.*

BACK UP FIRST

A factory reset deletes everything on the phone. Your MuditaOS K version stays the same. Open Mudita Center, connect Kompakt, go to **Overview** and click **Create backup**. You can protect the backup with a password, but it cannot be changed or recovered later.

RESET FROM SETTINGS

1. Open the Control Center and tap **Settings**.
2. Tap **System**, then **Factory Reset**.
3. Tap **Factory Reset**.
4. If you are sure, tap **Factory Reset** again to confirm.
5. Kompakt restarts, ready to set up.

RESET FROM RECOVERY

Use this only when Kompakt does not start, for example if it is stuck in a loop at startup.

1. Power off the phone.
2. Hold **Power** and **Volume up** together until you see **Select Boot Mode**.

3. Press Volume up to move to **Recovery Mode**, then Volume down to choose it.
4. When you see a broken robot icon, hold **Power** and press **Volume up** once to open the recovery menu.
5. Use the volume buttons to move to **Wipe data/factory reset** and press **Power** to confirm.
6. Wait for the reset to finish.

AFTER THE RESET

Run the initial setup, then in Mudita Center go to **Overview**, **Restore from backup**, and pick your backup.

Files do not show when connecting Kompakt via USB-C

> *If you connect Kompakt to your computer but can’t see your files, you’ll need to allow file transfer.*

TO ALLOW FILE TRANSFER

1. Connect Kompakt to a computer with a USB-C cable
2. Press the **Control Center** button
3. Tap the **Settings** icon
4. Tap **Connected Devices**
5. Tap **USB Preferences***

6. Tap **File Transfer**

*If Kompakt isn’t connected to the computer, you won’t see this option!

I forgot my Kompakt PIN or screen pattern

> *If you forget your PIN or screen pattern, you will need to perform a factory reset to regain access. This erases all data on the phone.*

If you forget your PIN or screen pattern for the Mudita Kompakt, you will need to perform a factory reset to regain access.

This process will erase all data on the phone, so please be aware that any information not backed up will be lost.

FACTORY RESET PROCEDURE

1. Power off the phone
2. Hold Power and + Volume Up buttons together until you see the "Select Boot Mode" screen
3. Use the Volume Up button to scroll to "Recovery Mode", then click the Volume Down button to press "OK"
4. Once the screen shows a broken robot icon, press and hold the Power button, then click the Volume Up button once to open the Recovery menu

5. Use the Volume Up/Down buttons to scroll to "Wipe data/factory reset" and click the Power button to confirm
6. Wait for the factory reset to complete

Kompakt is stuck in a loop when it starts up

> *If your Mudita Kompakt is stuck in a loop when it starts up, you need to perform a factory reset. This erases all data on the phone.*

This process will erase all data on the phone, so please be aware that any information not backed up will be lost.

FACTORY RESET PROCEDURE

1. Power off the phone
2. Hold Power and + Volume Up buttons together until you see the "Select Boot Mode" screen
3. Use the Volume Up button to scroll to "Recovery Mode", then click the Volume Down button to press "OK"
4. Once the screen shows a broken robot icon, press and hold the Power button, then click the Volume Up button once to open the Recovery menu

5. Use the Volume Up/Down buttons to scroll to "Wipe data/factory reset" and click the Power button to confirm
6. Wait for the factory reset to complete

13. Calendar app

How to create a calendar event

> *Tap the date on the home screen, pick the day, tap the Plus icon, add a title and times, and tap Create.*

STEP BY STEP

1. Tap **today's date** on the home screen*
2. Tap the **left** and **right arrows** to select the month
3. Tap **the Day** you want your event on
4. Tap the **Plus** icon
5. Tap **Add Title** to customize the even name
6. Tap the **up** and **down arrows** to select the start time
7. Tap the **up** and **down arrows** to select the end time
8. Tap **Create**

*You can also unhide the app icon to enable access by tapping Apps > Calendar

14. Alarm app

How to create an alarm

> *Tap the clock on the home screen and tap Create an Alarm, or the Plus icon if you already have alarms.*

TO CREATE YOUR FIRST ALARM

1. Tap **the clock** on the home screen*
2. Tap **Create an Alarm**
3. You can edit name and sound and the days it repeats
4. Tap **Create**

TO ADD ADDITIONAL ALARMS

1. Tap **the clock** on the home screen*
2. Tap the **Plus** icon
3. You can edit name and sound and the days it repeats
4. Tap **Create**

How to edit an alarm

> *Tap the clock on the home screen, tap the alarm, change what you need and tap Save.*

STEP BY STEP

1. Tap **the clock** on the home screen*
2. Tap on the time Alarm you want to edit

3. Edit the time using the **up** and **down arrows** or using the keypad
4. You can edit name and sound and the days it repeats
5. Tap **Save**

How to delete an alarm

> *Tap the clock on the home screen, tap the Pencil icon, then the Delete icon.*

STEP BY STEP

1. Tap **the clock** on the home screen*
2. Tap the **Pencil** icon
3. Tap the **Delete** icon

How to snooze an alarm

> *Snooze is fixed to a 5 minute interval and is not automatic.*

TO SNOOZE THE ALARM

1. Wait until your alarm rings
2. Tap **Snooze**

*You can also unhide the app icon to enable access by tapping Apps > Alarm

How to manage alarms on Mudita

Kompakt

> *Tap the clock on the home screen to create and manage your alarms. The steps are below.*

HOW TO CREATE AN ALARM

To create your first alarm:

1. Tap **the clock** on the home screen*
2. Tap **Create an Alarm**
3. You can edit name and sound and the days it repeats
4. Tap **Create**

To add additional alarms:

1. Tap **the clock** on the home screen*
2. Tap the **Plus** icon
3. You can edit name and sound and the days it repeats
4. Tap **Create**

HOW TO EDIT AN ALARM

1. Tap **the clock** on the home screen*
2. Tap on the time Alarm you want to edit
3. Edit the time using the **up** and **down arrows** or using the keypad
4. You can edit name and sound and the days it repeats
5. Tap **Save**

HOW TO DELETE AN ALARM

1. Tap **the clock** on the home screen*
2. Tap the **Pencil** icon
3. Tap the **Delete** icon

HOW TO SNOOZE AN ALARM

Snooze is fixed to a 5 minute interval and is not automatic.

To snooze the alarm:

1. Wait until your alarm rings
2. Tap **Snooze**

*You can also unhide the app icon to enable access by tapping Apps > Alarm

15. Camera app

How to take a photo

> *Open Apps, then Camera, aim and tap the photo button.*

STEP BY STEP

1. Tap **Apps**
2. Tap **Camera**
3. Aim the camera at the object
4. Tap the **photo** button*

*As Kompakt has an E Ink display, you may need to hold the phone still for a little longer than a typical smart phone

How to view photos

> *You can only view photos on Kompakt in greyscale but when you transfer your photos to a computer you can view them in full color.*

STEP BY STEP

1. Tap **Apps**
2. Tap **Camera**
3. Tap the **Image** icon
4. Tap **the photo** you want to view

How to take a screenshot

> *Press the Power and Volume down buttons at the same time.*

STEP BY STEP

1. Press **Power** button and **Volume down** buttons at the same time*

*Currently there is no feedback that the screenshot was taken, but it will be there when you view your photos

How to use the camera and gallery on Mudita Kompakt

> *To take a photo, open Apps, then Camera. Photos show in greyscale on Kompakt and in full color on a computer.*

HOW TO TAKE A PHOTO

1. Tap **Apps**
2. Tap **Camera**
3. Aim the camera at the object
4. Tap the **photo** button*

*As Kompakt has an E Ink display, you may need to hold the phone still for a little longer than a typical smart phone

HOW TO VIEW PHOTOS

You can only view photos on Kompakt in greyscale but when you transfer your photos to a computer you can view them in full color.

1. Tap **Apps**
2. Tap **Camera**
3. Tap the **Image** icon
4. Tap **the photo** you want to view

HOW TO TAKE A SCREENSHOT

1. Press **Power** button and **Volume down** buttons at the same time*

*Currently there is no feedback that the screenshot was taken, but it will be there when you view your photos

16. Notes app

How to delete notes

> *In Notes, tap the Edit icon, tick the notes and tap Delete.*

STEP BY STEP

1. Tap **Apps**
2. Tap **Notes**
3. Tap the **Edit** icon
4. Tap the **Check box** to select the note(s) you want to delete
5. Tap **Delete**
6. Tap **Delete**

How to create notes

> *Open Apps, then Notes, tap the Plus icon, write a title and your note, and tap Done.*

1. Tap **Apps**
2. Tap **Notes**
3. Tap the **Plus** icon*
4. Write a title for your note (max. 54 characters)
5. Tap **Enter** on the keyboard
6. Write more detail for your note
7. Tap **Done**

***IF IT IS YOUR FIRST NOTE, TAP CREATE NEW NOTE**

17. Maps app

How to plan a route

> *Open Maps, choose a destination by searching or tapping the map, and start navigation. The route always starts from your current location.*

Open **Maps**, choose a destination by searching or tapping on the map, then start navigation. The route always starts from your current location, so Kompakt needs a GPS fix.

BEFORE YOU START

- Download the maps for every area on the route. Maps tells you if one is missing and shows its size before you download it.
- Turn on location sharing for Maps: **Settings**, **Location Sharing**.
- Go outside or near a window. Kompakt uses satellite GPS only, so a first fix can take a while indoors or between tall buildings. Turning on A-GPS in settings (MuditaOS K 1.5.0 and newer) makes it faster.

PLAN THE ROUTE

1. Tap **Apps**
2. Tap **Maps**

3. Search for your destination, or tap the place on the map
4. Add up to 3 stops along the way if you need them
5. Choose **Walking**, **Cycling** or **Driving**. Driving is the default from MuditaOS K 1.6.
6. Start navigation

WHILE YOU NAVIGATE

- There are two modes: **Map Navigation Mode**, the default, and **Step-by-Step Mode**. Both have voice guidance in 8 languages.
- The map can turn to match your direction of travel. You can move it around and recentre it on your position.
- If a long route takes too long to calculate, Maps tells you and lets you cancel or change it.
- GPS navigation uses a lot of battery. Charge before a long trip.

You cannot set a different starting point at the moment. Routes always begin where you are.

How to delete a map

> *In Maps, open the Menu, then Manage Maps, tap the Edit icon and delete the map.*

STEP BY STEP

1. Tap **Apps**
2. Tap **Maps**
3. Tap the **Menu** icon
4. Tap **Manage Maps**
5. Tap the **Edit** icon
6. Tap the **Delete** icon for the map you want to delete
7. Tap **Delete Map**

How to change where maps are stored

> *In Maps, open the Menu icon, then Settings, Storage, and choose SD Card.*

In **Maps**, tap the **Menu** icon, then **Settings**, **Storage**, and choose **SD Card**. Country maps can be large, so the SD card keeps space free on the phone.

CHANGE THE STORAGE LOCATION

1. Insert a microSD card if there is none yet
2. Tap **Apps**
3. Tap **Maps**
4. Tap the **Menu** icon
5. Tap **Settings**
6. Tap **Storage**

7. Tap **SD Card**

Maps you download after switching are saved to the SD card. If a map is missing, download it again.

MAKE ROOM FIRST IF YOU ARE OUT OF SPACE

If a download failed because of low space, delete maps you do not need, then download them again after you switch to the SD card.

1. Tap **Apps**
2. Tap **Maps**
3. Tap the **Menu** icon
4. Tap **Manage Maps**
5. Tap the **Edit** icon
6. Tap the **Delete** icon for the map you want to delete
7. Tap **Delete Map**

Maps shows the size of each map before you download it, so you can check it fits.

How to download a map

> *To view a region or country on the maps app, you will need to download the map. This requires an internet connection.*

Once you have downloaded the map, you won’t need the internet to search or view the

map.

TO DOWNLOAD A MAP

1. Tap **Apps**
2. Tap **Maps** > Tap **Continue***
3. Tap the **Menu** icon
4. Tap **Manage Maps**
5. Tap the **Search** icon**
6. Enter the country or region name of the map you want
7. Tap the **Download** icon

***ONLY WHEN USING MAPS FOR THE FIRST TIME**

****OR TAP ALL MAPS AND SELECT THE REGION YOU WANT**

18. Weather app

How to change the weather default location

> *In the Weather app, open the Menu, tap the Pencil icon and choose a new default location.*

1. Open the **Weather** app
2. Tap the **Menu** icon
3. Tap the **Pencil** icon
4. Select the current default location
5. Either search for the location you want or tap **Use your current location***
6. Tap **Done**

*** YOU MAY NEED TO MANAGE LOCATION SHARING IN SETTINGS**

How to open the weather app

> *Press the Control Center button and tap the Weather widget.*

STEP BY STEP

1. Press the **Control Center** button
2. Tap **Weather** widget*

*You can also unhide the app icon to enable access by tapping Apps > Weather

19. Managing files

How to transfer photos to Kompakt

> *You can easily transfer photos to your Kompakt using Mudita Center. Follow the steps below to upload your images*

STEP BY STEP

1. Open Mudita Center and connect your Kompakt to your computer.
2. Under Your Kompakt, click Manage Files.
3. Select the Photos tab.
4. Click Add file.
5. Browse your computer and select the image files you want to upload.
6. Confirm the transfer to copy the selected photos to your Kompakt.

How to transfer music to Kompakt

> *You can easily transfer music to your Kompakt using Mudita Center. Follow the steps below to upload your audio files*

STEP BY STEP

1. Open Mudita Center and connect your Kompakt to your computer.
2. Under Your Kompakt, click Manage Files.
3. Select the Music tab.

4. Click Add file.
5. Browse your computer and select the audio files you want to upload.
6. Confirm the transfer to copy the selected music files to your Kompakt.

Important: If a file format is not supported by Kompakt, you won't be able to select or upload it

How to transfer e-books to Kompakt

> *You can easily transfer e-books to your Kompakt using Mudita Center. Follow the steps below to upload your e-book files*

STEP BY STEP

1. Open Mudita Center and connect your Kompakt to your computer.
2. Under Your Kompakt, click Manage Files.
3. Select the E-books tab.
4. Click Add file.
5. Browse your computer and select the e-book files you want to upload.
6. Confirm the transfer to copy the selected e-books to your Kompakt.

Important: If a file format is not supported by Kompakt, you won't be able to select or upload

it.

How to delete files from Kompakt

> *You can easily delete files from your Kompakt using Mudita Center. Follow the steps below to remove unwanted content*

STEP BY STEP

1. Open Mudita Center and connect your Kompakt to your computer.
2. Under Your Kompakt, click Manage (Music, Photos, or E-books).
3. Navigate to the files you want to delete.
4. Select the files using the checkbox.
    - To select all files, click the minus icon checkbox at the top of the screen.
5. Click Delete.
6. Confirm by clicking Delete file.

How do I transfer photos from Kompakt to my computer?

> *You can currently transfer photos using Windows File Manager or by sending MMS messages. Connect over USB-C, open the DCIM folder and copy the photos to your computer.*

You can currently transfer photos using Windows File Manager or by sending MMS messages.

To transfer photos using Windows:

1. Connect Kompakt to a computer with a USB-C cable*
2. Access Kompakt's files
3. Open the DCIM folder**
4. Select the photos you want to transfer and copy them to your computer

* If files don't show when connecting Kompakt, you need to allow file transfer.

** For screenshots, open the Pictures folder.

Meditation Cards for Kompakt

> *The Meditation Cards are e-books (.epub) in eight languages. Download your language and copy the file to Kompakt to read it in the E-reader app.*

The Meditation Cards come as .epub files, the format the Kompakt E-reader app opens.

DOWNLOAD THE MEDITATION CARDS

Language	File
English	EPUB, 126 KB
Polish	EPUB, 135 KB

German	EPUB, 230 KB
Spanish	EPUB, 131 KB
French	EPUB, 133 KB
Portuguese	EPUB, 131 KB
Dutch	EPUB, 132 KB
Italian	EPUB, 128 KB

PUT THEM ON KOMPAKT

Copy the .epub file to Kompakt the same way as any other e-book. See How to transfer e-books to Kompakt.

20. Backup and restore

How to create a backup for Kompakt

> *In Mudita Center, open Your Kompakt, then Overview, and click Create backup. You protect the backup with a password.*

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Overview**
3. Click **Create backup**
4. Click **Create backup** to confirm
5. Create a password to protect your backup data*
6. Click **Confirm passcode**
7. Enter your passcode to create the backup

*Warning! You can not change the password after you confirm it.

IF YOU DON’T WANT A PASSWORD, CLICK SKIP PASSWORD TO CREATE THE BACKUP

How to find the backup file to restore Kompakt

> *In Mudita Center, open Settings. It shows the folder on your computer where backups are saved.*

STEP BY STEP

1. Open Mudita Center and connect your device
2. Look under **Mudita Center** > Click **Settings***
3. You will see the file path (Example: C:/User/Documents/Mudita/Kompakt/backup)
4. Follow the file path using your computer’s browser

*The backup tab opens by default, if it does not, click Backup at the top of the screen

How to restore Kompakt from a backup

> *In Mudita Center, open Your Kompakt, then Overview, click Restore from backup and pick the backup you want.*

STEP BY STEP

1. Open Mudita Center and connect your device
2. Look under **Your Kompakt** > Click **Overview**
3. Click **Restore from backup**
4. Select the Backup you want to restore from the list
5. Click **Restore from backup**
6. Enter the password protecting the backup*
7. Click **Confirm**

*Warning! There is no way to recover or change the password for backups.

If no password was created, you will skip this step and start the restore process

21. Voice recorder

How to record a voice recording

> *To record a voice recording on your device, follow these steps. See below.*

STEP BY STEP

1. Tap Apps
2. Tap Recorder
3. Tap the Record button to start recording
4. Tap the Pause button to pause the recording
5. Tap Done to stop recording
6. Tap New recording to add a title
7. Tap Done to save your recording

How to listen to a voice recording

> *Listening to a voice recording on your device is quick and easy. Follow the steps below to access and play your recordings*

STEP BY STEP

1. Tap Apps
2. Tap Recorder
3. Tap the Menu icon
4. Select the recording you want to listen to
5. Tap the Play button to start playback
6. Tap Done to close the recording screen

How to delete voice recordings

> *You can delete individual recordings or multiple recordings at the same time*

TO DELETE A SINGLE VOICE RECORDING

1. Tap Apps.
2. Tap Recorder.
3. Tap the Menu icon.
4. Select the recording you want to delete.
5. Tap the Bin icon.
6. Tap Delete.

TO DELETE MANY VOICE RECORDINGS

1. Tap Apps.
2. Tap Recorder.
3. Tap the Menu icon.
4. Tap the Pencil (Edit) icon.
5. Select the check boxes next to the recordings you want to delete.
6. Tap Delete.
7. Tap Delete again to confirm.

22. Safety

Safety in brief

> *The main warnings from the printed manual, shortened. The full text is in the manual on Mudita's quick start page.*

GENERAL

- Don't drop, strike or shake it hard, and don't leave it in direct sun.
- Not waterproof: don't use it in the bath or in wet places, and don't handle it with wet hands while it charges.
- Don't take it apart. Only authorized service should repair it. If you think the phone or battery is damaged, stop using it.
- Keep the packaging away from children.

HEARING

Long listening at high volume can damage your hearing. Background noise makes sound seem quieter than it is. Start playback and check the volume before putting anything in your ears.

MEDICAL DEVICES

Kompakt has magnets and radios that may interfere with medical devices. Ask your doctor or the device's maker.

RADIO EXPOSURE

- Kompakt gives off radio waves while it runs, except in Offline+.
- Keep some distance between the phone and your body, especially when you aren't using it, and use the speaker or headphones when you can.

AROUND YOU

- Don't use a hand-held phone while driving or running machinery, or headphones while cycling.
- Follow rules where phones are restricted, on planes and in places with explosive atmospheres (the phone may spark).

BATTERY AND CABLE

- Don't bend, twist, pull, heat, crush or sit on the cable. Stop using a damaged cable or a loose plug.
- Keep the charger out of direct sun and damp rooms like bathrooms. Unplug during lightning storms.
- Keep sharp things (nails, teeth) away from the battery. If the phone bulges, smells, makes noise or gets too hot to touch, switch it off, unplug it and stop using it.
- If the battery leaks, keep it off skin and eyes, rinse with plenty of water and see a

doctor.

- Don't throw the phone or battery in household waste or fire. Take it to an electronics recycling point.

23. Appendix: networks and radios

Supported bands

> *Check these against your carrier's bands before you buy a SIM or travel.*

GLOBAL VERSION

2G (GSM)	850, 900, 1800 MHz
3G (WCDMA)	Bands 1 (2100), 5 (850), 8 (900)
4G (LTE)	Bands 1, 3, 5, 7, 8, 12, 13, 18, 19, 20, 26, 34, 38, 39, 40, 41
Wi-Fi	802.11 b/g/n (2.4 GHz), a/n/ac (5 GHz)
Bluetooth	Yes (2.4 GHz)
NFC	Yes
Wireless charging	Yes (10 W)

NORTH AMERICAN (NAM) VERSION

4G (LTE)	Bands 2, 4, 5, 7, 8, 12, 13, 17, 18, 19, 25, 26, 34, 38, 40, 41, 66, 71
2G / 3G	Not listed in the manual
Wi-Fi	802.11 b/g/n (2.4 GHz), a/n/ac (5 GHz)
Bluetooth	Yes (2.4 GHz)

NFC	Yes
Wireless charging	Yes (receive)
FM radio	Receive, 87.5–108 MHz

From the frequency tables in Mudita's printed manual (version 04). The manual also lists the maximum power output for each band.