

2-Tier Hexagonal Rotating Garment Rack

Assembly Instructions | Applies to 57.1 in and 70.9 in models | Adult assembly recommended

Before you begin

Assemble on a clean, level surface. Keep the rack unloaded during assembly. Sort the tubes and connectors by length and shape before joining them. No screws are shown in the available product configuration; joints are assembled by fully seating the tubes in their matching connectors.

High-quality material
hard-wearing & durable



Assembly Steps

1

Lay out the components

Place all tubes, corner connectors and casters on the floor. Match tubes of the same length. Do not force mismatched parts.

2

Build the lower hexagonal base

Insert the horizontal base tubes into the lower corner connectors to form an even hexagon. Push every tube fully into its socket.

3

Install and lock the casters

Press each caster stem into the bottom socket until fully seated. Engage the wheel locks before continuing.

4

Insert the vertical supports

Fit the vertical tubes into the base connectors. Keep all supports upright and at the same insertion depth.

5

Add the middle and upper hanging frames

Assemble each hexagonal hanging ring with matching horizontal tubes and connectors. Seat the middle tier first, then complete the top frame.

6

Square, test and secure

Stand the rack upright. Press all joints again, confirm the frame is level, then test movement while unloaded. Lock the casters before adding garments.

Safety Check Before Use

- Confirm every tube is fully inserted.
- Keep all casters locked when the rack is stationary.
- Distribute garments evenly around both tiers.
- Do not climb, sit, lean or hang from the rack.
- Keep children away during assembly.
- Do not exceed the manufacturer-rated load.

Final Appearance and Model Reference

The same assembly sequence applies to both model heights. Tube lengths and final tier spacing vary by model.

	
70.9 in model Approx. 31.5 W x 31.5 D x 70.9 H in	57.1 in model Approx. 31.9 W x 31.9 D x 57.1 H in

After Assembly

Check	Required result
Frame	Hexagonal base and hanging tiers are even, level and not visibly twisted.
Connections	Every tube is inserted to the same depth; no connector is cracked or loose.
Casters	Each caster is fully seated; locks hold the unloaded rack in place.
Rotation and movement	Move or rotate the unloaded rack slowly; stop use if any joint separates.
Loading	Add garments gradually and distribute weight evenly around the frame.

Care

Wipe with a soft damp cloth and dry promptly. Do not use abrasive cleaners. Periodically recheck tube connections and caster seating, especially after moving the rack.