pve-fcsan Runbook

Version 1.3.0

Purpose and scope

`pvesan` (Debian package `pve-fcsan`) gives Proxmox VE the SAN storage workflow vCenter has: list HBAs, rescan, manage LUNs and paths, and create, grow, rename, mount, unmount, reclaim and delete shared datastores on Fibre Channel LUNs. With an array driver it also creates and maps the volume on the array. You can use it from the web GUI (**Node → Disks → SAN / Fibre Channel**), from the `pvesan` CLI, or through the REST API under `/nodes/{node}/san`.

A pvesan *datastore* is a shared thick LVM volume group on one or more multipathed LUNs. It is registered in `/etc/pve/storage.cfg` as storage type `fcsan`, a subclass of Proxmox's built-in LVM plugin, so live migration and HA work the same way they do on shared LVM. iSCSI LUNs also show up in the device lists and work the same way, but FC is the main target.

vCenter action	pvesan GUI	pvesan CLI
Rescan Storage	Adapters → Rescan / Rescan all nodes	`pvesan rescan` / `pvesan rescan-all`
Storage Adapters view	Adapters tab	`pvesan adapters`
Storage Devices view	Devices tab	`pvesan devices`
Paths view, path state	Paths tab	`pvesan paths`
Edit Multipathing (Fixed / MRU / Round Robin)	Devices → Properties → Path policy	`pvesan device set <wwid> --policy ...`
Device display name	Devices → Properties → Alias	`pvesan device set <wwid> --alias ...`
New Datastore (VMFS)	Datastores → Create	`pvesan datastore create`
Increase Datastore Capacity (grow LUN)	Datastores → Increase capacity	`pvesan datastore extend <id>`

vCenter action	pvesan GUI	pvesan CLI
Increase Capacity (add extent)	Datastores → Increase capacity → Add LUN	`pvesan datastore extend <id> --add-devices ...`
Rename datastore	Datastores → Rename	`pvesan datastore rename <id> --label ...` (or `--new-id`)
Unmount / Mount datastore	Datastores → Unmount / Mount	`pvesan datastore unmount` / `mount`
Delete datastore	Datastores → Delete	`pvesan datastore delete <id>`
Detach / Attach device	Devices → Detach / Attach	`pvesan device detach` / `attach`
Reclaim space (UNMAP)	Datastores → Reclaim	`pvesan datastore reclaim <id>`
Remove dead paths after unmap	Devices → Clean up dead paths	`pvesan device cleanup`
Array plugin: new datastore on a new volume	Arrays → Provision datastore	`pvesan provision <array> <id> ...`

Not in scope: you can't shrink a datastore (vCenter can't either), there is no Storage I/O Control, and there is no automatic resignaturing of snapshot LUNs. The troubleshooting section gives a manual resignature procedure.

Prerequisites

Every cluster node needs the same LUNs, presented the same way, before pvesan can build a datastore. pvesan checks this and refuses to create a datastore on a LUN that some node can't see.

Software

- Proxmox VE 8.x or 9.x on every node, all on the same pve-fcsan version.
- `multipath-tools` and `lvm2`. The package pulls them in.
- `multipathd` enabled: `systemctl enable --now multipathd`.

Fabric and array

1. Zone each node's HBA ports (WWPNs) to the array target ports. Single-initiator zoning is best practice. Get the WWPNs with `pvesan adapters` or from the GUI **Adapters** tab.
2. Put every node's WWPNs in one host group / host cluster on the array, with the same LUN ID on every node. With an array driver, pvesan does this for you (P12).
3. Turn on ALUA on the array if it supports it.
4. Use thin LUNs with UNMAP turned on if you want space reclaim.

Multipath base configuration

pvesan writes only `/etc/multipath/conf.d/pvesan.conf` and `/etc/multipath/wwids`. Keep `/etc/multipath.conf` identical on every node. A good starting point:

```
defaults {
    find_multipaths     strict
    user_friendly_names no
    polling_interval    5
    path_selector       "service-time 0"
}
```

Add the `devices { }` settings from your array vendor's Linux host guide. Don't list pvesan-managed WWIDs in a `multipaths { }` section there, because two sections for the same WWID conflict. `user_friendly_names no` matters: map names must be the same on every node.

LVM

- Leave `devices/multipath_component_detection = 1` as it is (the default). It stops LVM from using the raw `sdX` paths.
- If `use_devicesfile = 1` is set, pvesan adds each datastore's `/dev/mapper` device to the devices file on every node for you.
- Optional: set `devices/issue_discards = 1` in `/etc/lvm/lvm.conf` on every node. Space from deleted VM disks then goes back to a thin array right away, like VMFS6 automatic UNMAP.

Permissions

Action	Required privilege
View adapters, devices, paths, datastores	`Sys.Audit` on `/nodes/{node}`

Action	Required privilege
Rescan, clean up paths on one node	`Sys.Modify` on `/nodes/{node}`
Any cluster-wide action (datastores, aliases, policies, detach, rescan all, arrays)	`Sys.Modify` on `/` and `Datastore.Allocate` on `/storage`

Installation, upgrade, uninstall

Install the same `pve-fcsan` .deb on every node. A node without it can't read `fcsan` entries in `storage.cfg`.

Get the package. Download it from the project's GitHub releases, or build it on any Debian 12/13 machine or Proxmox node:

```
apt install build-essential debhelper git
git clone <repository-url> pve-fcsan
cd pve-fcsan
make test
make deb
```

Install on each node, one at a time:

```
apt install ./pve-fcsan_1.3.0_all.deb
/usr/share/pve-fcsan/pvesan-integrate status
pvesan adapters
```

The status command should report both `Nodes.pm` and `index.html.tpl` as `integrated`. Reload the browser with Ctrl+F5, then open **Node → Disks → SAN / Fibre Channel**.

Installing does four things:

1. Installs the storage plugin to `/usr/share/perl5/PVE/Storage/Custom/FCSANPlugin.pm`.
2. Adds one marked line each to `PVE/API2/Nodes.pm` (API) and `index.html.tpl` (GUI). If `Nodes.pm` doesn't compile with the line added, the change is reverted.
3. Enables `pvesan-sync.service`. At boot it applies the cluster-wide aliases, policies and detached-LUN list before guests start.
4. Reloads `pvedaemon`, `pveproxy` and `pvestatd`.

Upgrading Proxmox VE. A pve-manager upgrade replaces `Nodes.pm` and `index.html.tpl`. A dpkg trigger re-runs the integration and reloads the services on its own. After any Proxmox VE upgrade, check:

```
/usr/share/pve-fcsan/pvesan-integrate status
```

If it says `NOT integrated`, run `/usr/share/pve-fcsan/pvesan-integrate apply` and read the reason it prints. The storage plugin and existing datastores keep working without the integration; only the GUI panel and the `/san` API go away until it is fixed.

Uninstall. Package removal is blocked while `fcsan` storages exist, because Proxmox VE would otherwise drop them and guests would fail to start. Convert each one to plain LVM first; the data and the VG stay as they are.

1. Edit `/etc/pve/storage.cfg` on any node. Change `fcsan: <id>` to `lvm: <id>` and delete the `fc-wwids` and `fc-autorescan` lines.
2. Run `apt remove pve-fcsan` on every node. Use `apt purge` to also remove `/etc/multipath/conf.d/pvesan.conf`.
3. If you still want the aliases after a purge, copy them into `/etc/multipath.conf`.

Procedures

All cluster-wide actions run as a task on the node you issue them from, which then drives every online node. The task log, in the GUI task list or on CLI stdout, prints a `[node]` line for each step. You can run every procedure from any node.

P1. Rescan storage

Use this after you present, unpresent or grow LUNs on the array.

- **GUI:** SAN → Adapters → **Rescan all nodes**.
- **CLI:** `pvesan rescan-all`, or `pvesan rescan` for this node only.

A rescan scans every FC and iSCSI host for new targets and LUNs and re-reads the capacity of existing LUNs. It also resizes any multipath map whose LUN grew, and removes paths of detached LUNs again.

Use **Rescan with LIP** (`--lip 1`) only when the fabric doesn't show new targets. A LIP logs each port in to the fabric again and pauses I/O on that port for a moment. pvesan does one port at a time, so multipath keeps I/O running on the other ports.

P2. Add a new LUN

1. On the array, map the LUN to the host group that holds every node.
2. Run P1 (rescan all nodes).
3. Go to SAN → Devices. The LUN shows with usage `free` and the flag `not multipathed`.
4. Optional: select it and click **Add (multipath)**, or run `pvesan device add <wwid> --alias <name>`. Creating a datastore does this for you.

P3. Alias and path policy

Select the LUN, then **Properties**, or run:

```
pvesan device set <wwid> --alias ds-gold-01 --policy alua
```

Policy	vSphere equivalent	Use for
`alua`	RR on an ALUA array	Most modern arrays
`round-robin`	VMW_PSP_RR	Active/active arrays without ALUA
`mru`	VMW_PSP_MRU	Active/passive arrays that must not fail back
`fixed`	VMW_PSP_FIXED	One preferred path, fail back when it returns
`array-default`	SATP default	Settings from multipath-tools' built-in array table

Changes apply on every node at once with `multipathd reconfigure`, with no I/O outage. Changing an alias renames the `/dev/mapper` device of a LUN in use; LVM tracks devices by number, so running guests aren't affected.

P4. Create a datastore

- **GUI:** SAN → Datastores → **Create**. Enter an ID, an optional display name, content and node restriction, then tick one or more unused LUNs.
- **CLI:**

```
pvesan datastore create ds1 --devices 3600a098038303053453f463045727a41 --
label "Gold tier 01"
```

pvesan checks that every target node sees each LUN with at least one active path (and warns about single-path LUNs), then that the LUN is free on the local node. Existing partition tables or filesystem signatures need `--force 1` (**Wipe LUNs** in the GUI). LUNs that hold a volume group are always refused.

It then registers an alias for each LUN (`ds1`, or `ds1-00`, `ds1-01` for several), applies it on all nodes, runs `pvcreate` and `vgcreate san_ds1`, and registers storage `ds1` of type `fcsan`, shared, with content `images,rootdir`. If any step fails, the LVM changes are rolled back. Check the result with `pvesm status`.

P5. Increase capacity

Grow a LUN: grow it on the array, then run `pvesan datastore extend ds1` (GUI: **Increase capacity → Expand**). On every node, pvesan re-reads the LUN size on each path and resizes the multipath map. It aborts if the nodes report different sizes, then runs `pvresize` under the cluster storage lock.

Add an extent:

```
pvesan datastore extend ds1 --add-devices <wwid>
```

The new LUN goes through the same checks as in P4 and is added with `vgextend`. As with VMFS extents, if any extent LUN fails, the whole datastore fails.

For array-linked datastores, see P12: one step grows the volume on the array and the datastore.

P6. Rename a datastore

- **Display name** (online, cosmetic): `pvesan datastore rename ds1 --label "Gold tier"`.
- **Storage ID** (maintenance window): `pvesan datastore rename ds1 --new-id gold01 [--rename-vg 1]`.

Before an ID rename, stop every guest whose config refers to `ds1:` and make sure every node is online. pvesan deactivates the VG on all nodes, renames the `storage.cfg` entry, optionally renames the VG to `san_gold01`, and rewrites all guest configs, snapshots included. Update backup jobs or scripts that use the old ID by hand.

P7. Unmount and mount

- **Unmount from some nodes:** `pvesan datastore unmount ds1 --nodes <node>` removes the nodes from the storage's `nodes` list and deactivates the VG there.
- **Unmount everywhere:** `pvesan datastore unmount ds1` disables the storage and deactivates the VG on every node.
- **Mount:** `pvesan datastore mount ds1 [--nodes <node>]` re-enables the storage or adds the nodes back, then activates it on each node.

Unmount is refused while guests that use the datastore are running on the target nodes.

P8. Reclaim space (UNMAP)

The Datastores **UNMAP** column shows whether every backing LUN supports discard. To reclaim:

```
pvesan datastore reclaim ds1 --reserve 100
```

pvesan allocates the free space, except the reserve in GiB, as a temporary LV, discards it, and removes it. New disks can only use the reserve while this runs, so run it outside busy periods. If a reclaim is ever interrupted, remove the leftover LV with `lvremove san_ds1/pvesan_reclaim`.

P9. Delete a datastore and retire its LUNs

1. Move or delete every guest disk on it. pvesan refuses while any guest config refers to it.
2. In the GUI, click **Delete** and type the ID, or run `pvesan datastore delete ds1 --detach 1`. Add `--destroy-data 1` to remove volumes no guest refers to.
3. pvesan deactivates the VG on all nodes, removes the storage, runs `vgremove`, `pvremove` and `wipefs`, and with `--detach` detaches the LUNs.
4. Unmap the LUNs on the array (or use P12's delete-with-volume).
5. Run P1, then `pvesan device cleanup` on each node to drop any leftover dead paths.

P10. Detach and attach a LUN

Detach is only allowed for unused LUNs. `pvesan device detach <wwid>` blacklists the WWID on every node, flushes the map and deletes every SCSI path; later rescans remove the paths again until you run `pvesan device attach <wwid>`. Always detach before you

unmap a LUN on the array: unmapping an attached LUN leaves dead paths, and with `queue_if_no_path` it can hang I/O.

P11. Node maintenance

After a node reboots, `pvesan-sync.service` applies the cluster SAN config before `pvestatd` and the guests start. If a datastore's LUN is missing when Proxmox VE activates it, the `fcsan` plugin rescans the SAN on that node by itself, at most once every 5 minutes per datastore. To turn that off: `pvesm set ds1 --fc-autorescan 0`.

P12. Array integration (provisioning)

With an array driver, pvesan drives the array itself, the way the Pure Storage and INFINIDAT vSphere plugins do: one task creates the volume, maps it to the cluster, rescans and builds the datastore.

One-time setup

1. On the array, create a dedicated API user with the role listed for your array below.
2. Zone every node's FC ports to the array. **SAN → Adapters** lists the WWPNs.
3. In **SAN → Arrays → Add**, choose the type, enter an ID, the management address and the credentials, plus any extra settings the type needs.
4. Click **Fetch** and compare the SHA-256 certificate fingerprint with the one in the array's management GUI. Confirm it only if it matches. pvesan pins this fingerprint and refuses any other certificate. The connection and login are tested before anything is saved, and the secret is stored root-only in `/etc/pve/priv/pvesan/`.
5. Select the array, open **Registration**, and click **Register cluster on array**. pvesan creates one host per node with its WWPNs (or reuses a host that already owns them) and puts them in a host cluster named after the Proxmox cluster, unless you set another name. Every node should then show **Registered**.

Provision a datastore

Open **SAN → Arrays → Provision datastore** (or **Datastores → Provision from array**). Pick the array, pool, size, thin or thick, and a datastore ID. One task then:

1. Checks the cluster registration.
2. Creates the volume.
3. Maps it to the cluster's host cluster.
4. Rescans all nodes until every node sees the LUN (timeout 120 s).

5. Sets the path policy (the vendor's recommendation unless you choose one) and creates the datastore.

If step 3, 4 or 5 fails, the task unmaps and deletes the new volume again.

CLI equivalent:

```
pvesan array probe 192.0.2.10 --type ibm-sv
pvesan array add fs01 --type ibm-sv --address 192.0.2.10 --username pvesan --
fingerprint 'sha256$...'
pvesan array register-cluster fs01
pvesan provision fs01 gold01 --pool Pool0 --size 2048 --thin 1 --label "Gold
01"
```

`pvesan array add` and `array set` prompt for the password, so it never appears on the command line or in shell history.

Grow, delete, link

- **Grow:** for an array datastore, **Datastores → Increase capacity** asks for the new size in GiB. pvesan expands the volume on the array, every node re-reads the LUN, and the datastore grows (`pvesan datastore array-grow gold01 --size 4096`).
- **Delete:** the delete dialog has **Also unmap and delete the volume on the array**. Without it, the datastore is removed and the LUN is detached, but the volume stays on the array.
- **Link:** a datastore created by hand can be linked to its array with **Arrays → Link datastore**; pvesan finds its volumes by UID, and grow and delete then work as above.

Supported arrays

Array	`--type`	Port	Credentials	Extra settings	Cluster object pvesan creates	Pool	Notes
IBM FlashSystem / Spectrum Virtualize	`ibm-sv`	7443	User, Administrator role	—	Host cluster	Pool	Default path policy `alua`
Pure Storage FlashArray	`pure`	443	API token of a Storage Admin user (no username)	—	Host group	`default`	Always thin; deleted volumes recoverable until eradicated
INFINIDAT InfiniBox	`infinidat`	443	User, Pool Admin or Admin	—	Cluster	Pool	Thin or thick
Dell PowerStore	`dell-powerstore`	443	User, Storage Administrator	—	Host group	`default`	Always thin

Array	`--type`	Port	Credentials	Extra settings	Cluster object pvesan creates	Pool	Notes
Dell PowerMax / VMAX	`dell-powermax`	8443 (Unisphere)	Unisphere user, StorageAdmin	`--system-id` (Symmetrix ID), `--portgroup` (required); `--srp`, `--slo`	Host group, storage group `<cluster>_SG`, masking view `<cluster>_MV`	The SRP of `<cluster>_SG`	Create a port group of the zoned array FC ports first
NetApp ONTAP (AFF / ASA / FAS)	`netapp-ontap`	443	Cluster or SVM admin with REST access	`--svm` (required)	FCP igroup	Aggregate	One FlexVol (`/vol/<name>/lun0`) per datastore; names use `_` instead of `-`
NetApp E-Series	`netapp-eseries`	8443	Storage admin	`--system-id` (default `1`)	Host group	Pool / DDP	Thick volumes only; names up to 30 characters
Hitachi VSP	`hitachi-vsp`	443 (embedded) or your Configuration Manager port	Storage Administrator (Provisioning)	`--target-ports` (required, e.g. `CL1-A,CL2-A`); `--system-id`	One host group per target port (host mode LINUX/IRIX)	DP pool	LU path on every target port; WWID known after mapping

First use with a new array type: before your first production datastore, provision and delete a 10 GiB test datastore. Every driver's calls were checked against the vendor's own SDK or tooling, but real-array results are still being collected. If a step fails, the task log shows the array's own error code; please report it.

Troubleshooting and recovery

Start from the task log. Every cluster-wide step prints `[node] FAILED: <reason>`, and that reason is the stderr of the LVM or multipath command, or the array's error message.

Symptom	Likely cause	Fix
`LUN ... not visible` on create or extend	The node isn't zoned, or its WWPN isn't in the array host group	Fix zoning or masking, run P1, try again
`nodes disagree about the size` on extend	Some nodes still see the old capacity, or the LUN ID differs per node	Run P1 on all nodes; check every node maps the same LUN
Datastore `inactive`, `backing LUN(s) not present`	The LUN was unmapped or the paths are down on that node	`pvesan paths`, `pvesan adapters`; fix the fabric, then `pvesan rescan`

Symptom	Likely cause	Fix
Device flag `not multipathed` on a datastore LUN	The node was offline when the datastore was created	`pvesan sync` on that node (also runs at boot)
`Found duplicate PV` warnings	LVM sees the raw `sdX` paths	Make sure `multipath_component_detection = 1`, then `pvesan sync`
Paths `faulty` or `offline` after an array change	The LUN was unmapped before it was detached	`pvesan device cleanup`; if the map is still open, stop what uses it first
Device flag `resize pending`	The LUN grew but the map didn't	`pvesan datastore extend <id>` or `pvesan device refresh <wwid>`
GUI panel missing after a Proxmox VE update	The integration was overwritten and the trigger failed	`/usr/share/pve-fcsan/pvesan-integrate apply`, then Ctrl+F5
`'<name>'-locked command timed out`	A cluster lock was held for more than 60 s	Retry; report it if it happens again
Array step fails	Credentials, role, certificate or array state	Read the array error code in the task log; check the user's role and `pvesan array status <id>`

Useful commands

```
multipath -ll
multipathd show paths format "%d %t %T %o %p %m"
pvs; vgs; lvs
cat /etc/multipath/conf.d/pvesan.conf
cat /etc/pve/pvesan/config.json
journalctl -u pvesan-sync -u multipathd -b
```

Mount a snapshot or replica LUN (manual resignature). A copy of a datastore LUN carries the same VG name and PV UUIDs as the original, so don't present it to nodes that see the original until it has a new identity. On one node:

1. Present the copy, then run `pvesan rescan` and `pvesan device add <copy-wwid> --alias ds1-snap`.

2. Run `vgimportclone --basevgname san_ds1_snap /dev/mapper/ds1-snap` to give it new UUIDs and a new VG name.
3. `pvesm add lvm ds1-snap --vgname san_ds1_snap --shared 1`, or keep it local to restore single disks.

Lost `/etc/pve/pvesan/config.json`. Datastores keep working, because LVM metadata lives on the LUNs. Aliases and policies fall back to multipath defaults, and arrays must be added again. Re-run `pvesan device set` for each LUN, or restore the file from a backup of `/etc/pve`.

CLI and API reference

Each `pvesan` command calls the API method in the same row, so `pvesan help <command>` and the API viewer show the same parameters. List commands accept `--output-format json|yaml|text`. Cluster tasks exit non-zero when they fail.

CLI	REST (under `/nodes/{node}/san`)	Scope	Key options
`pvesan adapters`	`GET adapters`	node	
`pvesan remote-ports`	`GET remote-ports`	node	
`pvesan devices`	`GET devices`	node	`--all`, `--unused`
`pvesan paths`	`GET paths`	node	
`pvesan policies`	`GET policies`	—	
`pvesan rescan`	`POST rescan`	node	`--lip`, `--resize`
`pvesan rescan-all`	`POST rescan-all`	cluster task	`--lip`
`pvesan sync`	`POST sync`	node	
`pvesan device add <wwid>`	`POST devices/{wwid}/claim`	cluster task	`--alias`
`pvesan device set <wwid>`	`PUT devices/{wwid}`	cluster task	`--alias`, `--policy`, `--delete`

CLI	REST (under `/nodes/{node}/san`)	Scope	Key options
`pvesan device detach <wwid>`	`POST devices/{wwid}/detach`	cluster task	
`pvesan device attach <wwid>`	`POST devices/{wwid}/attach`	cluster task	
`pvesan device refresh <wwid>`	`POST devices/{wwid}/refresh`	node	
`pvesan device cleanup`	`POST cleanup-paths`	node	
`pvesan datastore list`	`GET datastores`	cluster view	
`pvesan datastore create <id>`	`POST datastores`	cluster task	`--devices`, `--label`, `--vgname`, `--content`, `--nodes`, `--saferemove`, `--force`
`pvesan datastore extend <id>`	`POST datastores/{id}/extend`	cluster task	`--add-devices`, `--devices`, `--force`
`pvesan datastore array-grow <id>`	`POST datastores/{id}/array-grow`	cluster task	`--size <GiB>`
`pvesan datastore rename <id>`	`POST datastores/{id}/rename`	cluster task	`--label`, `--new-id`, `--rename-vg`
`pvesan datastore unmount <id>`	`POST datastores/{id}/unmount`	cluster task	`--nodes`
`pvesan datastore mount <id>`	`POST datastores/{id}/mount`	cluster task	`--nodes`
`pvesan datastore reclaim <id>`	`POST datastores/{id}/reclaim`	cluster task	`--reserve <GiB>`
`pvesan datastore delete <id>`	`DELETE datastores/{id}`	cluster task	`--destroy-data`, `--detach`, `--delete-volume`

CLI	REST (under `/nodes/{node}/san`)	Scope	Key options
`pvesan array list`	`GET arrays`	cluster view	
`pvesan array probe <address>`	`POST array-probe`	node	`--port`, `--type`
`pvesan array add <id>`	`POST arrays`	cluster	`--type`, `--address`, `--port`, `--username`, `--fingerprint`, `--hostcluster`, vendor settings
`pvesan array set <id>`	`PUT arrays/{id}`	cluster	as add, `--delete`
`pvesan array remove <id>`	`DELETE arrays/{id}`	cluster	
`pvesan array status <id>`	`GET arrays/{id}/status`	cluster view	
`pvesan array pools <id>`	`GET arrays/{id}/pools`	—	
`pvesan array register-cluster <id>`	`POST arrays/{id}/register-cluster`	cluster task	
`pvesan array link <id> <storage>`	`POST arrays/{id}/link`	cluster	
`pvesan provision <array> <storage>`	`POST arrays/{id}/provision`	cluster task	`--pool`, `--size`, `--thin`, `--volume`, `--label`, `--content`, `--policy`

There are also two internal steps, `POST devices/{wwid}/detach-local` and `POST vg-deactivate`. Cluster tasks call them on each node; don't call them by hand.

Storage options added by the `fcsan` type. All LVM options (`vgname` , `shared` , `saferemove` , `nodes` , `content` , `snapshot-as-volume-chain` on Proxmox VE 9, …) also apply.

Option	Default	Meaning
`fc-wwids`	set at create	WWIDs of the backing LUNs, comma separated
`fc-autorescan`	`1`	Rescan the SAN on activation when a backing LUN is missing

Example entry:

```
fcsan: ds1
        vgname san_ds1
        content images,rootdir
        shared 1
        fc-wwids 3600a098038303053453f463045727a41
```