



SERIES 6
650

Contact SAMSUNG WORLDWIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

Contacte con SAMSUNG WORLDWIDE

Si tiene alguna pregunta o comentario referente a nuestros productos, por favor contacte con nuestro Servicio de Atención al Cliente.

Country	Customer Care Center	Web Site	Address
CANADA	1-800-SAMSUNG(726-7864)	www.samsung.com/ca	Samsung Electronics Canada Inc., Customer Service 55 Standish Court Mississauga, Ontario L5R 4B2 Canada
			Samsung Electronique Canada Inc., Service à la Clientèle 55 Standish Court Mississauga, Ontario L5R 4B2 Canada
U.S.A	1-800-SAMSUNG(726-7864)	www.samsung.com	Samsung Electronics America, Inc. 105 Challenger Road Ridgefield Park, NJ 07660-0511

LCD TV
user manual

imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service, please register
your product at

www.samsung.com/global/register

Model _____ Serial No. _____



BN68-01429A-02



Important Warranty Information Regarding Television Format Viewing

Wide screen format LCD Displays (16:9, the aspect ratio of the screen width to height) are primarily designed to view wide screen format full-motion video. The images displayed on them should primarily be in the wide screen 16:9 ratio format, or expanded to fill the screen if your model offers this feature and the images are constantly moving. Displaying stationary graphics and images on screen, such as the dark sidebars on nonexpanded standard format television video and programming, should be limited to no more than 5% of the total television viewing per week.

Additionally, viewing other stationary images and text such as stock market reports, video game displays, station logos, web sites or computer graphics and patterns, should be limited as described above for all televisions. Displaying stationary images that exceed the above guidelines can cause uneven aging of LCD Displays that leave subtle, but permanent burned-in ghost images in the LCD picture. To avoid this, vary the programming and images, and primarily display full screen moving images, not stationary patterns or dark bars.

On LCD models that offer picture sizing features, use these controls to view different formats as a full screen picture.

Be careful in the selection and duration of television formats used for viewing. Uneven LCD aging as a result of format selection and use, as well as burned-in images, are not covered by your Samsung limited warranty.

SAMSUNG ELECTRONICS NORTH AMERICAN LIMITED WARRANTY STATEMENT

Subject to the requirements, conditions, exclusions and limitations of the original Limited Warranty supplied with Samsung Electronics (SAMSUNG) products, and the requirements, conditions, exclusions and limitations contained herein, SAMSUNG will additionally provide Warranty Repair Service in the United States on SAMSUNG products purchased in Canada, and in Canada on SAMSUNG products purchased in the United States, for the warranty period originally specified, and to the Original Purchaser only.

The above described warranty repairs must be performed by a SAMSUNG Authorized Service Center. Along with this Statement, the Original Limited Warranty Statement and a dated Bill of Sale as Proof of Purchase must be presented to the Service Center. Transportation to and from the Service Center is the responsibility of the purchaser.

Conditions covered are limited only to manufacturing defects in material or workmanship, and only those encountered in normal use of the product.

Excluded, but not limited to, are any originally specified provisions for, in-home or on-site services, minimum or maximum repair times, exchanges or replacements, accessories, options, upgrades, or consumables.

For the location of a SAMSUNG Authorized Service Center, please call toll-free:

In the United States : 1-800-SAMSUNG (1-800-726-7864)

In Canada : 1-800-SAMSUNG

> See the warranty card for more information on warranty terms.

Precautions When Displaying a Still Image

A still image may cause permanent damage to the TV screen

- Do not display a still image on the LCD panel for more than 2 hours as it can cause screen image retention. This image retention is also known as "screen burn". To avoid such image retention, reduce the degree of brightness and contrast of the screen when displaying a still image.
-  Watching the LCD TV in 4:3 format for a long period of time may leave traces of borders displayed on the left, right and center of the screen caused by the difference of light emission on the screen.
Playing a DVD or a game console may cause a similar effect to the screen.
Damages caused by the above effect are not covered by the Warranty.
- Displaying still images from Video games and PC for longer than a certain period of time may produce partial after-images. To prevent this effect, reduce the 'brightness' and 'contrast' when displaying still images.

© 2008 Samsung Electronics Co., Ltd. All rights reserved.

Contents

General Information

■ List of Features	2
■ Accessories	2
■ Viewing the Control Panel	3
■ Viewing the Connection Panel	4
■ Remote Control	5
■ Installing Batteries in the Remote Control	6

Connections

■ Connecting VHF and UHF Antennas	6
■ Connecting Cable TV	7
■ Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via HDMI	8
■ Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via DVI	8
■ Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via Component cables	9
■ Connecting a Camcorder	9
■ Connecting a VCR	10
■ Connecting a Digital Audio System	11
■ Connecting an Amplifier/DVD Home Theater	11
■ Connecting a PC	12

Operation

■ Turning the TV On and Off	13
■ Plug & Play Feature	13
■ Changing Channels	15
■ Adjusting the Volume	15
■ Viewing the Display	16
■ Viewing the Menus	16
■ Using the Remote Control Backlight Buttons	16
■ Using the TOOLS Button	17
■ Memorizing the Channels	17
■ To Select the Source	19
■ To Edit the Input Source Name	19

Picture Control

■ Changing the Picture Standard	20
■ Customizing the Picture Settings	20
■ Adjusting the Detailed Settings	21
■ Resetting the Picture Settings to the Factory Defaults	24
■ Configuring Picture Options	25
■ Viewing Picture-in-Picture	29

Sound Control

■ Changing the Sound Standard	31
■ Customizing the Sound	31
■ Setting the TruSurround XT	32
■ Choosing Preferred Language	33
■ Choosing a Multi-Channel Sound (MTS) track	33
■ Automatic Volume Control	34
■ Setting the TV Speakers On/Off	34
■ Listening to the Sound of the Sub (PIP) Picture	35
■ Resetting the Sound Settings to the Factory Defaults	35
■ Connecting Headphones (Sold separately)	35

Channel Control

■ Managing Channels	36
■ Clearing Scrambled Channels - Digital	42
■ Fine Tuning Analog Channels	42
■ Checking the Digital-Signal Strength	43

PC Display

■ Using Your TV as a Computer (PC) Display	44
■ Display Modes	44
■ Setting up the TV with your PC	45

Time Setting

■ Setting the Clock	47
---------------------------	----

Function Description

■ Selecting a Menu Language	51
■ Using the V-Chip	51
■ Viewing Closed Captions (On-Screen Text Messages) - Analog	58
■ Viewing Closed Captions (On-Screen Text Messages) - Digital	59
■ Adjusting the TV On/Off Melody Sound	60
■ Setting the Entertainment mode	60
■ Using the Energy Saving Feature	61
■ Upgrading the Software	62

WISELINK

■ Using the WISELINK Function	63
■ Using the Photo List	64
■ Viewing a Photo or Slide Show	70
■ Using the Music List	74
■ Playing a Music File	79
■ Using the Setup Menu	81

Network Settings and InfoLink

■ Network Connection (DHCP) and Automatic Setup	82
■ Network Connection (Static IP) and Manual Setup	84
■ Network Test	86
■ Using InfoLink	87
■ InfoLink Setup	90

About Anynet+

■ What is Anynet+?	91
■ Connecting Anynet+ Devices	91
■ Setting Up Anynet+	92
■ Scanning and Switching between Anynet+ Devices	92
■ Recording	93
■ Listening through a Receiver (Home theater)	94
■ Troubleshooting for Anynet+	94

Appendix

■ Troubleshooting	95
■ Installing the Stand	97
■ Disconnecting the Stand	97
■ Auto Wall-Mount Adjustment (Sold separately)	98
■ Wall Mount Kit Specifications (VESA)	99
■ Using the Anti-Theft Kensington Lock (LN32A650A1F, LN40A650A1F, LN46A650A1F)	100
■ Specifications	101
■ Dimensions	102

 Symbol  Press  Note  One-Touch Button



General Information

List of Features

- Adjustable picture settings that can be stored in the TV's memory.
- Automatic timer to turn the TV on and off.
- A special sleep timer.
- Excellent Digital Interface & Networking :
With a built-in HD digital tuner, non-subscription HD broadcasts can be viewed with no Cable Box/Satellite receiver (Set-Top Box) needed.
- You can view News, Weather, and Stock information over the network (SAMSUNG's InfoLink Service).
- You can listen to music files and view pictures on USB Mass Storage Class (MSC) devices.
- **HDMI/DVI connection of your PC to this TV.**
- Excellent Picture Quality
 - DNle technology provides life-like clear images.
- SRS TruSurround XT
 - SRS TruSurround XT provides a virtual surround system.

Accessories

Please make sure the following items are included with your LCD TV. If any items are missing, contact your dealer.



Remote Control & Batteries
(AAA x 2)
(BN59-00695A)



Warranty Card / Registration Card /
Safety Guide Manual
(Not available in all locations)



Cover-Bottom
(LN32A650A1F: BN63-04294A)
(LN40A650A1F: BN63-04243A)
(LN46A650A1F: BN63-04288A)
(LN52A650A1F: BN63-04330A)



Power Cord
(3903-000144)



Cleaning Cloth
(BN63-01798A)



Owner's Instructions




Ferrite Core for Side-HDMI
(HDMI4)
(LN46A650A1F: 3301-001305)

➤ The items color and shape may vary depending on the model.

➤ **Ferrite Core (Side-HDMI Cable)**

The ferrite cores are used to shield the cables from interference. When connecting a cable, open the ferrite core and clip it around the cable near the plug.




Viewing the Control Panel

Buttons on the Lower-Right Part of the Panel

The buttons on the lower-right panel control your TV's basic features, including the on-screen menu.

To use the more advanced features, you must use the remote control.



① SOURCE

Toggles between all the available input sources (TV, AV1, AV2, S-Video, Component1, Component2, PC, HDMI1, HDMI2/DVI, HDMI3, HDMI4, USB). In the on-screen menu, use this button as you would use the **ENTER** button on the remote control.

② MENU

Press to see an on-screen menu of your TV's features.

③ + VOL +

Press to increase or decrease the volume.
In the on-screen menu, use the **+ VOL +** buttons as you would use the **◀** and **▶** buttons on the remote control.

④ CH ▲

Press to change channels.
In the on-screen menu, use the **CH ▲** buttons as you would use the **▼** and **▲** buttons on the remote control.

⑤ POWER INDICATOR

Blinks and turns off when the power is on and lights up in stand-by mode.

⑥

Press to turn the TV on and off.


⑦ REMOTE CONTROL SENSOR

Aim the remote control towards this spot on the TV.

⑧ SPEAKERS

Viewing the Connection Panel

Use the connection panel jacks to connect A/V components that will be connected continuously, such as DVD players or a VCR. For more information on connecting equipment, see pages 6~12.



① AUDIO OUT

Connects to the audio input jacks on your Amplifier/ Home theater.

② LAN

Connect a LAN cable to this port to connect to the Network (SAMSUNG InfoLink's Service). (See page 82)

③ PC IN [PC] / [AUDIO]

Connects to the video and audio output jacks on your PC.

④ HDMI IN 1, 2, 3, 4 / DVI IN(HDMI2)[R-AUDIO-L]

Connects to the HDMI jack of a device with an HDMI output.

- No sound connection is needed for an HDMI to HDMI connection.

Use the HDMI IN 2 jack for DVI connection to an external device. Use a DVI to HDMI cable or DVI-HDMI adapter (DVI to HDMI) for video connection and the DVI IN (HDMI2) [R-AUDIO-L] jacks for audio.

- When using an HDMI/DVI cable connection, you must use the HDMI IN 2 jack.

⑤ DIGITAL AUDIO OUT (OPTICAL)

Connects to a Digital Audio component.

⑥ ANT IN

Connects to an antenna or cable TV system.

⑦ WISELINK

Connect a USB mass storage device to view photo files and play audio files.

⑧ AV IN 2

Video and audio inputs for external devices, such as a camcorder or VCR.

S-VIDEO

Connects an S-Video signal from a camcorder or VCR.

⑨ HEADPHONE

Connects a set of external headphones for private listening.

⑩ POWER INPUT

Connects the supplied power cord.

⑪ COMPONENT IN 1, 2 / AV IN 1

Connects Component video/audio.

The COMPONENT IN 1 jack is also used as the AV IN 1 jack.

- Connect the video cable to the COMPONENT IN 1 [Y/VIDEO] jack and the audio cable to the COMPONENT IN 1 [R-AUDIO-L] jacks.

⑫ EX-LINK

Connect this to the jack on the optional wall mount bracket. This will allow you to adjust the TV viewing angle using your remote control.

⑬ KENSINGTON LOCK

(LN32A650A1F, LN40A650A1F, LN46A650A1F)

The Kensington Lock (optional) is a device used to physically fix the system when used in a public place. If you want to use a locking device, contact the dealer where you purchased the TV.

> The location of the Kensington Lock may be different depending on its model.


Remote Control

You can use the remote control up to a distance of about 23 feet from the TV.

- ① POWER**
Turns the TV on and off.
- ② TV**
Selects the TV mode directly.
- ③ NUMERIC BUTTONS**
Press to change the channel.
- ④ []**
Press to select additional channels (digital and analog) being broadcast by the same station. For example, to select channel "54-3", press "54", then press "[]" and "3".
- ⑤ [MUTE]**
Press to temporarily cut off the sound.
- ⑥ VOL - / VOL +**
Press to increase or decrease the volume.
- ⑦ CH LIST**
Used to display Channel Lists on the screen.
- ⑧ TOOLS**
Use to quickly select frequently used functions.
- ⑨ INFO**
Press to display information on the TV screen.
- ⑩ COLOR BUTTONS**
Use these buttons in the Channel list, WISELINK, etc.
- ⑪ CC**
Controls the caption decoder.
- ⑫ E.MODE**
Press to select the preset display and sound modes for sports, cinema and games.
- ⑬** Use these buttons in the DMA, WISELINK and Anynet+ modes.
(: This remote can be used to control recording on Samsung recorders with the Anynet+ feature)
- ⑭ [] ON/OFF**
Press to backlight the buttons on the remote. This function is convenient for using at night or when the room is dark. (Using the remote control with the ON/OFF light button set to On will reduce the battery usage time.) (see page 16)
- ⑮ PRE-CH**
Tunes to the previous channel.
- ⑯ CH ▼ / CH ▲**
Press to change channels.
- ⑰ SOURCE**
Press to display and select the available video sources.
- ⑱ W.LINK (WISELINK)**
This function enables you to view and play photo and music files from an external device. (Refer to pages 64 (Photo) and 74 (Music))
- ⑲ MENU**
Displays the main on-screen menu.
- ⑳ RETURN**
Returns to the previous menu.
- ㉑ UP ▲ / DOWN ▼ / LEFT ◀ / RIGHT ▶ / ENTER ⌂**
Press the Up/Down/Left/Right sections of the wheel button and Enter to select on-screen menu items and change menu values.
You can navigate up and down the menu, switch channels and adjust the volume by turning the wheel button. (See pages 15~16)
- ㉒ EXIT**
Press to exit the menu.
- ㉓ DMA (Digital Media Adapter)**
Use this when connecting a SAMSUNG DMA device through an HDMI interface and switching to DMA mode.
For more information on the operating procedures, refer to the user manual of the DMA. This button is available when "Anynet+(HDMI-CEC)" is "On". (see page 92)
- ㉔ INFO.L**
Press to use the News, Stock Market and Weather Forecast information services available over the network. (see page 87)
- ㉕ FAV.CH**
Press to switch to your favorite channels.
- ㉖ P.SIZE**
Picture size selection.




> The performance of the remote control may be affected by bright light.

English - 5



Installing Batteries in the Remote Control


1. Lift the cover at the back of the remote control upward as shown in the figure.
 2. Install two AAA size batteries.
 - > Make sure to match the "+" and "−" ends of the batteries with the diagram inside the compartment.
 3. Replace the cover.
 - > Remove the batteries and store them in a cool, dry place if you won't be using the remote control for a long time.
- The remote control can be used up to about 23 feet from the TV.
(Assuming typical TV usage, the batteries should last for about one year.)
> Using the remote control with the **ON/OFF**  light button set to On will reduce the battery usage time.
-
- > If the remote control doesn't work, check the following:
 1. Is the TV power on?
 2. Are the plus and minus ends of the batteries reversed?
 3. Are the batteries drained?
 4. Is there a power outage or is the power cord unplugged?
 5. Is there a special fluorescent light or neon sign nearby?




Connections

Connecting VHF and UHF Antennas

If your antenna has a set of leads that look like the diagram to the right, see "Antennas with 300 Ω Flat Twin Leads" below.





If your antenna has one lead that looks like the diagram to the right, see "Antennas with 75 Ω Round Leads".



Antennas with 300 Ω Flat Twin Leads


If you are using an off-air antenna (such as a roof antenna or "rabbit ears") that has 300 Ω twin flat leads, follow the directions below.

1. Place the wires from the twin leads under the screws on a 300-75 Ω adapter (not supplied). Use a screwdriver to tighten the screws.
2. Plug the adaptor into the ANT IN terminal on the back of the TV.



Antennas with 75 Ω Round Leads



1. Plug the antenna lead into the ANT IN terminal on the back of the TV.



Separate VHF and UHF Antennas

If you have two separate antennas for your TV (one VHF and one UHF), you must combine the two antenna signals before connecting the antennas to the TV. This procedure requires an optional combiner-adaptor (available at most electronics shops).

1. Connect both antenna leads to the combiner.
2. Plug the combiner into the ANT IN terminal on the bottom of the rear panel.




Connecting Cable TV

To connect to a cable TV system, follow the instructions below.


Cable without a Cable Box

1. Plug the incoming cable into the ANT IN terminal on the back of the TV.
 - Because this TV is cable-ready, you do not need a cable box to view unscrambled cable channels.



Connecting to a Cable Box that Descrambles All Channels


1. Find the cable that is connected to the ANT OUT terminal on your cable box.
 - This terminal might be labeled "ANT OUT", "VHF OUT" or simply, "OUT".
2. Connect the other end of this cable to the ANT IN terminal on the back of the TV.



Connecting to a Cable Box that Descrambles Some Channels

If your cable box descrambles only some channels (such as premium channels), follow the instructions below. You will need a two-way splitter, an RF (A/B) switch and four lengths of RF cable. (These items are available at most electronics stores.)

1. Find and disconnect the cable that is connected to the ANT IN terminal on your cable box.
 - This terminal might be labeled "ANT IN", "VHF IN" or simply, "IN".
2. Connect this cable to a two-way splitter.
3. Connect an RF cable between the OUTPUT terminal on the splitter and the IN terminal on the cable box.
4. Connect an RF cable between the ANT OUT terminal on the cable box and the B-IN terminal on the RF(A/B) switch.
5. Connect another cable between the other OUT terminal on the splitter and the A-IN terminal on the RF (A/B) switch.
6. Connect the last RF cable between the OUT terminal on the RF (A/B) switch and the ANT IN terminal on the rear of the TV.




After you have made this connection, set the A/B switch to the "A" position for normal viewing. Set the A/B switch to the "B" position to view scrambled channels. (When you set the A/B switch to "B", you will need to tune your TV to the cable box's output channel, which is usually channel 3 or 4.)

Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via HDMI

This connection can only be made if there is an HDMI Output connector on the external device.

1. Connect an HDMI Cable between the HDMI IN (1, 2, 3 or 4) jack on the TV and the HDMI jack on the DVD Player or Cable Box/Satellite receiver (Set-Top Box).




- What is HDMI?
 - HDMI(High-Definition Multimedia Interface), is an interface that enables the transmission of digital audio and video signals using a single cable.
 - The difference between HDMI and DVI is that the HDMI device is smaller in size and has the HDCP (High Bandwidth Digital Copy Protection) coding feature installed.
- Each DVD Player or Cable Box/Satellite receiver (Set-Top Box) has a different back panel configuration.
- The TV may not output sound and pictures may be displayed with abnormal color when DVD players/Cable Boxes/Satellite receivers supporting HDMI versions older than 1.3 are connected. When connecting an older HDMI cable and there is no sound, connect the HDMI cable to the HDMI IN 2 jack and the audio cables to the DVI IN (HDMI2) [R-AUDIO-L] jacks on the back of the TV. If this happens, contact the company that provided the DVD player/Cable Box/Satellite receiver to confirm the HDMI version, then request an upgrade.
- HDMI cables that are not 1.3 may cause annoying flicker or no screen display.

Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via DVI

This connection can only be made if there is a DVI Output connector on the external device.

1. Connect a DVI to HDMI Cable or DVI-HDMI Adapter between the HDMI IN 2 jack on the TV and the DVI jack on the DVD Player or Cable Box/Satellite receiver (Set-Top Box).
2. Connect Audio Cables between the DVI IN (HDMI 2) [R-AUDIO-L] jack on the TV and the DVD Player or Cable Box/Satellite receiver (Set-Top Box).




- Each DVD Player or Cable Box/Satellite receiver (Set-Top Box) has a different back panel configuration.
- When connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box), match the color of the connection terminal to the cable.
- When using an HDMI/DVI cable connection, you must use the HDMI IN 2 jack.

Connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box) via Component cables

The rear panel jacks on your TV make it easy to connect a DVD Player or Cable Box/Satellite receiver (Set-Top Box) to your TV.

1. Connect a Component Cable between the COMPONENT IN (1 or 2) [Y, Pb, Pr] jacks on the TV and the COMPONENT [Y, Pb, Pr] jacks on the DVD Player or Cable Box/Satellite receiver (Set-Top Box).
2. Connect Audio Cables between the COMPONENT IN(1 or 2) [R-AUDIO-L] jacks on the TV and the AUDIO OUT jacks on the DVD Player or Cable Box/Satellite receiver (Set-Top Box).




- Component video separates the video into Y (Luminance (brightness)), Pb (Blue) and Pr (Red) for enhanced video quality.
Be sure to match the component video and audio connections.
For example, if connecting a Component video cable to COMPONENT IN 1, connect the audio cable to COMPONENT IN 1 also.
- Each DVD Player or Cable Box/Satellite receiver (Set-Top Box) has a different back panel configuration.
- When connecting a DVD Player or Cable Box/Satellite receiver (Set-Top Box), match the color of the connection terminal to the cable.

Connecting a Camcorder

The side panel jacks on your TV make it easy to connect a camcorder to your TV.
They allow you to view the camcorder tapes without using a VCR.

1. Connect a Video Cable (or S-Video Cable) between the AV IN 2 [VIDEO] (or S-VIDEO) jack on the TV and the VIDEO OUT jack on the camcorder.
2. Connect Audio Cables between the AV IN 2 [R-AUDIO-L] jacks on the TV and the AUDIO OUT jacks on the camcorder.



- Each Camcorder has a different back panel configuration.
- When connecting a Camcorder, match the color of the connection terminal to the cable.

Connecting a VCR



Video Connection

These instructions assume that you have already connected your TV to an antenna or a cable TV system (according to the instructions on pages 6~7). Skip step 1 if you have not yet connected to an antenna or a cable system.

1. Unplug the cable or antenna from the back of the TV.
2. Connect the cable or antenna to the ANT IN terminal on the back of the VCR.
3. Connect an RF Cable between the ANT OUT terminal on the VCR and the ANT IN terminal on the TV.
4. Connect a Video Cable between the VIDEO OUT jack on the VCR and the AV IN 1 [Y/VIDEO] or AV IN 2 [VIDEO] jack on the TV.
5. Connect Audio Cables between the AUDIO OUT jacks on the VCR and the AV IN 1 (or AV IN 2) [R-AUDIO-L] jacks on the TV.

➢ If you have a "mono" (non-stereo) VCR, use a Y-connector (not supplied) to connect to the right and left audio input jacks of the TV.

Alternatively, connect the cable to the "R" jack. If your VCR is stereo, you must connect two cables.




Follow the instructions in "Viewing a VCR or Camcorder Tape" to view your VCR tape.

- Each VCR has a different back panel configuration.
- When connecting a VCR, match the color of the connection terminal to the cable.
- When connecting to AV IN 1, the color of the AV IN 1 [Y/VIDEO] jack (Green) does not match the color of the video cable (Yellow).

S-Video Connection

Your Samsung TV can be connected to an S-Video jack on a VCR. (This connection delivers a better picture as compared to a standard VCR.)

1. To begin, follow steps 1–3 in the previous section to connect the antenna or cable to your VCR and your TV.
2. Connect an S-Video Cable between the S-VIDEO OUT jack on the VCR and the AV IN 2 [S-VIDEO] jack on the TV.
3. Connect Audio Cables between the AUDIO OUT jacks on the VCR and the AV IN 2 [R-AUDIO-L] jacks on the TV.



An S-Video cable may be included with a VCR. (If not, check your local electronics store.)


- Each VCR has a different back panel configuration.
- When connecting a VCR, match the color of the connection terminal to the cable.

Connecting a Digital Audio System

The rear panel jacks on your TV make it easy to connect a Digital Audio System (Home theater/Receiver) to your TV.

1. Connect an Optical Cable between the "DIGITAL AUDIO OUT (OPTICAL)" jacks on the TV and the Digital Audio Input jacks on the Digital Audio System.

When a Digital Audio System is connected to the "DIGITAL AUDIO OUT (OPTICAL)" jack: Decrease the volume of the TV and adjust the volume level with the system's volume control.




- 5.1CH audio is possible when the TV is connected to an external device supporting 5.1CH.
- Each Digital Audio System has a different back panel configuration.
- When the receiver (home theater) is set to On, you can hear sound output from the TV's Optical jack. When the TV is displaying a DTV(air) signal, the TV will send out 5.1 channel sound to the Home theater receiver. When the source is a digital component such as a DVD and is connected to the TV via HDMI, only 2 channel sound will be heard from the Home Theater receiver. If you want to hear 5.1 channel audio, connect the DIGITAL AUDIO OUT (OPTICAL) jack on the DVD player or Cable/Satellite Box directly to an Amplifier or Home Theater, not the TV.

Connecting an Amplifier/DVD Home Theater

1. Connect Audio Cables between the AUDIO OUT [R-AUDIO-L] jacks on the TV and AUDIO IN [R-AUDIO-L] jacks on the Amplifier/DVD Home Theater.

When an audio amplifier is connected to the "AUDIO OUT [R-AUDIO-L]" jacks: Decrease the volume of the TV and adjust the volume level with the Amplifier's volume control.




- Each Amplifier/DVD Home Theater has a different back panel configuration.
- When connecting an Amplifier/DVD Home Theater, match the color of the connection terminal to the cable.

Connecting a PC


Using the D-Sub Cable

1. Connect a D-Sub Cable between PC IN [PC] connector on the TV and the PC output connector on your computer.
2. Connect a PC Audio Cable between the PC IN [AUDIO] jack on the TV and the Audio Out jack of the sound card on your computer.



Using the HDMI/DVI Cable

1. Connect an HDMI/DVI cable between the HDMI IN 2 jack on the TV and the PC output jack on your computer.
2. Connect a 3.5 mm Stereo mini-plug/2RCA Cable between the DVI IN(HDMI2) [R-AUDIO-L] jack on the TV and the Audio Out jack of the sound card on your computer.




- Each PC has a different back panel configuration.
- When connecting a PC, match the color of the connection terminal to the cable.
- When using an HDMI/DVI cable connection, you must use the HDMI IN 2 terminal.

Operation

Turning the TV On and Off


Press the **POWER** button on the remote control.
You can also use the **POWER** button on the TV.




Plug & Play Feature

When the TV is initially powered on, basic settings proceed automatically and subsequently.


1. Press the **POWER** button on the remote control.
The message "Menu Language, Store Demo, Channels and Time will be set." is displayed.
Press the **ENTER** button, then "Select language of the OSD." menu is automatically displayed. Press the **ENTER** button.
2. Press the **▲** or **▼** button to select language, then press the **ENTER** button.
The message "Select 'Home Use' when installing this TV in your home." is displayed.
3. Press the **◀** or **▶** button to select "Store Demo" or "Home Use", then press the **ENTER** button. The message "Select the Antenna source to memorize." is displayed.
 - We recommend setting the TV to "Home Use" mode for the best picture in your home environment.
 - "Store Demo" mode is only intended for use in retail environments.
 - If the unit is accidentally set to "Store Demo" mode and you want to return to "Home Use" (Standard): Press the Volume button on the TV. When the volume OSD is displayed, press and hold the **MENU** button on the TV for 5 seconds.
4. Press the **▲** or **▼** button to memorize the channels of the selected connection. Press the **ENTER** button to select "Start".
 - Air: "Air" antenna signal.
 - Cable: "Cable" antenna signal.
 - Auto: "Air" and "Cable" antenna signals.
 - In Cable mode, you can select the correct signal source among STD, HRC, and IRC by pressing the **▲**, **▼**, **◀** or **▶** button, then press the **ENTER** button. If you have Digital cable, select the cable system signal source for both Analog and Digital. Contact your local cable company to identify the type of cable system that exists in your particular area.




- The TV will begin memorizing all of the available channels.
➢ To stop the search before it has finished, press the **ENTER** button with "Stop" selected.
After all the available channels are stored, it starts to remove scrambled channels (see page 42). And then, the Auto program menu reappears. Press the **ENTER** button when channel memorization is complete. The message "Set the Clock Mode." is displayed.




- Press the **ENTER** button.
Press the **▲** or **▼** button to select "Auto", then Press the **ENTER** button.
The message "Set to daylight saving time." is displayed.
If you select "Manual", "Set current date and time" is displayed.
(See page 47)




- Press the **▲** or **▼** button to select "Off" or "On", then press the **ENTER** button.
The message "Select the time zone in which you live." is displayed.



- Press the **▲** or **▼** button to highlight the time zone for your local area. Press the **ENTER** button. If you have received a digital signal, the time will be set automatically. If not, see page 47 to set the clock.




- The message "Enjoy your watching." is displayed.
When you have finished, press the **ENTER** button.



If you want to reset this feature...



- Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
- Press the **ENTER** button again to select "Plug & Play".
For further details on setting up options, refer to the pages 13~14.
➢ The "Plug & Play" feature is only available in the TV mode.



Changing Channels


Using the Channel Buttons

1. Press the **CH ▼** or **CH ▲** button to change channels.
 - When you press the **CH ▼** or **CH ▲** button, the TV changes channels in sequence.
 - You will see all the channels that the TV has memorized. (The TV must have memorized at least three channels). You will not see channels that were either erased or not memorized. See page 18 to memorize channels.
 - To increase the channel number, turn the wheel clockwise when the Channel Display is displayed. To decrease the channel number, turn the wheel counterclockwise.



Using the Number Buttons


1. Press the number buttons to go directly to a channel. For example, to select channel 27, press **2**, then **7**.
 - For quick channel change, press the number buttons, then press the **ENTER** button.



Using the **[]** Button


The **[]** button is used to select stations that broadcast a digital signal.

1. For example, for Channel 7-1, press **7**, then **[]**, then **1**.
 - HD indicates the TV is receiving a Digital High Definition signal.
 - SD indicates the TV is receiving a Standard Definition signal.
 - For quick channel change, press the number buttons, then press the **ENTER** button.



Using the PRE-CH Button to select the Previous Channel


1. Press the **PRE-CH** button. The TV will switch to the last channel viewed.
 - To quickly switch between two channels that are far apart, tune to one channel, then use the number button to select the second channel. Then use the **PRE-CH** button to quickly alternate between them.




Adjusting the Volume

Using the Volume Button

1. Press the **VOL -** or **VOL +** button to increase or decrease the volume.




- To turn the volume up, turn the wheel clockwise when the Volume Control window is displayed. To turn the volume down, turn the wheel counterclockwise.



Using the MUTE button

At any time, you can cut off the sound using the **MUTE** button.

1. Press **MUTE** button and the sound cuts off.
 - “**[]**” is displayed on the screen.
2. To turn mute off, press the **MUTE** button again or simply press the **VOL -** or **VOL +** button.




Viewing the Display

The display identifies the current channel and the status of certain audio-video settings.

1. Press the **INFO** button on the remote control.

The TV will display the channel, the type of sound, and the status of certain picture and sound settings.




- Press the **INFO** button once more or wait approximately 10 seconds and the display disappears automatically.

Viewing the Menus

1. With the power on, press the **MENU** button.

The main menu appears on the screen.


The menu's left side has icons: Picture, Sound, Channel, Setup, Input, Application.



2. Press the **▲** or **▼** button to select one of the icons.


Then press the **ENTER** button to access the icon's sub-menu.

➢ To move to a lower menu, turn the wheel clockwise when the menu Display is displayed. To move to a higher menu, turn the wheel counterclockwise.



3. Press the **EXIT** button to exit.

➢ The on-screen menus disappear from the screen after about one minute.



Using the Remote Control Backlight Buttons

Use this feature in dark surroundings and when you are unable to see the remote control buttons clearly.

1. Press the **ON/OFF** light button.



- Pressing the **ON/OFF** light button toggles between ON and OFF.
- When ON, the button backlight is turned on for a moment.
- Pressing a remote control button when the remote control is on turns the button backlight on for a moment. If you touch or move the remote control and the motion is detected by the sensor of the remote control, the button backlight will be turned on for a moment.
- The remote contains two small movement sensors that control the backlight function. If you shake or drop the remote, you may hear the sensors rattle. This is normal and is not a defect.
- The button backlight will not be turned on when the remote control is turned off.

Using the TOOLS Button

You can use the **TOOLS** button to select your frequently used functions quickly and easily. The "TOOLS" menu changes depending on which external input mode you are viewing.

1. Press the **TOOLS** button. The "TOOLS" menu will appear.
2. Press the **▲** or **▼** button to select a menu.
3. Press the **▲/▼/◀/▶/ENTER** button to display, change, or use the selected items. For a more detailed description of each function, refer to the corresponding page.

- Device List: see page 92
- Multi-Track Sound: see pages 33
- Picture Mode: see page 20
- Sound Mode: see page 31
- Sleep Timer: see page 49
- Add to Favorite: see page 38
- Switch to Cable (or Switch to Air): see page 17
- PIP: see pages 29~30
- Auto adjustment: see page 45





Memorizing the Channels

Your TV can memorize and store all of the available channels for both "off-air" (Air) and "Cable" channels. After the available channels are memorized, use the **CH ▼** or **CH ▲** button to scan through the channels. This eliminates the need to change channels by entering the channel digits. There are three steps for memorizing channels: selecting a broadcast source, memorizing the channels (automatic) and adding or deleting channels (Channel Lists).

Selecting the Video Signal-source


Before your television can begin memorizing the available channels, you must specify the type of signal source that is connected to the TV (i.e. an Air or a Cable system).

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
2. Press the **ENTER** button to select "Antenna".
Press the **▲** or **▼** button to select "Air" or "Cable", then press the **ENTER** button.
Press the **EXIT** button to exit.




Easy Setting

1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Switch to Cable (or Switch to Air)".
3. Press the **ENTER** button to switch "Cable" (or "Air").









Storing Channels in Memory (Automatic Method)

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Auto Program", then press the **ENTER** button.



3. Press the **▲** or **▼** button to select the antenna connection, then press the **ENTER** button.
 - Air: "Air" antenna signal.
 - Cable: "Cable" antenna signal.
 - Auto: "Air" and "Cable" antenna signals.
4. When selecting the Cable TV system:
Press the **ENTER** button to start the auto program.
Press the **▲**, **▼**, **◀** or **▶** to select the correct analog signal cable system source among "STD", "HRC", and "IRC". Press the **▲** or **▼** button to select "Start", then press the **ENTER** button. If you have Digital cable TV, select the cable system signal source for both Analog and Digital.
 - STD, HRC and IRC identify various types of cable TV systems. Contact your local cable company to identify the type of cable system that exists in your particular area. At this point the signal source has been selected.



5. The TV begins memorizing all available stations.
 - After all the available channels are stored, it starts to remove scrambled channels (see page 42). The Auto program menu then reappears.
 - If you want to stop Auto Programming, press the **ENTER** button. The "Stop Auto Program?" message will be displayed. Select "Yes" by pressing the **◀** or **▶** button, then press the **ENTER** button.

Press the **EXIT** button to exit.



To Select the Source

Use to select TV or other external input sources such as DVD players or Cable Box/Satellite receivers (Set-Top Box) connected to the TV. Use to select the input source of your choice.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Input", then press the **ENTER** button.
2. Press the **ENTER** button to select "Source List".
Press the **▲** or **▼** button to select signal source, then press the **ENTER** button.
 - Available signal sources: TV, AV1, AV2, S-Video, Component1, Component2, PC, HDMI1, HDMI2/DVI, HDMI3, HDMI4, USB.
 - You can choose only those external devices that are connected to the TV. In the "Source List", connected inputs will be highlighted and sorted to the top. Inputs that are not connected will be sorted to the bottom.

Using the Color buttons on the remote with the Source list

- **Red (Refresh)**: Refreshes the connecting external devices.
- **TOOLS (Option)**: Displays the "Edit Name" and "Information" menus.






Press the **SOURCE** button on the remote control to view an external signal source.



To Edit the Input Source Name

Name the device connected to the input jacks to make your input source selection easier.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Input", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Edit Name", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "AV1", "AV2", "S-Video", "Component1", "Component2", "PC", "HDMI1", "HDMI2/DVI", "HDMI3", "HDMI4" input jack, then press the **ENTER** button.
3. Press the **▲** or **▼** button to select "VCR", "DVD", "Cable STB", "Satellite STB", "PVR STB", "AV Receiver", "Game", "Camcorder", "PC", "TV", "IPTV", "Blu-Ray", "HD DVD", "Digital Media Adapter" input source, then press the **ENTER** button.
Press the **EXIT** button to exit.
 - When a PC with a resolution of 1920 x 1080@60Hz is connected to the HDMI IN 2 port, you should set the "HDMI2/DVI" mode to "PC" in the "Edit Name" of the "Input" mode.




Picture Control

Changing the Picture Standard


You can select the type of picture which best corresponds to your viewing requirements.

1. Press the **MENU** button to display the menu.
Press the **ENTER** button to select "Picture".




2. Press the **ENTER** button to select "Mode". Press the **▲** or **▼** button to select "Dynamic", "Standard" or "Movie". Press the **ENTER** button.

- **Dynamic:** Selects the picture for high-definition in a bright room.
- **Standard:** Selects the picture for the optimum display in a normal environment.
- **Movie:** Selects the picture for viewing movies in a dark room.



3. Press the **EXIT** button to exit.



Easy Setting

1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Picture Mode".
3. Press the **◀** or **▶** button to select the required option.
4. Press the **EXIT** or **TOOLS** button to exit.

Customizing the Picture Settings

Your television has several setting options that allow you to control the picture quality.

1. To select the desired picture mode, follow the "Changing the Picture Standard" instructions numbers 1 and 2.
 2. Press the **▲** or **▼** button to select "Backlight", "Contrast", "Brightness", "Sharpness", "Color" or "Tint(G/R)", then press the **ENTER** button.
 3. Press the **◀** or **▶** button to decrease or increase the value of a particular item. Press the **ENTER** button.
Press the **EXIT** button to exit.
 - When you make changes to "Backlight", "Contrast", "Brightness", "Sharpness", "Color" or "Tint(G/R)", the OSD will be adjusted accordingly.
 - In PC mode, you can only make changes to "Backlight", "Contrast" and "Brightness".
 - Settings can be adjusted and stored for each external device you have connected to an input of the TV.
- **Backlight:** Adjusts the brightness of LCD back light.
 - **Contrast:** Adjusts the contrast level of the picture.
 - **Brightness:** Adjusts the brightness level of the picture.
 - **Sharpness:** Adjusts the edge definition of the picture.
 - **Color:** Adjusts color saturation of the picture.
 - **Tint(G/R):** Adjusts the color tint of the picture.




Adjusting the Detailed Settings


Samsung's new TVs allow you to make even more precise picture settings than previous models. See below to adjust detailed picture settings.

Activating Detailed Settings

1. Press the **MENU** button to display the menu.
Press the **ENTER** button to select "Picture".
2. Press the **ENTER** button to select "Mode".
Press the **▲** or **▼** button to select "Standard" or "Movie", then press the **ENTER** button.
➢ "Detailed Settings" is available in "Standard" or "Movie" mode.




3. Press the **▲** or **▼** button to select "Detailed Settings", then press the **ENTER** button.
➢ In PC mode, you can only make changes to "Dynamic Contrast", "Gamma" and "White Balance" from among the "Detailed Settings" items.



Setting the Black adjust

You can select the black level on the screen to adjust the screen depth.


4. Press the **▲** or **▼** button to select "Black adjust", then press the **ENTER** button.
5. Press the **▲** or **▼** button to select "Off", "Low", "Medium" or "High".
Press the **ENTER** button.
 - **Off:** Turns off the black adjustment function.
 - **Low:** Sets the black color depth to low.
 - **Medium:** Sets the black color depth to medium.
 - **High:** Sets the black color depth to high.



Setting the Dynamic Contrast

You can adjust the screen contrast so that the optimal contrast is provided.


6. Press the **▲** or **▼** button to select "Dynamic Contrast", then press the **ENTER** button.
7. Press the **▲** or **▼** button to select "Off", "Low", "Medium" or "High".
Press the **ENTER** button.
 - **Off:** Turns off the dynamic contrast adjustment function.
 - **Low:** Sets the dynamic contrast to low.
 - **Medium:** Sets the dynamic contrast to medium.
 - **High:** Sets the dynamic contrast to high.



Adjusting the Gamma

You can adjust the Primary Color (Red, Green, Blue) Intensity. (-3 ~ +3)

8. Press the ▲ or ▼ button to select "Gamma", then press the **ENTER** button.
9. Press the ◀ or ▶ button to decrease or increase the value.
Press the **ENTER** button.




Setting the Color Space

Color space is a color matrix composed of red, green and blue colors.
Select your favorite color space to experience the most natural color.

10. Press the ▲ or ▼ button to select "Color Space", then press the **ENTER** button.
11. Press the **ENTER** button again to select "Color Space".
12. Press the ▲ or ▼ button to select "Auto", "Native" or "Custom".
Press the **ENTER** button.

- **Auto:** Auto Color Space automatically adjusts to the most natural color tone based on program sources.
- **Native:** Native Color Space offers deep and rich color tone.
- **Custom:** Adjusts the color range to suit your preference.
(see "Customizing the Color Space")





Customizing the Color Space

13. Press the ▲ or ▼ button to select "Color", then press the **ENTER** button.
➢ "Color" is available when "Color Space" is set to "Custom".
14. Press the ▲ or ▼ button to select "Red", "Green", "Blue", "Yellow", "Cyan" or "Magenta". Press the **ENTER** button.
15. Press the ▲ or ▼ button to select "Red", "Green", or "Blue" to change it.
Press the **ENTER** button.
16. Press the ◀ or ▶ button to decrease or increase the value of a particular item. Press the **ENTER** button.
➢ In "Color", you can adjust the RGB values for the selected color.
➢ To reset the adjusted RGB value, select "Reset".

- **Red:** Adjusts the red saturation level of the selected color.
- **Green:** Adjusts the green saturation level of the selected color.
- **Blue:** Adjusts the blue saturation level of the selected color.
- **Reset:** Resets the color space to the default values.

- Changing the adjustment value will refresh the adjusted screen.
- Settings can be adjusted and stored for each external device you have connected to an input of the TV. For example, if you have a DVD player connected to HDMI 1 and it is currently selected, settings and adjustments will be saved for the DVD player.






Adjusting the White Balance

You can adjust the color temperature for more natural picture colors.

17. Press the ▲ or ▼ button to select "White Balance", then press the **ENTER** button.
18. Select the required option by pressing the ▲ or ▼ button, then press the **ENTER** button.
19. Press the ◀ or ▶ button to decrease or increase the value of a particular item. Press the **ENTER** button.

- **R-Offset:** Adjusts the red color darkness.
- **G-Offset:** Adjusts the green color darkness.
- **B-Offset:** Adjusts the blue color darkness.
- **R-Gain:** Adjusts the red color brightness.
- **G-Gain:** Adjusts the green color brightness.
- **B-Gain:** Adjusts the blue color brightness.
- **Reset:** The previously adjusted white balance will be reset to the factory defaults.

➤ Changing the adjustment value will refresh the adjusted screen.




Adjusting the Flesh Tone

You can emphasize the pink 'flesh tone' in the picture.

20. Press the ▲ or ▼ button to select "Flesh Tone", then press the **ENTER** button.
21. Press the ◀ or ▶ button to decrease or increase the value.
Press the **ENTER** button.


➤ Changing the adjustment value will refresh the adjusted screen.



Setting the Edge Enhancement

You can emphasize object boundaries in the picture.


22. Press the ▲ or ▼ button to select "Edge Enhancement", then press the **ENTER** button.
23. Press the ▲ or ▼ button to select "Off" or "On". Press the **ENTER** button.



Setting the xvYCC


Setting the xvYCC mode to "On" increases detail and color space when watching movies from an external device (ie. DVD player) connected to the HDMI or Component IN jacks.

24. Press the ▲ or ▼ button to select "xvYCC", then press the **ENTER** button.
25. Press the ▲ or ▼ button to select "Off" or "On".
Press the **ENTER** button.
➢ "xvYCC" is available when the picture mode is set to "Movie", and the external input is set to "HDMI" or "Component" mode.




Resetting the Picture Settings to the Factory Defaults

1. To select the desired picture mode, follow the "Changing the Picture Standard" instructions numbers 1 and 2. (see page 20)




2. Press the ▲ or ▼ button to select "Picture Reset", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "OK" or "Cancel", then press the **ENTER** button.
Press the **EXIT** button to exit.
➢ Each mode can be reset.



Configuring Picture Options


Activating Picture Options

1. Press the **MENU** button to display the menu.
Press the **ENTER** button to select "Picture".
2. Press the **▲** or **▼** button to select "Picture Options", then press the **ENTER** button.
 - Press the **▲** or **▼** button to select a particular item. Press the **ENTER** button.
 - When you are satisfied with your setting, press the **ENTER** button.
 - In PC mode, you can only make changes to the "Color Tone" and "Size" from among the items in "Picture Options".



Setting the Color Tone

1. Follow the "Activating Picture Options" instructions numbers 1 and 2.
2. Press the **▲** or **▼** button to select "Color Tone", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select "Cool2", "Cool1", "Normal", "Warm1" or "Warm2". Press the **ENTER** button.
 - "Warm1" or "Warm2" is only activated when the picture mode is "Movie".
 - Settings can be adjusted and stored for each external device you have connected to an input of the TV.



Setting the Screen Size

Occasionally, you may want to change the size of the image on your screen. Your TV comes with six screen size options, each designed to work best with specific types of video input. Your cable box or satellite receiver may have its own set of screen sizes as well. In general, though, you should view the TV in 16:9 mode as much as possible.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2.
2. Press the **▲** or **▼** button to select "Size", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select the screen format you want.
Press the **ENTER** button.

Press the **EXIT** button to exit.


- **16:9** : Sets the picture to 16:9 wide mode.
- **Zoom1**: Magnifies the size of the picture on the screen.
- **Zoom2**: Magnifies the size of the picture more than "Zoom1".
- **Wide Fit**: Enlarges the aspect ratio of the picture to fit the entire screen.
- **4:3** : Sets the picture to 4:3 normal mode.
- **Just Scan**: Use the function to see the full image without any cutoff when HDMI (720p/1080i/1080p), Component (1080i/1080p) or DTV (1080i) signals are input.



- > When Double (□□, □□) mode has been set in PIP, the Picture Size cannot be set.
- > Temporary image retention may occur when viewing a static image on the set for more than two hours.
- > **After selecting "Zoom1", "Zoom2" or "Wide Fit":**
Press the **◀** or **▶** button to select "Position", then press the **ENTER** button. Press the **▲** or **▼** button to move the picture up and down.
Reset: Press the **◀** or **▶** button to select "Reset", then press the **ENTER** button. You can initialize the setting.





- > **After selecting "Just Scan" in HDMI (1080i/1080p) or Component (1080i/1080p) mode:**
Press the **◀** or **▶** button to select "Position", then press the **ENTER** button. Press the **▲**, **▼**, **◀** or **▶** button to move the picture.
Reset: Press the **◀** or **▶** button to select "Reset", then press the **ENTER** button. You can initialize the setting.
- > HD (High Definition)
16:9 - 1080i/1080p (1920x1080), 720p (1280x720)



- > Settings can be adjusted and stored for each external device you have connected to an input of the TV.

Input Source	Picture Size
ATV, Video, S-Video, Component (480i, 480p)	16:9, Zoom1, Zoom2, 4:3
DTV(720p), Component (720p)	16:9, 4:3, Wide Fit
DTV(1080i), Component (1080i, 1080p), HDMI (720p, 1080i, 1080P)	16:9, 4:3, Wide Fit, Just Scan
PC	16:9, 4:3

☞ Alternately, you can press the **P.SIZE** button on the remote control repeatedly to change the picture size.



16:9

Sets the picture to 16:9 wide mode.



Zoom1

Magnifies the size of the picture on the screen.



Zoom2

Magnifies the size of the picture more than "Zoom1".



Wide Fit

Enlarges the aspect ratio of the picture to fit the entire screen.



4:3

Sets the picture to 4:3 normal mode.



Just Scan

Use the function to see the full image without any cutoff when HDMI (720p/1080i/1080p), Component (1080i/1080p) or DTV (1080i) signals are input.



Setting the Digital Noise Reduction

If the broadcast signal received by your TV is weak, you can activate the Digital Noise Reduction feature to help reduce any static and ghosting that may appear on the screen.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
2. Press the ▲ or ▼ button to select "Digital NR", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "Off", "Low", "Medium", "High" or "Auto". Press the **ENTER** button.

- **Off:** Turns the screen noise reduction function off.
- **Low:** Reduces screen noise at a low level.
- **Medium:** Reduces screen noise at a medium level.
- **High:** Reduces screen noise at a high level.
- **Auto:** Automatically recognizes and reduces screen noise.

Press the **EXIT** button to exit.





Setting the DNle (Digital Natural Image engine)

This TV includes the DNle function to provide high visual quality. If you set DNle to on, you can view the screen with the DNle feature activated.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
 2. Press the ▲ or ▼ button to select "DNle", then press the **ENTER** button.
 3. Press the ▲ or ▼ button to select "Off" or "On", then press the **ENTER** button.
- **Off:** Switches off the DNle mode.
 - **On:** Switches on the DNle mode.

Press the **EXIT** button to exit.

- DNle™ (Digital Natural Image engine) **[DNle]**
This feature brings you a more detailed image with 3D noise reduction and detail, contrast and white enhancement.
- "DNle" is only available in "Dynamic" mode.



Setting the HDMI Black Level



You can select the black level on the screen to adjust the screen depth.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
2. Press the ▲ or ▼ button to select "HDMI Black Level", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "Normal" or "Low", then press the **ENTER** button.

- **Normal:** The screen gets brighter.
- **Low:** The screen gets darker.

- This function is active only when an external device is connected to the TV via HDMI. "HDMI Black Level" function may not be compatible with all external devices.



Press the **EXIT** button to exit.



Setting the Film Mode

The TV can be set to automatically sense and process film signals from all sources and adjust the picture for optimum quality.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
2. Press the ▲ or ▼ button to select "Film Mode", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "Off" or "Auto", then press the **ENTER** button.
Press the **EXIT** button to exit.
➤ "Film mode" is supported in TV, Video, S-Video, Component (480i / 1080i) and HDMI (480i / 1080i).





Setting the Blue Only Mode

This function is for AV device measurement experts. This function displays the blue signal only by removing the red and green signals from the video signal so as to provide a Blue Filter effect that is used to adjust the Color and Tint of video equipment such as DVD players, Home Theaters, etc.

Using this function, you can adjust the Color and Tint to preferred values appropriate to the signal level of each video device using the Red/Green/Blue/Cyan/Magenta/Yellow Color Bar Patterns, without using an additional Blue Filter.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
2. Press the ▲ or ▼ button to select "Blue Only Mode", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "Off" or "On", then press the **ENTER** button.
Press the **EXIT** button to exit.
➤ "Blue Only Mode" is available when the picture mode is set to "Movie" or "Standard".



Setting the Auto Motion Plus 120Hz (LN40A650A1F, LN46A650A1F, LN52A650A1F)


Removes drag from fast scenes with a lot of movement to provide a clearer picture.

1. Follow the "Activating Picture Options" instructions numbers 1 and 2. (Refer to page 25)
2. Press the ▲ or ▼ button to select "Auto Motion Plus 120Hz", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select "Off", "Low", "Medium", "High" or "Demo", then press the **ENTER** button:

- **Off:** Switches Auto Motion Plus 120Hz off.
- **Low:** Sets Auto Motion Plus 120Hz to minimum.
- **Medium:** Sets Auto Motion Plus 120Hz to medium.
- **High:** Sets Auto Motion Plus 120Hz to maximum.
- **Demo:** Displays the difference between Auto Motion Plus 120Hz on and off modes. The screen after applying "Auto Motion Plus 120Hz" appears on the left.

Press the **EXIT** button to exit.

- If you enable "Auto Motion Plus 120Hz", noise may appear on the screen. If this occurs, set "Auto Motion Plus 120Hz" to "Off".




Viewing Picture-in-Picture

You can use the PIP feature to simultaneously watch the TV tuner (analog broadcasts only) and one external video source. (See page 35 to select the PIP picture sound.) This product has one built-in tuner, which does not allow PIP to function in the same mode. Please see 'PIP Settings' below for details.

- While V-Chip (See page 51) is in operation, the PIP function cannot be used.

Activating Picture-in-Picture


- Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
Press the **▲** or **▼** button to select "PIP", then press the **ENTER** button.



- Press the **ENTER** button again.
Press the **▲** or **▼** button to select "On", then press the **ENTER** button.
 - If you turn the TV off while watching in PIP mode and turn it on again, the PIP window will disappear.
 - You can view Analog TV broadcasts on the PIP screen (sub-picture) when the main picture is from an external device connected to HDMI 1, HDMI/DVI 2, HDMI 3, HDMI 4, Component1, 2 or PC.


PIP Settings

Main picture	Sub picture
Component 1, 2	
HDMI 1, HDMI/DVI 2, HDMI 3, HDMI 4	Analog TV broadcasts only
PC	




Changing the Size of the PIP Window

- Press the **▲** or **▼** button to select "Size", then press the **ENTER** button.
Press the **▲** or **▼** button to select the required option, then press the **ENTER** button.
 - You may notice that the picture in the PIP window becomes slightly unnatural when you use the main screen to view a game or karaoke.




Changing the Position of the PIP Window

- Press the **▲** or **▼** button to select "Position", then press the **ENTER** button.
Press the **▲** or **▼** button to select the required option, then press the **ENTER** button.
 - In Double Window (□□) and Double Wide (□□) modes, "Position" cannot be selected.




Changing the PIP Channel

5. Press the ▲ or ▼ button to select "Air/Cable", then press the **ENTER** button.
6. Press the ▲ or ▼ button to select "Air" or "Cable", then press the **ENTER** button.




7. Press the ▲ or ▼ button to select "Channel", then press the **ENTER** button.
 8. Press the ▲ or ▼ button to select the desired channel in the PIP window. Press the **ENTER** button.
- You can select only analog TV broadcasts on the PIP screen (sub-picture).

Press the **EXIT** button to exit.



Easy Setting

1. Press the **TOOLS** button on the remote control.
2. Press the ▲ or ▼ button to select "PIP", then press the **ENTER** button.
3. Press the ▲ or ▼ button to select a particular item.
4. Press the ◀ or ▶ button to select the required option.
5. Press the **EXIT** or **TOOLS** button to exit.




Sound Control

Changing the Sound Standard

You can select the sound mode to best suit the programming you're watching.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER**  button.



2. Press the **ENTER**  button to select "Mode". Press the **▲** or **▼** button to select "Standard", "Music", "Movie", "Speech", or "Custom" sound setting, then press the **ENTER**  button.


Press the **EXIT** button to exit.

- **Standard:** Selects the normal sound mode.
- **Music:** Emphasizes music over voices.
- **Movie:** Provides the best sound for movies
- **Speech:** Emphasizes voice over other sounds.
- **Custom:** Recalls your customized sound settings. (see "Customizing the Sound")



Easy Setting


1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Sound Mode".
3. Press the **◀** or **▶** button to select the required option.
4. Press the **EXIT** or **TOOLS** button to exit.




Customizing the Sound

The sound settings can be adjusted to suit your personal preference.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "Equalizer", then press the **ENTER**  button.




3. Press the **ENTER**  button to select "Mode".
Press the **▲** or **▼** button to select "Standard", "Music", "Movie", "Speech", or "Custom" sound setting, then press the **ENTER**  button.




4. Press the **▲** or **▼** button to select a particular frequency to adjust.
Press the **◀** or **▶** button to increase or decrease the level of the particular frequency.

- **Mode:** Selects the sound mode among the predefined settings.
- **Balance L/R:** Adjusts the balance between the right and left speaker.
- **Bandwidth Adjustment (100Hz, 300Hz, 1kHz, 2kHz, 3kHz, 10kHz):**
To adjust the level of different bandwidth frequencies.



Resetting the Equalizer Settings to the Factory Defaults


5. Press the **▲** or **▼** button to select “Reset”, then press the **ENTER** button.
➤ The equalizer resets to the factory defaults.
Press the **EXIT** button to exit.




Setting the TruSurround XT

TruSurround XT is a patented SRS technology that solves the problem of playing 5.1 multichannel content over two speakers. TruSurround delivers a compelling, virtual surround sound experience through any two-speaker playback system, including internal television speakers. It is fully compatible with all multichannel formats.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select “Sound”, then press the **ENTER** button.
2. Press the **▲** or **▼** button to select “SRS TruSurround XT”, then press the **ENTER** button.



3. Press the **▲** or **▼** button to select “Off” or “On”, then press the **ENTER** button.
Press the **EXIT** button to exit.




TruSurround XT, SRS and Symbol are trademarks of SRS Labs, Inc.
TruSurround XT technology is incorporated under license from SRS Labs, Inc.

Choosing Preferred Language

The digital-TV transmission system is capable of simultaneous transmission of many audio tracks (for example, simultaneous translations of the program into foreign languages). Select the language you would like to hear the audio track in.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER** button.



2. Press the **▲** or **▼** button to select "Preferred Language", then press the **ENTER** button.
3. Press the **▲** or **▼** button to choose the language (English, Spanish or French) you want, then press the **ENTER** button.


Press the **EXIT** button to exit.

- "Preferred Language" is available only in Digital TV mode.
- You can only select the language from among the actual languages being broadcast.



Choosing a Multi-Channel Sound (MTS) track


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Multi-Track Sound", then press the **ENTER** button.



3. Press the **▲** or **▼** button to select a setting you want, then press the **ENTER** button. Press the **EXIT** button to exit.


- **Mono**: Choose for channels that are broadcasting in mono or if you are having difficulty receiving a stereo signal.
- **Stereo**: Choose for channels that are broadcasting in stereo.
- **SAP**: Choose to listen to the Separate Audio Program, which is usually a foreign-language translation.

- "Multi-Track Sound" is available only in Analog TV mode.
- Depending on the particular program being broadcast, you can listen to "Mono", "Stereo" or "SAP".



Easy Setting

1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Multi-Track Sound".
3. Press the **◀** or **▶** button to select the required option.
4. Press the **EXIT** or **TOOLS** button to exit.



Automatic Volume Control


Reduces the differences in volume level among broadcasters.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "Auto Volume", then press the **ENTER**  button.



3. Press the **▲** or **▼** button to set "Auto Volume" "Off" or "On" then press the **ENTER**  button.


Press the **EXIT** button to exit.



Setting the TV Speakers On/Off

Sound output from the TV speakers is muted.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "TV Speaker", then press the **ENTER**  button.



3. Press the **▲** or **▼** button to select "Off", then press the **ENTER**  button.

Press the **EXIT** button to exit.

➢ When "TV Speaker" is set to "Off", you can operate only "Preferred Language" (in digital TV mode), "Multi-Track Sound" (in analog TV mode), "Sound Select" (in PIP mode) and "Sound Reset" in Sound menu.

➢ The **VOL -**, **VOL +** and **MUTE** buttons do not operate when the "TV Speaker" is set to "Off".



	TV's Internal Speakers			Audio Out (Optical, L/R Out) to Sound System		
	RF	AV, S-Video	Component, PC, HDMI	RF	AV, S-Video	Component, PC, HDMI
TV Speaker On	Speaker Output	Speaker Output	Speaker Output	Sound Output	Sound Output	Sound Output
TV Speaker Off	Mute	Mute	Mute	Sound Output	Sound Output	Sound Output
Video No Signal	Mute	Mute	Mute	Mute	Mute	Mute




Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

Listening to the Sound of the Sub (PIP) Picture

When the PIP feature is activated, you can listen to the sound of the sub (PIP) picture.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Sound Select", then press the **ENTER** button.




3. Press the **▲** or **▼** button to select "Main" or "Sub", then press the **ENTER** button.

Press the **EXIT** button to exit.

- **Main:** Used to listen to the sound of the main picture.
- **Sub:** Used to listen to the sound of the sub picture.

➢ You can select this option when "PIP" is set to "On". (See page 29)





Resetting the Sound Settings to the Factory Defaults

You can restore the Sound settings to the factory defaults.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Sound", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Sound Reset", then press the **ENTER** button.
Press the **EXIT** button to exit.
3. Press the **◀** or **▶** button to select "Reset All", "Reset Sound Mode" or "Cancel" then press the **ENTER** button.
Press the **EXIT** button to exit.


- **Reset All:** All the sound values return to default settings.
- **Reset Sound Mode:** Current sound values return to default settings.



Connecting Headphones (Sold separately)

You can connect a set of headphones to your set if you wish to watch a TV program without disturbing other people in the room.

- When you insert the headphone's plug into the headphone jack, you can operate only "Preferred Language" (in digital TV mode), "Multi-Track Sound" (in analog TV mode), "Auto Volume", "Sound Select" (in PIP mode) and "Sound Reset" in Sound menu.
- Prolonged use of headphones at a high volume may damage your hearing.
- You will not hear sound from the speakers when you connect headphones to the TV.
- The headphone volume and TV volume are adjusted separately.



Channel Control

Managing Channels


Using this menu, you can Add/Delete or set Favorite channels and use the program guide for digital broadcasts.

Viewing All Channels


Show all currently available channels.

To use the Channel List function, first run "Auto Program" (see page 18).


1. Press the **MENU** button.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER** button.



2. Press the **◀** button to select "Added Channels".



3. Press the **▲** or **▼** button to select "All Channels".
➤ Shows all currently available channels.
Press the **ENTER** button.
4. Press the **▲** or **▼** button to select a channel to view, then press the **ENTER** button. You can watch the selected channel.




- Press the **CH LIST** button on the remote control to bring up the channel lists.



Using the Color buttons on the Remote with the Channel List

- **Red (Antenna)**: Switches to Air or Cable.
- **Green (Zoom)**: Enlarges or shrinks a channel number.
- **Yellow (Select)**: Selects multiple channel lists.
- **TOOLS (Option)**: Displays the "Add" (or "Delete"), "Add to Favorite"(or "Delete from Favorite"), "Timer Viewing", "Channel Name Edit", and "Auto Program" menus.




- A gray-colored channel indicates the channel has been deleted.
The "Add" menu only appears for deleted channels.
- A channel marked with the "♥" mark means the channel has been set as a Favorite.
The "Delete from Favorite" menu only appears for channels with the "♥" mark.

Erasing and Adding Channels

You can delete or add a channel to display the channels you want.

1. Press the **MENU** button.

Press the **▲** or **▼** button to select "Channel", then press the **ENTER**  button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER**  button.




2. Press the **◀** button to select "Added Channels".



3. Press the **▲** or **▼** button to select "All Channels".

➢ Shows all currently available channels.

Press the **ENTER**  button.



4. Press the **▲** or **▼** button to select a channel to delete, then press the **TOOLS** button.

5. Press the **ENTER**  button to select "Delete".


➢ All deleted channels will be shown on "All Channels" menu.

6. Press the **EXIT** button to exit.


➢ You can also add a channel to the "Added Channels" menu in the same manner.

➢ A channel must be deleted before it can be added back to the "Added Channels" list.

➢ To Add (Restore) a channel back to the Added Channel List, follow steps 1-3 above, press the **▲** or **▼** button to select a channel to add, the press the **TOOLS** button. Press the **ENTER**  button to select Add.





- Press the **CH LIST** button on the remote control to bring up the channel lists.



Setting Your Favorite Channels

You can set channels you watch frequently as favorites.

1. Press the **MENU** button.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER**  button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER**  button.
2. Press the **◀** button to select "Added Channels".
3. Press the **▲** or **▼** button to select "All Channels".
➤ Shows all currently available channels.
Press the **ENTER**  button.
4. Press the **▲** or **▼** button to select a channel as a favorite channel.
➤ **Adding multiple channels to Favorites**
Press the **▲** or **▼** button to select the desired channel in the channel list. Then press the yellow button. Repeat the above operation to select multiple channels. The **✓** mark appears to the left of the selected channels.
5. Press the **TOOLS** button.
6. Press the **▲** or **▼** button to select "Add to Favorite", then press the **ENTER**  button. The "**♥**" symbol will be displayed and the channel will be set as a favorite.
7. To cancel your favorite channel selection, press the **TOOLS** button when a favorite channel is selected.
Press the **▲** or **▼** button to select "Delete from Favorite", then press the **ENTER**  button.
The channel is deleted from "Favorites" and the "**♥**" mark also disappears.
Press the **EXIT** button to exit.
➤ You can also Add or Delete a channel from Favorites in the "Added Channels" menu in the same manner.
➤ All favorite channels will be shown on "Favorite" menu.






 Press the **CH LIST** button on the remote control to bring up the channel lists.

 To select the favorite channels you have set up, press the **FAV.CH** button on the remote control.

Easy Setting

1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Add to Favorite" (or "Delete from Favorite"), then press the **ENTER**  button.
➤ The current channel is added to (or deleted from) Favorites.




Reserving a Program (Timer Viewing)

If you reserve a program you want to watch, the channel is automatically switched to the reserved channel in the Channel List; even when you are watching another channel.

To reserve a program, set the current time first. See pages 47~48. Reserved channels can only be set if they are in the "Channel List" (See page 36).

1. Press the **MENU** button.

Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER** button.





2. Press the **▲** or **▼** button to select a channel, then press the **TOOLS** button.

3. Press the **▲** or **▼** button to select "Timer Viewing", then press the **ENTER** button. The Reserve a Program (Timer Viewing) screen appears.


4. Press the **▲/▼/◀/▶** buttons to reserve a program and then press the **ENTER** button. Reserving a program has been completed.

Press the **EXIT** button to exit.

- You can also reserve a program in the "All Channels" or "Favorite" menus using the same procedures.
- For information on how to confirm a viewing reservation, refer to page 40. Only memorized channels can be reserved.
- You can set the channel, month, day, year, hour and minute directly by pressing the number buttons on the remote control.



- Press the **CH LIST** button on the remote control to bring up the channel lists.




Digital Program Guide and Viewing Reservation

When a digital channel is selected, and you press the **▶** button, the Program Guide for the channel appears. You can reserve a program according to the procedures described above.

▶ : A program currently being broadcast.


◎ : A reserved program




Confirming a Viewing Reservation

You can view, modify or delete a reservation.

1. Press the **MENU** button.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER** button.



2. Press the **◀** button to select "Added Channels".




3. Press the **▲** or **▼** button to select "Programmed".
Shows all current reserved programs.

Press the **ENTER** button.



Modifying a viewing reservation

4. To select a reservation item to be modified, press the **▲** or **▼** button and then press the **TOOLS** button.
5. Press the **ENTER** button to select "Change Info".
6. Press the **▲/▼/◀/▶** buttons to change a reservation setting and then press the **ENTER** button. The reservation modification is applied.



Cancelling a reservation


4. To select a reservation item to be canceled, press the **▲** or **▼** button, and then press the **TOOLS** button.
5. Press the **▲** or **▼** button to select "Cancel schedules", then press the **ENTER** button.
6. Press the **◀** or **▶** button to select "OK", then press the **ENTER** button. The viewing reservation has been canceled.

Press the **EXIT** button to exit.

Programmed Option

- **Change Info:** Select to change a viewing reservation.
- **Cancel schedules:** Select to cancel a viewing reservation.
- **Information:** Select to view a viewing reservation.


Press the **CH LIST** button on the remote control to bring up the channel lists.



Labeling Channels - Analog

Channels can be labeled so that their call letters appear whenever the channel is selected.


1. Press the **MENU** button.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Channel List", then press the **ENTER** button.



2. Press the **▲** or **▼** button to select the channel to be assigned a new name, then press the **TOOLS** button.



3. Press the **▲** or **▼** button to select "Channel Name Edit", then press the **ENTER** button.



4. Press the **▲/▼/◀/▶** button to select a letter, then press the **ENTER** button.

- **Numeric buttons:** You can enter numbers.
- **Red button:** You can switch between English and Characters.
- **Green button:** You can delete an already entered character.
- **Yellow button:** You can enter a blank space.
- **Blue button:** Press this button to finish renaming a channel.



5. When you have finished, press the blue button to assign the new name.


Press the **EXIT** button to exit.

- The names of digital broadcasting channels are automatically assigned and cannot be labelled.

Storing Channels in Memory (Auto Program)

1. Press the **MENU** button.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button. Press the **▲** or **▼** button to select "Channel List", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select the channel to be assigned a new name, then press the **TOOLS** button.
3. Press the **▲** or **▼** button to select "Auto Program", then press the **ENTER** button.


- For further details on setting up options, refer to page 18.



Clearing Scrambled Channels - Digital

The "Clear Scrambled Channel" function is used to filter out scrambled channels after "Auto Program" is completed. This process may take up to 20~30 minutes.



1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Clear Scrambled Channel", then press the **ENTER** button. It searches scrambled channels, which are to be removed from the list.
 - To stop searching scrambled channels:
Press the **ENTER** button to select "Stop".
Press the **◀** button to select "Yes", then press the **ENTER** button.
3. When the scrambled channel searching is completed, press the **ENTER** button.
Press the **EXIT** button to exit.
 - This function is only available in "Cable" mode.



Fine Tuning Analog Channels

Use fine tuning to manually adjust a particular channel for optimal reception.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Channel", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Fine Tune", then press the **ENTER** button.
3. Press the **◀** or **▶** button to adjust the fine tuning.
To store the fine tuning setting in the TV's memory, press the **ENTER** button.
 - If you do not store the fine-tuned channel in memory, adjustments are not saved.
4. To reset the fine tuning setting, press the **▼** button to select "Reset", then press the **ENTER** button.
Press the **EXIT** button to exit.
 - "*" will appear next to the name of fine-tuned channels.
 - Only analog TV channels can be fine tuned.



Checking the Digital-Signal Strength

Unlike analog channels, which can vary in reception quality from "snowy" to clear, digital (HDTV) channels have either perfect reception quality or you will not receive them at all. So, unlike analog channels, you cannot fine tune a digital channel. You can, however, adjust your antenna to improve the reception of available digital channels.


1. Press the **MENU** button to display the menu. Press the **▲** or **▼** button to select "Channel", then press the **ENTER**  button.

2. Press the **▲** or **▼** button to select "Signal Strength", then press the **ENTER**  button.

If the signal strength meter indicates that the signal is weak, physically adjust your antenna to increase the signal strength.

Continue to adjust the antenna until you find the best position with the strongest signal.

Press the **EXIT** button to exit.



PC Display

Using Your TV as a Computer (PC) Display

Setting Up Your PC Software (Based on Windows XP)

The Windows display-settings for a typical computer are shown below. The actual screens on your PC will probably be different, depending upon your particular version of Windows and your particular video card. However, even if your actual screens look different, the same basic set-up information will apply in almost all cases. (If not, contact your computer manufacturer or Samsung Dealer.)

1. First, click on "Control Panel" on the Windows start menu.
2. When the control panel window appears, click on "Appearance and Themes" and a display dialog-box will appear.
3. When the control panel window appears, click on "Display" and a display dialog-box will appear.
4. Navigate to the "Settings" tab on the display dialog-box.

The correct size setting (resolution)

Optimum: 1920 X 1080 pixels

If a vertical-frequency option exists on your display settings dialog box, the correct value is "60" or "60 Hz". Otherwise, just click "OK" and exit the dialog box.



Display Modes

If the signal from the system equals the standard signal mode, the screen is adjusted automatically. If the signal from the system doesn't equal the standard signal mode, adjust the mode by referring to your videocard user guide; otherwise there may be no video. For the display modes listed below, the screen image has been optimized during manufacturing.

D-Sub Input

Mode	Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity (H/V)
IBM	640 x 350	31.469	70.086	25.175	+ / -
	720 x 400	31.469	70.087	28.322	- / +
VESA	640 x 480	31.469	59.940	25.175	- / -
	640 x 480	37.861	72.809	31.500	- / -
	640 x 480	37.500	75.000	31.500	- / -
	800 x 600	37.879	60.317	40.000	+ / +
	800 x 600	48.077	72.188	50.000	+ / +
	800 x 600	46.875	75.000	49.500	+ / +
	1024 x 768	48.363	60.004	65.000	- / -
	1024 x 768	56.476	70.069	75.000	- / -
	1024 x 768	60.023	75.029	78.750	+ / +
	1280 x 1024	63.981	60.020	108.000	+ / +
	1280 x 1024	79.976	75.025	135.000	+ / +
	1360 x 768	47.712	60.015	85.500	+ / +
CVT	1920 x 1080RB	66.587	59.934	138.500	+ / -

HDMI/DVI Input



Mode	Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity (H/V)
VESA	640 x 480	31.469	59.940	25.175	- / -
	800 x 600	37.879	60.317	40.000	+ / +
	1024 x 768	48.363	60.004	65.000	- / -
	1280 x 1024	63.981	60.020	108.000	+ / +
	1360 x 768	47.712	60.015	85.500	+ / +
CEA	1920 x 1080p	67.500	60.000	148.500	+ / +

Setting up the TV with your PC

How to Auto Adjust




Use the Auto "Adjust function" to have the TV set automatically adjust the video signals it receives. The function also automatically fine-tunes the settings and adjusts the frequency values and positions.

- This function does not work in DVI-Digital mode.
 - Preset: Press the **SOURCE** button to select PC mode.
1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Picture", then press the **ENTER** button.
Press the **EXIT** button to exit.
 2. Press the **▲** or **▼** button to select "Auto Adjustment", then press the **ENTER** button.
Press the **EXIT** button to exit.



Easy Setting


1. Press the **TOOLS** button on the remote control.
2. Press the **▲** or **▼** button to select "Auto Adjustment", then press the **ENTER** button.




Changing the Screen Position

Adjust the PC's screen positioning if it does not fit the TV screen.


- Preset: Press the **SOURCE** button to select PC mode.
- 1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Picture", then press the **ENTER** button.



- 2. Press the **▲** or **▼** button to select "Screen", then press the **ENTER** button.





- 3. Press the **▲** or **▼** button to select "Position", then press the **ENTER** button.
4. Press the **▲** or **▼** button to adjust the V-Position.
Press the **◀** or **▶** button to adjust the H-Position.
Press the **ENTER** button.
Press the **EXIT** button to exit.



Initializing the Screen Position, Coarse and Fine

You can replace all image settings with the factory default values.

- Preset: Press the **SOURCE** button to select PC mode.
- 1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Picture", then press the **ENTER** button.
- 2. Press the **▲** or **▼** button to select "Screen", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select "Image Reset", then press the **ENTER** button.
Press the **EXIT** button to exit.




Time Setting

Setting the Clock


Setting the clock is necessary in order to use the various timer features of the TV.
Also, you can check the time while watching the TV. (Just press the **INFO** button.)

Option 1: Setting the Clock Manually


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.
Press the **▲** or **▼** button to select "Time", then press the **ENTER**  button.




2. Press the **ENTER**  button to select "Clock".




3. Press the **ENTER**  button to select "Clock Mode".
Press the **▲** or **▼** button to select "Manual", then press the **ENTER**  button.



4. Press the **▲** or **▼** button to select "Clock Set", then press the **ENTER**  button.




5. Press the **◀** or **▶** button to move to "Month", "Day", "Year", "Hour", "Minute", or "am/pm". Set the date and time you want by pressing the **▲** or **▼** button, then press the **ENTER**  button.
Press the **EXIT** button to exit.
 - The current time will appear every time you press the **INFO** button.
 - You can set the month, day, year, hour and minute directly by pressing the number buttons on the remote control.




Option 2: Setting the Clock Automatically

The Clock can be set automatically if you are receiving a digital signal.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Time", then press the **ENTER** button.




2. Press the **ENTER** button to select "Clock".




3. Press the **ENTER** button to select "Clock Mode".
Press the **▲** or **▼** button to select "Auto", then press the **ENTER** button.



4. Press the **▲** or **▼** button to select "Time Zone", then press the **ENTER** button.



5. Press the **▲** or **▼** button to highlight the time zone for your local area, then press the **ENTER** button.



6. Press the **▲** or **▼** button to select "DST" (Daylight Saving Time), then press the **ENTER** button. Press the **▲** or **▼** button to select "Off" or "On", then press the **ENTER** button.


Press the **EXIT** button to exit.

- Depending on the broadcast station and signal, the auto time may not be set correctly. If this occurs, set the time manually.
- The Antenna or cable must be connected in order to set the time automatically.


Setting the Sleep Timer

The sleep timer automatically shuts off the TV after a preset time (30, 60, 90, 120, 150 and 180 minutes).

- 1.** Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Time", then press the **ENTER** button.




- 2.** Press the **▲** or **▼** button to select "Sleep Timer", then press the **ENTER** button.
- 3.** Press the **▲** or **▼** button to select the minute, then press the **ENTER** button.
To cancel the set sleep timer:
Press the **▲** or **▼** button to select "Off", then press the **ENTER** button.
- 4.** Press the **EXIT** button to exit.




Easy Setting

- 1.** Press the **TOOLS** button on the remote control.
- 2.** Press the **▲** or **▼** button to select "Sleep Timer".
- 3.** Press the **◀** or **▶** button to select the minute.
- 4.** Press the **EXIT** or **TOOLS** button to exit.




Setting the On/Off Timer

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Time", then press the **ENTER** button.





2. Three different On/Off Timer Settings can be made. Press the **▲** or **▼** button to select "Timer 1", "Timer 2" or "Timer 3", then press the **ENTER** button.



3. Press the **◀** or **▶** button to select the desired item below.

Press the **▲** or **▼** button to adjust the setting.

- **On Time:** Set the Hour, Minute, am/pm, and Activate/Inactivate.
(To activate timer with the setting you've chosen, set to "Activate".)
- **Off Time:** Set the Hour, Minute, am/pm, and Activate/Inactivate.
(To activate timer with the setting you've chosen, set to "Activate".)
- **Volume:** Set the required volume level.
- **Contents:** When the "On Time" is active, you can turn on a specific channel or play back contents such as photo or audio files.
 - TV/USB: Select TV or USB. (Make sure that an USB device is connected to your TV.)
 - Antenna: Select "Air" or "Cable".
 - Channel: Select the desired channel.
 - Music: Select the folder containing MP3 files on the USB device.
 - Photo: Select the folder containing JPEG files on the USB device.
- **Repeat:** Select "Once", "Everyday", "Mon~Fri", "Mon~Sat", "Sat~Sun", or "Manual".
 - When "Manual" is selected, press the **▶** button to select the desired day of the week. Press the **ENTER** button over the desired day and the **✓** mark will appear.



Press the **EXIT** button to exit.

➢ You can set the hour, minute and channel by pressing the number buttons on the remote control.


> Auto Power Off

When you set the timer On, the television will eventually turn off, if no controls are operated for 3 hours after the TV was turned on by the timer. This function is only available in timer On mode and prevents overheating, which may occur if a TV is on for too long time.

Function Description

Selecting a Menu Language

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Language", then press the **ENTER** button.



2. Press the **▲** or **▼** button to select "English", "Español" or "Français".
Press the **ENTER** button.
Press the **EXIT** button to exit.





Using the V-Chip

The V-Chip feature automatically locks out programs that are deemed inappropriate for children. The user must enter a PIN (personal ID number) before any of the V-Chip restrictions are set up or changed.


➤ "V-Chip" function is not available in HDMI, Component or PC mode.

Setting Up Your Personal ID Number (PIN)

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER** button.
The message "Enter PIN" will appear. Enter your 4 digit PIN number.
➤ The default PIN number of a new TV set is "0-0-0-0".





- 3.** The "V-Chip" screen will appear.
 Press the **▲** or **▼** button to select "Change PIN", then press the **ENTER** button. The Change PIN screen will appear. Choose any 4 digits for your PIN and enter them. As soon as the 4 digits are entered, the "Confirm new PIN." screen appears. Re-enter the same 4 digits. When the Confirm screen disappears, your PIN has been memorized.
 Press the **EXIT** button to exit.
- If you forget the PIN, press the remote-control buttons in the following sequence, which resets the pin to 0-0-0-0 : Power Off. → Mute → 8 → 2 → 4 → Power On.



How to Enable/Disable the V-Chip

- 1.** Press the **MENU** button to display the menu.
 Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER** button.
 The message "Enter PIN" will appear. Enter your 4 digit PIN number.



- 3.** The "V-Chip" screen will appear.
 To enable the V-Chip feature, press the **ENTER** button so that the "V-Chip Lock" field is "On". (Pressing the **▲** or **▼** button will alternate between "On" and "Off".)
 Press the **ENTER** button.
 Press the **EXIT** button to exit.



How to Set up Restrictions Using the TV Parental Guidelines

First, set up a personal identification number (PIN) and enable the V-Chip. (See previous section.) Parental restrictions can be set up using either of two methods: The TV guidelines or the MPAA rating.





1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER**  button. The message "Enter PIN" will appear. Enter your 4 digit PIN number.
3. The "V-Chip" screen will appear. Press the **▲** or **▼** button to select "TV Parental Guidelines", then press the **ENTER**  button.
4. The "TV Parental Guidelines" screen will appear.
Press the **▲** or **▼** button to select one of the six aged based categories:

- | | |
|--------------------------------------|--------------------------------------|
| • TV-Y : Young children | • TV-PG : Parental guidance |
| • TV-Y7 : Children 7 and over | • TV-14 : Viewers 14 and over |
| • TV-G : General audience | • TV-MA : Mature audience |

5. At this point, one of the TV-Ratings is selected.
Press the **ENTER**  button. Depending on your existing setup, the " symbol will be selected. (Blank = Unblocked,  = Blocked)
While " is selected, press the **ENTER**  button to block or unblock the category. To select a different TV-Rating, press the **▲** or **▼** button and then repeat the process.
 - Allow all: Press to unlock all TV ratings.
Block all: Press to lock all TV ratings.
 - The TV-Y, TV-Y7, TV-G, TV-PG, TV-14 and TV-MA have additional options. See the next step to change any of the following sub-ratings: ALL / FV / V / S / L / D
 - The V-Chip will automatically block certain categories that are "more restrictive". For example, if you block "TV-Y" category, then TV-Y7 will automatically be blocked. Similarly, if you block the TV-G category, then all the categories in the "young adult" group will be blocked (TV-G, TV-PG, TV-14 and TV-MA). The sub-ratings (D, L, S, V) work together similarly. (See next section.)
6. How to set the FV, D, L, S and V sub-ratings.
First, select one of these TV-Ratings: TV-Y, TV-Y7, TV-G, TV-PG, TV-14 or TV-MA (See Step 4) and press the **►** button.
The " symbol will be displayed for each sub-rating. While " is selected, press the **ENTER**  button to go to a sub rating. Press **ENTER**  to block the sub rating. To select a different TV-Rating, press the **▲** or **▼** button and then repeat the process.

- | | |
|-------------------------------------|---|
| • ALL : Lock all TV ratings. | • S : Sexual situation |
| • FV : Fantasy violence | • L : Adult Language |
| • V : Violence | • D : Sexually Suggestive Dialog |


- The V-chip will automatically block certain categories that are "More restrictive". For example, if you block "L" sub-rating in TV-PG, then the "L" sub-ratings in TV-14 and TV-MA will automatically be blocked.
7. Press the **EXIT** button to clear all the screens. (Or proceed to the next section, and set up additional restrictions based on the MPAA codes.)
 - These categories consist of two separate groups: TV-Y and TV-Y7 (young children through age 7) and TV-G through TV-MA (everybody else). The restrictions for these two groups work independently: If a household includes very young children as well as young adults, the TV guidelines must be set up separately for each age group. (See next step.)




How to Set up Restrictions Using the MPAA Ratings: G, PG, PG-13, R, NC-17, X, NR

The MPAA rating system uses the Motion Picture Association of America (MPAA) system and its main application is for movies. When the V-Chip lock is on, the TV will automatically block any programs that are coded with objectionable ratings (either MPAA or TV-Ratings).


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.



2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER**  button.
The message "Enter PIN" will appear. Enter your 4 digit PIN number.



3. The "V-Chip" screen will appear. Press the **▲** or **▼** button to select "MPAA Rating", then press the **ENTER**  button.





4. The "MPAA Rating" screen will appear. Repeatedly press the **▲** or **▼** button to select a particular MPAA category. Pressing the **▲** or **▼** button will cycle through the MPAA categories:

- **G**: General audience (no restrictions).
- **PG**: Parental guidance suggested.
- **PG-13**: Parents strongly cautioned.
- **R**: Restricted. Children under 17 should be accompanied by an adult.
- **NC-17**: No children under age 17.
- **X**: Adults only.
- **NR**: Not rated.


- Allow all: Press to unlock all TV ratings.
Block all: Press to lock all TV ratings.
- While a particular category is selected, press the **ENTER**  button to activate it. The "🔒" symbol will be displayed. Press the **ENTER**  button to block or unblock the category.
- The V-Chip will automatically block any category that is "More restrictive". For example, if you block the "PG-13" category, then "R", "NC-17" and "X" will automatically be blocked also.

Press the **EXIT** button to exit.




How to Set up Restrictions Using the Canadian English


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.



2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER**  button.
The message "Enter PIN" will appear. Enter your 4 digit PIN number.



3. The "V-Chip" screen will appear. Press the **▲** or **▼** button to select "Canadian English", then press the **ENTER**  button.





4. Press the **▲** or **▼** button to select a appropriate restriction. Press the **ENTER**  button to activate the restriction selected. The "🔒" symbol is indicated.

Press the **EXIT** button to exit.

- Allow all: Press to unlock all TV ratings.
Block all: Press to lock all TV ratings.


- **C:** Programming intended for children under age 8.
- **C8+:** Programming generally considered acceptable for children 8 years and over to watch on their own.
- **G:** General programming, suitable for all audiences.
- **PG:** Parental Guidance.
- **14+:** Programming contains themes or content which may not be suitable for viewers under the age of 14.
- **18+:** Adult programming.

- The V-Chip will automatically block any category that is "More restrictive".
For example, if you block G category, then PG, 14+ and 18+ will automatically be blocked also.




How to Set up Restrictions Using the Canadian French


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.



2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER**  button.
The message "Enter PIN" will appear. Enter your 4 digit PIN number.



3. The "V-Chip" screen will appear. Press the **▲** or **▼** button to select "Canadian French", then press the **ENTER**  button.





4. Press the **▲** or **▼** button to select an appropriate restriction. Press the **ENTER**  button to activate the restriction selected. The "🔒" symbol is indicated.

Press the **EXIT** button to exit.

- Allow all: Press to unlock all TV ratings.
Block all: Press to lock all TV ratings.

- **G**: General
- **8 ans+**: Programming generally considered acceptable for children 8 years and over to watch on their own.
- **13 ans+**: Programming may not be suitable for children under the age of 13.
- **16 ans+**: Programming is not suitable for children under the age of 16.
- **18 ans+**: Programming restricted to adults.


- The V-Chip will automatically block any category that is "More restrictive". For example, if you block 8 ans+ category, then 13 ans+, 16 ans+ and 18 ans+ will automatically be blocked also.



Using the V-Chip for Digital channels


Parental restriction information can be used while watching DTV channels.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.




2. Press the **▲** or **▼** button to select "V-Chip", then press the **ENTER** button.

The message "Enter PIN" will appear. Enter your 4 digit PIN number.




3. The "V-Chip" screen will appear. Press the **▲** or **▼** button to select "Downloadable U.S. Rating", then press the **ENTER** button.
➢ If information is not downloaded from the broadcasting station, the Downloadable U.S. rating menu is deactivated.
➢ Parental restriction information is automatically downloaded while watching DTV channels. It may take several seconds.
➢ The Downloadable U.S. rating menu is available for use after information is downloaded from the broadcasting station. However, depending on the information from the broadcasting station, it may not be available for use.



4. Press the **▲** or **▼** button to select a appropriate restriction. Press the **ENTER** button to activate the restriction selected. The "🔒" symbol is indicated.

Press the **EXIT** button to exit.



- Allow all: Press to unlock all TV ratings.
Block all: Press to lock all TV ratings.
- Parental restriction levels differ depending on the broadcasting station.
- The default menu name and Downloadable US rating changes depending on the downloaded information.
- Even if you set the On-screen display to your desired language, the "Downloadable U.S. Rating" menu will appear in English only.
- The rating will automatically block certain categories that are more restrictive.
- The rating titles (For example: Humor Level..etc) and TV ratings (For example: DH, MH, H..etc) may differ depending on the broadcasting station.



How to Reset the TV after the V-Chip Blocks a Channel ("Emergency Escape")

If the TV is tuned to a restricted channel, the V-Chip will block it. The screen will go blank and the following message will appear:


1. Press the **ENTER** button to select OK.
To resume normal viewing, tune to a different channel using **CH ▼** or **CH ▲** button. Under certain conditions (depending on the rating of the local TV programs) the V-Chip might lock out all the channels. In this case, use the V-Chip function for an "emergency escape".
2. Enter your PIN, then press the **ENTER** button, and press the **▲** or **▼** button to temporarily disable the V-Chip Lock.
➢ If you forget the PIN, press the remote-control buttons in the following sequence, which resets the pin to 0-0-0-0 :
Power Off. → MUTE → 8 → 2 → 4 → Power On.




Viewing Closed Captions (On-Screen Text Messages) - Analog

The Analog Caption function operates in either analog TV channel mode or when a signal is supplied from an external device to TV. (Depending on the broadcasting signal, the Analog Caption function may operate on digital channels.)


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.



2. Press the **▲** or **▼** button to select "Caption", then press the **ENTER**  button.



3. Press the **ENTER**  button to select "Caption". Press the **▲** or **▼** button to select "On", then press the **ENTER**  button.




4. Press the **▲** or **▼** button to select "Caption Mode", then press the **ENTER**  button. Press the **▲** or **▼** button to select submenu (Default, CC1~CC4 or Text1~Text4) you want, then press the **ENTER**  button.

Press the **EXIT** button to exit.

- The default is "CC1".
- **CC1:** The Primary Synchronous Caption Service. These are captions in the primary language that must be in sync with the sound, preferably matched to a specific frame.
- **CC2:** The Special Non-Synchronous Use Captions. This channel carries data that is intended to augment information carried in the program.
- **CC3:** Secondary Synchronous Caption Service. Alternate program-related caption data, typically second language captions.
- **CC4:** Special Non-Synchronous Use Captions. Similar to CC2.
- **Text1:** First Text Service. This may be various non-program related data.
- **Text2:** Second Text Service. Additional data, usually not program related.
- **Text3/Text4:** Third and Fourth Text Services. These data channels should be used only if Text1 and Text2 are not sufficient.

- The Caption feature doesn't work in Component, HDMI or PC modes.
- The availability of captions depends on the program being broadcast.


 Press the **CC** button on the remote control to turn the Caption "On" or "Off".



Viewing Closed Captions (On-Screen Text Messages) - Digital

The Digital Captions function operates on digital channels.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "Caption", then press the **ENTER**  button.
3. Press the **ENTER**  button to select "Caption".
Press the **▲** or **▼** button to select "On", then press the **ENTER**  button.
4. Press the **▲** or **▼** button to select "Caption Mode", then press the **ENTER**  button. Press the **▲** or **▼** button to select submenu (Default, Service1~Service6, CC1~CC4 or Text1~Text4) you want, then press the **ENTER**  button.



5. Press the **▲** or **▼** button to select "Digital Caption Options", then press the **ENTER**  button.





- "Digital Caption Options" are available only when "Default" and "Service 1~Service 6" can be selected in "Caption Mode".
- Service1~6 in digital caption mode may not be available depending on the broadcast.

6. Press the **▲** or **▼** button to select "Size", then press the **ENTER**  button. Press the **▲** or **▼** button to select the desired Caption option, then press the **ENTER**  button. Press the **▲** or **▼** button to select the desired sub-menu options (see options below), then press **ENTER** .


Press the **EXIT** button to exit.

- The availability of captions depends on the program being broadcast.
- "Default" means to follow the standard set by the broadcaster.
- Foreground and Background cannot be set to have the same color.
- "Foreground Opacity" and "Background Opacity" cannot be both set to Transparent.

- **Size:** This option consists of "Default", "Small", "Standard" and "Large". The default is "Standard".
- **Font Style:** This option consists of "Default", "Style0 ~ Style 7". You can change the font you want. The default is "Style 0".
- **Foreground Color:** This option consists of "Default", "White", "Black", "Red", "Green", "Blue", "Yellow", "Magenta" and "Cyan". You can change the color of the letter. The default is "White".
- **Background Color:** This option consists of "Default", "White", "Black", "Red", "Green", "Blue", "Yellow", "Magenta" and "Cyan". You can change the background color of the caption. The default is "Black".
- **Foreground Opacity:** This option consists of "Default", "Transparent", "Translucent", "Solid" and "Flashing". You can change the opacity of the letter.
- **Background Opacity:** This option consists of "Default", "Transparent", "Translucent", "Solid" and "Flashing". You can change the background opacity of the caption.
- **Return to Default:** This option sets each of "Size", "Font Style", "Foreground Color", "Background color", "Foreground Opacity" and "Background Opacity" to its default.



-  Press the **CC** button on the remote control to turn the Caption "On" or "Off".



Adjusting the TV On/Off Melody Sound

A melody sound can be set to come on when the TV is powered On or Off.



1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "External Settings", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select "Melody", then press the **ENTER** button.
Press the **▲** or **▼** button to select "Off", "Low", "Medium" or "High", then press the **ENTER** button.

- **Off:** Turns off the melody function.
- **Low:** Sets the melody volume to low.
- **Medium:** Sets the melody volume to medium.
- **High:** Sets the melody volume to high.

Press the **EXIT** button to exit.

➤ **The Melody does not play**

- When no sound is output from the TV because the **MUTE** button has been pressed,
- When no sound is output from the TV because the volume has been reduced to minimum with the **VOL -** button.
- When the TV is turned off by Timer function.





Setting the Entertainment mode

The "Entertainment" mode enables you to select the optimal display and sound for sports, cinema and games.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
 2. Press the **▲** or **▼** button to select "Entertainment", then press the **ENTER** button.
 3. Press the **▲** or **▼** button to select "Off", "Sports", "Cinema" or "Game", then press the **ENTER** button.
- **Off:** Switches the "Entertainment" function off.
 - **Sports:** Provides the optimal picture and sound quality for sports.
 - **Cinema:** Provides the optimal picture and sound quality for movie watching. You can experience a richer picture and enhanced sound.
 - **Game:** Provides the optimal picture and sound quality for games. This mode accelerates the playing speed when using an external game console connected to the TV.

Press the **EXIT** button to exit.

- If you set any of the three "Entertainment" modes to On, the settings will be locked and can not be adjusted. If you want to make Picture and Sound mode adjustments, the "Entertainment" mode must be turned off.
- If you set any of the three "Entertainment" modes to On, "SRS TruSurround XT" function is not available.
- The "Entertainment" settings are saved for each input source.




- You can press the **E.MODE** button on the remote control repeatedly to change the "Entertainment" setting.



Using the Energy Saving Feature

This feature adjusts the brightness of the TV in order to reduce power consumption. When watching TV at night, set the "Energy Saving" mode option to "High" to reduce eye fatigue as well as power consumption.


1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.



2. Press the **▲** or **▼** button to select "Energy Saving", then press the **ENTER**  button. Select the required option (Off, Low, Medium, High, Auto) by pressing the **▲** or **▼** button.

Press the **ENTER**  button.

- **Off:** Turns off the energy saving function.
- **Low:** Sets the TV to low energy saving mode.
- **Medium:** Sets the TV to medium energy saving mode.
- **High:** Sets the TV to high energy saving mode.
- **Auto:** Automatically adjusts the brightness of the TV screen in accordance with the scenes.




Press the **EXIT** button to exit.




Upgrading the Software

Samsung may offer upgrades for TV's firmware in the future. Please contact the Samsung call center at 1-800-SAMSUNG (726-7864) to receive information about downloading upgrades and using a USB drive. Upgrades will be possible by connecting a USB drive to the USB port located on your TV.

1. Insert a USB drive containing the firmware upgrade into the WISELINK port on the side of the TV.
 - > Software can not be upgraded through the LAN connection.



2. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select "SW Upgrade", then press the **ENTER** button.
4. Press the **ENTER** button.
The message "Scanning for USB... It may take up to 30 seconds." is displayed.
5. The message "Upgrade version XXXX to version XXXX? The system will be reset after upgrade." is displayed.
Press the **◀** or **▶** to select the "OK", then press the **ENTER** button.



Please be careful to not disconnect the power or remove the USB drive while upgrades are being applied. The TV will turn off and turn on automatically after completing the firmware upgrade. Please check the firmware version after the upgrades are complete. When software is upgraded, video and audio settings you have made will return to their default (factory) settings. We recommend you write down your settings so that you can easily reset them after the upgrade.


WISELINK

Using the WISELINK Function

Connecting a USB Device

This function enables you to view and listen to photo (JPEG) and audio files (MP3) saved on a USB Mass Storage Class (MSC) device.

1. Press the **POWER** button on the remote control or front panel.
➤ The TV is powered on.
2. Connect a USB device containing JPEG and/or MP3 files to the WISELINK jack (USB jack) on the side of the TV.




- If you enter the WISELINK mode with no USB device connected the message "No external storage device found. Check the connection status." will appear. In this case, insert the USB device, exit the screen by pressing the **WLINK** button on the remote control and enter the WISELINK screen again.
- MTP (Media Transfer Protocol) is not supported.
- The file system only supports FAT16/32 (The NTFS file system is not supported).
- Certain types of USB Digital camera and audio devices may not be compatible with this TV.
- Wiselink only supports USB Mass Storage Class devices (MSC). MSC is a Mass Storage Class Bulk-Only Transport device. Examples of MSC are Thumb drives and Flash Card Readers (Both USB HDD and HUB are not supported.)
- Please connect directly to the USB port of your TV. If you are using a separate cable connection, there may be a USB Compatibility problem.
- Before connecting your device to the TV, please back up your files to prevent them from damage or loss of data. SAMSUNG is not responsible for any data file damage or data loss.
- Do not disconnect the USB device while it is loading.
- MSC supports MP3 and JPEG files, while a PTP device supports JPEG files only.
- The sequential jpeg format is supported.
- Photo and audio files must be named in English, French or Spanish. If not, the files can not be played. Change the file names to English, French or Spanish if necessary.
- The higher the resolution of the image, the longer it takes to display on the screen.
- The maximum supported JPEG resolution is 15360x8640 pixels.
- For unsupported or corrupted files, the "Not Supported File Format" message is displayed.

Using the Remote Control Button in WISELINK Menu


Button	Operations
Wheel (▲/▼/◀/▶)	Move the cursor and select an item.
ENTER ↴	Select the currently selected item. During a Slide Show or Music Play: - Pressing the ENTER ↴ button during play pauses the play. - Pressing the ENTER ↴ button during pause resumes the play.
▶ / ■	Play or pause the Slide Show or Music file.
RETURN	Return to the previous menu.
TOOLS	Run various functions from the Photo and Music menus.
■	Stop the current slide show or Music file.
◀ / ▶	Jump to previous group / Jump to next group.
INFO	Show file information.
WLINK	Exit WISELINK mode.
CH ▼/▲ PRE.CH / FAV.CH	Stop WISELINK mode and Returns to TV mode.
EXIT	Stop the current function and return to the WISELINK main menu.

Using the WISELINK Menu

1. Press the **MENU** button. Press the **▲** or **▼** button to select "Application", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "WISELINK", then press the **ENTER** button.
➢ The "WISELINK" menu is displayed.



Press the **W.LINK** button on the remote control to display the "WISELINK" menu.



Press the **SOURCE** button on the remote control repeatedly to select "USB", then press the **ENTER** button.

3. Press the Red button, then press the **▲** or **▼** button to select the corresponding USB Memory Device (i.e. if connected through a hub). Press the **ENTER** button.
➢ This function differs depending on the USB Memory Device connected to TV.
➢ The selected USB device name appears at the bottom left of the screen.
4. Press the **◀** or **▶** button to select an icon (Photo, Music, Setup), then press the **ENTER** button.
➢ To exit "WISELINK" mode, press the **W.LINK** button on the remote control.

Using the Photo List


This menu shows Photo files saved on an USB memory device.

Photo List

1. Press the **W.LINK** button on the remote control to display the "WISELINK" menu.
2. Press the **◀** or **▶** button to select "Photo", then press the **ENTER** button.
➢ Photo files are displayed.
➢ This menu only shows files whose file extension is jpg. Files of other formats such as bmp or tiff will not be displayed.
➢ Press the **▶** (Play) / **ENTER** button to start the Slide Show.
➢ To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
➢ When moving to a photo, loading may take a few seconds. At this point, the loading icon will appear at the screen.
➢ It may take some time to load photo files as Thumbnail images.
➢ Photos without EXIF information may not be displayed as thumbnail images in the Photo List depending on the picture quality and resolution.



Screen Display



① Currently selected photo

Shows the currently selected photo.

② Photo Information Window

Shows information about the currently selected photo. You can change the "Color", "Composition", and "Favorite".

③ Current Sort Standard

Press the ▲ or ▼ button to change the standard for sorting photos.
("Monthly", "Timeline", "Color", "Composition", "Folder", "Preference")

The item that is selected as the sorting standing is highlighted in the Photo Information Window.

④ View Groups

Shows the sorting groups. The sorting group including the currently selected photo is highlighted.

⑤ Current Device

Shows the currently selected device name. Press the Red button to select a device.

⑥ Item Selection Information

Shows the number of photos that are selected by pressing the Yellow button.



⑦ Help Items

- **Red(Device) button:** Selects a connected device.
- **Green(Favorites Setting) button:** Changes the favorites setting for the selected photo. Press this button repeatedly until the desired value appears. (Refer to page 68)
- **Yellow(Select) button:** Selects photos from the photo list. Selected photos are marked with a symbol ✓ on the left.
- **◀▶ (Jump) button:** Jumps to the previous sorting group / Jumps to the next sorting group.
- **TOOLS(Option) button:** Displays the "Slide Show", "Play Current Group", "Delete", "Change Group Info" (in "Color" or "Composition" group), "Information" or "Safe Remove" menus.

Sorting Photo List

You can sort photos in the Photo List by a particular standard.


1. Press the **WLINK** button on the remote control to display the "WISELINK" menu.
2. Press the **◀** or **▶** button to select "Photo", then press the **ENTER** button.
➢ Photo files are displayed.
3. Press the **▲** or **▼** button to select a sorting standard. ("Monthly", "Timeline", "Color", "Composition", "Folder", "Preference")
➢ The photos are sorted according to the newly selected sorting standard.
4. Press the **ENTER** button to start the Slide Show in the order selected by the user.
➢ Wiselink identifies the color and composition of images and groups them accordingly by analyzing the images on the USB device.
➢ The "Composition" and "Color" information extracted from a photo file may be different from what you selected.
➢ Photo information is automatically set. You can change the "Color", "Composition", and "Favorite".
➢ Photos for which information cannot be displayed are set as "Unclassified".
➢ PTP does not support folder sort mode.



Monthly

Sorts photos by month.


- It sorts and shows photos in the file by month. It sorts only by month (from January to December) regardless of year.
1. Select "Monthly" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by Month.
➢ To move to the previous / next group, press the **[◀]** (REW) or **[▶]** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.



Timeline

Sorts photos by time.

- It sorts and shows photos by date. It sorts by year and month from the earliest photo.
1. Select "Timeline" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by Timeline.
➢ To move to the previous / next group, press the **[◀]** (REW) or **[▶]** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.



Color

Sorts photos by color.

- You can change the photo color information.
1. Select "Color" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by color.
 - To move to the previous / next group, press the **◀** (REW) or **▶** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.



Changing the color information


1. Select "Color" as the sorting standard in the Photo List and press the **◀** or **▶** button to select a photo.
- **Changing the information of multiple files**
Press the **◀** or **▶** button to select the desired photo in the Photo list. Then press the yellow button.
Repeat the above operation to select multiple photos.
The **✓** mark appears to the left of the selected photo.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select "Change Group Info".
Press the **ENTER** button.
4. Press the **◀** or **▶** button to select the desired option, then press the **ENTER** button.
 - The group information of the current file is updated and the file is moved to the new group.
 - "Color" option: Red, Yellow, Green, Blue, Magenta, Black, Gray, Unclassified.



Composition


Sorts photos by composition.

- You can change the compositional information of photos.
1. Select "Composition" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by composition.
 - To move to the previous / next group, press the **◀** (REW) or **▶** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.



Changing the composition information

1. Select "Composition" as the sorting standard in the Photo List and press the **◀** or **▶** button to select a photo.
- **Changing the information of multiple files**
Press the **◀** or **▶** button to select the desired photo in the Photo list. Then press the yellow button.
Repeat the above operation to select multiple photos.
The **✓** mark appears to the left of the selected photo.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select "Change Group Info".
Press the **ENTER** button.
4. Press the **◀** or **▶** button to select the desired option, then press the **ENTER** button.
 - The group information of the current file is updated and the file is moved to the new group.
 - "Composition" option: **Horizontal**, **Vertical**, **Object**, **Perspective**, **Pattern**, **Unclassified**.



Folder

Sorts photos by folder.

- If there are many folders in USB, the photo files are shown in order in each folder. The photo file in the Root folder is shown first and the others are shown in alphabetical order by name.
1. Select "Folder" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by folder.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.



Preference

Sorts photos by preference. (Favorite)

- You can change the photo preferences.
1. Select "Preference" as the sorting standard in the Photo List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by preference.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
 3. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Play Current Group".
 4. Press **ENTER** to play the selected group of photo files from the sublist.


Changing the Favorites setting

1. Press the **◀** or **▶** button to select the desired photo in the Photo list.
 - **Changing the information of multiple files**
Press the **◀** or **▶** button to select the desired photo in the Photo list. Then press the yellow button.
Repeat the above operation to select multiple photos.
The **✓** mark appears to the left of the selected photo.
2. Press the Green button repeatedly until the desired setting appears.
 - Favorites settings change completed.
 - "Favorite" option: *** * ***, *** * ***, *** * ***, *** * ***
 - Users can select the number of stars (up to 3) according to their preference.




Deleting the Photo file

1. Press the **◀** or **▶** button to select the desired photo in the Photo list.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Delete”, then press the **ENTER**  button.
 - The “Delete this file?” message appear.
4. Press the **◀** or **▶** button to select “OK”, then press the **ENTER**  button.
 - The photo is deleted.
 - When a read-only file is deleted, the “Read-only file(s). Delete the file(s)?” message appear.
 - If you select “Cancel”, the deletion is cancelled.
5. To exit “WISELINK” mode, press the **WLINK** button on the remote control.
 - You cannot remove the PTP-connected digital camera picture files.
 - While removing files, don’t remove the USB memory device.
 - You cannot recover a deleted photo file.



Deleting Multiple Photos


1. Press the **◀** or **▶** button to select the desired photo in the Photo list. Then press the yellow button.
 - Repeat the above operation to select multiple photos.
 - The **✓** mark appears to the left of the selected photo.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Delete selected File”, then press the **ENTER**  button.
 - The “Delete the selected files?” message appear.
4. Press the **◀** or **▶** button to select “OK”, then press the **ENTER**  button.
 - The selected photos are deleted.
 - If you select “Cancel”, the deletion is cancelled.
5. To exit “WISELINK” mode, press the **WLINK** button on the remote control.
 - You cannot remove the read-only files from the selected ones.
 - You cannot recover a deleted photo file.



Viewing the Photo Information

The photo file information including the order of the file in the current directory, the name, the size, the resolution, the date modified and the path is displayed.

1. Press the **◀** or **▶** button to select the desired photo in the Photo list.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Information”, then press the **ENTER**  button.
 - The information on the selected photo appears.




 Press the **INFO** button to viewing the information.




Viewing a Photo or Slide Show

Viewing a Slide Show

1. Press the **WLINK** button on the remote control to display the "WISELINK" menu.
2. Press the **◀** or **▶** button to move to "Photo", then press the **ENTER** button.
 - Photo files are displayed.
3. Press the **◀** or **▶** button to select the desired photo in the Photo list.
4. Press the **TOOLS** button.
5. Press the **▲** or **▼** button to select "Slide Show", then press the **ENTER** button.
 - All files in the photo list will be used for the Slide Show.
 - During the slide show, files are displayed in order from the currently shown file.
 - The Slide Show progresses in the order sorted in the Photo list.
 - Music files can be automatically played during the Slide Show if the "Background Music" is set to "On".
(Refer to page 72).



- While a photo list is displayed, press the **[▶]** (Play) / **ENTER** button on the remote control to start slide show.



To perform a SlideShow with only the selected files

1. Press the **◀** or **▶** button to select the desired photo in the Photo list. Then press the yellow button. Repeat the above operation to select multiple photos.
 - The **✓** mark appears to the left of the selected photo.
 - If you select one file, the SlideShow will not be performed.
2. Press the **[▶]** (Play) / **ENTER** button.
 - The selected files will be used for the Slide Show.
 - If you have selected files, only the selected files will be used for the Slide Show.

Playing current group

1. Press the **▲** or **▼** button to select a sorting standard. ("Monthly", "Timeline", "Color", "Composition", "Folder", "Preference")
2. Press the **◀** or **▶** button to select the desired photo in the Photo list.
 - To move to the previous / next group, press the **[◀]** (REW) or **[▶]** (FF) button.
3. Press the **TOOLS** button.
4. Press the **▲** or **▼** button to select "Play Current Group", then press the **ENTER** button. Only the photos in the sorting group including the selected files will be used for the Slide Show.
5. To exit "WISELINK" mode, press the **WLINK** button on the remote control.




Slide show function information icon (Displayed at the top left of the screen)

Icon	Current OSD	Function
▶	(Photo) SlideShow	Photo Slide Show is in progress.
⏸	Photo Pause	You can pause a Slide Show by pressing the [■] (Pause)/ ENTER button on the remote control during a Slide Show. To resume the Slide Show, press the [▶] (Play)/ ENTER button on the remote control again.

Viewing a photo

1. Press the **WLINK** button on the remote control to display the "WISELINK" menu.
2. Press the **◀** or **▶** button to move to "Photo", then press the **ENTER**  button.
 - Photo files are displayed.
3. Press the **◀** or **▶** button to select the desired photo in the Photo list. Then Press the Yellow button to select only one file.
4. Press the **ENTER**  button over a photo icon.
 - The currently selected photo is displayed in full screen.




Using the option menu during a slide show (or Viewing a Photo)

1. During a slide show(or viewing a photo), Press the **TOOLS** button to set the option.
2. Press the **▲** or **▼** button to select the desired option. Then press the **ENTER**  button.

Start Slide Show (or Stop Slide Show)

You can start or stop a Slide Show.

Press the **▲** or **▼** button to select "Start Slide Show" (or "Stop Slide Show"), then press the **ENTER**  button.




Rotate

You can rotate images in full screen mode.

Press the **▲** or **▼** button to select "Rotate", then press the **ENTER**  button. Press the **◀** or **▶** button repeatedly to rotate the photo by the desired amount.

- Whenever you press the **◀** button, it rotates by 270°, 180°, 90°, and 0°.
- Whenever you press the **▶** button, it rotates by 90°, 180°, 270°, and 0°.
- If you have select "Zoom", the "Rotate" function is deactivate
- The rotated file is not saved.
- The Rotating function information icon is displayed at the top right of the screen



Icon	Current OSD	Function
	Rotating (0°)	This rotates a photo to its original position
	Rotating (90°)	This rotates a photo by 90 degrees
	Rotating (180°)	This rotates a photo by 180 degrees
	Rotating (270°)	This rotates a photo by 270 degrees

Zoom



You can zoom into images in full screen mode.

Press the ▲ or ▼ button to select "Zoom", then press the **ENTER** button.
Press the ◀ or ▶ button repeatedly to increase or decrease the Zoom effect.
(x1 → x2 → x4)

To move the enlarged photo image, press the **ENTER** button, then press the ▲/▼/◀/▶ buttons.

- Note that when the enlarged picture is smaller than the original screen size, the location change function doesn't work.
- The enlarged file is not saved.
- If you have select "Rotate", the "Zoom" function is deactivate
- Zoom function information icon is displayed at the top right of the screen.

Icon	Current OSD	Function
x2	Zoom (x 2)	Zoom-into a photo at 2x.
x4	Zoom (x 4)	Zoom-into a photo at 4x.
x1	Zoom (x 1)	Restore a photo to its original size.
▼	Pan Down	Pan down to view the lower part of a zoomed-in photo.
▲	Pan Up	Pan up to view the upper part of a zoomed-in photo.
▶	Pan Right	Pan right to view the right side of a zoomed-in photo.
◀	Pan Left	Pan left to view the left side of a zoomed-in photo.





Slide Show Speed

You can select the slide show speed.

Press the ▲ or ▼ button to select "Slide Show Speed".

Press the ◀ or ▶ button to select the desired option. (Fast → Slow → Normal)

- You can select the SlideShow speed only during a slide show.



Background Music

If you set "Background Music" to On, the background music will be played when viewing photos one by one or in a Slide Show.

Press the ▲ or ▼ button to select "Background Music".

Press the ◀ or ▶ button to select "On" or "Off".

- If you set "Background Music" to On, a screen appears immediately where you can set the Background Music.

• **On:** When the background music is available, if you select On, the music is played back. To use this feature, there must be music and photo files stored on the USB device.


• **Off:** Background music is not played.

Background Music Setting


You can set the background music.

Press the ▲ or ▼ button to select "Background Music Setting", then press the **ENTER** button.


- If you turn off the "Background Music", even if the "Background Music Settings" have been set up, the background music will not be played.




- Loading music files is needed to change BGM mode. Play music files in music category to load.
 - **"Background Music setting" menu is displayed.**
- Press the ▲ or ▶ button to select the desired BGM (Background music) mode. (Shuffle, Selected file, Mood)
- **Shuffle:** Plays music files in random order.
 - **Selected file:** Plays a selected music file.
 - **Mood:** Plays music files of a particular mood only.



- **Selecting the background music file**
- Press the ▲ or ▶ button to set "BGM Mode" to "Selected file".
Press the ▲ or ▼ button to select "Select Music File", then press the **ENTER** button.
Press the ▲ or ▶ button to select a music file, then press the yellow button.
The ✓ mark appears to the left of the selected music.
Repeat the above operation to select multiple music files.
Press the **ENTER** button.



- **Selecting the background music file mood**
- Press the ▲ or ▶ button to set "BGM Mode" to Mood".
Press the ▲ or ▼ button to select "BGM Mood". Then press ▲ or ▶ button to select the desired BGM mood. Press the **ENTER** button.
BGM mode option: Energetic, Rhythrical, Sad, Exciting, Calm
➤ WISELINK identifies the mood of the music files and groups them accordingly by analyzing the music files on the USB device.



Picture Mode

You can set the Picture mode. (Refer to page 20)

Sound Mode

You can set the Sound mode. (Refer to page 31)

Safe Remove

You can remove the device safely from the TV.

Press the ▲ or ▼ button to select "Safe Remove", then press the **ENTER** button.


The "Safely removing USB device." message appears and then the "USB device can now be safely removed from TV." appears.

Remove the USB device from the TV.

Using the Music List

This menu shows MP3 files from among the files saved on a USB memory device.


1. Press the **WLINK** button on the remote control to display the "WISELINK" menu.



2. Press the **◀** or **▶** button to select "Music", then press the **ENTER** button.
 - Music files are displayed.
 - Press the **▶** (Play) / **ENTER** button over a music icon to play the music.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.



Screen Display



① Currently selected music

Shows the currently selected music.

② Current Sort Standard

Press the **▲** or **▼** button to change the standard for sorting music files. ("Title", "Artist", "Mood", "Genre", "Folder", "Preference")

③ View Groups

Shows the sorting groups. The sorting group including the currently selected music file is highlighted.

④ Current Device

Shows the currently selected device name. Press the Red button to select a device.

⑤ Item Selection Information

Shows the number of music files that are selected by pressing the Yellow button.


⑥ Help Items

- **Red(Device) button:** Selects a connected device.
- **Green(Favorites Setting) button:** Changes the favorites setting for the selected music. Press this button repeatedly until the desired value appears. (Refer to page 77)
- **Yellow(Select) button:** Selects music files from the music list. Selected music files are marked with a symbol on the left.
- **◀▶ (Jump) button:** Jumps to the previous sorting group / Jumps to the next sorting group.
- **TOOLS(Option) button:** Displays the “Play Current Group”, “Delete”, “Change Group Info” (in “Mood” group), “Information” or “Safe Remove” menus.

Sorting Music List

You can sort music files in the Music List by a particular standard.

1. Press the **WLINK** button on the remote control to display the WISELINK menu.
2. Press the **◀** or **▶** button to select “Music”, then press the **ENTER**  button.
➢ Music files are displayed.
3. Press the **▲** or **▼** button to select a sorting standard. (“Title”, “Artist”, “Mood”, “Genre”, “Folder”, “Preference”)
➢ Music files are sorted according to the newly selected sorting standard.
4. Press the **ENTER**  button to start playing music in the order selected by the user.
➢ Music information is set automatically and you can change the Favorite information.
➢ Music files for which information cannot be displayed are set to “Unclassified”.
➢ If there is no title information for a music file, the filename is displayed.
➢ If no information is available for the Genre, Artist, Album, or Year, the corresponding item is displayed as blank.



Title

Sorts music files by the title.

- It sorts the Music titles in alphabetical order, and shows the music file.
1. Select “Title” as the sorting standard in the Music List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped in alphabetical order.
➢ To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
 3. Press the **TOOLS** button.
 4. Press the **▲** or **▼** button to select “Play Current Group”.
 5. Press **ENTER**  to play the selected group of music files from the sublist.



Artist

Sorts music files by the artist.

- It sorts the music file by artist in alphabetical order.

1. Select “Artist” as the sorting standard in the Music List.
2. Press the **◀** or **▶** button to select from the sublist of files grouped in alphabetical order.
 - To move to the previous / next group, press the **[◀]** (REW) or **[▶]** (FF) button.
3. Press the **TOOLS** button.
4. Press the **▲** or **▼** button to select “Play Current Group”.
5. Press **ENTER** to play the selected group of music files from the sublist.



Mood

Sorts music files by the mood.


- You can change the music mood information.

1. Select “Artist” as the sorting standard in the Music List.
2. Press the **◀** or **▶** button to select from the sublist of files grouped by mood.
 - To move to the previous / next group, press the **[◀]** (REW) or **[▶]** (FF) button.
3. Press the **TOOLS** button.
4. Press the **▲** or **▼** button to select “Play Current Group”.
5. Press **ENTER** to play the selected group of music files from the sublist.



Changing the Mood information

1. Select “Mood” as the sorting standard in the Music List and press the **◀** or **▶** button to select a music file.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Change Group Info”. Press the **ENTER** button.
 - Wiselink identifies the mood of the music files and groups them accordingly by analyzing the music files on the USB device.
 - “Mood” information extracted from a music file may not always match the Mood option. For example, a file you think is “Energetic” may be extracted to the “Exciting” mood option.
4. Press the **◀** or **▶** button to select the desired option, then press the **ENTER** button.
 - The group information of the current file is updated and the file is moved to the new group.
 - “Mood” options: Energetic, Rhythrical, Sad, Exciting, Calm, Unclassified



Genre

Sorts music files by the genre.

1. Select "Genre" as the sorting standard in the Music List.
2. Press the **◀** or **▶** button to select from the sublist of files grouped by Genre.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
3. Press the **TOOLS** button.
4. Press the **▲** or **▼** button to select "Play Current Group".
5. Press **ENTER**  to play the selected group of music files from the sublist.



Folder

Sorts music files by the folder.

- If there are many folders in USB, the files are shown in order in each folder. The music file in the Root folder is shown first and the others are shown in alphabetical order by name.
1. Select "Folder" as the sorting standard in the Music List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by Folder.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
 3. Press the **TOOLS** button.
 4. Press the **▲** or **▼** button to select "Play Current Group".
 5. Press **ENTER**  to play the selected group of music files from the sublist.




Preference

Sorts music files by preference. (Favorite)

- You can change the music files preferences.
1. Select "Preference" as the sorting standard in the Music List.
 2. Press the **◀** or **▶** button to select from the sublist of files grouped by Preference.
 - To move to the previous / next group, press the **◀◀** (REW) or **▶▶** (FF) button.
 3. Press the **TOOLS** button.
 4. Press the **▲** or **▼** button to select "Play Current Group".
 5. Press **ENTER**  to play the selected group of music files from the sublist.


Changing the Favorites setting

1. Press the **◀** or **▶** button to select the desired music in the music list.
 - **Changing the information of multiple files**
Press the **◀** or **▶** button to select the desired music in the music list. Then press the yellow button.
Repeat the above operation to select multiple musics.
The **✓** mark appears to the left of the selected music.
2. Press the Green button repeatedly until the desired setting appears.
 - Favorites settings change completed.
 - "Favorite" option: , , , 
 - Users can select the number of stars (up to 3) according to their preference.
3. Press the **ENTER**  button to start playing music.



Deleting the Music file

1. Press the **◀** or **▶** button to select the desired music file in the music list.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Delete”, then press the **ENTER**  button.
➤ The “Delete this file?” message appear.
4. Press the **◀** or **▶** button to select “OK”, then press the **ENTER**  button.
➤ The music is deleted.
➤ When a read-only file is deleted, the “Read-only file(s). Delete the file(s)?” message appear.
➤ If you select “Cancel”, the deletion is cancelled.
5. To exit “WISELINK” mode, press the **WLINK** button on the remote control.
➤ While removing files, don’t remove the USB memory device.
➤ You cannot recover deleted music files.



Deleting Multiple Music files


1. Press the **◀** or **▶** button to select the desired music in the music list. Then press the yellow button.
➤ Repeat the above operation to select multiple music files.
➤ The **✓** mark appears to the left of the selected music files.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Delete selected File”, then press the **ENTER**  button.
➤ The “Delete the selected files?” message appear.
4. Press the **◀** or **▶** button to select “OK”, then press the **ENTER**  button.
➤ The selected music files are deleted.
➤ If you select “Cancel”, the deletion is cancelled.
5. To exit “WISELINK” mode, press the **WLINK** button on the remote control.
➤ You cannot remove the read-only files from the selected ones.
➤ You cannot restore the deleted music files.



Viewing the Information

The music file information including the order of the file in the current directory, the name, the size, the date modified and the path is displayed.

1. Press the **◀** or **▶** button to select the desired music in the music list.
2. Press the **TOOLS** button.
3. Press the **▲** or **▼** button to select “Information”, then press the **ENTER**  button.
➤ The information on the selected file appears.





 Press the **INFO** button to viewing the information.



Playing a Music File


Playing a music file

1. Press the **WLINK** button on the remote control to display the "WISELINK" menu.
2. Press the **◀** or **▶** button to select "Music", then press the **ENTER** button.
 - Music files are displayed.
3. Pressing the **◀** or **▶** button to select a music file to be played, then press the **ENTER** button.
 - This menu only shows files with the MP3 file extension. Files with other file extensions are not displayed, even if they are saved on the same USB device.
 - Press the **▶** (Play) / **ENTER** button over a music icon to play the music.
 - **◀** (REW) or **▶** (FF) buttons do not function during play.
 - Press the **II** (Pause) / **ENTER** button while playing a music file to pause the file. Press the **■** (Stop) button to exit Play mode.
 - The selected file is displayed at the top with its playing time.
 - To adjust the music volume, press the **VOL -** or **VOL +** button on the remote control. To mute the sound, press the **MUTE** button on the remote control.
 - The playing duration of a music file may be displayed as '00:00:00' if its playing time information is not found at the start of the file.
4. To exit "WISELINK" mode, press the **WLINK** button on the remote control.



Playing the music group

1. Press the **WLINK** button on the remote control to display the WISELINK menu.
2. Press the **◀** or **▶** button to select "Music", then press the **ENTER** button.
 - To move to the previous / next group, press the **◀** (REW) or **▶** (FF) button.
3. Press the **◀** or **▶** button to select the desired music file.
4. Press the **TOOLS** button.
5. Press the **▲** or **▼** button to select "Play Current Group", then press the **ENTER** button.
 - The music files in the sorting group including the selected file are played.
6. To exit "WISELINK" mode, press the **WLINK** button on the remote control.



Playing the selected music files

1. Press the **WLINK** button on the remote control to display the WISELINK menu.
2. Press the **◀** or **▶** button to select "Music", then press the **ENTER** button.
3. Press the **◀** or **▶** button to select the desired music file, then press the yellow button. Repeat the above operation to select multiple music files.
➤ The **✓** mark appears to the left of the selected music file.
4. Press the **▶** (Play) / **ENTER** button.
➤ Only the selected file is played.
➤ Press the **■** (Stop) button while playing to stop the current item and to return to the music list.
5. To exit "WISELINK" mode, press the **WLINK** button on the remote control.




Music function information icon (Displayed at the top left of the screen)

Icon	Current OSD	Function
⟳	(Music) Repeat	When all music files in the folder(or the selected file) are repeated. "Repeat Mode" is "On".
⟲	(Music) Once	When all music files in the folder(or the selected file) are played once. "Repeat Mode" is "Off".
▶ / II	(Music) Play/Pause	When pressing the ▶ (Play)/ ■ (Pause)/ ENTER button on the remote control while music is playing.

Repeating Music Play

1. While a Music file is playing, press the **TOOLS** button.
2. Press the **▲** or **▼** button to select "Repeat Mode".
3. Press the **◀** or **▶** button to select "On" or "Off".
 - **On:** Plays back all music files in the folder(or the selected file) repeatedly.
 - **Off:** Doesn't play back repeatedly.
4. To exit "WISELINK" mode, press the **WLINK** button on the remote control.



Using the Setup Menu

Setup displays the user settings of the WISELINK menu.

1. Press the **WLINK** button on the remote control to display the WISELINK menu.
2. Press the **◀** or **▶** button to select "Setup", then press the **ENTER** button.
3. Press the **▲** or **▼** button to select the desired option.
(Slide Show Speed, Music Repeat Mode, Screen Saver Run Time, Information, Safe Remove)
4. Press the **◀** or **▶** button to select the option, then press the **ENTER** button.




Slide Show Speed

Select to control the slide show speed.

Press the **▲** or **▼** button to select "Slide Show Speed".

Press the **◀** or **▶** button to select "Fast", "Normal" or "Slow".




Music Repeat Mode

Select to repeatedly play music files.

Press the **▲** or **▼** button to select "Music Repeat Mode".

Press the **◀** or **▶** button to select "On" or "Off".




Screen Saver Run Time

Select to set the waiting time before the screen saver appears.

Press the **▲** or **▼** button to select "Screen Saver Run Time".


Press the **◀** or **▶** button to select "1 min", "3 min" or "5 min".



Information

Select to viewing the information of the connected device.

Press the **▲** or **▼** button to select "Information", then press the **ENTER** button.



Safe Remove

You can remove the device safely from the TV. (Refer to page 73)


To exit WISELINK mode, press the **WLINK** button on the remote control.

Network Settings and InfoLink


Network Connection (DHCP) and Automatic Setup

The procedures to set up the network using Dynamic Host Configuration Protocol (DHCP) are described below. Since an IP address, subnet mask, gateway, and DNS are automatically allocated when DHCP is selected, you do not have to enter them manually.

LAN Connection for a DHCP Environment



1. Connect the [LAN] port on the rear panel of the TV and the external modem with a LAN Cable.
2. Connect the LAN port on the wall and the external modem with a modem cable.




- The terminals (the position of the port and the type) of the external device may differ depending on the manufacturer.
- If the IP address allocation by the DHCP server has failed, turn the external modem off, turn it on again after at least 10 seconds and then try again.
- For the connections between the external modem and the Sharer (Router), refer to the owner's manual of the corresponding product.
- You can connect the TV to the LAN directly without connecting it through a Sharer (Router)
- You cannot use a manual-connection-type ADSL modem because it does not support DHCP. You have to use an automatic-connection-type ADSL modem.

Automatic Network Setup

If you connect a LAN cable in a location that supports DHCP, the Internet Protocol (IP) Settings are automatically configured.


- Please check if a LAN cable is connected first.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select “Setup”, then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select “Network Setup”, then press the **ENTER**  button.



3. Press the **ENTER**  button to select “Internet Protocol Setup”.
4. Press the **▲** or **▼** button to select “Auto Setup”, then press the **ENTER**  button.
 - The Internet Protocol is set automatically.
 - Select “Network Test” to check the network connectivity.
(Refer to page 86)


Press the **EXIT** button to exit.




Network Connection (Static IP) and Manual Setup

The procedures to set up the network using a static IP address are described below. You have to manually enter the IP address, subnet mask, gateway, and DNS that are provided by your Internet Service Provider (ISP).

LAN Connection for Static IP Environment



1. Connect the [LAN] port on the rear panel of the TV and the LAN port on the wall using a LAN cable.




- The terminals (the position of the port and the type) of the external device may differ depending on the manufacturer.
- If you are using a static IP address, your ISP will inform you of the IP address, subnet mask, gateway, and DNS. You must enter these values to complete the network settings. If you do not know the values, ask your network administrator.
- For the information on how to configure and connect a Sharer (Router), refer to the owner's manual for the corresponding product.
- You can connect the TV to the LAN directly without connecting it through a Sharer (Router).
- If you use an IP Sharer (IP Router) that supports DHCP, you can set up the device as either DHCP or static IP.
- For the procedures to use a static IP address, ask your Internet Service Provider.

Manual Network Setup


To connect the TV to a LAN using a static IP address, you must set up the Internet Protocol (IP).

- > Please check if a LAN cable is connected first. (Refer to page 84)

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "Network Setup", then press the **ENTER**  button.




3. Press the **ENTER**  button to select "Internet Protocol Setup".
4. Press the **▲** or **▼** button to select "Manual Setup", then press the **ENTER**  button.



5. Press the **▲**, **▼**, **◀** or **▶** button to move to an item, and press the numeric button to configure the selected item. Press the **ENTER**  button.
> Select "Network Test" to check the network connectivity.
(Refer to page 86)


Press the **EXIT** button to exit.



Network Test



You can test or confirm the network connection status after setting up the network.

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Setup", then press the **ENTER**  button.
2. Press the **▲** or **▼** button to select "Network Setup", then press the **ENTER**  button.



3. Press the **▲** or **▼** button to select "Network Test", then press the **ENTER**  button.
➤ The current network settings will appear.

Press the **EXIT** button to exit.




Using InfoLink

You can view news, stock market and weather information services using SAMSUNG's InfoLink service.

- Set up the network. (Refer to pages 83, 85)

Activating InfoLink

1. Press the **MENU** button to display the menu.
Press the **▲** or **▼** button to select "Application", then press the **ENTER**  button.




2. Press the **▲** or **▼** button to select "InfoLink", then press the **ENTER**  button.
3. Press the **◀** or **▶** button to select a service ("Weather", "News", "Stock" or "Setup") and press the **ENTER**  button.
 - You can select and view more than one service at the same time only for 'News (without detailed information)', 'Weather-Today's Weather', and 'Stocks-Favorite Stocks, Market Summary'.

Press the **EXIT** button to exit.



- ④ Press the **INFO.L** button on the remote control to display the "InfoLink" menu.



Using the Weather Service

1. Press the **INFO.L** button on the remote control.
2. Press the **◀** or **▶** button to move to the "Weather" service and press the **ENTER ↴** button.

Set up the Region

3. Press Yellow button. Input the postal (zip) code of the region by pressing the number buttons on the remote, then press the **ENTER ↴** button.
 - You can check the weather of the selected region.
 - If you select the "Weather" service when no region is set, a message will appear asking if you want to set up the region. If you select "Yes" using the **◀** or **▶** button, a screen will appear where you can set up the postal (zip) code.



Set up Weather Option

4. Press the Red button while using the service to change the "Weather" service option.
5. Press **▲** or **▼** button and select "Weather" option, then press the **ENTER ↴** button.
 - To exit the "Weather" service, press the blue button.
 - To exit the "InfoLink" service, press the **EXIT** button.



Using the News Service

1. Press the **INFO.L** button on the remote control.
2. Press the **◀** or **▶** button to move to the "News" service and press the **ENTER ↴** button.
 - Press the **ENTER ↴** button to view the detailed article.
 - Press the **◀** or **▶** button to view the previous or next article.



3. Press the Red button while using the service to change the "News" service Option.
4. Press **▲** or **▼** button and select "News" service option, then press the **ENTER ↴** button.
 - The News service option changes depending on the provided web service.
 - To exit the "News" service, press the blue button.
 - To exit the "InfoLink" service, press the **EXIT** button.



Using the Stock Service

1. Press the **INFO.L** button on the remote control.
2. Press the **◀** or **▶** button to move to the "Stock" service and press the **ENTER**  button.



3. Press the Red button while using the service to change the "Stock" service option.
4. Press **▲** or **▼** button and select "Stock" service option, then press the **ENTER**  button.
 - **Favorite Stocks:** The Favorite stock information is displayed. You can set up the Favorite Stocks by pressing the Yellow button.
 - **Market Summary:** Dow Jones, Nasdaq and S&P 500 are toggled and the entire index, amount of up or down, and % are displayed.
 - **Stocks & News:** The Favorite stock information and Dow Jones, NASDAQ and S&P 500 index and Financial news are displayed.



- Stock quotes delayed at least 15 minutes.
- To exit the "Stock" service, press the blue button.
- To exit the "InfoLink" service, press the **EXIT** button.

Setting Favorite Stocks Items

1. Press the Yellow button when "Favorite Stocks" or "Stocks & News" is selected. The Set Favorite Stocks screen appears.
2. Press the **◀** button to move to the Category. Press the **▲** or **▼** button to select a Category. Press the **ENTER**  button.
3. Press the **▲** or **▼** button to select a stock item and press the **ENTER**  button.
 - The selected stock is set as a Favorite Stock.
 - The **✓** mark will appear to the left of the stock name.
 - Press the **ENTER**  button again to cancel the setting. The **✓** mark will disappear.
 - To cancel all selections, press the Green button.
 - Pressing the Red button toggles between NYSE and NASDAQ.
4. To finish the settings, press the **RETURN** button.




InfoLink Setup

1. Press the **INFO.L** button on the remote control.
2. Press the **◀** or **▶** button to select "Setup", then press the **ENTER**  button.




3. Press the **▲** or **▼** button to select the desired option. ("Auto Launch", "Display Time", "Font Size", "Background Color", "InfoLink's Position")
4. Press the **▲** or **▼** button to select an option, then press the **ENTER**  button

- **Auto Launch:** Determines whether to launch InfoLink automatically when the TV is turned on. You can select either "Off" or "On".
- **Display Time:** Determines the time to display the news service on the TV screen. You can select "4 Hours", "8 Hours", "10 Hours", or "Always".
- **Font Size:** You can select letter size "Standard" or "Large" through InfoLink service.
- **Background Color:** You can select the Background Color of InfoLink service. The color is applied to each service, option and setup window.
- **InfoLink's Position:** You can set the position of each InfoLink service on the screen. You can select from six preset InfoLink positions ("Position 1"~"Position 6").



- To exit the "Setup" service, press the **RETURN** button.
- To exit the "InfoLink" service, press the **EXIT** button.

InfoLink's Position



All the materials available through InfoLink provided by USA TODAY are the property of USA TODAY and/or its affiliates or licensors, and are protected by copyright, trademark, and other intellectual property laws. InfoLink content provided by USA TODAY is provided solely for your personal noncommercial use. You may not use the InfoLink content provided by USA TODAY or the USA TODAY materials available on InfoLink in a manner that constitutes an infringement of USA TODAY's rights or that has not been authorized by USA TODAY. More specifically, unless explicitly authorized in this disclaimer or by the owner of the materials, you may not modify, copy, reproduce, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium (including by email or other electronic means) any USA TODAY material from the InfoLink service. Content provided in connection with the InfoLink service may be time-delayed as specified by USA TODAY and/or its affiliates.

About Anynet+


What is Anynet+?

Anynet+ is a function that enables you to control all connected Samsung devices that support Anynet+ with your Samsung TV's remote.

Connecting Anynet+ Devices


The Anynet+ system can be used only with Samsung devices that have the Anynet+ feature. To be sure your Samsung device has this feature, check if there is an Anynet+ logo on it.

To connect to a TV



Connect the [HDMI 1], [HDMI 2], [HDMI 3] or [HDMI 4] jack on the TV and the HDMI OUT jack of the corresponding Anynet+ device using an HDMI cable.

To connect to Home Theater



1. Connect the [HDMI 1], [HDMI 2], [HDMI 3] or [HDMI 4] jack on the TV and the HDMI OUT jack of the corresponding Anynet+ device using an HDMI cable.
2. Connect the HDMI IN jack of the home theater and the HDMI OUT jack of the corresponding Anynet+ device using an HDMI cable.


- Connect the Optical cable between the Digital Audio Out (Optical) jack on your TV and the Digital Audio Input on the Home Theater.
- When following the connection above, the Optical jack only outputs 2 channel audio. You will only hear sound from the Home Theater's Front Left and Right speakers and the subwoofer. If you want to hear 5.1 channel audio, connect the DIGITAL AUDIO OUT (OPTICAL) jack on the DVD player or Cable/Satellite Box (ie Anynet Device 1 or 2) directly to the Amplifier or Home Theater, not the TV.
- Connect only one Home Theater.
- You can connect an Anynet+ device using the HDMI 1.3 cable. Some HDMI cables may not support Anynet+ functions.
- Anynet+ works when the AV device supporting Anynet+ is in the Standby or On status.
- Anynet+ supports up to 12 AV devices in total. Note that you can connect up to 3 devices of the same type.

Setting Up Anynet+

The following settings help set the Anynet+ functions.


To use the Anynet+ Function, Anynet+ (HDMI-CEC) must be set to On

1. Press the **MENU** button. Press the **▲** or **▼** button to select "Application", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Anynet+ (HDMI-CEC)", then press the **ENTER** button.
3. Press the **ENTER** button to select "Anynet+ (HDMI-CEC)".
4. Press the **▲** or **▼** button to select "On", then press the **ENTER** button.
 - The "Anynet+ (HDMI-CEC)" function is enabled.
 - If you select Off, "Anynet+ (HDMI-CEC)" is disabled.
 - When the "Anynet+ (HDMI-CEC)" function is disabled, all the Anynet+ related operations are deactivated.



Setting an Anynet+ Device to turn Off Automatically when the TV is Turned Off

1. Press the **▲** or **▼** button to select "Auto Turn Off", then press the **ENTER** button.
2. Press the **▲** or **▼** button to select "Yes", then press the **ENTER** button.
 - The "Auto Turn Off" function is enabled.
 - If you select "No", the "Auto Turn Off" function is canceled.Press the **EXIT** button to exit.
 - The active source on the TV remote must be set to TV to use the Anynet+ function.
 - If you set "Auto Turn Off" to "Yes", connected external devices are also turned off when the TV is turned off. If an external device is still recording, it may or may not turn off.



Scanning and Switching between Anynet+ Devices

1. Press the **TOOLS** button.
Press the **▲** or **▼** button to select "Device List", then press the **ENTER** button.
 - Anynet+ devices connected to the TV are listed.
 - If you cannot find a device you want, press the red button to scan for devices.
2. Press the **▲** or **▼** button to select to a particular device and press the **ENTER** button. It is switched to the selected device.
 - Only when you set "Anynet+ (HDMI-CEC)" to On in the "Application" menu, the "Device List" menu appears.
 - Switching to the selected devices may take up to 2 minutes. You cannot cancel the operation during the switching operation.
 - The time required to scan for devices is determined by the number of connected devices.
 - When the device scan is complete, the number of devices found are not displayed.
 - Although the TV automatically scans devices when it is turned on using the **POWER** button, devices connected when the TV is already on are not displayed in the device list. In this case, select the Searching Connections menu to search devices.
 - If you have selected external input mode by pressing the **SOURCE** button, you cannot use the Anynet+ function. Make sure to switch to an Anynet+ device by using the **TOOLS** button.



Anynet+ Menu

The Anynet+ menu changes depending on the type and status of the Anynet+ devices connected to the TV.

Anynet+ Menu	Description
View TV	Switches from Anynet+ to TV broadcast mode.
Device List	Displays the Anynet+ device list.
Record	Starts a recording. (This menu works only for a device supporting recording.)
Menu on Device	Shows the menu of the connected device. Example: When a DVD Recorder is connected, the DVD Recorder's title menu appears.
Device Operation	Shows the play control menu of the connected device. Example: When a DVD Recorder is connected, the play control menu of the DVD Recorder appears.
Timer Recording	Allows reserving a recording. (This menu works only for a device supporting recording reservations.)
Stop Recording	Stops recording.
Receiver	Sound is output through the receiver (home theater).
Setup	You can set the Anynet+ (HDMI-CEC), auto turn off, and searching connections for using Anynet+.

TV Remote Control Buttons Available in Anynet+ Mode

Device Type	Operating Status	Available Buttons
Anynet+ Device	After switching to the device, when the menu of the corresponding device is displayed on the screen.	Numeric buttons ▲/▼/◀/▶/ENTER buttons Color buttons / EXIT button
	After switching to the device, while playing a file	(Backward search) / (Forward search) (Stop) / (Play) / (Pause)
Device with built-in Tuner	After switching to the device, when you are watching a TV program	CH / CH button
Audio Device	When Receiver is activated	VOL - / VOL + / MUTE button

- The Anynet+ function only works when the active source on the TV remote control is set to TV.
- The button works only while in the recordable state.
- You cannot control Anynet+ devices using the buttons on the TV. You can control Anynet+ devices only using the TV remote control.
- The TV remote control may not work under certain conditions. In this case, reselect the Anynet+ device.
- The Anynet+ functions do not operate with other manufacturers' products.
- The , operations may differ depending on the device.

Recording

You can make a recording of a TV program using a Samsung recorder.


1. Press the **TOOLS** button.
2. Press the **▲** or **▼** button to select Recording Immediately and press the **ENTER** button. Recording begins.

When there is more than one recording device

When multiple recording devices are connected, the recording devices are listed. Press the **▲** or **▼** button to select a recording device and press the **ENTER** button. Recording begins.

When the recording device is not displayed

Select "Device List" and press the red button to search devices.



Press the **EXIT** button to exit.

- You can record the source streams by selecting "Record" after pressing the **TOOLS** button.
- Pressing the button will record whatever you are currently watching. If you are watching video from another device, the video from the device is recorded.
- Before recording, check whether the antenna jack is properly connected to the recording device. To properly connect an antenna to a recording device, refer to the recording device's users manual.



Listening through a Receiver (Home theater)

You can listen to sound through a receiver instead of the TV speaker.

1. Press the **TOOLS** button. Press the **▲** or **▼** button to select "Receiver".
2. Press the **◀** or **▶** button to select to "On".
Now you can listen to sound through the receiver.
3. Press the **EXIT** button to exit.
 - If your receiver supports audio only, it may not appear in the device list.
 - The receiver will work when you have properly connected the Optical IN jack of the receiver to the Optical Out jack of the TV.
 - When the receiver (home theater) is set to On, you can hear sound output from the TV's Optical jack. When the TV is displaying a DTV(air) signal, the TV will send out 5.1 channel sound to the Home theater receiver. When the source is a digital component such as a DVD and is connected to the TV via HDMI, only 2 channel sound will be heard from the Home Theater receiver.
 - When using the WISELINK feature, sound may not output properly through the receiver.
 - When listening through the receiver, there are restrictions for using the PIP and audio-related (MTS, Preferred language) menus.
 - If there is a power interruption to the TV when the "Receiver" is set to "On" (by disconnecting the power cord or a power failure), the "TV Speaker" may be set to "Off" when you turn the TV on again. (see page 34)



Troubleshooting for Anynet+

Symptom	Solution
Anynet+ does not work.	<ul style="list-style-type: none"> • Check if the device is an Anynet+ device. The Anynet+ system supports Anynet+ devices only. • Connect only one receiver (home theater). • Check if the Anynet+ device power cord is properly connected. • Check the Anynet+ device's Video/Audio/HDMI 1.3 cable connections. • Check whether Anynet+ (HDMI-CEC) is set to On in the Anynet+ setup menu. • Check whether the TV remote control is in TV mode. • Check whether it is Anynet+ exclusive remote control. • Anynet+ doesn't work in certain situations. (Searching channels, Operating WISELINK, Plug & Play, etc.) • When connecting or removing the HDMI 1.3 cable, please make sure to search devices again or turn your TV off and on again. • Check if the Anynet+ Function of Anynet+ device is set on.
I want to start Anynet+.	<ul style="list-style-type: none"> • Check if the Anynet+ device is properly connected to the TV and check if the Anynet+ (HDMI-CEC) is set to On in the Anynet+ Setup menu. • Press the TV button on the TV remote control to switch to TV. Then press the TOOLS button to show the Anynet+ menu and select a menu you want.
I want to exit Anynet+.	<ul style="list-style-type: none"> • Select View TV in the Anynet+ menu. • Press the SOURCE button on the TV remote control and select a device other than Anynet+ devices. • Press CH, CH LIST, PRE-CH, and FAV.CH to change the TV mode. (Note that the channel button operates only when a tuner-embedded Anynet+ device is not connected.)
The message Connecting to Anynet+ device... appears on the screen.	<ul style="list-style-type: none"> • You cannot use the remote control when you are configuring Anynet+ or switching to a view mode. • Use the remote control when the Anynet+ setting or switching to view mode is complete.
The Anynet+ device does not play.	You cannot use the play function when Plug & Play is in progress.
The connected device is not displayed.	<ul style="list-style-type: none"> • Check whether or not the device supports Anynet+ functions. • Check whether or not the HDMI 1.3 cable is properly connected. • Check whether Anynet+ (HDMI-CEC) is set to On in the Anynet+ setup menu. • Search Anynet+ devices again. • You can connect an Anynet+ device using the HDMI 1.3 cable only. Some HDMI cables may not support Anynet+ functions. • If it is terminated by an abnormal situation such as disconnecting the HDMI cable or power cord or a power failure, please repeat the device scan.
The TV program cannot be recorded.	Check whether the antenna jack on the recording device is properly connected.
The TV sound is not output through the receiver.	Connect the optical cable between TV and the receiver.

Appendix

Troubleshooting

If the TV seems to have a problem, first try this list of possible problems and solutions.
If none of these troubleshooting tips apply, call Samsung customer service at 1-800-SAMSUNG.


Problem	Possible Solution
Poor picture.	Try another channel. Adjust the antenna. Check all wire connections.
Poor sound quality.	Try another channel. Adjust the antenna.
No picture or sound.	Try another channel. Press the SOURCE button. Make sure the TV is plugged in. Check the antenna connections.
No sound or sound is too low at maximum volume.	First, check the volume of units connected to your TV (digital broadcasting receiver, DVD, cable broadcasting receiver, VCR, etc.). Then, adjust the TV volume accordingly.
Picture rolls vertically.	Check all wire connections.
The TV operates erratically.	Unplug the TV for 30 seconds, then try operating it again.
The TV won't turn on.	Make sure the wall outlet is working.
Remote control malfunctions.	Replace the remote control batteries. Clean the upper edge of the remote control (transmission window). Check the battery terminals.
"Check signal cable" message.	Ensure that the signal cable is firmly connected to the PC source.
"Not Supported Mode" message.	Check the maximum resolution and connected device's Video frequency. Compare these values with the data in the Display Modes.
Digital broadcasting screen problem.	Please check the digital signal strength and input antenna.
The image is too light or too dark.	Adjust the Brightness and Contrast. Adjust the Fine tuning.
Black bars on the screen.	Make sure the broadcast you're receiving is High Definition (HD). HD channels sometimes broadcast Standard Definition (SD) programming, which can cause black bars. Set your cable/satellite box to stretch or widescreen mode to eliminate the bars.
Picture has a Red/Green or Pink tint.	Make sure the Component cables are connected to the correct jacks.
Closed Captioning not working.	If you are using a Cable/Satellite box, you must set Closed Captioning on the box, not your TV.
Snowy picture.	Your cable box may need a firmware upgrade. Please contact your Cable company.
Ghosting on picture.	This is sometimes caused by compatibility issues with your cable box. Try connecting Component cables instead.
Horizontal bars appear to flicker, jitter or shimmer on the image.	Adjust the Coarse tuning and then adjust the Fine tuning.
Vertical bars appear to flicker, jitter or shimmer on the image.	Adjust the Coarse tuning and then adjust the Fine tuning.
Screen is black and power indicator light blinks steadily.	On your computer check: Power, Signal Cable. The TV is using its power management system. Move the computer's mouse or press any key on the keyboard.



Problem	Possible Solution						
Image is not stable and may appear to vibrate when you have a computer connected to the PC input.	If the setting is not correct, use your computer utility program to change the display settings. ➢ Your TV supports multiscan display functions within the following frequency domain: <table border="1"><tr><td>Horizontal frequency (kHz)</td><td>30~60</td></tr><tr><td>Vertical frequency (Hz)</td><td>60~75</td></tr><tr><td>PC Maximum refresh rate (at 60 Hz)</td><td>1920 x 1080</td></tr></table>	Horizontal frequency (kHz)	30~60	Vertical frequency (Hz)	60~75	PC Maximum refresh rate (at 60 Hz)	1920 x 1080
Horizontal frequency (kHz)	30~60						
Vertical frequency (Hz)	60~75						
PC Maximum refresh rate (at 60 Hz)	1920 x 1080						
Image is not centered on the screen.	Adjust the horizontal and vertical position. The screen position must be adjusted on the output source (i.e. STB) with a digital signal.						
The picture appears distorted in the corner of the screen.	If "Just Scan" is selected with some external devices, the picture may appear distorted in the corner of the screen. This symptom is caused by the external devices, not TV.						
The "Resets all settings to the default values" message appears.	This appears when you press and hold the EXIT button for a while. The product settings are reset to the factory defaults.						
You may see small particles if you look closely at the edge of the bezel surrounding the TV screen.	This is part of the product's design and is not a defect.						


This TFT LCD panel uses a panel consisting of sub pixels (6 220 800) which require sophisticated technology to produce. However, there may be few bright or dark pixels on the screen. These pixels will have no impact on the performance of the product.

Installing the Stand



1. Attach your LCD TV to the stand.
 - > Two or more people should carry the TV.
 - > Make sure to distinguish between the front and back of the stand when attaching it.
 - > To make sure the TV is installed on the stand at a proper level, do not apply excess downward pressure to the upper left or right sides of the TV.
2. Fasten two screws at position ① and then fasten two screws at position ②.
 - > Stand the product up and fasten the screws. If you fasten the screws with the LCD TV placed down, it may lean to one side.



Disconnecting the Stand



1. Remove four screws from the back of the TV.
2. Separate the stand from the TV.
 - > Two or more people should carry the TV.
3. Cover the bottom hole with the cover.

Auto Wall-Mount Adjustment (Sold separately)

Once the auto wall mount is installed, your TV's position can be easily adjusted.






Entering the menu

1. Press the **▲**, **▼**, **◀** or **▶** button on your remote control.
 - The Wall Mount Adjustment screen is displayed.
 - If the Wall Mount Adjustment screen is not displayed when clicking on a direction button while watching your TV, use the menu to display that screen.
- Press the **MENU** button to display the menu. Press the **▲** or **▼** button to select "Setup", then press the **ENTER** button.
- Press the **▲** or **▼** button to select "External Settings", then press the **ENTER** button.
- Press the **▲** or **▼** button to select "Wall-Mount Adjustment", then press the **ENTER** button.

Remembering the Position

2. Adjust to the desired position using the **▲**, **▼**, **◀**, **▶** buttons.
 - If you press an arrow button when no OSD is displayed on the TV screen, the Adjustment screen appears.
 - Press the **INFO** button to reset. Press the **◀** or **▶** button to select "Yes", then press the **ENTER** button. The position is initialized to the default setting.
3. Press the Blue button.
Press the **▲** and **▼** buttons to select a save mode from either Position 1, Position 2 or Position 3 in order to save the current position.
 - To not save the current position, press the **RETURN** button.
 - When selecting a save mode, you cannot use the Color buttons.
4. Press the **ENTER** button to save.
 - When Position1 is selected, the message "Current position saved as Position1" is displayed.
5. Press the **ENTER** button.
 - The saved Position appears on the left side of the OSD.




Moving to the remembered position

1. Complete Step 1 of "Entering the menu".
2. Pressing a Color (Red, Green, Yellow) button moves the auto wall mount to the saved position.
 - You can move the wall mount to one of the 3 pre-set positions by pressing the Red (Position 1), Green (Position 2) or Yellow (Position 3) buttons.
 - If you adjust the Position after moving to a pre-set position, the position display will disappear.
- For installation, refer to the Installation Manual provided with the wall mount.
- For product installation and the installation and moving of the wall mount, make sure to consult a specialized installation company.
- This installation manual is to be used when attaching the wall mount to a wall. When attaching to other building materials, please contact your nearest dealer.
- The auto wall mount will not work when Anynet+ or WISELINK is operating.
- LN40A650A1F and LN46A650A1F models are not compatible with the older wall mount model (WMN5090A).

Wall Mount Kit Specifications (VESA)

Install your wall mount on a solid wall perpendicular to the floor. When attaching to other building materials, please contact your nearest dealer. If installed on a ceiling or slanted wall, it may fall and result in severe personal injury.



Product Family	inches	VESA Spec. (A * B)	Standard Screw	Quantity	
LCD-TV	23~ 26	200 * 100	M4	4	
	32 ~ 40	200 * 200	M6		
	46 ~ 52	600 * 400	M8		
	57	700 * 400 (No VESA)			
	57 ~ 70	800 * 400			
	80 ~	1400 * 800			
PDP-TV	42 ~ 50	600 * 400	M8	4	
	55 ~ 70	800 * 400		6	
	63	No VESA		4	
	80 ~	1400 * 800			


- Standard dimensions for wall mount kits are shown in the table above.
- When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
- Do not use screws longer than the standard dimension, as they may cause damage to the inside of the TV set.
- For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on their specifications.
- Do not use screws that do not comply with the VESA standard screw specifications.
Do not fasten the screws too strongly, this may damage the product or cause the product to fall, leading to personal injury. Samsung is not liable for these kinds of accidents.
- Samsung is not liable for product damage or personal injury when a non-VESA or non-specified wall mount is used or the consumer fails to follow the product installation instructions.
- Our 57" and 63" models do not comply with VESA Specifications. Therefore, you should use our dedicated wall mount kit for this model.
- Do not exceed 15 degrees tilt when mounting this TV.



Do not install your Wall Mount Kit while your TV is turned on. It may result in personal injury due to electric shock.

Using the Anti-Theft Kensington Lock (LN32A650A1F, LN40A650A1F, LN46A650A1F)

The Kensington Lock is a device used to physically fix the system when using it in a public place. The appearance and locking method may differ from the illustration depending on the manufacturer. Refer to the manual provided with the Kensington Lock for proper use. The locking device has to be purchased separately.



> The location of the Kensington Lock may be different depending on its model.

1. Insert the locking device into the Kensington slot on the LCD TV (Figure 1) and turn it in the locking direction (Figure 2).
2. Connect the Kensington Lock cable.
3. Fix the Kensington Lock to a desk or a heavy stationary object.

Specifications


Model Name	LN32A650A1F	LN40A650A1F
Screen Size (Diagonal)	32 inches	40 inches
PC Resolution	1920 x 1080 @ 60 Hz	1920 x 1080 @ 60 Hz
Sound Output	10W X 2	10W X 2
Dimensions (WxDxH)		
Body	31.7 x 3.2 x 20.8 inches (806.0 x 81.0 x 528.2 mm)	39.3 x 3.3 x 25.1 inches (998.0 x 83.4 x 638.0 mm)
With stand	31.7 x 9.9 x 23.0 inches (806.0 x 251.9 x 584.4 mm)	39.3 x 11.8 x 27.5 inches (998.0 x 300.0 x 698.2 mm)
Weight		
With Stand	31.3 lbs (14.2 kg)	44.5 lbs (20.2 kg)
Without Stand	26.5 lbs (12.0 kg)	37.5 lbs (17.0 kg)
Environmental Considerations		
Operating Temperature	50°F to 104°F (10°C to 40°C)	
Operating Humidity	10% to 80%, non-condensing	
Storage Temperature	-4°F to 113°F (-20°C to 45°C)	
Storage Humidity	5% to 95%, non-condensing	
Stand Swivel (Left / Right)		-20° ~ 20°

Model Name	LN46A650A1F	LN52A650A1F
Screen Size (Diagonal)	46 inches	52 inches
PC Resolution	1920 x 1080 @ 60 Hz	1920 x 1080 @ 60 Hz
Sound Output	10W X 2	10W X 2
Dimensions (WxDxH)		
Body	44.5 x 3.7 x 28.1 inches (1131.0 x 94.5 x 714.2 mm)	50.2 x 4.1 x 31.7 inches (1276.0 x 105.0 x 805.7 mm)
With stand	44.5 x 11.0 x 30.5 inches (1131.0 x 279.9 x 774.5 mm)	50.2 x 12.8 x 34.1 inches (1276.0 x 326.0 x 866.1 mm)
Weight		
With Stand	58.6 lbs (26.6 kg)	76.7 lbs (34.8 kg)
Without Stand	49.2 lbs (22.3 kg)	64.6 lbs (29.3 kg)
Environmental Considerations		
Operating Temperature	50°F to 104°F (10°C to 40°C)	
Operating Humidity	10% to 80%, non-condensing	
Storage Temperature	-4°F to 113°F (-20°C to 45°C)	
Storage Humidity	5% to 95%, non-condensing	
Stand Swivel (Left / Right)		-20° ~ 20°


- Design and specifications are subject to change without prior notice.
- This device is a Class B digital apparatus.
- For the power supply and Power Consumption, refer to the label attached to the product.

Dimensions


LN32A650A1F




TOP VIEW



JACK PANEL DETAIL 3.7"H X 9.1"W



FRONT VIEW / SIDE VIEW



REAR VIEW

NOTE: All drawings are not necessarily to scale.

Some dimensions are subject to change without prior notice.


Refer to the dimensions prior to performing installation of your TV.

Not responsible for typographical or printed errors.


© 2008 Samsung Electronics America, Inc.

Dimensions


LN40A650A1F




TOP VIEW



JACK PANEL DETAIL 3.7"H X 9.1"W



FRONT VIEW / SIDE VIEW



REAR VIEW

NOTE: All drawings are not necessarily to scale.

Some dimensions are subject to change without prior notice.


Refer to the dimensions prior to performing installation of your TV.

Not responsible for typographical or printed errors.


© 2008 Samsung Electronics America, Inc.

Dimensions


LN46A650A1F




TOP VIEW



JACK PANEL DETAIL 3.7"H X 9.1"W



FRONT VIEW / SIDE VIEW



REAR VIEW

NOTE: All drawings are not necessarily to scale.

Some dimensions are subject to change without prior notice.


Refer to the dimensions prior to performing installation of your TV.

Not responsible for typographical or printed errors.


© 2008 Samsung Electronics America, Inc.

Dimensions


LN52A650A1F




TOP VIEW



JACK PANEL DETAIL 3.7"H X 9.1"W



FRONT VIEW / SIDE VIEW



REAR VIEW

NOTE: All drawings are not necessarily to scale.

Some dimensions are subject to change without prior notice.

Refer to the dimensions prior to performing installation of your TV.

Not responsible for typographical or printed errors.

© 2008 Samsung Electronics America, Inc.

- This product uses some software programs which are distributed under the Independent JPEG Group.
- This product uses some software programs which are distributed under the Freetype Project.(www.freetype.org).
- This product uses some software programs which are distributed under the GPL/LGPL.Accordingly, the following GPL and LGPL software source codes that have been used in this product can be provided after asking to vdsmanager@samsung.com.

GPL software: Linux Kernel, Busybox, Binutils

LGPL software: Glibc, ffmpeg, smpeg, libgphoto2, libusb, SDL

The GNU General Public License (GPL)

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it. For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

One line to give the program's name and a brief idea of what it does.

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

signature of Ty Coon, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.



GNU Lesser General Public License (LGPL)

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a “work that uses the Library”. Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a “work that uses the Library” with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a “work that uses the library”. The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a “work that uses the Library” uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a “work that uses the Library” with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer’s own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable “work that uses the Library”, as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user’s computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the “work that uses the Library” must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.



END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and an idea of what it does.> Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.

signature of Ty Coon, 1 April 1990

Ty Coon, President of Vice

That's all there is to it!



Información importante sobre la garantía relativa al formato de visualización del televisor

Las pantallas LCD con formato de pantalla panorámica (16:9, la relación de aspecto:alto de la pantalla) están diseñadas principalmente para visualizar videos de movimiento de formato panorámico. Las imágenes deben estar principalmente en el formato panorámico de relación 16:9, o ampliadas para llenar la pantalla si el modelo tiene esta opción, y las imágenes están en movimiento constante. La visualización de imágenes y gráficos estáticos en la pantalla, como las barras oscuras laterales en programación y videos de televisión en formato estándar no ampliados, debe limitarse a no más del 5% del tiempo total de visualización del televisor por semana.

Además, la visualización de otras imágenes estáticas y texto, como los informes de bolsa, pantallas de videojuegos, logotipos de emisoras, sitios Web o gráficos y dibujos de ordenador, deberá limitarse en todos los televisores como ya se ha descrito. La visualización de imágenes estáticas que supere los límites de las instrucciones anteriores puede producir un envejecimiento desigual de las pantallas LCD, lo que provocará una reproducción superpuesta sutil pero permanente de la imagen de la LCD. Para evitarlo, varíe la programación y las imágenes y, sobre todo, visualice imágenes en movimiento a toda pantalla, no gráficos estáticos ni barras oscuras.

En modelos de LCD que ofrezcan opciones para el tamaño de la imagen, utilice estos controles para ver los distintos formatos como imagen a toda pantalla.

Tenga cuidado en la selección y duración de los formatos de televisión utilizados para la visualización. La garantía limitada de Samsung no cubre el envejecimiento desigual de la LCD como resultado de la selección y uso de formatos, así como otras imágenes retenidas.

Sólo EE.UU.

La unidad del producto que se incluye con este manual del usuario se suministra con licencia bajo derechos de propiedad intelectual de otras empresas. En concreto, este producto se suministra con licencia bajo las siguientes patentes de EE.UU.: 5,991,715, 5,740,317, 4,972,484, 5,214,678, 5,323,396, 5,539,829, 5,606,618, 5,530,655, 5,777,992, 6,289,308, 5,610,985, 5,481,643, 5,544,247, 5,960,037, 6,023,490, 5,878,080 y bajo el número de aplicación de patentes publicadas de EE.UU. 2001-44713-A1.

Esta licencia está limitada al uso no comercial privado de consumidores que sean usuarios finales para contenido con licencia. No se otorga ningún derecho para uso comercial. La licencia no cubre a ninguna unidad del producto que no sea ésta y la licencia no se extiende a ninguna unidad del producto o proceso sin licencia en conformidad con el ISO/IEC 11172-3 o ISO/IEC 13818-3 utilizada o vendida en combinación con esta unidad del producto. La licencia sólo cubre el uso de esta unidad para codificar y/o decodificar archivos de audio en conformidad con el ISO/IEC 11172-3 o ISO/IEC 13818-3. No se otorga ningún derecho bajo esta licencia para características o funciones del producto que no estén conformes con el ISO/IEC 11172-3 o ISO/IEC 13818-3.

Otros países

La unidad del producto que se incluye con este manual del usuario se suministra con licencia bajo derechos de propiedad intelectual de otras empresas. Esta licencia está limitada al uso no comercial privado de consumidores que sean usuarios finales para contenido con licencia. No se otorga ningún derecho para uso comercial. La licencia no cubre ninguna unidad del producto que no sea ésta y la licencia no se extiende a ninguna unidad del producto o proceso sin licencia en conformidad con el ISO/IEC 11172-3 o ISO/IEC 13818-3 utilizada o vendida en combinación con esta unidad del producto. La licencia sólo cubre el uso de esta unidad para codificar y/o decodificar archivos de audio en conformidad con el ISO/IEC 11172-3 o ISO/IEC 13818-3. No se otorga ningún derecho bajo esta licencia para características o funciones del producto que no estén conformes con el ISO/IEC 11172-3 o ISO/IEC 13818-3.

Precauciones al mostrar en la pantalla una imagen fija

La imagen fija puede causar daños permanentes en la pantalla del televisor.

- No deje una imagen fija en la pantalla LCD durante más de dos horas ya que se podría producir una retención de la imagen en la pantalla. Este fenómeno de retención de imágenes también se denomina "quemadura de pantalla". Para evitar que se produzca esa persistencia de la imagen, reduzca el nivel de luminosidad y de contraste de la pantalla cuando muestre imágenes fijas.
-  El uso del televisor LCD en formato 4:3 durante un tiempo prolongado puede dejar rastros de bordes en las partes izquierda, derecha y central de la pantalla debido a las diferencias en la emisión lumínica de la pantalla. La reproducción de un DVD o el uso de una consola de videojuegos pueden provocar un efecto similar en la pantalla. Reproducir un DVD o una videoconsola puede causar un efecto similar en la pantalla. La garantía no cubre estos daños.
- Ver imágenes fijas de videojuegos y PC durante más tiempo del indicado puede producir restos de imágenes parciales. Para evitar este efecto, reduzca el 'brillo' y el 'contraste' cuando vea imágenes fijas.



Contenido

Información General

■ Listado de características.....	2
■ Accesorios.....	2
■ Aspecto general del panel de control.....	3
■ Aspecto general del panel de conexiones.....	4
■ Mando a distancia	5
■ Instalación de las pilas en el mando a distancia	6

Conexiones

■ Conexión de antenas de VHF y UHF	6
■ Conexión de TV por cable	7
■ Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de HDMI.....	8
■ Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de DVI.....	8
■ Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de los cables de componentes.....	9
■ Conexión de una videocámara.....	9
■ Conexión de un reproductor de vídeo.....	10
■ Conexión de un sistema de audio digital.....	11
■ Conexión de un amplificador/DVD para cine en casa.....	11
■ Conexión a un PC	12

Funcionamiento

■ Encendido o apagado del TV	13
■ Función Plug & Play.....	13
■ Cambio de canales.....	15
■ Ajuste del volumen	15
■ Visualización de la pantalla	16
■ Visualización de los menús	16
■ Using the Remote Control Backlight Buttons	16
■ Uso del botón TOOLS	17
■ Memorización de los canales	17
■ Para seleccionar la fuente.....	19
■ Edición del Nombre de la Fuente de entrada.....	19

Control de la Imagen

■ Cambio del formato de la imagen	20
■ Personalización de la configuración de la imagen	20
■ Activación de la configuración detallada	21
■ Reajuste de valores de la imagen a los valores predefinidos de fábrica.....	24
■ Activación de las opciones de la imagen	25
■ Visualización Imagen en imagen.....	29

Control de Sonido

■ Cambio del estándar de sonido.....	31
■ Personalización del sonido.....	31
■ Configuración del TruSurround XT (SRS TS XT).....	32
■ Elección del idioma preferido	33
■ Selección de una pista de sonido multicanal (MTS)	33
■ Control automático de volumen.....	34
■ Encendido/apagado del altavoz del televisor	34
■ Escuchar el sonido de la sub imagen del PIP	35
■ Reajuste de valores de sonido a los valores predefinidos de fábrica.....	35
■ Conexión de los auriculares (se vende por separado).....	35

Control de los Canales

■ Gestión de los canales	36
■ Supresión de los canales codificados digitales	42
■ Sintonización fina de los canales analógicos.....	42
■ Comprobación de la potencia de la señal digital.....	43

Pantalla de PC

■ Uso del TV como pantalla de ordenador (PC)	44
■ Modos de visualización	44
■ Ajuste del televisor con el ordenador	45

Ajuste de la Hora

■ Configuración del Reloj	47
---------------------------------	----

Descripción de las Funciones

■ Selección del idioma de menú	51
■ Uso de V-Chip	51
■ Visión de subtítulos (mensajes de texto en pantalla) - Analógico ..	58
■ Visión de subtítulos (mensajes de texto en pantalla) - Digital....	59
■ Ajuste de la melodía de encendido y apagado del televisor	60
■ Configuración del modo Entretenimiento	60
■ Uso de la función de ahorro de energía.....	61
■ Guía de actualización del software	62

WISELINK

■ Uso de la función WISELINK	63
■ Uso de la lista de fotos	64
■ Visualización de una foto o una presentación	70
■ Uso de la lista de música	74
■ Reproducción de un archivo de música	79
■ Uso del menú de configuración	81

Network Settings and InfoLink

■ Network Connection (DHCP) and Automatic Setup	82
■ Network Connection (Static IP) and Manual Setup	84
■ Network Test.....	86
■ Using InfoLink.....	87
■ InfoLink Setup	90

Acerca de Anynet+

■ ¿Qué es Anynet+?	91
■ Conexión de dispositivos Anynet+	91
■ Configuración de Anynet+	92
■ Búsqueda y cambio de dispositivos Anynet+	92
■ Grabación	93
■ Escucha a través de un receptor.....	94
■ Solución de problemas de Anynet+	94

Apéndice

■ Identificación de problemas.....	95
■ Instalación del soporte	97
■ Desconexión del soporte	97
■ Ajuste de montaje mural automático (se vende por separado) ..	98
■ Especificaciones del equipo de montaje en la pared (VESA)	99
■ Uso del cierre antirrobo kensington (LN32A650A1F, LN40A650A1F, LN46A650A1F).....	100
■ Especificaciones	101
■ Tamaño	102

Antes de usar el equipo lea este manual para evitar fallas y guarde para futuras referencias.

 Pulse
  Nota
  Botón de una pulsación




Información General

Listado de características

- Valores ajustables de la imagen que se pueden almacenar en la memoria del televisor.
- Temporizador automático para encender o apagar el televisor.
- Temporizador de desconexión especial.
- Excelente interfaz digital y capacidad de trabajo en red:
El sintonizador digital HD incorporado permite ver las emisiones HD que no exigen una suscripción sin que sea necesario disponer de un receptor de televisión por cable/satélite (decodificador).
- Puede ver noticias e información meteorológica y bursátil en la red. (servicio InfoLink de SAMSUNG).
- Se pueden escuchar archivos de música y ver imágenes de los dispositivos de clase de almacenamiento masivo USB (MSC).
- **Conexión HDMI/DVI del PC con este televisor.**
- Calidad excelente de la imagen
 - La tecnología DNle proporciona imágenes completamente reales.
- SRS TruSurround XT
 - SRS TruSurround XT proporciona un sistema surround virtual.

Accesorios

Compruebe que las opciones siguientes se incluyen con su TV LCD. Si falta alguna opción, póngase en contacto con el proveedor.



Mando A Distancia y Pilas
(AAA x 2)
(BN59-00695A)



Tarjeta de garantía / Tarjetas de registro
/ Guía de seguridad
(no está disponible en todas las
localidades)



Cubierta inferior
(LN32A650A1F: BN63-04294A)
(LN40A650A1F: BN63-04243A)
(LN46A650A1F: BN63-04288A)
(LN52A650A1F: BN63-04330A)



Cable de alimentación
(3903-000144)



Paño de limpieza
(BN63-01798A)



Manual de Instrucciones




Núcleo de ferrita para cable
HDMI lateral (HDMI4)
(LN46A650A1F: 3301-001305)

> El color y la forma de los elementos puede variar según el modelo.

> **Núcleo de ferrita (Cable HDMI lateral)**


Los núcleos de ferrita se utilizan para proteger los cables de las interferencias. Cuando conecte un cable, abra el núcleo de ferrita y fíjelo alrededor del cable cerca del conector.



Aspecto general del panel de control

Botones de la parte inferior derecha del panel

Los botones del panel inferior derecho controlan las funciones básicas del televisor, incluido el menú en pantalla. Para usar las funciones más avanzadas, debe usar el mando a distancia.



① SOURCE

Cambia entre todas las fuentes de entrada disponibles (TV, AV1, AV2, S-Video, Componente1, Componente2, PC, HDMI1, HDMI2/DVI, HDMI3, HDMI4, USB). En el menú de la pantalla, utilice este botón del mismo modo que el botón **ENTER** del mando a distancia.

② MENU

Pulse para ver en pantalla un menú con las características del TV.

③ - VOL +

Pulse para aumentar o reducir el volumen. En el menú de la pantalla, utilice los botones **- VOL +** del mismo modo que los botones **◀** y **▶** del mando a distancia.

④ ▼ CH ^

Pulse para cambiar de canal.

En el menú de la pantalla, utilice estos botones **▼ CH ^** del mismo modo que los botones **▼** y **▲** del mando a distancia.

⑤ INDICADOR DE ALIMENTACIÓN

Parpadea y se apaga cuando se enciende el aparato y se ilumina en el modo en espera.

⑥ (ENCENDIDO)

Pulse para encender o apagar el TV.


⑦ SENSOR DEL MANDO A DISTANCIA

Dirija el mando a distancia hacia este punto del TV.

⑧ ALTAVOCES

Aspecto general del panel de conexiones

Use los terminales del panel de conexión para conectar componentes de A/V que estarán disponibles permanentemente, como un vídeo o un reproductor de DVD. Si precisa información sobre la conexión de equipos, consulte las páginas 6 a 12.



① AUDIO OUT

Permite conectar las tomas de la entrada de audio del amplificador/sistema de Home Película.

② LAN

Conecte un cable LAN a este puerto para conectar a la red (servicio InfoLink de SAMSUNG). (Consulte la página 82.)

③ PC IN [PC] / [AUDIO]

Permite conectar a las tomas de salida de audio y de vídeo de su PC.

④ HDMI IN 1, 2, 3, 4 / DVI IN(HDMI2)[R-AUDIO-L]

Permite conectar a la toma HDMI de un dispositivo que tenga salida HDMI.

- No se necesita ninguna conexión de sonido para una conexión de HDMI a HDMI.

Use el terminal HDMI IN 2 para conectar el DVI a un dispositivo externo. Use un cable de DVI a HDMI o un adaptador de DVI-HDMI (DVI a HDMI) para la conexión del vídeo, y las tomas [R-AUDIO-L] de DVI IN (HDMI2) para el audio.

- Cuando se usa una conexión de cable HDMI/DVI, se debe conectar en el terminal HDMI IN 2.

⑤ DIGITAL AUDIO OUT (OPTICAL)

Se conecta al componente de audio digital.

⑥ ANT IN

Permite conectar a una antena o un sistema de TV por cable.

⑦ WISELINK

Se usa para conectar un dispositivo de almacenamiento masivo USB para ver archivos de fotos y reproducir archivos de audio.

⑧ AV IN 2

Entradas de vídeo y audio para dispositivos externos, como una videocámara o un reproductor de vídeo.

S-VIDEO

Permite conectar la señal de S-Vídeo de una cámara o de un vídeo.

⑨ (AURICULAR)

Permite conectar unos auriculares externos para audiciones privadas.

⑩ ENTRADA DE ALIMENTACIÓN

Permite conectar el cable de alimentación suministrado.

⑪ COMPONENT IN 1, 2 / AV IN 1

Permite conectar el vídeo/audio de componentes.

El terminal COMPONENT IN 1 también se usa como terminal AV IN 1.

- Conecte el cable de vídeo al terminal COMPONENT IN 1 [Y/VIDEO] y el cable de audio al terminal COMPONENT IN 1 [R-AUDIO-L].

⑫ EX-LINK

Toma de conexión para un soporte de montaje mural opcional. Permite ajustar el ángulo de visualización del televisor mediante el mando a distancia.

⑬ BLOQUEO KENSINGTON

(LN32A650A1F, LN40A650A1F, LN46A650A1F)

El bloqueo Kensington (opcional) es un dispositivo que se utiliza para fijar físicamente el sistema cuando se utiliza en un sitio público. Si desea usar un dispositivo de bloqueo, póngase en contacto con el distribuidor donde adquirió el televisor.


> La ubicación del 'Bloqueo Kensington' puede variar según el modelo.

Mando a distancia

Puede utilizar el mando a una distancia de hasta 7 metros del televisor.




- 1 POWER**
Enciende o apaga el TV.
- 2 TV**
Selecciona directamente el modo TV.
- 3 BOTONES NUMÉRICOS**
Pulsar para cambiar el canal.
- 4 []**
Pulse este botón para seleccionar canales adicionales (digitales y analógicos) emitidos por la misma emisora. Por ejemplo, para elecciónar el canal "54-3" pulse "54", "[-]" y "3".
- 5 [MUTE]**
Pulse para desactivar momentáneamente el sonido.
- 6 VOL - / VOL +**
Pulse para aumentar o reducir el volumen.
- 7 CH LIST**
Muestra el "Gestor canales" en la pantalla.
- 8 TOOLS**
Se usa para seleccionar rápidamente las funciones que se usan con mayor frecuencia.
- 9 INFO**
Púlselo para mostrar información en la pantalla del televisor.
- 10 Botones de colores**
Use estos botones en la Lista de canales, WISELINK, etc.
- 11 CC**
Controla el decodificador de subtítulos.
- 12 E.MODE**
Pulse este botón para seleccionar los modos de visualización y de sonido establecidos para deportes, películas y juegos.
- 13** Use estos botones en los modos DMA, WISELINK y Anynet+.
(): Este mando remoto se puede usar para controlar la grabación en las grabadoras de Samsung con la función Anynet+.
- 14 [ON/OFF]**
Pulse este botón para activar la luz de fondo de los botones del mando a distancia. Esta función es útil cuando se usa de noche o en una sala a oscuras. (El uso del mando a distancia con los botones de iluminación ON/OFF activados reduce el tiempo de uso de las pilas.) (Consulte la página 16)
- 15 PRE-CH**
Sintoniza el canal anterior.
- 16 CH ▼ / CH ▲**
Permiten cambiar de canal.
- 17 SOURCE**
Pulse este botón para ver y seleccionar las fuentes de video disponibles.
- 18 W.LINK (WISELINK)**
Esta función permite ver y reproducir archivos de fotos y de música desde un dispositivo externo. (Consulte las páginas 64 (fotos) y 74 (música).)
- 19 MENU**
Muestra el menú de pantalla principal.
- 20 RETURN**
Vuelve al menú anterior.
- 21 ARRIBA▲ / ABAJO▼ / IZQUIERDA◀ / DERECHA▶ / ENTER ↴**
Pulse las secciones arriba/abajo/izquierda/derecha del botón de rueda y Enter para seleccionar los elementos del menú en pantalla y cambiar los valores del menú.
Con el botón de rueda puede desplazarse arriba y abajo en el menú, cambiar canales y ajustar el volumen. (Consulte las páginas 15~16)
- 22 EXIT**
Pulse el botón para salir.
- 23 DMA (Adaptador digital multimedia)**
Use este botón en las conexiones de dispositivos SAMSUNG DMA a través de una interfaz HDMI y para cambiar al modo DMA.
Para obtener más información sobre los procedimientos de funcionamiento, consulte el manual del usuario del dispositivo DMA. Este botón está disponible cuando "Anynet+(HDMI-CEC)" está configurado como "Encendido". (Consulte la página 92)
- 24 INFO.L**
Pulse este botón para usar los servicios de noticias, información bursátil y meteorológica disponibles en la red. (Consulte la página 87)
- 25 FAV.CH**
Pulse este botón para sintonizar sus canales favoritos.
- 26 P.SIZE**
Selección del tamaño de la imagen.

➤ El exceso de luz puede influir en el rendimiento del mando a distancia.



Instalación de las pilas en el mando a distancia


1. Levante la tapa de la parte posterior del mando a distancia, como se muestra en la ilustración.
 2. Coloque dos pilas de tamaño AAA.
 - Compruebe que los extremos "+" y "-" de las pilas concuerden con el diagrama del interior del compartimiento.
 3. Vuelva a colocar la tapa.
 - Si no va a usar el mando a distancia durante un largo período de tiempo, extraiga las pilas y guárdelas en un lugar fresco y seco.
- El mando se puede utilizar hasta una distancia de unos 7 metros del televisor.
(Con un uso normal del TV, las pilas duran alrededor de un año.)
- El uso del mando a distancia con los botones de iluminación **ON/OFF**  activados reduce el tiempo de uso de las pilas.
- Si el mando a distancia no funciona, haga estas comprobaciones:
1. ¿Está encendido el TV?
 2. ¿Están invertidos los polos positivo y negativo de la batería?
 3. ¿Se han agotado las baterías?
 4. ¿Ha habido un corte de luz o el cable está desconectado?
 5. ¿Hay cerca una luz fluorescente o un letrero de neón?



Conexiones

Conexión de antenas de VHF y UHF

Si su antena tiene un conjunto de cables con este aspecto, consulte "Antenas de par de cables planos de 300 Ω" a continuación.





Si la antena tiene un cable como el que se muestra en el diagrama de la derecha, consulte "Antenas con cables coaxiales de 75 ohmios".



Antenas de par de cables planos de 300 Ω


Si utiliza una antena externa (de techo o de "orejas de conejo") de par de cables planos de 300 Ω, siga las indicaciones siguientes.

1. Coloque los conductores del par de cables bajo los tornillos del adaptador de 300-75 Ω (no incluido). Utilice un destornillador para apretar los tornillos.
2. Conecte el adaptador en el terminal ANT IN en la parte posterior del televisor.



Antenas de cable coaxial de 75 Ω



1. Conecte el cable de la antena en el terminal ANT IN de la parte inferior del panel posterior.



Antenas de VHF y UHF independientes

Si dispone de dos antenas independientes para el TV (una de VHF y otra de UHF), debe combinar ambas señales de la antena antes de conectarlas al TV. Este procedimiento precisa un adaptador-combinador especial (disponible en la mayoría de tiendas de electrónica).

1. Conecte ambos cables de antena al combinador.
2. Conecte el combinador en el terminal ANT IN de la parte inferior del panel posterior.




Conexión de TV por cable

Para conectar a un sistema de TV por cable, siga estas instrucciones.



TV por cable sin decodificador

1. Conecte el cable de entrada en el terminal de la antena ANT IN de la parte posterior del TV.
 - Dado que el TV está preparado para la televisión por cable, no se necesita un decodificador para ver canales de cable no codificados.



Conexión al decodificador que decodifica todos los canales


1. Busque el cable conectado al terminal ANT OUT del decodificador.
 - Este terminal puede estar indicado como "ANT OUT", "VHF OUT" o "OUT".
2. Conecte el otro extremo del cable en el terminal ANT IN de la parte posterior del TV.



Conexión a un decodificador que decodifica algunos canales

Si su decodificador sólo decodifica algunos canales (como los canales de pago), siga las instrucciones siguientes. Necesitará un divisor de dos vías, un conmutador de RF (A/B) y cuatro largos de cable RF.
(Estas opciones se encuentran en la mayoría de tiendas de electrónica.)

1. Busque y desconecte el cable que está conectado al terminal ANT IN (entrada de antena) del decodificador.
 - Este terminal puede estar indicado como "ANT IN", "VHF IN" o "IN".
2. Conecte este cable al divisor de dos vías.
3. Conecte el cable RF entre un terminal OUTPUT(salida) del divisor y el terminal IN (entrada) del decodificador.
4. Conecte el cable RF entre el terminal ANT OUT del decodificador y el terminal B.IN del conmutador A/B.
5. Conecte otro cable RF entre el otro terminal OUT del divisor y el terminal A.IN del conmutador de RF (A/B).
6. Conecte el último cable RF entre el terminal OUT del conmutador RF (A/B) y el terminal ANT IN en la parte posterior del televisor.




Una vez hecha esta conexión, coloque el conmutador A/B en la posición "A" para la visualización normal. Coloque el conmutador A/B en la posición "B" para ver los canales codificados. (Cuando sitúe el conmutador A/B en "B", deberá sintonizar el TV al canal de salida del decodificador, que normalmente es el canal 3 o 4.)

Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de HDMI

Solo es aplicable si hay un conector de salida de HDMI en el dispositivo externo.

1. Conecte un cable HDMI entre la toma HDMI IN (1, 2, 3 o 4) del televisor y la toma HDMI del reproductor de DVD o receptor de televisión por cable/satélite (decodificador).




- ¿Qué es HDMI?
 - HDMI, o interfaz multimedia de alta definición, es una interfaz de la siguiente generación que permite la transmisión de señales digitales de audio y de video mediante un cable simple sin compresión.
 - La diferencia entre los dispositivos HDMI y DVI es que el HDMI es más pequeño y tiene instalada la función de codificación HDCP (protección alta de la copia digital del ancho de banda).
- Cada reproductor de DVD o receptor de televisión por cable/satélite (decodificador) tiene una configuración diferente del panel posterior.
- Puede que el televisor no proporcione salida de sonido y muestre imágenes con colores anómalos si hay conectados reproductores de DVD o receptores de cable/satélite que admiten versiones de HDMI anteriores a la versión 1.3. Si se conecta un cable antiguo HDMI y no hay sonido, conecte el cable HDMI a la toma HDMI IN 2 y los cables de audio a las tomas DVI IN (HDMI2) [R-AUDIO-L] de la parte posterior del televisor. Si sucede esto, póngase en contacto con la empresa suministradora del dispositivo externo para confirmar la versión HDMI y solicitar una actualización. Si ocurriera esto, póngase en contacto con la empresa que suministró el reproductor de DVD o receptor de televisión por cable o satélite para confirmar la versión HDMI y solicite una actualización.
- Los cables HDMI que no son 1.3 pueden causar un molesto parpadeo o que no se muestre la pantalla

Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de DVI

Solo es aplicable si hay un conector de salida de DVI en el dispositivo externo.

1. Conecte un cable de DVI a HDMI o un adaptador de DVI-HDMI entre la toma HDMI IN 2 del televisor y la toma DVI del reproductor de DVD o receptor de televisión por cable/satélite (decodificador).
2. Conecte cables de audio entre la toma DVI IN (HDMI 2) [R-AUDIO-L] del televisor y el reproductor de DVD o receptor de televisión por cable/satélite (decodificador).




- Cada reproductor de DVD o receptor de televisión por cable/satélite (decodificador) tiene una configuración diferente del panel posterior.
- Cuando conecte un reproductor de DVD o receptor de televisión por cable/satélite (decodificador), debe hacer coincidir los colores del terminal de conexión y del cable.
- Cuando se usa una conexión de cable HDMI/DVI, se debe conectar en el terminal HDMI IN 2.

Conexión de un reproductor de DVD o receptores de televisión por cable/satélite (decodificadores) a través de los cables de componentes

Las tomas del panel posterior del televisor facilitan la conexión de un reproductor de DVD o un receptor de televisión por cable/satélite (decodificador) al TV.

1. Conecte un cable de componentes entre las tomas COMPONENT IN (1 o 2) [Y, Pb, Pr] del televisor y las tomas COMPONENT [Y, Pb, Pr] del reproductor de DVD o receptor de televisión por cable/satélite (decodificador).
2. Conecte cables de audio entre las tomas COMPONENT IN (1 o 2) [R-AUDIO-L] del televisor y las tomas AUDIO OUT del reproductor de DVD o receptor de televisión por cable/satélite (decodificador).




- El video Componente separa el video en Y (Luminancia (brillo)), el Pb (azul) y el Pr (rojo) para realizar la calidad del video. Las conexiones de audio y de vídeo componente deben coincidir. Por ejemplo, si conecta un cable de video de componentes a COMPONENT IN 1, conecte también el cable de audio a la misma entrada COMPONENT IN 1.
- Cada reproductor de DVD o receptor de televisión por cable/satélite (decodificador) tiene una configuración diferente del panel posterior.
- Cuando conecte un reproductor de DVD o receptor de televisión por cable/satélite (decodificador), debe hacer coincidir los colores del terminal de conexión y del cable.

Conexión de una videocámara

Las tomas del panel lateral del televisor facilitan la conexión de la videocámara. Permiten ver las cintas de la videocámara sin utilizar un aparato de video.

1. Conecte un Cable de Video (o Cable de S-Vídeo) entre las tomas AV IN 2 [VIDEO] (o S-VIDEO) del televisor y las tomas AUDIO OUT (Salida de audio) de la videocámara.
2. Conecte un cable de audio entre las tomas AV IN 2 [R-AUDIO-L] del televisor y las tomas AUDIO OUT (Salida de audio) de la videocámara.



- Cada videocamara tiene una configuración distinta en el panel posterior.
- Cuando conecte una videocamara, debe hacer coincidir los colores del terminal de conexión y del cable.



Conexión de un reproductor de vídeo

Conexión de vídeo

Estas instrucciones presuponen que ya ha conectado el TV a una antena o sistema de TV por cable (siguiendo las instrucciones de las páginas 6 a 7). Si aún no ha conectado el TV a una antena o un sistema de cable, sáltense el paso 1.

1. Desconecte el cable o la antena de la parte posterior del TV.
2. Conecte el cable o la antena en el terminal ANT IN de la parte posterior del reproductor de vídeo.
3. Conecte el cable RF entre el terminal ANT OUT (salida de antena) del reproductor de vídeo y el terminal ANT IN del televisor.
4. Conecte un cable de vídeo entre el terminal VIDEO OUT del aparato de vídeo y el terminal AV IN 1 [Y/VIDEO] o AV IN 2 [VIDEO] del televisor.
5. Conecte un juego de cables de audio entre los conectores AUDIO OUT del reproductor de VCR y los conectores AV IN 1 (o AV IN 2) [R-AUDIO-L] del TV.

➤ Si tiene un reproductor de vídeo "mono" (sin estéreo), use el conector Y (no suministrado) para conectar los conectores de entrada de audio izquierdo o derecho del TV. También se puede conectar el cable a la toma "R". Si el video es estéreo, tendrá que conectar dos cables.




Siga las instrucciones de "Visualización de una cinta de vídeo o de cámara de vídeo" para ver sus cintas.

- Cada reproductor de video tiene una configuración distinta en el panel posterior.
- Cuando conecte un reproductor de video, debe hacer coincidir los colores del terminal de conexión y del cable.
- Cuando se conecta a AV IN 1 el color (verde) del terminal AV IN 1 [Y/VIDEO] no coincide con el color (amarillo) del cable de vídeo.

Conexión de S-Vídeo

Este televisor Samsung se puede conectar a un terminal S-Video de un aparato de vídeo. (Esta conexión proporciona una calidad de imagen mejor que una conexión normal de vídeo.)

1. Para empezar, siga los pasos 1 a 3 del apartado anterior para conectar la antena o el sistema de cable al reproductor de VCR y al TV.
2. Conecte un cable de S-Vídeo entre la toma de salida de S-Vídeo del reproductor y la toma de entrada de AV IN 2 [S-VIDEO] del televisor.
3. Conecte un juego de cables de audio entre los conectores AUDIO OUT del reproductor de VCR y los conectores AV IN 2 [R-AUDIO-L] del TV.



Con el aparato de vídeo se puede incluir una conexión S-Vídeo. (En caso contrario, consulte en la tienda de electrónica.)


- Cada aparato de vídeo tiene una configuración diferente del panel posterior.
- Cuando conecte un aparato de vídeo, debe hacer coincidir los colores del terminal de conexión y del cable.

Conexión de un sistema de audio digital

Los terminales del panel posterior del televisor facilitan la conexión de un sistema de audio digital (Home Cinema/receptor) al televisor.

1. Conecte un cable óptico entre las tomas "DIGITAL AUDIO OUT (OPTICAL)" Salida de audio digital, óptica) del televisor y las tomas Digital Audio Entrada Entrada de audio digital) del sistema de audio digital.

Cuando un sistema de audio digital se conecta a la terminal "DIGITAL AUDIO OUT (OPTICAL)" terminal: Reduzca la ganancia volumen) del TV, y ajuste el volumen con el control del amplificador.




- El audio de 5.1 canales es posible cuando el televisor está conectado a un dispositivo externo que admite 5.1 canales.
- Cada sistema de audio digital tiene una configuración diferente del panel posterior.
- Cuando el receptor (sistema Home Cinema) está establecido en Enc., se puede oír la salida de sonido del terminal Optical del televisor. Cuando se ve la televisión a través de una señal DTV (aérea), el televisor envía el sonido de 5.1 canales al receptor del sistema Home Cinema. Cuando la fuente es un componente digital, como un DVD, y está conectada al televisor a través de HDMI, sólo se oye el sonido de 2 canales del receptor del sistema Home Cinema. Si desea oír audio de 5.1 canales, conecte el terminal DIGITAL AUDIO OUT (OPTICAL) del reproductor de DVD o del decodificador de cable/satélite directamente a un amplificador o un sistema Home Cinema, no al televisor.

Conexión de un amplificador/DVD para cine en casa

1. Conecte un cable de audio entre las tomas AUDIO OUT [R-AUDIO-L] del televisor y las tomas AUDIÓ IN [R-AUDIÓ-L] del amplificador/DVD para cine en casa.

Cuando un amplificador de audio se conecta a los terminales "AUDIO OUT [R-AUDIO-L]" : Reduzca la ganancia (volumen) del TV, y ajuste el volumen con el control del amplificador.




- Cada Amplificador/DVD para cine en casa tiene una configuración distinta en el panel posterior.
- Cuando conecte un Amplificador/DVD para cine en casa, debe hacer coincidir los colores del terminal de conexión y del cable.

Conexión a un PC


Uso del cable D-Sub

1. Conecte un cable D-Sub entre el conector PC IN [PC] del televisor y el conector de salida de PC del ordenador.
2. Conecte un cable de audio PC entre la toma PC IN [AUDIO] del televisor y la toma de salida de audio de la tarjeta de sonido del ordenador.



Uso del cable HDMI/DVI

1. Conecte un cable HDMI/DVI entre la toma HDMI IN 2 del televisor y la toma de salida PC del ordenador.
2. Conecte un cable estéreo miniclavija/2 RCA de 3,5 mm entre la toma DVI IN (HDMI 2) [R-AUDIO-L] del televisor y la toma de salida de audio de la tarjeta de sonido del ordenador.




- Cada PC tiene una configuración distinta en el panel posterior.
- Cuando conecte una PC, debe hacer coincidir los colores del terminal de conexión y del cable.
- Cuando se usa una conexión de cable HDMI/DVI, se debe conectar en el terminal HDMI IN 2.

Funcionamiento

Encendido o apagado del TV

Pulse el botón **POWER** del mando a distancia.
También puede usar el botón **POWER** del televisor.



Función Plug & Play

Cuando se enciende el televisor por primera vez, se configuran seguidos y automáticamente dos ajustes básicos del usuario.

1. Pulse el botón **POWER** en el mando a distancia.
Aparece el mensaje "Menu Language, Store Demo, Channels and Time will be set.".
Pulse el botón **ENTER** y aparecerá automáticamente el menú "Seleccionar idioma de OSD". Pulse el botón **ENTER** .
2. Pulse los botón **▲** o **▼** para seleccionar el idioma; pulse después el botón **ENTER** .
3. Se muestra el mensaje "Seleccione 'Use domiciliario' para instalar este TV en su casa.".
 - Es recomendable configurar el televisor en el modo "Use domiciliario" para obtener la mejor imagen en un entorno doméstico.
 - El modo "Demo comercio" sólo es necesario en los entornos comerciales.
 - Si la unidad accidentalmente se configura en el modo "Demo comercio" y se desea volver a "Use domiciliario" (Normal): Pulse el botón del volumen del televisor. Cuando se muestra la OSD del volumen, mantenga pulsado el botón **MENU** del televisor durante 5 segundos.
4. Pulse los botón **▲** o **▼** para memorizar los canales de la conexión seleccionada. Pulse el botón **ENTER** para seleccionar "Iniciar".
 - Aire: Señal de antena "Aire".
 - Cable: señal de antena de "Cable".
 - Auto: señales de antena "Aire" y de "Cable".
 - En el modo de cable, puede seleccionar el origen de señal correcto entre STD, HRC e IRC pulsando los botón **▲**, **▼**, **◀** o **▶** a continuación, pulse el botón **ENTER** .




- El televisor empezará a memorizar todos los canales disponibles.
Para detener la búsqueda antes de que termine, pulse el botón **ENTER** con la opción "Detener" seleccionada.


Una vez guardados todos los canales disponibles, se inicia la eliminación de los canales codificados (ver página 42). Y, a continuación, vuelve a mostrarse el menú Auto Program. Pulse el botón **ENTER** cuando se complete la memorización de canales. Aparece automáticamente el menú "Configurar el modo de Reloj".




- Pulse el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar "Auto" después, pulse el botón **ENTER**. Se muestra el mensaje "Configurar la hora de verano.". Si selecciona "Manual", se muestra "Configurar fecha y hora actuales". (Consulte las páginas 47)



- Pulse los botones **▲** o **▼** para seleccionar "Apagado" o "Encendido" después, pulse el botón **ENTER**. Se muestra el mensaje "Seleccionar la zona horaria en la que vive".



- Pulse los botones **▲** o **▼** para resaltar la zona horaria del área local. Pulse el botón **ENTER**. Si ha recibido una señal digital, se ajustará la hora automáticamente. En caso negativo, consulte la página 47 para ajustar el reloj.




- Aparece el mensaje "Disfrutar su vision." Cuando termine, pulse el botón **ENTER**.



Si desea reiniciar esta función...

- Pulse el botón **MENU** para ver el menú.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" después, pulse el botón **ENTER**.
- Pulse de nuevo el botón **ENTER** para seleccionar "Plug & Play".
Si desea más detalles sobre las opciones de configuración, consulte las páginas 13~14.
Para la función "Plug & Play" está disponible sólo en el modo TV.





Cambio de canales

Mediante los botones de canal


- Pulse los botones **CH ▼** o **CH ▲** para cambiar los canales.

- Cuando pulse los botones **CH ▼** o **CH ▲** el TV cambiará los canales por orden. Verá todos los canales que ha memorizado el TV. (El TV deberá haber memorizado como mínimo tres canales.) No verá los canales borrados o no memorizados. Consulte las páginas 16 para la memorización de los canales.
- Para aumentar el número del canal gire la rueda hacia la derecha cuando se vea el canal. Para disminuir el número del canal gire la rueda hacia la izquierda.



Utilización de los botones numéricos


- Utilice los botones numéricos para ir directamente a un canal. Por ejemplo, para seleccionar el canal 27, pulse **2** y luego **7**. El televisor cambiará de canal cuando pulse el segundo número.
- Pulse los botones numéricos y después el botón **ENTER** para cambiar rápidamente de canal.



Uso del botón


El botón se utiliza para seleccionar emisoras que emiten con señal digital.

- Por ejemplo, para seleccionar el canal 7-1, pulse **7**, y **1**.
- HD indica que el televisor está recibiendo una señal digital de alta definición. SD indica que el televisor está recibiendo una señal digital de definición estándar.
- Pulse los botones numéricos y después el botón **ENTER** para cambiar rápidamente de canal.



Utilización del botón PRE-CH para seleccionar el canal anterior


- Pulse el botón **PRE-CH**. El TV volverá al último canal visualizado.
- Para comutar rápidamente entre dos canales bastante distantes, sintonice un canal y use los botones numéricos para seleccionar el segundo. Despues use el botón **PRE-CH** para comutar rápidamente entre ellos.




Ajuste del volumen

Utilización de los botones de volumen

- Pulse los botones **VOL -** o **VOL +** para bajar o subir el volumen.




- Para subir el volumen gire la rueda hacia la derecha cuando se muestre la ventana de control del volumen. Para bajar el volumen gire la rueda hacia la izquierda.



Uso del botón MUTE

Puede interrumpir el sonido en cualquier momento pulsando el botón **MUTE**.

- Pulse el botón **MUTE** y el sonido se desconectará. En pantalla se visualiza ".
- Para recuperar el sonido vuelva a pulsar **MUTE** o, simplemente, pulse los botones **VOL -** o **VOL +**.




Visualización de la pantalla

La pantalla identifica el canal actual y el estado de algunos ajustes de audio-vídeo.

- Pulse el botón **INFO** del mando a distancia.

El TV visualizará el canal, el tipo de sonido y el estado de determinados ajustes de sonido e imagen.

- Pulse el botón **INFO** otra vez o espere unos 10 segundos y desaparecerá automáticamente.




Visualización de los menús

- Con el aparato encendido, pulse el botón **MENU**.

En la pantalla aparece el menú principal.


En el lado izquierdo del menú hay los iconos: Imagen, Sonido, Canal, Configuración, Entrada, Aplicacion.



- Pulse los botones **▲** o **▼** para seleccionar uno de los iconos.


A continuación, pulse **ENTER** para acceder al submenú del ícono.

➤ Para ir a un menú inferior, gire la rueda hacia la derecha cuando se muestre el menú. Para ir a un menú superior, gire la rueda hacia la izquierda.



- Pulse el botón **EXIT** para salir.

➤ Pasado aproximadamente un minuto, los menús de la pantalla desaparecen de ésta.



Uso de los botones de la luz de fondo del mando a distancia

Use esta función en un entorno oscuro donde no sea posible ver los botones del mando a distancia con claridad.

- Pulse el botón de iluminación **ON/OFF** .

➤ Al pulsar el botón de iluminación **ON/OFF** se cambia entre ON y OFF.

➤ Si está activado, la iluminación del botón se enciende durante unos momentos.

➤ Si se pulsa un botón del mando a distancia cuando éste está activado la iluminación del botón se enciende durante unos momentos. Si se toca o se mueve el mando a distancia y el sensor de éste lo detecta, la iluminación del botón se enciende durante unos momentos.

➤ El mando a distancia tiene dos pequeños sensores de movimiento que controlan la función de la luz de fondo. Si se agita o se deja caer el mando, es posible que los sensores emitan un ruido. Esto es normal y no es ningún defecto.


➤ La iluminación del botón no se enciende si el mando a distancia está desactivado.

Uso del botón TOOLS

Se puede usar el botón **TOOLS** para seleccionar rápida y fácilmente las funciones que se usan con más frecuencia. El menú "Herramientas" cambia según el modo de entrada externo que se está viendo.

1. Pulse el botón **TOOLS**. Aparece el menú "Herramientas".
2. Pulse los botones **▲** o **▼** para seleccionar un menú.
3. Pulse los botones **▲/▼/◀/▶/ENTER** para ver, cambiar o usar las opciones seleccionadas. Para ver una descripción más detallada de cada función, consulte la página correspondiente.

- Lista Disp.: página 92
- Sonido Multi-track: página 33
- Imagen Mode: página 20
- Sonido Modo: página 31
- Temporizador: página 49
- Agregar a Favoritos: página 38
- Cambiar a Cable (o Cambiar a Aereos): página 17
- PIP: página 29~30
- Ajuste automático: página 45





Memorización de los canales

El TV puede memorizar y almacenar todos los canales disponibles, tanto de "antena" como de cable. Una vez memorizados los canales disponibles, use los botones **CH ▼** y **CH ▲** para explorarlos. De este modo no es necesario cambiar los canal introduciendo los dígitos. La memorización de canales tiene tres pasos: seleccionar una emisora de origen, memorizar los canales (automático) y agregar o borrar canales (manual).

Selección del origen de la señal de vídeo


Antes de empezar a memorizar los canales disponibles, debe indicar el tipo de origen de la señal conectada al TV (es decir, antena o sistema de cable).

1. Pulse el botón **MENU** para visualizar el menú.
Pulse los botones **▲** o **▼** para seleccionar "Canal" y, después, pulse el botón **ENTER**.
2. Pulse el botón **ENTER** para seleccionar "Antena".
Pulse los botones **▲** o **▼** para seleccionar "Aire" o "Cable" después, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.




Configuración sencilla

1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones **▲** o **▼** para elegir "Cambiar a Cable (o Cambiar a Aereos)".
3. Pulse el botón **ENTER** para seleccionar "Cable" (o "Aire").



Almacenamiento de los canales en la memoria (método automático)

1. Pulse el botón **MENU** para visualizar el menú.
Pulse los botón **▲** o **▼** para seleccionar "Canal" y, después, pulse el botón **ENTER** .
2. Pulse los botón **▲** o **▼** para seleccionar "Prog. Auto" y, después, pulse el botón **ENTER** .




3. Pulse los botón **▲** o **▼** para seleccionar la conexión de la antena, después pulse **ENTER** .

 - Aire: Señal de antena "Aire".
 - Cable: Señal de antena "Cable".
 - Auto: Señales de antena "Aire" y de "Cable".

4. Al seleccionar el sistema de TV de cable:
Pulse el botón **ENTER**  para iniciar el programa automático.
Pulse **▲**, **▼**, **◀** o **▶** para seleccionar la fuente del sistema de cable de señal analógica correcta entre "STD", "HRC" e "IRC". Pulse los botón **▲** o **▼** para seleccionar "Iniciar" y, después, pulse el botón **ENTER** . Si tiene un televisor de cable digital, seleccione la fuente de la señal del sistema de cable analógica y digital.

 - STD, HRC e IRC identifican los distintos tipos de sistemas de TV por cable. Póngase en contacto con su proveedor de cable para averiguar el tipo de sistema de cable existente en su zona. En este momento ya se ha seleccionado el origen de la señal.




5. El televisor empieza a memorizar todas las emisoras disponibles.
 - Una vez guardados todos los canales disponibles, se inicia la eliminación de los canales codificados (ver página 42). Vuelve a mostrarse el menú Auto Program.
 - Si desea detener la programación automática, pulse el botón **ENTER** . Aparece el mensaje "¿Detener programación automática?". Seleccione "Sí" con los botones **◀** o **▶** y, a continuación, pulse el botón **ENTER** .

Pulse el botón **EXIT** para salir.


Para seleccionar la fuente

Úselo para seleccionar TV u otras fuentes de entrada externas como reproductores de DVD o receptores de cable y satélite (decodificadores), conectados al televisor. Permite seleccionar la fuente de entrada que se prefiera.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Entrada" y, después, pulse el botón **ENTER**.
2. Pulse el botón **ENTER** para seleccionar "Lista de Origen".
Pulse los botones **▲** o **▼** para seleccionar la fuente de la señal, después pulse el botón **ENTER**.
 - Orígenes de señal disponibles: TV, AV1, AV2, S-Video, Componente1, Componente2, PC, HDMI1, HDMI2/DVI, HDMI3, HDMI4, USB.
 - Puede elegir solamente los dispositivos externos que estén conectados al televisor. En "Lista de Origen", las entradas conectadas se resaltan y se ordenan en la parte superior. Las entradas que no están conectadas se ordenan en la parte inferior.
3. **Uso de los botones de colores del mando a distancia con la lista de fuentes**
 - **Rojo (Actualizar)**: Actualiza los dispositivos externos conectados.
 - **TOOLS (Opción)**: Muestra los menús "Editar Nombre" e "Información".





4. Pulse el botón **SOURCE** del mando a distancia para ver una fuente de señal externa.



Edición del Nombre de la Fuente de entrada

Nombre al dispositivo de entrada de información conectado con las tomas de entrada para facilitar la selección de fuente de entrada.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Entrada" y, después, pulse el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar "Editar Nombre" y pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar la toma de entrada "AV1", "AV2", "S-Video", "Componente1", "Componente2", "PC", "HDMI1", "HDMI2/DVI", "HDMI3" o "HDMI4" y, a continuación pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - Cuando se conecta un ordenador con una resolución 1920 x 1080 a 60 Hz al puerto HDMI IN 2, se debe configurar el modo "HDMI2/DVI" como "PC" en "Editar Nombre" en el modo "Entrada".
3. Pulse los botones **▲** o **▼** para seleccionar la fuente de entrada "Vídeo", "DVD", "Cable STB", "Satélite STB", "PVR STB", "Receptor AV", "Juego", "Filmadora", "PC", "TV", "IPTV", "Blu-ray", "HD DVD", "Adaptador digital multimedia", y, a continuación pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.



Control de la Imagen

Cambio del formato de la imagen

Puede seleccionar el tipo de imagen que mejor cumpla sus requisitos de visualización.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse el botón **ENTER**  para seleccionar "Imagen".



2. Pulse el botón **ENTER**  para seleccionar "Modo".
Pulse los botones **▲** o **▼** para seleccionar "Dinámico", "Normal" o "Película".
Pulse el botón **ENTER** .

- **Dinámico:** Selecciona la alta definición en la imagen, en una habitación luminosa.
- **Normal:** Selecciona la visualización óptima de la imagen, en un entorno normal.
- **Película:** Selecciona la visualización para ver películas en una sala oscura.

3. Pulse el botón **EXIT** para salir.



Configuración sencilla

1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones **▲** o **▼** para seleccionar "Imagen Modo".
3. Pulse los botones **◀** o **▶** para seleccionar la opción deseada.
4. Pulse los botones **EXIT** o **TOOLS** para salir.



Personalización de la configuración de la imagen

El televisor tiene varias opciones de configuración que permiten controlar la calidad de la imagen.

1. Para seleccionar el modo de imagen deseado, siga las instrucciones 1 y 2 de "Cambio del formato de la imagen".
2. Pulse los botones **▲** o **▼** para seleccionar "Luz de fondo", "Contraste", "Brillo", "Definición", "Color" y "Tinte (V/R)", después, pulse el botón **ENTER** .
3. Pulse los botones **◀** o **▶** para aumentar o reducir el valor de una opción concreta. Pulse el botón **ENTER** .

Pulse el botón **EXIT** para salir.

- Cuando haga cambios en "Luz de fondo", "Contraste", "Brillo", "Definición", "Color" y "Tinte (V/R)", el color del OSD también se ajustará.
- En el modo PC (PC), sólo se pueden realizar cambios en las opciones "Luz de fondo", "Contraste" y "Brillo".
- La configuración de cada dispositivo externo conectado a la entrada del televisor se puede ajustar y guardar.

- **Luz de fondo:** Ajusta el brillo de la luz de fondo de la pantalla LCD.
- **Contraste:** Ajusta el nivel del contraste de la imagen.
- **Brillo:** Ajusta el nivel del brillo de la imagen.
- **Definición:** Ajusta la definición de los bordes de la imagen.
- **Color:** Ajusta la saturación del color de la imagen.
- **Tinte (V/R):** Ajusta el matiz del color de la imagen.




Activación de la configuración detallada

Los nuevos televisores Samsung permiten una configuración más precisa de la imagen que los modelos anteriores. Consulte más adelante cómo realizar una configuración detallada.

Activación de la configuración detallada



- Pulse el botón **MENU** para ver el menú.
Pulse el botón **ENTER** ▶ para seleccionar "Imagen".
- Pulse el botón **ENTER** ▶ para seleccionar "Modo".
Pulse los botones ▲ o ▼ para seleccionar "Normal" o "Película" y, a continuación, pulse el botón **ENTER** ▶.
➤ La opción "Configuración detallada" está disponible en los modos "Normal" o "Película".
- Pulse los botones ▲ o ▼ para seleccionar "Configuración detallada" y pulse el botón **ENTER** ▶.
➤ En el modo PC, sólo se pueden cambiar "Contraste dinám.", "Gamma" y "Balance de blanco" entre los elementos de "Configuración detallada".



Configuración del ajuste del negro

Se puede seleccionar el nivel de negro en la pantalla para ajustar la profundidad de ésta.



- Pulse los botones ▲ o ▼ para seleccionar "Ajuste del negro" y pulse el botón **ENTER** ▶.
- Pulse los botones ▲ o ▼ para seleccionar "Apagado", "Bajo", "Medio" o "Alto". Pulse el botón **ENTER** ▶.
 - Apagado:** Apaga la función de ajuste del negro.
 - Bajo:** Establece la profundidad del color negro en un nivel bajo.
 - Medio:** Establece la profundidad del color negro en un nivel medio.
 - Alto:** Establece la profundidad del color negro en un nivel alto.



Ajuste del contraste dinámico

Se puede ajustar el contraste de la pantalla para conseguir un contraste óptimo.


- Pulse los botones ▲ o ▼ para seleccionar "Contraste dinám." y pulse el botón **ENTER** ▶.
- Pulse los botones ▲ o ▼ para seleccionar "Apagado", "Bajo", "Medio" o "Alto". Pulse el botón **ENTER** ▶.
 - Apagado:** Apaga la función de ajuste del contraste dinámico.
 - Bajo:** Establece el contraste dinámico en un nivel bajo.
 - Medio:** Establece el contraste dinámico en un nivel medio.
 - Alto:** Establece el contraste dinámico en un nivel alto.



Ajuste de la gama

Se puede ajustar la intensidad de los colores primarios (rojo, verde y azul). (-3 ~ +3)

8. Pulse los botón ▲ o ▼ para seleccionar "Gamma" y pulse el botón ENTER .
9. Pulse los botones ◀ o ▶ para disminuir o aumentar el valor. Pulse el botón ENTER .




Configuración del espacio de color

El espacio de color es una matriz compuesta por los colores rojo, verde y azul. Seleccione su espacio de color favorito y disfrute de unos colores auténticamente naturales.

10. Pulse los botón ▲ o ▼ para seleccionar "Espacio de color" y pulse el botón ENTER .
11. Pulse de nuevo el botón ENTER  para seleccionar "Espacio de color".
12. Pulse los botón ▲ o ▼ para seleccionar "Auto", "Nativo" o "Favorito". Pulse el botón ENTER .

- **Auto:** El espacio de color automático ajusta el tono de color natural de acuerdo con las fuentes del programa.
- **Nativo:** El espacio de color nativo proporciona tonos de color profundos y ricos.
- **Favorito:** Ajusta la gama del color según las preferencias del usuario. (vea "Personalización del espacio de color")




Personalización del espacio de color

13. Pulse los botón ▲ o ▼ para seleccionar "Color" y, a continuación, pulse el botón ENTER .
- > "Color" está disponible cuando "Espacio de color" está configurado en "Favorito".
14. Pulse los botón ▲ o ▼ para seleccionar "Rojo", "Verde", "Azul", "Amarillo", "Cian" o "Magenta". Pulse el botón ENTER .
15. Pulse los botones ▲ o ▼ para seleccionar "Rojo", "Verde" o "Azul" a fin de cambiarlos. Pulse el botón ENTER .
16. Pulse los botón ◀ o ▶ para reducir o aumentar el valor de un elemento concreto. Pulse el botón ENTER .
- > En "Color", se pueden ajustar los valores RGB del color seleccionado.
- > Para restablecer el valor RGB ajustado, seleccione "Reiniciar".

- **Rojo:** Ajusta el nivel de saturación del rojo del color seleccionado.
- **Verde:** Ajusta el nivel de saturación del verde del color seleccionado.
- **Azul:** Ajusta el nivel de saturación del azul del color seleccionado.
- **Reiniciar:** Restablece la gama de colores en los valores predeterminados.

- > El cambio del valor de ajuste actualizará la pantalla ajustada.
- > La configuración de cada dispositivo externo conectado a la entrada del televisor se puede ajustar y guardar. Por ejemplo, si se tiene un reproductor DVD conectado a HDMI 1 y está seleccionado, se guardarán la configuración y los ajustes del reproductor DVD.




Ajuste del balance de blancos

Se puede ajustar la temperatura del color para conseguir colores más naturales.

17. Pulse los botón ▲ o ▼ para seleccionar "Balance de blanco" y, a continuación, pulse el botón **ENTER**.
18. Seleccione la opción necesaria pulsando los botón ▲ o ▼ y, a continuación, pulse el botón **ENTER**.
19. Pulse los botón ◀ o ▶ para reducir o aumentar el valor de un elemento concreto. Pulse el botón **ENTER**.

- **Balance de Rojo:** Ajusta la intensidad del color rojo.
- **Balance de Verde:** Ajusta la intensidad del color verde.
- **Balance de Azul:** Ajusta la intensidad del color azul.
- **Ganancia de Rojo:** Ajusta el brillo del color rojo.
- **Ganancia de Verde:** Ajusta el brillo del color verde.
- **Ganancia de Azul:** Ajusta el brillo del color azul.
- **Reiniciar:** El balance de blanco anteriormente ajustado se restablecerá con los valores predefinidos de fábrica.

➤ El cambio del valor de ajuste renovará la pantalla ajustada.




Ajuste del tono de piel

Permite acentuar el tono rosa de la opción 'Tono piel' en las imágenes.

20. Pulse los botón ▲ o ▼ para seleccionar "Tono piel" y, a continuación, pulse el botón **ENTER**.
21. Pulse los botones ◀ o ▶ para disminuir o aumentar el valor. Pulse el botón **ENTER**.



➤ El cambio del valor de ajuste actualizará la pantalla ajustada.



Configuración de la mejora de los bordes

Permite acentuar los bordes de los objetos en las imágenes.

22. Pulse los botón ▲ o ▼ para seleccionar "Mejora de perfiles" y, a continuación, pulse el botón **ENTER**.
23. Pulse los botón ▲ o ▼ para seleccionar "Apagado" o "Encendido". Pulse el botón **ENTER**.



Configuración de xvYCC

Si ajusta el modo xvYCC como "Encendido" se aumenta el detalle y el espacio de color mientras se ven películas desde un dispositivo externo (es decir, un reproductor DVD) conectado en las tomas HDMI o Component IN.

24. Pulse los botón ▲ o ▼ para seleccionar "xvYCC" y, a continuación, pulse el botón **ENTER** ▶.
25. Pulse los botón ▲ o ▼ para seleccionar "Apagado" o "Encendido".
Pulse el botón **ENTER** ▶.
➢ "xvYCC" está disponible cuando el modo de imagen está configurado en "Película" y la entrada externa está establecida en los modos "HDMI" o "Componente".



Reajuste de valores de la imagen a los valores predefinidos de fábrica

1. Para seleccionar el modo de imagen que deseé, siga las instrucciones 1 y 2 de "Cambio del formato de la imagen". (Consulte la página 20)




2. Pulse los botón ▲ o ▼ para seleccionar "Reinicio de la imagen" y, a continuación, pulse el botón **ENTER** ▶.
3. Pulse los botón ▲ o ▼ para seleccionar "Aceptar" o "Cancelar" y, a continuación, pulse el botón **ENTER** ▶.
Pulse el botón **EXIT** para salir.
➢ Se puede restaurar cada modo.

Activación de las opciones de la imagen


Activación de las opciones de la imagen

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse el botón **ENTER** ▶ para seleccionar "Imagen".
- Pulse los botones ▲ o ▼ para seleccionar "Opciones de imagen" y, a continuación, pulse el botón **ENTER** ▶.
 - Pulse los botones ▲ o ▼ para seleccionar una opción concreta.
Pulse el botón **ENTER** ▶.
 - Cuando esté satisfecho con los ajustes, pulse el botón **ENTER** ▶.
 - En el modo PC sólo se pueden hacer cambios en los elementos "Tono Color" y "Tamaño" del menú "Opciones de imagen".



Configuración del tono del color

- Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen".
- Pulse los botón ▲ o ▼ para seleccionar "Tono Color" y, a continuación, pulse el botón **ENTER** ▶.



- Pulse los botón ▲ o ▼ para seleccionar "Frío2", "Frío1", "Normal", "Tibio1" o "Tibio2". Pulse el botón **ENTER** ▶.
 - "Tibio1" o "Tibio2" sólo están disponibles cuando el modo de imagen está configurado en "Película".
 - La configuración de cada dispositivo externo conectado a la entrada del televisor se puede ajustar y guardar.





Configuración del tamaño de la pantalla

Es posible que alguna vez desee cambiar el tamaño de la imagen en la pantalla. El televisor se suministra con seis opciones de tamaño de la pantalla, cada una diseñada para que funcione lo mejor posible con tipos específicos de entrada de vídeo. Es posible que el receptor de cable o satélite tenga también su propia gama de tamaños de pantalla. Sin embargo, en general, debe ver el televisor en el modo 16:9 tanto como sea posible.

- Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen".
- Pulse los botón ▲ o ▼ para seleccionar "Tamaño" y, a continuación, pulse el botón **ENTER** ▶.
- Pulse los botón ▲ o ▼ para seleccionar el formato de pantalla que deseé.
Pulse el botón **ENTER** ▶.

Pulse el botón **EXIT** para salir.


- 16:9** : Establece la imagen en modo panorámico 16:9.
- Zoom1**: Aumenta el tamaño de la imagen en la pantalla.
- Zoom2**: Aumenta el tamaño de la imagen más aún que el modo "Zoom1".
- Ajuste ancho**: Amplía la relación de aspecto de la imagen para que se ajuste al ancho total de la pantalla.
- 4:3** : Establece la imagen en modo normal 4:3.
- Sólo buscar**: Use esta función para ver toda la imagen sin cortes cuando se reciban señales de HDMI (720p/1080i/1080p), Componente (1080i/1080p) o DTV (1080i).



- > Si se ha seleccionado el modo doble (□, □) en el menú PIP, el tamaño de la imagen no se puede definir.
- > Puede producirse una retención temporal de imagen cuando se ve una imagen estática durante más de dos horas.
- > Despues de seleccionar "Zoom1", "Zoom2" o "Ajuste ancho":
Pulse los botones ▲ o ▼ para seleccionar "Posición" y, a continuación, pulse el botón **ENTER** □. Utilice los botones ▲ o ▼ para desplazar la imagen hacia arriba o hacia abajo.
Reiniciar: Pulse los botones ▲ o ▼ para seleccionar "Reiniciar" y, a continuación, pulse el botón **ENTER** □.




- > Despues de seleccionar "Sólo buscar" en los modos HDMI (1080i/1080p) o Component (1080i/1080p):
Pulse los botones ▲ o ▼ para seleccionar "Posición" y, a continuación, pulse el botón **ENTER** □. Pulse los botones ▲, ▼, ▲ o ▼ para mover la imagen.
Reiniciar: Pulse los botones ▲ o ▼ para seleccionar "Reiniciar" y, a continuación, pulse el botón **ENTER** □. Puede inicializar la configuración.
- > HD (alta definición)
16:9 - 1080i/1080p (1920x1080), 720p (1280x720)



- > La configuración de cada dispositivo externo conectado a la entrada del televisor se puede ajustar y guardar.


Fuente entrada	Tamaño imagen
ATV, Video, S-Video, Componente (480i, 480p)	16:9, Zoom1, Zoom2, 4:3
DTV(720p), Componente (720p)	16:9, 4:3, Ajuste ancho
DTV(1080i), Componente (1080i, 1080p), HDMI (720p, 1080i, 1080P)	16:9, 4:3, Ajuste ancho, Sólo buscar
PC	16:9, 4:3

Alternativo, pulse el botón **P.SIZE** del mando a distancia de forma repetida para seleccionar uno de los ajustes de tamaño de imagen.



16:9

Establece la imagen en modo panorámico 16:9.



Zoom1

Aumenta el tamaño de la imagen en la pantalla.



Zoom2

Aumenta el tamaño de la imagen más aún que el modo "Zoom1".



Ajuste ancho

Amplía la relación de aspecto de la imagen para que se ajuste al ancho total de la pantalla.



4:3

Establece la imagen en modo normal 4:3.



Sólo buscar

Use esta función para ver toda la imagen sin cortes cuando se reciben señales de HDMI (720p/1080i/1080p), Componente (1080i/1080p) o DTV (1080i).


Configuración de la reducción digital de ruido

Si la señal de emisión que recibe el televisor es débil, puede activarse la función de reducción digital del ruido (Digital Noise Reduction) para reducir la estática y las imágenes superpuestas que pueden aparecer en la pantalla.

1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "Digital NR" y, a continuación, pulse el botón ENTER 
3. Pulse los botón ▲ o ▼ para seleccionar "Apagado", "Bajo", "Medio", "Alto" o "Auto". Pulse el botón ENTER 

- **Apagado:** Apaga la función de la reducción del ruido de la pantalla.
- **Bajo:** Reduce el ruido de la pantalla a un nivel bajo.
- **Medio:** Reduce el ruido de la pantalla a un nivel medio.
- **Alto:** Reduce el ruido de la pantalla a un nivel alto.
- **Auto:** Reconoce y reduce el ruido de la pantalla automáticamente.

Pulse el botón EXIT para salir.



Configuración de DNle (Motor de imagen natural digital)

Este televisor incluye la función DNle con el fin de conseguir una gran calidad visual. Si activa DNle, podrá ver la pantalla con la función DNle activada.



1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "DNle" y, a continuación, pulse el botón ENTER 
3. Pulse los botón ▲ o ▼ para seleccionar "Apagado" o "Encendido" y, a continuación, pulse el botón ENTER 

- **Apagado:** Desactiva el modo "DNle".
- **Encendido:** Activa el modo "DNle".

Pulse el botón EXIT para salir.

➤ DNle™ (Digital Natural Image engine, Motor de imagen digital natural) **DNle™** Esta función proporciona una imagen más detallada con reducción de interferencias 3D, ampliación de los detalles, mejora del contraste y de los blancos.

➤ "DNle" sólo está disponible en el modo "Dinámico".



Configuración del nivel de negro HDMI



Se puede seleccionar el nivel de negro en la pantalla para ajustar la profundidad de ésta.

1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "N. neg HDMI" y, a continuación, pulse el botón ENTER 
3. Pulse los botón ▲ o ▼ para seleccionar "Normal" o "Bajo" y, a continuación, pulse el botón ENTER 

- **Normal:** La pantalla adquiere más brillo.
- **Bajo:** La pantalla se oscurece.

➤ Esta función sólo está activa cuando un dispositivo externo está conectado al televisor a través de HDMI. La función "N. neg HDMI" puede que no sea compatible con dispositivos externos.


Pulse el botón EXIT para salir.



Configuración del modo de película

El televisor se puede configurar para detectar automáticamente y procesar las señales de las películas procedentes de todas las fuentes y ajustar la imagen para conseguir una calidad óptima.

1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "Modo película" y, a continuación, pulse el botón **ENTER**.
3. Pulse los botón ▲ o ▼ para seleccionar "Apagado" o "Auto" y, a continuación, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
➢ "Modo película" es compatible con TV, Vídeo, S-Vídeo, Componente (480i / 1080i) y HDMI (480i / 1080i).




Configuración del modo sólo azul

Esta función es para expertos en la medición de dispositivos AV. Esta función muestra sólo una señal azul ya que se eliminan las señales rojas y verdes de la señal de vídeo a fin de proporcionar un efecto de filtro azul que se usa para ajustar el color y el matiz de los equipos de vídeo, como reproductores DVD, sistemas Home Cinema, etc.

Con esta función, se puede ajustar el color y el matiz de acuerdo con los valores preferidos adecuados al nivel de la señal de cada dispositivo de vídeo mediante los patrones de barras de colores rojo/verde/azul/cián/magenta/amarillo, sin usar un filtro azul adicional.

1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "Sólo modo azul" y, a continuación, pulse el botón **ENTER**.
3. Pulse los botón ▲ o ▼ para seleccionar "Apagado" o "Encendido" y, a continuación, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
➢ "Sólo modo azul" está disponible cuando el modo de imagen está configurado como "Película" o "Normal".



Configuración de Auto Motion Plus 120 Hz (LN40A650A1F, LN46A650A1F, LN52A650A1F)





Elimina los retrasos de las escenas rápidas con mucho movimiento para conseguir imágenes más claras.

1. Sigas las instrucciones 1 y 2 de "Activación de las opciones de la imagen". (Consulte la página 25)
2. Pulse los botón ▲ o ▼ para seleccionar "Auto Motion Plus 120 Hz" y, a continuación, pulse el botón **ENTER**.
3. Pulse los botón ▲ o ▼ para seleccionar "Apagado", "Bajo", "Medio", "Alto" o "Demo" y, a continuación, pulse el botón **ENTER**.

- **Apagado:** Desactiva Auto Motion Plus 120 Hz.
- **Bajo:** Configura Auto Motion Plus 120 Hz al mínimo.
- **Medio:** Configura Auto Motion Plus 120 Hz con el valor medio.
- **Alto:** Configura Auto Motion Plus 120 Hz al máximo.
- **Demo:** Muestra la diferencia entre los modos activado y desactivado de Auto Motion Plus 120 Hz. La pantalla después de aplicar "Auto Motion Plus 120 Hz" aparece a la izquierda.

Pulse el botón **EXIT** para salir.

- Si se habilita "Auto Motion Plus 120 Hz", se puede producir ruido en la pantalla. Si esto ocurre, establezca "Auto Motion Plus 120 Hz" como "Off".



Visualización Imagen en imagen

Puede usar la función PIP para ver simultáneamente la televisión (sólo emisiones analógicas) y una fuente de video externa. (Vea la página 35 para seleccionar el sonido de la imagen PIP.) Este producto lleva un sintonizador incorporado que no permite la función PIP en el mismo modo. En el apartado 'Configuración de PIP' encontrará más detalles.



- Mientras la opción V-chip activada (Consulte la página 51), la función de PIP no se puede usar.

Activación de Imagen en imagen

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "PIP" y, a continuación, pulse el botón **ENTER**.
3. Pulse de nuevo el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar "Encendido" y, a continuación, pulse el botón **ENTER**.
 - Si mientras mira la televisión en el modo PIP, apaga el televisor y vuelve a encenderlo, la ventana PIP desaparecerá.
 - Puede ver emisiones de televisión analógicas en la pantalla PIP (imagen secundaria) cuando la imagen principal proviene de un dispositivo externo conectado a los modos HDMI 1, HDMI/DVI 2, HDMI 3, HDMI 4, Componente 1, 2 o PC.


➤ Configuración de PIP

Imagen principal	Imagen Secundaria
Componente 1, 2 HDMI 1, HDMI/DVI 2, HDMI 3, HDMI 4 PC	Sólo emisiones de televisión analógicas Mover




Cambio del tamaño de la ventana PIP

3. Pulse los botones **▲** o **▼** para seleccionar "Tamaño" y, a continuación, pulse el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar la opción necesaria y, a continuación, pulse **ENTER**.
 - Puede notar que la imagen de la ventana PIP llega a ser ligeramente artificial cuando utiliza la pantalla principal para visualizar juegos o Karaoke.




Cambio de la posición de la ventana PIP

4. Pulse los botones **▲** o **▼** para seleccionar "Posición" y, a continuación, pulse el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar la opción necesaria y, a continuación, pulse **ENTER**.
 - En los modos (□) y (□), la opción "Posición" no se puede seleccionar.




Cambio del canal PIP

5. Pulse los botón ▲ o ▼ para seleccionar “Aire/Cable” y, a continuación, pulse el botón **ENTER**.
6. Pulse los botón ▲ o ▼ para seleccionar “Aire” o “Cable” y, a continuación, pulse el botón **ENTER**.



7. Pulse los botón ▲ o ▼ para seleccionar “Canal” y, a continuación, pulse el botón **ENTER**.
8. Pulse los botón ▲ o ▼ para seleccionar el canal deseado en la ventana PIP. Pulse el botón **ENTER**.
 - Se pueden seleccionar sólo emisoras de televisión analógicas en la pantalla PIP (imagen secundaria).

Pulse el botón **EXIT** para salir.



Configuración sencilla

1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones ▲ o ▼ para seleccionar “PIP” y, a continuación, pulse el botón **ENTER**.
3. Pulse los botones ▲ o ▼ para seleccionar una opción concreta.
4. Pulse los botones ◀ o ▶ para seleccionar la opción deseada.
5. Pulse los botones **EXIT** o **TOOLS** para salir.





Control de Sonido

Cambio del estándar de sonido


Puede seleccionar el modo de sonido que mejor se ajuste al programa que está viendo.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.
2. Pulse el botón **ENTER** para seleccionar "Modo".
Pulse los botones **▲** o **▼** para seleccionar el ajuste de sonido "Normal", "Música", "Película", "Diálogo", o "Favorito" y pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - **Normal:** Selecciona el modo de sonido normal.
 - **Música:** Realza la música respecto de las voces.
 - **Película:** Proporciona el mejor sonido para ver películas.
 - **Diálogo:** Realza las voces respecto de los sonidos.
 - **Favorito:** Recupera la configuración de sonido personalizada. (vea "Personalización del sonido").



Configuración sencilla



1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones **▲** o **▼** para seleccionar "Sonido Modo".
3. Pulse los botones **◀** o **▶** para seleccionar la opción deseada.
4. Pulse los botones **EXIT** o **TOOLS** para salir.



Personalización del sonido

Es posible ajustar los parámetros del sonido según sus preferencias personales.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "Ecualizador" y, a continuación, pulse el botón **ENTER**.
3. Pulse el botón **ENTER** para seleccionar "Modo".
Pulse los botones **▲** o **▼** para seleccionar el ajuste de sonido "Normal", "Música", "Película", "Diálogo", o "Favorito" y pulse el botón **ENTER**.



4. Pulse los botón **▲** o **▼** para seleccionar una frecuencia determinada con el fin de ajustarla.
Pulse los botón **◀** o **▶** para aumentar o reducir el nivel de una frecuencia concreta.

- **Modo:** Selecciona el modo de sonido entre los valores predefinidos.
- **Balance I/D:** Ajusta el balance entre los altavoces izquierdo y derecho.
- **Ajuste del ancho de banda (100Hz, 300Hz, 1kHz, 2kHz, 3kHz, 10kHz):** Para ajustar el nivel de las diferentes frecuencias de ancho de banda.



Reajuste de la configuración del ecualizador a los valores predefinidos de fábrica



5. Pulse los botón **▲** o **▼** para seleccionar “Reiniciar” y, a continuación, pulse el botón **ENTER** .
➤ El ecualizador restablece los ajustes predeterminados de fábrica.
Pulse el botón **EXIT** para salir.



Configuración del TruSurround XT (SRS TS XT)

TruSurround XT es una tecnología SRS patentada que solventa el problema de reproducir contenido multicanal 5.1 en dos altavoces. Trusurround proporciona una experiencia de sonido virtual convincente a través de cualquier sistema de reproducción con dos altavoces. Es totalmente compatible con todos los formatos multicanal.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar “Sonido” y, a continuación, pulse el botón **ENTER** .
 2. Pulse los botón **▲** o **▼** para seleccionar “SRS TruSurround XT” y, a continuación, pulse el botón **ENTER** .
 3. Pulse los botón **▲** o **▼** para seleccionar “Apagado” o “Encendido” y, a continuación, pulse el botón **ENTER** .
- Pulse el botón **EXIT** para salir.




TruSurround XT, SRS y el símbolo son marcas comerciales de SRS Labs, Inc.
La tecnología TruSurround XT está incorporada bajo licencia de SRS Labs, Inc.

Elección del idioma preferido

El sistema de transmisión de TV digital permite transmitir simultáneamente muchas pistas de audio (por ejemplo, traducciones simultáneas del programa en otros idiomas). Seleccione el idioma con el que desea oír la pista de audio.


- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar "Idioma preferido" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para elegir el idioma que desee (English, Español o Francés) y pulse el botón **ENTER**.


Pulse el botón **EXIT** para salir.

- “Idioma preferido” está disponible sólo en el modo de televisión digital.
- Sólo se puede seleccionar uno de los idiomas que ofrece la emisora.



Selección de una pista de sonido multicanal (MTS)

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Sonido Multi-track" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar una configuración que desee; pulse después el botón **ENTER**. Pulse el botón **EXIT** para salir.


- Mono**: Elija para canales que emiten en monoaural o si tiene dificultades con la recepción de señales estéreo.
- Estéreo**: Elija para canales que emiten en estéreo.
- SAP**: Elija esta opción para escuchar el programa de audio independiente, que normalmente es una traducción de otro idioma.

- “Sonido Multi-track” está disponible sólo en el modo de televisión analógica.
- Según el programa concreto emitido, puede escuchar en “Mono”, “Estéreo” o “SAP”.



Configuración sencilla

- Pulse el botón **TOOLS** del mando a distancia.
- Pulse los botones **▲** o **▼** para seleccionar "Sonido Multi-track".
- Pulse los botones **◀** o **▶** para seleccionar la opción deseada.
- Pulse los botones **EXIT** o **TOOLS** para salir.







Control automático de volumen

Reduce las diferencias en el nivel de volumen entre las emisoras.



- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar "Vol.Auto" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para configurar "Vol.Auto", "Apagado" o "Encendido" y pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.



Encendido/apagado del altavoz del televisor

Se silencia la salida de sonido desde los altavoces del televisor.

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar "TV Speaker" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Apagado" y, a continuación, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - Cuando "TV Speaker" está establecido en "Apagado", sólo están activas las opciones "Idioma preferido" (en el modo de televisión digital), "Sonido Multi-track" (en el modo de televisión analógica), "Sel. Sonido" (en el modo PIP) y "Reinicio del sonido" en el menú Sonido.
 - Los botones **VOL -**, **VOL +** y **MUTE** no funcionan si "TV Speaker" está establecido en "Apagado".



	Altavoces internos del televisor			Audio Out (Optical, R/L Out) para el sistema de sonido		
	RF	AV, S-Video	Component, PC, HDMI	RF	AV, S-Video	Component, PC, HDMI
TV Speaker Encendido	Salida de altavoces	Salida de altavoces	Salida de altavoces	Salida de sonido	Salida de sonido	Salida de sonido
TV Speaker Apagado	Silencio	Silencio	Silencio	Salida de sonido	Salida de sonido	Salida de sonido
Sin señal del video	Silencio	Silencio	Silencio	Silencio	Silencio	Silencio



Fabricado bajo licencia de Dolby Laboratories. "Dolby" y el símbolo de la doble D son marcas registradas de Dolby Laboratories.



Escuchar el sonido de la sub imagen del PIP

Cuando la opción PIP esta activada, usted puede escuchar el sonido de la sub imagen del PIP.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER** .
 2. Pulse los botón **▲** o **▼** para seleccionar "Sel. Sonido" y, a continuación, pulse el botón **ENTER** .
 3. Pulse los botón **▲** o **▼** para seleccionar "Principal" o "Sub" y, a continuación, pulse el botón **ENTER** .
- Pulse el botón **EXIT** para salir.
- **Principal:** Se usa para escuchar el sonido de la imagen principal.
 - **Sub:** Se usa para escuchar el sonido de la imagen secundaria.
- Puede seleccionar esta opción cuando "PIP" está ajustado como "Encendido". (Consulte la página 29)



Reajuste de valores de sonido a los valores predefinidos de fábrica

Puede restaurar la configuración del sonido con los valores predeterminados de fábrica.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Sonido" y, a continuación, pulse el botón **ENTER** .
 2. Pulse los botón **▲** o **▼** para seleccionar "Reinicio del sonido" y, a continuación, pulse el botón **ENTER** .
- Pulse el botón **EXIT** para salir.
3. Pulse los botón **◀** o **▶** para seleccionar "Reiniciar todo", "Reiniciar modo del sonido" o "Cancelar" y, a continuación, pulse el botón **ENTER** .
- Pulse el botón **EXIT** para salir.
- **Reiniciar todo:** Todos los valores del sonido regresan a los predeterminados.
 - **Reiniciar modo del sonido:** Los valores del sonido actual regresan a los predeterminados.




Conexión de los auriculares (se vende por separado)

Puede conectar unos auriculares al equipo si desea ver un programa de televisión sin molestar a las personas que están en la misma habitación.

- Cuando se inserta el enchufe de un auricular en el terminal del auricular, sólo están activas las opciones "Idioma preferido" (en el modo de televisión digital), "Sonido Multi-track" (en el modo de televisión analógica), "Vol.Auto", "Sel. Sonido" (en el modo PIP) y "Reinicio del sonido" en el menú Sonido.
- El uso continuo de auriculares a un volumen elevado puede dañar la capacidad auditiva.
- No recibirá sonido de los altavoces cuando conecte los auriculares al televisor.
- El volumen de los auriculares y el del televisor se ajustan de manera distinta.

Panel lateral del TV



15

Control de los Canales

Gestión de los canales

Con este menú puede agregar y borrar los canales o configurarlos como favoritos y usar la guía de programas de las emisoras digitales.

Visualización de todos los canales


Puede ver todos los canales que tiene disponibles.

Para usar la función "Lista de canales", primero debe ejecutar "Prog. Auto". (Consulte la página 18).


1. Pulse el botón **MENU**.

Pulse los botones **▲** o **▼** para seleccionar "Canal" y, a continuación, pulse el botón **ENTER**

Pulse los botones **▲** o **▼** para seleccionar "Lista de canales" y, a continuación, pulse el botón **ENTER**




2. Pulse el botón **◀** para seleccionar "Canales agregados".




3. Pulse los botones **▲** o **▼** para seleccionar "Todos los canales".

➤ Muestra todos los canales disponibles actualmente.

Pulse el botón **ENTER**




4. Pulse los botones **▲** o **▼** para seleccionar el canal que desea ver y, a continuación, pulse el botón **ENTER**



➤ Pulse el botón **CH LIST** del mando a distancia para mostrar las listas de canales.

Uso de los botones de colores del mando a distancia con la lista de canales.

- **Rojo (Antena)**: Cambia a aérea o por cable
- **Verde (Zoom)**: Amplía o disminuye el número del canal.
- **Amarillo (Selección)**: Selecciona varias listas de canales.
- **TOOLS (Opción)**: Muestra los menús "Agregar" (o "Borrar"), "Agregar a Favoritos" (o "Borrar de Favoritos"), "Visualización con temporizador", "Edición de nombre de canal" y "Prog. Auto".



- Un canal de color gris quiere decir que se ha suprimido.
El menú "Agregar" sólo aparece con los canales borrados.
- Un canal con la marca "♥" indica que es un canal configurado como favorito.
El menú "Borrar de Favoritos" sólo aparece con los canales marcados con "♥".


Supresión y adición de canales

Puede suprimir o añadir un canal para que se muestren los canales que deseé.


1. Pulse el botón MENU.

Pulse los botones **▲** o **▼** para seleccionar “Canal” y, a continuación, pulse el botón **ENTER** .

Pulse los botones **▲** o **▼** para seleccionar “Lista de canales” y, a continuación, pulse el botón **ENTER** .




2. Pulse el botón ▲ para seleccionar “Canales agregados”.



3. Pulse los botones ▲ o ▼ para seleccionar “Todos los canales”.

➢ Muestra todos los canales disponibles actualmente.

Pulse el botón **ENTER** .



4. Pulse los botones ▲ o ▼ para seleccionar el canal que desea borrar y, a continuación, pulse el botón **TOOLS.**

5. Pulse el botón **ENTER  para seleccionar “Borrar”.**

➢ Todos los canales borrados se mostrarán en el menú “Todos los canales”.

6. Pulse el botón **EXIT para salir.**


➢ También puede borrar un canal en el menú “Canales agregados” de la misma manera.

➢ Para agregar de nuevo un canal a la lista “Canales agregados”, primero hay que borrarlo.

➢ Para volver a añadir (restablecer) un canal a la lista de canales agregados, siga los pasos 1-3 anteriores, pulse los botones **▲** o **▼** para seleccionar el canal y pulse el botón **TOOLS**. Pulse el botón **ENTER**  para seleccionar Agregar.



 **Pulse el botón **CH LIST** del mando a distancia para mostrar las listas de canales.**



Ajuste de los canales favoritos

Puede configurar como favoritos los canales que vea con más frecuencia.

1. Pulse el botón MENU.

Pulse los botones ▲ o ▼ para seleccionar "Canal" y, a continuación, pulse el botón ENTER .

Pulse los botones ▲ o ▼ para seleccionar "Lista de canales" y, a continuación, pulse el botón ENTER .



2. Pulse el botón ◀ para seleccionar "Canales agregados".

3. Pulse los botones ▲ o ▼ para seleccionar "Todos los canales".

➢ Muestra todos los canales disponibles actualmente.

Pulse el botón ENTER .


4. Pulse los botones ▲ o ▼ para seleccionar un canal como favorito.

➢ Agregación de varios canales a la lista de favoritos

Pulse los botones ▲ o ▼ para seleccionar el canal que deseé en la lista. A continuación pulse el botón amarillo. Repita el proceso anterior para seleccionar varios canales. La marca ✓ aparece a la izquierda de los canales seleccionados.

5. Pulse el botón TOOLS.

6. Pulse los botones ▲ o ▼ para seleccionar "Añadir a Favoritos" y, a continuación, pulse el botón ENTER .




7. Si desea cancelar la selección de un canal como favorito, pulse el botón TOOLS cuando esté seleccionado un canal favorito.

Pulse los botones ▲ o ▼ para seleccionar "Borrar de Favoritos" y, a continuación, pulse el botón ENTER .


El canal se borra de la lista "Favorites" y la marca "✓" también desaparece.

Pulse el botón EXIT para salir.


- Puede añadir o borrar un canal en la lista de favoritos en el menú "Canales agregados" siguiendo el mismo procedimiento.
- Todos los canales seleccionados se mostrarán en "Favoritos".



-  Pulse el botón CH LIST del mando a distancia para mostrar las listas de canales.



-  Si desea seleccionar los canales favoritos que ha configurado, pulse el botón FAV.CH en el mando a distancia.



Configuración sencilla

1. Pulse el botón TOOLS del mando a distancia.

2. Pulse los botones ▲ o ▼ para seleccionar "Añadir a Favoritos" (o "Borrar de Favoritos") y, a continuación, pulse el botón ENTER .

- El canal actual se añade o se borra en la lista de favoritos.



Reserva de un programa (visualización con temporizador)


Si reserva un programa que desea ver, el canal se cambia automáticamente al canal reservado en la lista de canales aunque esté viendo otro canal.

Para reservar un canal primero debe configurar la hora actual. Consulte las páginas 47~48. Los canales reservados sólo se pueden configurar si se encuentran en "Lista de canales". (Consulte la página 36).


- Pulse el botón **MENU**.

Pulse los botón **▲** o **▼** para seleccionar "Canal" y, a continuación, pulse el botón **ENTER** .

Pulse los botón **▲** o **▼** para seleccionar "Lista de canales" y, a continuación, pulse el botón **ENTER** .



- Pulse el botón **▲** o **▼** para seleccionar un canal y pulse el botón **TOOLS**.



- Pulse los botones **▲** o **▼** para seleccionar "Visualización con temporizador" y pulse el botón **ENTER** .

Aparece la pantalla para reservar un programa (visualización con temporizador).


- Pulse los botones **▲/▼/◀/▶** para reservar un programa y, a continuación, pulse el botón **ENTER** .

Pulse el botón **EXIT** para salir.

- También puede reservar un programa en los menús "Todos los canales" o "Favoritos" con el mismo procedimiento.
- Para obtener información sobre cómo confirmar una reserva de visualización, consulte la página 40. Sólo se pueden reservar los canales memorizados.
- Puede ajustar el canal, el mes, el día, el año, la hora y el minuto directamente pulsando los botones numéricos del mando a distancia.



- Pulse el botón **CH LIST** del mando a distancia para mostrar las listas de canales.




Guía de programas digitales y reserva de visualización

Si se ha seleccionado un canal digital y se pulsa el botón **►** aparece la guía de programas del canal. Se puede reservar un programa mediante el procedimiento descrito anteriormente.

➤ : Un programa que se está emitiendo.

◎ : Un programa reservado



Confirmación de una reserva de visualización

Se puede ver, cambiar o borrar una reserva.


1. Pulse el botón MENU.

Pulse los botón ▲ o ▼ para seleccionar “Canal” y, a continuación, pulse el botón **ENTER**.

Pulse los botón ▲ o ▼ para seleccionar “Lista de canales” y, a continuación, pulse el botón **ENTER**.



2. Pulse el botón ▲ para seleccionar “Canales agregados”.



3. Pulse los botones ▲ o ▼ para elegir “Programmed”.

➤ Muestra todos los programas actualmente reservados.

Pulse el botón **ENTER**.




Modificación de una reserva de visualización

4. Para seleccionar el elemento de una reserva que deseé cambiar, pulse los botones ▲ o ▼ y, a continuación, pulse el botón **TOOLS.**

5. Pulse el botón **ENTER para seleccionar “Cambiar información”.**

6. Pulse los botones ▲/▼/◀/▶ para cambiar la configuración de la reserva y, a continuación, pulse el botón **ENTER. Se aplica la modificación de la reserva.**



Cancelación de una reserva

4. Para seleccionar el elemento de una reserva que deseé cancelar, pulse los botones ▲ o ▼ y, a continuación, pulse el botón **TOOLS.**

5. Pulse los botón ▲ o ▼ para seleccionar “Cancelar programaciones” y, a continuación, pulse el botón **ENTER.**

6. Pulse los botón ▲ o ▼ para seleccionar “Aceptar” y, a continuación, pulse el botón **ENTER.**

Se cancela la reserva de visualización.

Pulse el botón **EXIT** para salir.

Opciones programadas

- **Cambiar información:** Selecciónelo para cambiar la reserva de visualización.
- **Cancelar programaciones:** Selecciónelo para cancelar la reserva de visualización.
- **Información:** Selecciónelo para ver una reserva de visualización.

Pulse el botón **CH LIST** del mando a distancia para mostrar las listas de canales.




Etiquetado de canales analógicos

Los canales se pueden etiquetar con el propósito de que cuando éstos se seleccionan se pueda ver su nombre.


1. Pulse el botón MENU.

Pulse los botón ▲ o ▼ para seleccionar "Canal" y, a continuación, pulse el botón **ENTER**.


Pulse los botón ▲ o ▼ para seleccionar "Lista de canales" y, a continuación, pulse el botón **ENTER**.



2. Pulse los botones ▲ o ▼ para seleccionar el canal al que se va a asignar un nuevo nombre y pulse el botón **TOOLS.**




3. Pulse los botón ▲ o ▼ para seleccionar "Edición de nombre de canal" y, a continuación, pulse el botón **ENTER.**



4. Pulse los botones ▲/▼/◀/▶ para seleccionar una letra y, a continuación, pulse el botón **ENTER.**

- **Botones numéricos:** Permiten introducir números.
- **Botón rojo:** Permite cambiar entre English y Characters.
- **Botón verde:** Permite borrar un carácter introducido.
- **Botón amarillo:** Permite introducir un espacio vacío.
- **Botón azul:** Pulse este botón parar terminar el cambio del nombre del canal.



5. Cuando haya terminado, pulse el botón azul para asignar el nombre nuevo.

Pulse el botón **EXIT** para salir.

➢ Los nombres de los canales digitales se asignan automáticamente y no se pueden etiquetar.

Almacenamiento de los canales en la memoria (programa automático)

1. Pulse el botón MENU.

Pulse los botón ▲ o ▼ para seleccionar "Canal" y, a continuación, pulse el botón **ENTER**.

Pulse los botón ▲ o ▼ para seleccionar "Lista de canales" y, a continuación, pulse el botón **ENTER**.



2. Pulse los botones ▲ o ▼ para seleccionar el canal al que se va a asignar un nuevo nombre y pulse el botón **TOOLS.**



3. Pulse los botón ▲ o ▼ para seleccionar "Prog. Auto" y, a continuación, pulse el botón **ENTER.**

➢ Si desea más detalles sobre las opciones de configuración, consulte la página 18.

Supresión de los canales codificados digitales

La función "Borrar canal encriptado" se usa para filtrar los canales codificados después de que "Prog. Auto" se haya completado. Puede tardar de 20 a 30 minutos.



- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Canal" y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar "Borrar canal encriptado" y, a continuación, pulse el botón **ENTER**. Busca los canales codificados para borrarlos de la lista.
 - Para detener la búsqueda de canales codificados:
Pulse el botón **ENTER** para seleccionar "Detener".
Pulse el botón **◀** para seleccionar "Sí" y, a continuación, pulse el botón **ENTER**.
- Una vez completada la búsqueda de los canales codificados, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - Esta función sólo está disponible en el modo de "Cable".



Sintonización fina de los canales analógicos

Utilice la sintonización fina para ajustar manualmente un determinado canal a fin de que la recepción sea óptima.


- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Canal" y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar "Sintonía Fina" y, a continuación, pulse el botón **ENTER**.
 - Pulse los botón **◀** o **▶** para ajustar la sintonía con precisión.
Para memorizar la sintonía fina en la memoria del televisor, pulse el botón **ENTER**.
 - Si no almacena en la memoria el canal que ha ajustado de manera precisa, los ajustes no se guardan.
 - Para restablecer la sintonía fina, pulse el botón **▼** para seleccionar "Reiniciar", a continuación pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - El simbolo "*" aparecerá junto al nombre de los canales cuya sintonización se haya ajustado.
 - Sólo puede ajustarse la sintonización de los canales de televisión analógicos.



Comprobación de la potencia de la señal digital

A diferencia de los canales analógicos, cuya calidad de recepción puede variar desde "nebuloso" a claro, los canales digitales (HDTV) tienen una calidad de recepción perfecta o no se reciben en absoluto. Por tanto, a diferencia de los canales analógicos, no puede sintonizar ningún canal digital. Puede, no obstante, ajustar la antena para mejorar la recepción de los canales digitales disponibles.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Canal" y, a continuación, pulse el botón **ENTER** .
 2. Pulse los botones **▲** o **▼** para seleccionar "Intensidad señal" y, a continuación, pulse el botón **ENTER** .
- Si el medidor de potencia de señal indica que la señal es débil, ajuste físicamente su antena para incrementar la potencia de la señal.
- Continúe ajustando la antena hasta que encuentre la mejor posición con la señal más potente.
- Pulse el botón **EXIT** para salir.



Pantalla de PC

Uso del TV como pantalla de ordenador (PC)

Instalación del software en el equipo (según Windows XP)

A continuación se muestra una pantalla de configuración normal en un ordenador con Windows. No obstante, las pantallas reales en su PC probablemente serán diferentes, en función de su versión concreta de Windows y de su tarjeta de vídeo. Pero aunque las pantallas reales tengan un aspecto diferente, se aplicarán los mismos ajustes básicos e información en la mayoría de los casos. (Si no es así, póngase en contacto con el fabricante del ordenador o con un concesionario Samsung.)

1. Primero, haga clic en "Panel de control" en el menú Inicio de Windows.
2. Cuando aparezca la pantalla del Panel de control, haga clic en "Apariencia y Temas" y aparecerá un cuadro de diálogo.
3. Cuando aparezca la pantalla del Panel de control, haga clic en "Pantalla" y aparecerá un cuadro de diálogo.
4. Seleccione la ficha "Configuración" en el cuadro de diálogo.

La configuración de tamaño correcto (resolución)

Modo óptimo: 1920 X 1080 pixels

Si existe una opción de frecuencia vertical en el cuadro de diálogo de configuración de la pantalla, el valor correcto es "60" o "60 Hz". Si no, haga clic en "Aceptar" y salga del cuadro de diálogo.



Modos de visualización

Si la señal del sistema es igual al modo de señal estándar, la pantalla se ajusta automáticamente. Si la señal del sistema no es igual al modo de señal estándar, ajuste el modo consultando la guía del usuario de la tarjeta de vídeo; de lo contrario, puede no haber señal de vídeo. La imagen de pantalla se ha optimizado durante la fabricación para los modos de visualización enumerados a continuación.

D-Sub Entrada

Modo	Resolución	Frecuencia horizontal (kHz)	Frecuencia vertical (Hz)	Frecuencia del reloj de píxeles (MHz)	Polaridad de sincronización (H/V)
IBM	640 x 350	31,469	70,086	25,175	+ / -
	720 x 400	31,469	70,087	28,322	- / +
VESA	640 x 480	31,469	59,940	25,175	- / -
	640 x 480	37,861	72,809	31,500	- / -
	640 x 480	37,500	75,000	31,500	- / -
	800 x 600	37,879	60,317	40,000	+ / +
	800 x 600	48,077	72,188	50,000	+ / +
	800 x 600	46,875	75,000	49,500	+ / +
	1024 x 768	48,363	60,004	65,000	- / -
	1024 x 768	56,476	70,069	75,000	- / -
	1024 x 768	60,023	75,029	78,750	+ / +
	1280 x 1024	63,981	60,020	108,000	+ / +
	1280 x 1024	79,976	75,025	135,000	+ / +
	1360 x 768	47,712	60,015	85,500	+ / +
CVT	1920 x 1080RB	66,587	59,934	138,500	+ / -

HDMI/DVI Entrada

Modo	Resolución	Frecuencia horizontal (kHz)	Frecuencia vertical (Hz)	Frecuencia del reloj de píxeles (MHz)	Polaridad de sincronización (H/V)
VESA	640 x 480	31,469	59,940	25,175	- / -
	800 x 600	37,879	60,317	40,000	+ / +
	1024 x 768	48,363	60,004	65,000	- / -
	1280 x 1024	63,981	60,020	108,000	+ / +
	1360 x 768	47,712	60,015	85,500	+ / +
CEA	1920 x 1080p	67,500	60,000	148,500	+ / +

Ajuste del televisor con el ordenador

Cómo realizar el Ajuste automático


Mediante la función "Ajuste Auto" se puede establecer que el televisor se ajuste automáticamente de acuerdo con las señales de video que reciba. La función también ajusta automáticamente con más configuración y ajusta los valores y las posiciones de la frecuencia.

- > Esta función no se puede utilizar en modo DVI-Digital
 - > Preselección: Pulse el botón **SOURCE** para seleccionar el modo PC.
1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Imagen" y, a continuación, pulse el botón **ENTER**.
 2. Pulse los botones **▲** o **▼** para seleccionar "Ajuste automático" y, a continuación, pulse el botón **ENTER**.
 - Pulse el botón **EXIT** para salir.



Configuración sencilla

1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones **▲** o **▼** para seleccionar "Ajuste automático" y, a continuación, pulse el botón **ENTER**.



Ajuste de la calidad de la pantalla

El propósito del ajuste de la calidad de imagen es eliminar o reducir el ruido de la imagen. Si el ruido no desaparece sólo con la sintonización fina, realice los ajustes de frecuencia hasta el máximo y vuelva a realizar la sintonización fina. Después de reducir el ruido, vuelva a ajustar la imagen para que quede alineada en el centro de la pantalla.

- > Preselección: Pulse el botón **SOURCE** para seleccionar el modo PC.
1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Imagen" y, a continuación, pulse el botón **ENTER**.
 2. Pulse los botones **▲** o **▼** para seleccionar "Pantalla" y, a continuación, pulse el botón **ENTER**.
 3. Pulse los botones **▲** o **▼** para seleccionar "Grueso" o "Fino" y, a continuación, pulse el botón **ENTER**. Pulse los botones **◀** o **▶** para ajustar la calidad de la pantalla.
> Pueden aparecer rayas verticales o la imagen tener poca definición.
Pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.



Cambio de la posición de la pantalla

Ajuste la posición de la pantalla del PC si no se acopla a la pantalla del TV.

➤ Preselección: Pulse el botón **SOURCE** para seleccionar el modo PC.

1. Pulse el botón **MENU** para ver el menú en pantalla.

Pulse los botón **▲** o **▼** para seleccionar “Imagen” y, a continuación, pulse el botón **ENTER**.

2. Pulse los botón **▲** o **▼** para seleccionar “Pantalla” y, a continuación, pulse el botón **ENTER**.




3. Pulse los botón **▲** o **▼** para seleccionar “Posición” y, a continuación, pulse el botón **ENTER**.

4. Pulse los botón **▲** o **▼** para ajustar Posición V.

Pulse los botón **◀** o **▶** para ajustar Posición H.

Pulse el botón **ENTER**.

Pulse el botón **EXIT** para salir.



Inicialización de Posición de la pantalla, Grueso y Fino

Puede recuperar todos los ajustes de imagen predeterminados de fábrica.

➤ Preselección: Pulse el botón **SOURCE** para seleccionar el modo PC.



1. Pulse el botón **MENU** para ver el menú en pantalla.

Pulse los botón **▲** o **▼** para seleccionar “Imagen” y, a continuación, pulse el botón **ENTER**.

2. Pulse los botón **▲** o **▼** para seleccionar “Pantalla” y, a continuación, pulse el botón **ENTER**.

3. Pulse los botón **▲** o **▼** para seleccionar “Reiniciar Imagen” y, a continuación, pulse el botón **ENTER**.

Pulse el botón **EXIT** para salir.



Ajuste de la Hora


Configuración del Reloj

Establecer el reloj es necesario para usar las distintas características de temporizador del TV.


Además, puede comprobar la hora mientras está viendo el TV. (Simplemente pulse **INFO**.)

Opción 1: Ajuste manual del reloj

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Tiempo" y, a continuación, pulse el botón **ENTER**.



- Pulse el botón **ENTER** para seleccionar "Reloj".



- Pulse el botón **ENTER** para seleccionar "Modo Reloj".
Pulse los botones **▲** o **▼** para seleccionar "Manual" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar "Config. Reloj" y, a continuación, pulse el botón **ENTER**.




- Pulse los botones **◀** o **▶** para desplazarse a "Mes", "Día", "Año", "Tiempo", "Minuto", o "am/pm". Seleccione la fecha y la hora que deseé pulsando los botones **▲** o **▼**, pulse después el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - La hora actual aparecerá siempre que se pulse el botón **INFO**.
 - Puede ajustar el mes, el día, el año, la hora y el minuto directamente pulsando los botones numéricos del mando a distancia.




Opción 2: Ajuste automático del reloj

El reloj puede ajustarse automáticamente cuando se recibe una señal digital.

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar “Configuración” y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar “Tiempo” y, a continuación, pulse el botón **ENTER**.



- Pulse el botón **ENTER** para seleccionar “Reloj”.




- Pulse el botón **ENTER** para seleccionar “Modo Reloj”.
Pulse los botón **▲** o **▼** para seleccionar “Auto” y, a continuación, pulse el botón **ENTER**.



- Pulse los botón **▲** o **▼** para seleccionar “Zona Tiempo” y, a continuación, pulse el botón **ENTER**.





- Pulse los botón **▲** o **▼** para seleccionar “Tiempo Verano” (Horario de verano); después pulse el botón **ENTER**. Pulse los botón **▲** o **▼** para seleccionar “Apagado” o “Encendido” y, después, pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - Según la estación emisora y la señal, puede que el ajuste automático de la hora no se realice correctamente. En este caso, ajuste la hora manualmente.
 - La antena o el cable debe estar conectado para que se ajuste la hora automáticamente.



Configuración del Temporizador de sueño


El temporizador de desconexión apaga automáticamente el televisor después de un período prefijado (entre 30, 60, 90, 120, 150 y 180 minutos).

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar “Configuración” y, a continuación, pulse el botón **ENTER** .
2. Pulse los botón **▲** o **▼** para seleccionar “Temporizador” y, a continuación, pulse el botón **ENTER** .
3. Pulse los botones **▲** o **▼** para seleccionar los minutos y, a continuación, pulse el botón **ENTER** 
Para cancelar el temporizador:
Pulse los botón **▲** o **▼** para seleccionar “Apagado” y, a continuación, pulse el botón **ENTER** .
4. Pulse el botón **EXIT** para salir.




Configuración sencilla

1. Pulse el botón **TOOLS** del mando a distancia.
2. Pulse los botones **▲** o **▼** para seleccionar “Temporizador”.
3. Pulse los botones **◀** o **▶** para seleccionar los minutos.
4. Pulse los botones **EXIT** o **TOOLS** para salir.




Activación y desactivación del temporizador

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
- Pulse los botón **▲** o **▼** para seleccionar "Tiempo" y, a continuación, pulse el botón **ENTER**.




- La activación y desactivación del temporizador se puede configurar de tres maneras. Pulse los botón **▲** o **▼** para seleccionar "Temporizador 1", "Temporizador 2" o "Temporizador 3" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **◀** o **▶** para seleccionar el elemento deseado.
Pulse los botones **▲** o **▼** para ajustar la configuración.

- Hora de encendido:** Ajuste la hora, los minutos, "am/pm" y "Activar/ Inactivo". (Para activar el temporizador con la configuración deseada, establezcalo en "Activar").
- Hora de apagado:** Ajuste la hora, los minutos, "am/pm" y "Activar/ Inactivo". (Para activar el temporizador con la configuración deseada, establezcalo en "Activar").
- Volumen:** Seleccione el nivel de volumen deseado.
- Contenido:** Cuando la opción "Hora de encendido" está activa, se puede encender un canal determinado o reproducir contenidos como archivos de fotos o de audio.
 - USB TV: Permite seleccionar TV o USB. (Compruebe que haya un dispositivo USB conectado al televisor.)
 - Antena: Seleccione "Aire" o "Cable".
 - Canal: Permite seleccionar el canal deseado.
 - Música: Permite seleccionar la carpeta del dispositivo USB con archivos MP3.
 - Fotos: Permite seleccionar la carpeta del dispositivo USB con archivos JPEG.
- Repetir:** Seleccione "Una vez", "Cada día", "Lun~Vie", "Lun~Sáb", "Sáb~Dom" o "Manual".
 - Con "Manual" seleccionado, pulse el botón **▶** para seleccionar el día de la semana. Pulse el botón **ENTER** sobre el día deseado; aparecerá la marca **✓**.



Pulse el botón **EXIT** para salir.

➤ Puede ajustar la hora, los minutos y el canal pulsando los botones numéricos del mando a distancia.


➤ Apagado automático

Si activa el temporizador, el televisor se apagará si no se pulsa ningún botón durante 3 horas, después que el temporizador lo haya puesto en marcha. Esta función sólo está disponible en el modo Encendido del temporizador y evita el recalentamiento que se puede producir si el televisor está encendido durante demasiado tiempo.

Descripción de las Funciones

Selección del idioma de menú

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y después, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Idioma" y después, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar "English", "Español" o "Français".
Pulse el botón **ENTER**.
- Pulse el botón **EXIT** para salir.




Uso de V-Chip

La función V-Chip bloquea automáticamente la programación que se considera inadecuada para los niños. El usuario debe introducir primero un código PIN (número de identificación personal) antes de establecer o cambiar las restricciones de V-Chip.


- La función "V-Chip" no está disponible en los modos HDMI, Componente o PC.

Ajuste del número de identificación personal (código PIN)

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "V-Chip" y, a continuación, pulse el botón **ENTER**.
Aparecerá el mensaje "Ingresar Código". Escriba su código PIN de 4 dígitos.
➤ El código PIN predeterminado para un televisor nuevo es "0-0-0-0".




- 3.** Aparecerá la pantalla “V-Chip”.
 Pulse los botón **▲** o **▼** para seleccionar “Cambiar Código” y, después, pulse el botón **ENTER** . Aparecerá la pantalla Cambiar Código. Escriba un nuevo código PIN de 4 dígitos. En cuanto introduzca los 4 dígitos, aparece la pantalla “Confirmar Nuevo Código”. Vuelva a escribir los 4 dígitos. Cuando desaparezca la pantalla de confirmación, el código quedará memorizado.
 Pulse el botón **EXIT** para salir.
- Si olvida su código, pulse los botones del mando a distancia siguiendo la secuencia siguiente, que restablece el código a 0-0-0-0: Apagar → MUTE → 8 → 2 → 4 → Encender.



Cómo activar/desactivar V-Chip

- 1.** Pulse el botón **MENU** para ver el menú en pantalla.
 Pulse los botón **▲** o **▼** para seleccionar “Configuración” y, a continuación, pulse el botón **ENTER** .
- 2.** Pulse los botón **▲** o **▼** para seleccionar “V-Chip” y, a continuación, pulse el botón **ENTER** .
- Aparecerá el mensaje “Ingresar Código”. Escriba su código PIN de 4 dígitos.



- 3.** Aparecerá la pantalla “V-Chip”.
 Para activar la función V-Chip, pulse el botón **ENTER** para que “Bloqueo V-Chip” se ajuste en “Encendido”. (Si se pulsan repetidamente los botón **▲** o **▼** se alterna entre “Encendido” y “Apagado”.)
 Pulse el botón **ENTER** .
- Pulse el botón **EXIT** para salir.



Configuración de Restricciones usando la sección Guías pater. TV

Primero, establezca un número de identificación personal (PIN) y active V-Chip. (Consulte la sección anterior.) Las restricciones del bloqueo de programas se pueden establecer mediante dos métodos: Las guía de programas o la clasificación MPAA.


- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "V-Chip" y, a continuación, pulse el botón **ENTER**.
Aparecerá el mensaje "Ingresar Código". Escriba su código PIN de 4 dígitos.
- Aparecerá la pantalla "V-Chip". Use los botones **▲** o **▼** para seleccionar "Guías pater. TV" y, a continuación, pulse el botón **ENTER**.
- Aparecerá la pantalla "Guías pater. TV".
Pulse los botones **▲** o **▼** para seleccionar una de las seis categorías basadas en la edad:

- | | |
|---|---|
| • TV-Y : Niños pequeños | • TV-PG : Acompañados de un adulto |
| • TV-Y7 : Niños de más de 7 años | • TV-14 : Mayores de 14 años |
| • TV-G : Todos los públicos | • TV-MA : Para adultos |

- En este punto, ya ha seleccionado una de las clasificaciones.
Pulse el botón **ENTER**. Según la configuración, se seleccionará un símbolo "🔒". (En blanco = Desbloqueada, 🔒 = Bloqueada)
Mientras se selecciona "🔒" pulse el botón **ENTER** para bloquear o desbloquear la categoría. Para seleccionar una clasificación de TV distinta, pulse los botones **▲** o **▼**, y, después, repita el proceso.
 - > Perm. todo: Se pulsa para desbloquear todos los programas de televisión.
 - > Bloq. todo: Se pulsa para bloquear todos los programas de televisión.
 - > TV-Y, TV-Y7, TV-G, TV-PG, TV-14 y TV-MA incluyen opciones adicionales. Consulte el paso siguiente para cambiar las subclasificaciones: ALL / FV / V / S / L / D
 - > La opción V-Chip bloqueará automáticamente ciertas categorías que son "más restrictivas". Por ejemplo, si bloquea la categoría "TV-Y", automáticamente se bloqueará TV-Y7. De manera similar, si bloquea la categoría TV-G, todas las categorías en el grupo "adolescente" quedarán bloqueadas (TV-G, TV-PG, TV-14, y TV-MA). Las subclasificaciones (D, L, S, V) funcionan de manera similar. (Consulte la sección siguiente.)
- Cómo establecer las subclasificaciones FV, D, L, S y V.
Primero, seleccione una de las clasificaciones de TV: TV-Y, TV-Y7, TV-G, TV-PG, TV-14 o TV-MA (consulte el paso 4,) y pulse el botón **►**.
Por cada subclasificación aparecerá un símbolo "🔒". Con el "🔒" seleccionado, pulse el botón **ENTER** para ir a la subclasificación. Pulse **ENTER** para bloquear la subclasificación. Para seleccionar una clasificación de TV distinta, pulse los botones **▲** o **▼**, y, después, repita el proceso.

- | | |
|---|--|
| • ALL : Bloquea todas las clasificaciones de TV. | • S : Situación sexual |
| • FV : Violencia y fantasía | • L : Lenguaje grosero |
| • V : Violencia | • D : Diálogo de contenido sexual |


- La opción V-chip bloqueará automáticamente ciertas categorías que son "More restrictive". Por ejemplo, si bloquea la subclasificación "L" en TV-PG, las subclasificaciones "L" en TV-14 y TV-MA se bloquearán automáticamente.
- Pulse el botón **EXIT** para borrar todas las pantallas.
(O continúe en la sección siguiente y establezca restricciones adicionales según los códigos MPAA.)
Estas categorías se dividen en dos grupos: TV-Y y TV-Y7 (niños pequeños y niños a partir de 7 años), y TV-G a TV-MA (todos los demás). Las limitaciones para estos grupos funcionan de forma independiente. Si en la familia hay niños muy pequeños y adultos jóvenes, la opción Guía de programas debe configurarse por separado para grupo de edad. (Consulte el siguiente paso.)



Configuración de las restricciones mediante las clasificaciones MPAA: G, PG, PG-13, R, NC-17, X, NR

El sistema de clasificación MPAA utiliza el sistema de la MPAA (Motion Imagen Association of America, Asociación americana de cinematografía) que se aplica principalmente en las películas. Si el bloqueo de V-Chip está activado, el televisor bloqueará automáticamente programas que estén codificados con clasificaciones rechazables (de la MPAA o de televisión).

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER** .



2. Pulse los botón **▲** o **▼** para seleccionar "V-Chip" y, a continuación, pulse el botón **ENTER** .

Aparecerá el mensaje "Ingresar Código". Escriba su código PIN de 4 dígitos.



3. Aparecerá la pantalla "V-Chip".
Pulse los botón **▲** o **▼** para seleccionar "Clas. MPAA" y, a continuación, pulse el botón **ENTER** .





4. Aparecerá la pantalla "Clas. MPAA".

Pulse varias veces los botón **▲** o **▼** para seleccionar una categoría concreta de MPAA. Pulsando los botón **▲** o **▼** pasará secuencialmente por todas las categorías MPAA:

- **G:** Todos los públicos (sin restricciones).
- **PG:** Se sugiere la compañía de un adulto.
- **PG-13:** Menores acompañados de un adulto.
- **R:** Restringido. Los niños menores de 17 años deben estar acompañados por un adulto.
- **NC-17:** Prohibida la entrada a menores de 17 años.
- **X:** Sólo adultos.
- **NR:** Sin clasificación.


- **Perm. todo:** Se pulsa para desbloquear todos los programas de televisión.
Bloq. todo: Se pulsa para bloquear todos los programas de televisión.
- Con una determinada categoría seleccionada, pulse el botón **ENTER**  para activarla. En la pantalla aparecerá un símbolo "🔒" seleccionado.
Pulse el botón **ENTER**  para bloquear o desbloquear la categoría.
- La opción V-chip bloqueará automáticamente cualquier categoría que sea "More restrictive". Por ejemplo, si bloquea la categoría "PG-13", también se bloquearán automáticamente "R", "NC-17" y "X".

Pulse el botón **EXIT** para salir.



Cómo configurar las restricciones en el idioma Inglés Canadiense

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar “Configuración” y, a continuación, pulse el botón **ENTER** .



2. Pulse los botón **▲** o **▼** para seleccionar “V-Chip” y, a continuación, pulse el botón **ENTER** .
- Aparecerá el mensaje “Ingresar Código”. Escriba su código PIN de 4 dígitos.



3. Aparecerá la pantalla “V-Chip”. Pulse los botón **▲** o **▼** para seleccionar “Inglés Canadiense” y, después, pulse el botón **ENTER** .




4. Pulse los botón **▲** o **▼** para seleccionar la restricción apropiada.
Pulse el botón **ENTER**  para activar la restricción seleccionada.
Está resaltada la “- **Perm. todo:** Se pulsa para desbloquear todos los programas de televisión.
- **Bloq. todo:** Se pulsa para bloquear todos los programas de televisión.

C		Perm. todo
C8+		Bloq. todo
G		
PG		
14+		
18+		


• C: Programación para niños menores de 8 años.
• C8+: Programación generalmente considerada aceptable para niños mayores de 8 años sin acompañamiento de adultos.
• G: Programación general, ideal para todas las audiencias.
• PG: Supervisión paterna.
• 14+: La programación contiene temas y contenidos que puede que no sean adecuados para menores de 14 años.
• 18+: Programación para adultos.

➢ El V-Chip bloqueará automáticamente cualquier categoría que sea “More restrictive”. Por ejemplo, si bloquea la categoría G, automáticamente también se bloqueará PG, 14+ y 18+.



Cómo configurar las restricciones en el idioma Francés Canadiense

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botón **▲** o **▼** para seleccionar “Configuración” y, a continuación, pulse el botón **ENTER** .



- Pulse los botón **▲** o **▼** para seleccionar “V-Chip” y, a continuación, pulse el botón **ENTER** .

Aparecerá el mensaje “Ingresar Código”. Escriba su código PIN de 4 dígitos.



- Aparecerá la pantalla “V-Chip”. Pulse los botón **▲** o **▼** para seleccionar “Canadian French” y, a continuación, pulse el botón **ENTER** .





- Pulse los botón **▲** o **▼** para seleccionar la restricción apropiada.
Pulse el botón **ENTER**  para activar la restricción seleccionada. Está resaltada la “

Pulse el botón **EXIT** para salir.

- **Perm. todo:** Se pulsa para desbloquear todos los programas de televisión.
- **Bloq. todo:** Se pulsa para bloquear todos los programas de televisión.



- **G:** General
 - **8 ans+:** Programación generalmente considerada aceptable para niños mayores de 8 años sin acompañamiento de adultos.
 - **13 ans+:** Es posible que la programación no sea adecuada para niños menores de 13 años.
 - **16 ans+:** Es posible que la programación no sea adecuada para niños menores de 16 años.
 - **18 ans+:** Programación restringida para adultos.
- El V-Chip bloqueará automáticamente cualquier categoría que sea “More restrictive”. Por ejemplo, si bloquea la categoría 8 ans+, también se bloquearán automáticamente 13 ans+, 16 ans+ y 18 ans+.



Uso de V-Chip con los canales digitales

La información de la restricción de bloqueo se puede usar mientras se ven los canales DTV.



1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "V-Chip" y, a continuación, pulse el botón **ENTER**.
Aparecerá el mensaje "Ingresar Código". Escriba su código PIN de 4 dígitos.
3. Aparecerá la pantalla "V-Chip". Pulse los botones **▲** o **▼** para seleccionar "Clasificacion U.S. Descargable" y, a continuación, pulse el botón **ENTER**.
 - Si la información no se descarga desde la emisora, el menú "Clasificacion U.S. Descargable" está desactivado.
 - La información de la restricción de bloqueo se puede descargar automáticamente mientras se ven los canales DTV. Esto puede tardar algunos segundos.
 - El menú "Clasificacion U.S. Descargable" está disponible después de que la información se haya descargado desde la emisora. Sin embargo, según el tipo de información de la emisora, el menú podría no estar disponible para su uso.
4. Pulse los botones **▲** o **▼** para seleccionar la restricción apropiada.
Pulse el botón **ENTER** para activar la restricción seleccionada.
Está resaltada la "█".
Pulse el botón **EXIT** para salir.
 - Perm. todo: Se pulsa para desbloquear todos los programas de televisión.
Bloq. todo: Se pulsa para bloquear todos los programas de televisión.
 - Los niveles de restricción de bloqueo difieren según la emisora.
 - El nombre de menú predeterminado y "Clasificacion U.S. Descargable" cambian según la información descargada.
 - Aunque configure la visualización en pantalla en su propio idioma, el menú "Clasificacion U.S. Descargable" siempre lo verá en inglés.
 - La clasificación bloqueará automáticamente ciertas categorías que son más restrictivas.
 - Los títulos de clasificación (por ejemplo, Humor Level (Nivel humor), etc) y las clasificaciones de televisión (por ejemplo, DH, MH, H, etc) pueden diferir según la emisora.



Cómo reiniciar el televisor cuando el V-Chip bloquea un canal ("Escape de emergencia")

Si el televisor sintoniza un canal restringido, el V-Chip lo bloqueará. La pantalla quedará en blanco y aparecerá el siguiente mensaje:


1. Pulse el botón **ENTER** para seleccionar Aceptar.
Para volver al modo de visualización normal, sintonice un canal diferente con los botones **CH ▼** o **CH ▲**. En ciertas condiciones (según la clasificación de los programas de televisión locales) la función V-Chip puede bloquear todos los canales. En este caso, utilice la función V-Chip como "salida de emergencia":
2. Escriba su código PIN, pulse el botón **ENTER** y, a continuación, los botones **▲** o **▼** para desactivar temporalmente la función Bloqueo V-Chip.
 - Si olvida el PIN, pulse los botones del mando a distancia en la siguiente secuencia para reiniciar el código a 0-0-0-0 : Apagar → MUTE → 8 → 2 → 4 → Encender.




Visión de subtítulos (mensajes de texto en pantalla) - Analógico

La función Analog Caption (Subtítulo analógico) funciona tanto en el modo de canal de televisión analógica o como cuando la señal proviene de un dispositivo externo. (Dependiendo de la señal de transmisión, puede funcionar en canales digitales.)

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar "Subtítulo" y, a continuación, pulse el botón **ENTER**.



- Pulse el botón **ENTER** para seleccionar "Subtítulo". Pulse los botones **▲** o **▼** para seleccionar "Encendido" y, a continuación, pulse el botón **ENTER**.



- Pulse los botones **▲** o **▼** para seleccionar "Modo de Subtítulo" y, a continuación, pulse el botón **ENTER**. Pulse los botones **▲** o **▼** para seleccionar el submenú que deseé (Programado, CC1~CC4 o Texto1~Texto4); pulse después el botón **ENTER**.

Pulse el botón **EXIT** para salir.

- El valor predeterminado es "CC1".
- CC1:** El servicio primario de subtítulos sincronizados. Son subtítulos en el idioma principal que debe estar sincronizado con el sonido, preferiblemente que coincida con la secuencia específica.
- CC2:** Subtítulos especiales de uso no sincronizado. Este canal transporta datos que están destinados a ampliar la información del programa.
- CC3:** Servicio de subtítulos secundarios sincronizados. Datos alternativos de subtítulos relacionados con el programa, típicamente subtítulos del segundo idioma.
- CC4:** Subtítulos especiales de uso no sincronizado. Similar a "CC2".
- Texto1:** Primer servicio de texto. Se puede tratar de varios datos no relacionados con programa alguno.
- Texto2:** Segundo servicio de texto. Datos adicionales, normalmente sin relación con programa alguno.
- Texto3/Texto4:** Tercer y cuarto servicios de texto. Estos canales de datos sólo se deben usar si "Texto1" y "Texto2" no son suficientes.

- La función Subtítulo no está disponible en los modos Componente, HDMI ni PC.
- La disponibilidad de los subtítulos depende del programa que se esté emitiendo.

-  Pulse el botón **CC** del mando a distancia para establecer la función de subtítulos en "Encendido" o "Apagado".








Visión de subtítulos (mensajes de texto en pantalla) - Digital

La función Subtítulo digital funciona en canales digitales.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "Subtítulo" y, a continuación, pulse el botón **ENTER**.
3. Pulse el botón **ENTER** para seleccionar "Subtítulo".
Pulse los botones **▲** o **▼** para seleccionar "Encendido" y, a continuación, pulse el botón **ENTER**.
4. Pulse los botones **▲** o **▼** para seleccionar "Modo de Subtítulo" y, a continuación, pulse el botón **ENTER**. Pulse los botones **▲** o **▼** para seleccionar el submenú (Programado, Service1~Service6, CC1~CC4 o Texto1~Texto4) que deseas; pulse después el botón **ENTER**.
5. Pulse los botones **▲** o **▼** para seleccionar "Opciones - Subtítulos Dig." y, a continuación, pulse el botón **ENTER**.
 - La función "Opciones - Subtítulos Dig." sólo está disponible cuando puede seleccionarse "Programado" y "Service1~Service6" en el modo "Modo de Subtítulo".
 - Los modos de subtitulación "Service 1~6" pueden no estar disponibles según el tipo de emisión.
6. Pulse los botones **▲** o **▼** para seleccionar "Tamaño" y, a continuación, pulse el botón **ENTER**. Pulse los botones **▲** o **▼** para seleccionar la opción deseada para el Subtítulo; después pulse el botón **ENTER**. Pulse los botones **▲** o **▼** para seleccionar las opciones de submenú que deseas (vea las opciones en la página siguiente) y pulse el botón **ENTER**.
Pulse el botón **EXIT** para salir.
 - La disponibilidad de los subtítulos depende del programa que se esté emitiendo.
 - La opción "Programado" significa que se sigue el estándar establecido por el emisor.
 - Las opciones Color de primer plano y Color de fondo no se pueden ajustar con el mismo color.
 - "Opacidad de primer plano" y "Opacidad de fondo" no pueden ajustarse a la vez en Transparent.

- **Tamaño:** Esta opción consta de "Programado", "Pequeño", "Normal" y "Grande". El valor predeterminado es "Normal".
- **Estilo fuente:** Esta opción consta de "Programado", "Estilo 0 ~ Estilo 7". Puede cambiar el tipo de letra que deseas. El valor predeterminado es "Estilo 0".
- **Color de primer plano:** Esta opción consta de "Programado", "Blanco", "Negro", "Rojo", "Verde", "Azul", "Amarillo", "Magenta" y "Cian". Puede cambiar el color del texto. El valor predeterminado es "Blanco".
- **Color de fondo:** Esta opción consta de "Programado", "Blanco", "Negro", "Rojo", "Verde", "Azul", "Amarillo", "Magenta" y "Cian". Puede cambiar el color del fondo de los subtítulos. El valor predeterminado es "Negro".
- **Opacidad de primer plano:** Esta opción consta de "Programado", "Transparent", "Traslúcido", "Solid" y "Flashing". Puede cambiar la opacidad de la letra.
- **Opacidad de fondo:** Esta opción consta de "Programado", "Transparente", "Traslúcido", "Sólido" y "Intermitente". Puede cambiar la opacidad del fondo de los subtítulos.
- **Regresar al Predeterminado:** Esta opción reajusta las opciones "Tamaño", "Estilo fuente", "Color de primer plano", "Color de fondo", "Opacidad de primer plano" y "Opacidad de fondo" a sus valores predeterminados.

- ④ Pulse el botón **CC** del mando a distancia para establecer la función de subtítulos en "Encendido" o "Apagado".





Ajuste de la melodía de encendido y apagado del televisor

Puede definirse un sonido de melodía para que suene cuando se encienda o se apague el TV.



1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "Configuración externa" y, a continuación, pulse el botón **ENTER**.
3. Pulse los botones **▲** o **▼** para seleccionar "Melodía" y, a continuación, pulse el botón **ENTER**.
Pulse los botones **▲** o **▼** para seleccionar "Apagado", "Bajo", "Medio" o "Alto" y, a continuación, pulse el botón **ENTER**.

- **Apagado:** Apaga la función de la melodía.
- **Bajo:** Establece el volumen de la melodía en un nivel bajo.
- **Medio:** Establece el volumen de la melodía en un nivel medio.
- **Alto:** Establece el volumen de la melodía en un nivel alto.

Pulse el botón **EXIT** para salir.

➤ **La melodía no se reproduce**

- Cuando no hay salida de sonido desde el televisor porque se ha activado el botón **MUTE**
- Cuando no hay salida de sonido desde el televisor porque el volumen se ha reducido al mínimo con el botón **VOL -**.
- Cuando la función de temporizador ha apagado el televisor.



Configuración del modo Entretenimiento




El modo "Entretenimiento" permite seleccionar una visualización y un sonido óptimos en los deportes, películas y juegos.

1. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "Entretenimiento" y, a continuación, pulse el botón **ENTER**.
3. Pulse los botones **▲** o **▼** para seleccionar "Apagado", "Deportes", "Película" o "Juego" y, a continuación, pulse el botón **ENTER**.

- **Apagado:** Desactiva la función "Entretenimiento".
- **Deportes:** Proporciona una calidad óptima de imagen para los deportes.
- **Película:** Proporciona una calidad óptima de imagen para ver películas. Se obtienen mejores imágenes y se resalta el sonido.
- **Juego:** Proporciona una calidad óptima de imagen para los juegos. Este modo acelera la velocidad de reproducción de los juegos cuando se usa una consola de juegos externa conectada al televisor.

Pulse el botón **EXIT** para salir.

- Si configura cualquiera de los tres modos de "Entretenimiento" como Encendido, la configuración se bloquea y no se puede ajustar. Si de desea configurar los modos Imagen y Sonido, debe desactivar el modo "Entretenimiento".
- Si establece cualquiera de los tres modos de "Entretenimiento" como Encendido, la función "SRS TruSurround XT" no está disponible.
- La configuración de "Entretenimiento" se guarda para cada fuente de entrada.
- Se puede pulsar varias veces el botón **E.MODE** del mando a distancia para cambiar la configuración de "Entretenimiento".






Uso de la función de ahorro de energía


Esta función ajusta el brillo del televisor, lo cual reduce el consumo de energía. Si desea ver la televisión por la noche, ajuste la opción del modo "Ahorro energía" en "Alto"; sus ojos se lo agradecerán y, además, reducirá el consumo de energía.

- Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER** .



- Pulse los botones **▲** o **▼** para seleccionar "Ahorro energía" y, a continuación, pulse el botón **ENTER** . Seleccione la opción deseada (Apagado, Bajo, Medio, Alto, Auto) pulsando los botones **▲** o **▼**.
Pulse el botón **ENTER** .

- Apagado:** Apaga la función de ahorro de energía.
- Bajo:** Configura el televisor en el modo de ahorro de energía bajo.
- Medio:** Configura el televisor en el modo de ahorro de energía medio.
- Alto:** Configura el televisor en el modo de ahorro de energía alto.
- Auto:** Ajusta automáticamente el brillo de la pantalla del televisor según las escenas.




Pulse el botón **EXIT** para salir.



Guía de actualización del software

Samsung puede ofrecer actualizaciones para el firmware del televisor en el futuro. Póngase en contacto con el centro de llamadas de Samsung en 1-800-SAMSUNG(726-7864) para recibir información acerca de la descarga de las actualizaciones y del uso de un controlador USB. Las actualizaciones se pueden realizar conectando una unidad USB al puerto USB situado en el televisor.

1. Inserte una unidad USB que contenga las actualizaciones de firmware en las conexiones WISELINK de la parte posterior del televisor.
➤ El software no se puede actualizar a través de la conexión LAN.



2. Pulse el botón **MENU** para ver el menú en pantalla.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER** .
3. Pulse los botones **▲** o **▼** para seleccionar "Actualización del software" y, a continuación, pulse el botón **ENTER** .
4. Pulse el botón **ENTER** .
- Aparece el mensaje "Explorando USB... Puede tardar hasta 30 segundos. ".
5. Aparece el mensaje "¿Actualizar la versión XXXX a la versión XXXX? Después de la actualización el sistema se debe reiniciar.". Pulse los botones **◀** o **▶** para seleccionar "Aceptar" y, a continuación, pulse el botón **ENTER** .



No desconecte la alimentación ni retire la unidad USB mientras se aplican las actualizaciones. El televisor se apagará y se encenderá automáticamente después de completar la actualización de firmware. Después de realizar la actualización compruebe la versión del firmware. Cuando se actualiza el software, la configuración del vídeo y audio que se haya efectuado vuelve a la configuración predeterminada (de fábrica). Es aconsejable anotar la configuración para recuperarla fácilmente después de la actualización.


WISELINK

Uso de la función WISELINK

Conexión de un dispositivo USB

Esta función permite ver archivos de fotos (JPEG) y escuchar archivos de audio (MP3) guardados en un dispositivo de clase de almacenamiento masivo (MSC) USB.

- 1 Pulse el botón **POWER** del mando a distancia o del panel frontal.
➤ El televisor está encendido.
2. Conecte un dispositivo USB que contenga archivos JPEG o MP3 al terminal **WISELINK** (terminal USB) que se encuentra en el lateral del televisor.



- Si entra en el modo WISELINK y no hay ningún dispositivo USB conectado aparece el mensaje "No hay ningún dispositivo de almacenamiento externo. Verifique el estado de la conexión.". En tal caso, inserte el dispositivo USB, salga de la pantalla pulsando el botón **WLINK** del mando a distancia y vuelva a entrar en la pantalla WISELINK.
- MTP (Protocolo de transferencia de recursos) no se admite.
- El sistema de archivos sólo admite FAT16/32 (El sistema de archivos NTFS no se admite).
- Ciertos tipos de cámara digital USB y dispositivos de audio quizás no sean compatibles con este televisor.
- Wiselink sólo admite el dispositivo de clase de almacenamiento masivo (MSC) USB. MSC es un dispositivo de clase de almacenamiento masivo sólo de transporte de gran capacidad. Ejemplos de MSC son unidades de almacenamiento en miniatura y lectores de tarjetas Flash (se admite ni disco duro de USB ni de HUB).
- Conecte directamente al puerto USB del televisor. Si utiliza una conexión con un cable independiente, puede haber problemas de compatibilidad con el USB.
- Antes de conectar el dispositivo al televisor, haga una copia de seguridad de sus archivos para evitar daños o pérdidas de datos. SAMSUNG no se hace responsable por cualquier daño en los archivos o pérdida de datos.
- No desconecte el dispositivo USB mientras se esté cargando.
- MSC admite archivos MP3 y JPEG, mientras que un dispositivo PTP sólo admite archivos JPEG.
- Se admite el formato jpeg secuencial.
- Los archivos de fotos y de audio deben llevar un nombre en inglés, francés o español. De lo contrario, los archivos no se pueden reproducir. Si es necesario, póngales un nombre inglés, francés o español.
- Cuanto mayor sea la resolución de la imagen, más tiempo tardará en visualizarse en la pantalla.
- La resolución JPEG máxima admitida es 15360x8640 píxeles.
- Con archivos dañados o que no se admiten, se muestra el mensaje "Formato de archivo no admitido".

Uso de los botones del mando a distancia con el menú WISELINK

Botón	Función
Rueda (▲/▼/◀/▶)	Mover el cursor y seleccionar una opción
ENTER	Seleccionar la opción marcada. Durante una presentación o la reproducción de música: - Pulsando la botón ENTER durante la reproducción se hace una pausa en ésta. - Pulsando la botón ENTER durante la pausa se reanuda la reproducción.
▶ / II	Reproducir o interrumpir el archivo de visionado automático o de música.
RETURN	Volver al menú anterior.
TOOLS	Ejecutar diversas funciones desde los menús de fotos y música.
■	Detener el archivo de visionado automático o de música.
◀ / ▶	Saltar al grupo anterior/Saltar al grupo siguiente.
INFO	Mostrar información del archivo.
WLINK	Salir del modo WISELINK.
CH ▼/▲ PRE.CH / FAV.CH	Detener el modo WISELINK y volver al modo TV.
EXIT	Detener la función actual y volver al menú principal WISELINK.

Uso del menú WISELINK

- Pulse el botón **MENU**. Pulse los botones **▲** o **▼** para seleccionar "Aplicación", a continuación pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "WISELINK", a continuación pulse el botón **ENTER**.
 - Se muestra el menú "WISELINK".



④ Pulse el botón **W.LINK** del mando a distancia para mostrar el menú "WISELINK".

⑤ Pulse varias veces el botón **SOURCE** del mando a distancia para seleccionar "USB" y, a continuación, pulse el botón **ENTER**.

- Pulse el botón rojo y, a continuación, los botones **▲** o **▼** para seleccionar el correspondiente dispositivo de memoria USB (si está conectado a un concentrador). Pulse el botón **ENTER**.
 - Esta función puede variar según el dispositivo de memoria USB conectado al televisor.
 - El nombre del dispositivo USB seleccionado aparece en la parte inferior izquierda de la pantalla.
- Pulse los botones **◀** o **▶** para seleccionar un ícono (Photo, Music, Setup), a continuación, pulse el botón **ENTER**.
 - Para salir del modo "WISELINK", pulse el botón **W.LINK** en el mando a distancia.

Uso de la lista de fotos


Este menú muestra archivos de las fotos guardadas en un dispositivo de memoria USB.

Lista de fotos

- Pulse el botón **W.LINK** del mando a distancia para mostrar el menú "WISELINK".
- Pulse los botones **◀** o **▶** para seleccionar "Photo", a continuación pulse el botón **ENTER**.
 - Se muestran los archivos de fotos.
 - Este menú sólo muestra los archivos con extensión jpg. Los archivos con otro formato como bmp o tiff no se muestran.
 - Pulse el botón **▶** (Reproducir) / **ENTER** para iniciar Secuencia.
 - Para ir al grupo anterior/siguiente, pulse los botones **◀** (REW) o **▶** (FF).
 - Cuando se desplaza a una foto, la carga puede tardar varios segundos. En este punto, el icono de carga aparecerá en la pantalla.
 - La operación de cargar los archivos de fotos como imágenes en miniatura puede tardar algún tiempo.
 - Según la calidad y la resolución de la imagen, es posible que las fotos sin información EXIF no se muestren como imágenes en miniatura en la lista de PHOTO.



Pantalla de visualización



① Foto actualmente seleccionada

Muestra la foto actualmente seleccionada.

② Ventana de información de la foto

Muestra la información sobre la foto seleccionada. Se pueden cambiar "Color", "Composición" y "Favoritos".

③ Norma de clasificación actual

Pulse los botones ▲ o ▼ para cambiar la norma de clasificación de las fotos.
("Mensual", "Fecha", "Color", "Composición", "Carpeta", "Preferencias")

El elemento que se selecciona como norma de clasificación se resalta en la ventana de información de la foto.

④ Ver grupos

Muestra los grupos de clasificación. El grupo de clasificación que incluye la foto seleccionada se resalta.

⑤ Dispositivo actual

Muestra el nombre del dispositivo actualmente seleccionado. Pulse el botón rojo para seleccionar un dispositivo.

⑥ Información de selección del elemento

Muestra el número de fotos seleccionadas cuando se pulsa el botón amarillo.

⑦ Elementos de ayuda

- **Botón rojo (Dispositivo):** Selecciona un dispositivo conectado.
- **Botón verde (Conf fav):** Cambia la configuración de favorito del elemento seleccionado. Pulse este botón varias veces hasta que se muestre el valor que desee. (Consulte la página 68)
- **Botón amarillo (Selección):** Selecciona fotos en la lista de fotos. Las fotos seleccionadas se marcan con un símbolo ✓ situado a su izquierda.
- **Botón <>> (Saltar):** Salta al grupo de clasificación anterior/Salta al grupo de clasificación siguiente.
- **Botón TOOLS (Opción):** Muestra los menús "Secuencia", "Repr. grupo actual", "Borrar", "Cambiar info grupo" (en los grupos "Color" o "Composición"), "Información" o "Retirar con seg".

Clasificación de la lista de fotos

Se pueden clasificar las fotos de la lista según una norma particular.


1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀ o ▶** para seleccionar "Photo", a continuación pulse el botón **ENTER** .
3. Pulse los botones **▲ o ▼** para seleccionar una norma de clasificación. ("Mensual", "Fecha", "Color", "Composición", "Carpeta", "Preferencias")
 - Se muestran los archivos de fotos.
4. Pulse los botones **▲ o ▼** para seleccionar una norma de clasificación. ("Mensual", "Fecha", "Color", "Composición", "Carpeta", "Preferencias")
 - La fotos se clasifican según la nueva norma de clasificación seleccionada.
5. Pulse el botón **ENTER**  para iniciar la presentación en el orden elegido.
 - Wiselink identifica el color y la composición de las imágenes y las agrupa en consecuencia analizando las imágenes del dispositivo USB.
 - La información de "Composición" y "Color" extraída del archivo de foto puede diferir de la que el usuario ha seleccionado.
 - La información de la foto se establece automáticamente. Se pueden cambiar "Color", "Composición" y "Favoritos".
 - Las fotos cuya información no se puede mostrar se establecen como "Sin clasificar".
 - PTP no admite el modo de clasificación de la carpeta.



Mensual

Ordena las fotos por meses.

- Ordena y muestra las fotos del archivo por mes. Ordena sólo por mes (de enero a diciembre) sin tener en cuenta el año.
1. Seleccione "Mensual" como orden estándar de la lista de fotos.
 2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por mes.
 - Para ir al grupo anterior/siguiente, pulse los botones  (REW) o  (FF).
 3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER**  para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.



Fecha

Ordena las fotos por fecha.

- Ordena y muestra las fotos por fechas. Ordena por años y meses empezando por las más antiguas.
1. Seleccione "Fecha" como orden estándar de la lista de fotos.
 2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por cronología.
 - Para ir al grupo anterior/siguiente, pulse los botones  (REW) o  (FF).
 3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER**  para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.



Color

Ordena las fotos por color.

- Se puede cambiar la información del color de la foto.
1. Seleccione "Color" como orden estándar de la lista de fotos.
 2. Pulse los botones **◀** o **▶** para seleccionar en la lista secundaria de archivos agrupados por color.
 - Para ir al grupo anterior/siguiente, pulse los botones **◀◀** (REW) o **▶▶** (FF).
 3. Pulse el botón **TOOLS**. Pulse los botones **▲** o **▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER** para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.



Cambio de la información del color


1. Seleccione "Color" como norma de clasificación en la lista de fotos y pulse los botones **◀** o **▶** para seleccionar una foto.
 - **Cambio de la información de varios archivos**
Pulse los botones **◀** o **▶** para seleccionar la foto que deseé en la lista. A continuación pulse el botón amarillo.
Repita el proceso anterior para seleccionar varias fotos.
La **✓** marca aparece a la izquierda de la foto seleccionada.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲** o **▼** para seleccionar "Cambiar info grupo". Pulse el botón **ENTER** .
4. Pulse los botones **◀** o **▶** para seleccionar la opción que deseé y, a continuación, pulse el botón **ENTER** .
 - La información de grupo del archivo actual se actualiza y el archivo se desplaza al nuevo grupo.
 - Opciones de "Color": Rojo, Amarillo, Verde, Azul, Magenta, Negro, Gris, Sin clasificar.



Composición

Ordena las fotos por composición.

- Se puede cambiar la información de la composición de la foto.
1. Seleccione "Composición" como orden estándar de la lista de fotos.
 2. Pulse los botones **◀** o **▶** para seleccionar en la lista secundaria de archivos agrupados por composición
 - Para ir al grupo anterior/siguiente, pulse los botones **◀◀** (REW) o **▶▶** (FF).
 3. Pulse el botón **TOOLS**. Pulse los botones **▲** o **▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER** para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.



Cambio de la información de la composición

1. Seleccione "Composición" como norma de clasificación en la lista de fotos y pulse los botones **◀** o **▶** para seleccionar una foto.
 - **Cambio de la información de varios archivos**
Pulse los botones **◀** o **▶** para seleccionar la foto que deseé en la lista. A continuación pulse el botón amarillo.
Repita el proceso anterior para seleccionar varias fotos.
La **✓** marca aparece a la izquierda de la foto seleccionada.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲** o **▼** para seleccionar "Cambiar info grupo". Pulse el botón **ENTER** .
4. Pulse los botones **◀** o **▶** para seleccionar la opción que deseé y, a continuación, pulse el botón **ENTER** .
 - La información de grupo del archivo actual se actualiza y el archivo se desplaza al nuevo grupo.
 - Información de la "Composición": **≡** (horizontal), **☰** (vertical), **▣** (objeto), **■■■** (perspectiva), **■■■■** (patrón), Sin clasificar



Carpeta

Ordena las fotos por carpetas.

- Si hay varias carpetas en USB, los archivos de fotos se muestran ordenados en cada carpeta. El archivo de fotos de la carpeta raíz se muestra primero y los otros se muestran ordenados alfabéticamente por nombre.

1. Seleccione "Carpeta" como orden estándar de la lista de fotos.
2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por carpeta.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀]** (REW) o **[▶]** (FF).
3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
4. Pulse **ENTER** **[■]** para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.



Preferencias

Ordena las fotos por preferencias. (Favoritos)

- Se puede cambiar las preferencias de la foto.

1. Seleccione "Preferencias" como orden estándar de la lista de fotos.
2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por preferencias.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀]** (REW) o **[▶]** (FF).
3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
4. Pulse **ENTER** **[■]** para reproducir el grupo seleccionado de los archivos de fotos de la lista secundaria.

Cambio de la configuración de favorito

1. Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista.
 - **Cambio de la información de varios archivos**
Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista. A continuación pulse el botón amarillo.
Repita el proceso anterior para seleccionar varias fotos.
La **✓** marca aparece a la izquierda de la foto seleccionada.
2. Pulse varias veces el botón verde hasta que aparezca el valor de configuración que deseé.
 - Se ha completado el cambio de la configuración de los favoritos.
 - Opciones de "Favoritos": **★★★**, **★★★**, **★★★**, **★★★**
 - Los usuarios pueden seleccionar el número de estrellas (hasta 3) de acuerdo con sus preferencias.



Eliminación de archivos de fotos

1. Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Borrar" y, a continuación, pulse el botón **ENTER**.
- > Aparece el mensaje "¿Borrar arch. sel.?".
4. Pulse los botones **◀ o ▶** para seleccionar "Aceptar" y, a continuación, pulse el botón **ENTER**.
- > La foto se borra.
- > Cuando se borra un archivo de solo lectura, aparece el mensaje "Archivo(s) de sólo lectura. ¿Borrarlo(s)?".
- > Si selecciona "Cancelar", se cancela la operación de borrar.
5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.
- > No se pueden eliminar archivos de imágenes de una cámara digital conectada vía PTP.
- > Mientras se borran los archivos, no retire el dispositivo de memoria USB.
- > No se puede restaurar un archivo de fotos suprimido.



Supresión de varias fotos

1. Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista. A continuación pulse el botón amarillo.
- > Repita el proceso anterior para seleccionar varias fotos.
- > La **✓** marca aparece a la izquierda de la foto seleccionada.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Borrar archivo sel." y, a continuación, pulse el botón **ENTER**.
- > Aparece el mensaje "¿Borrar los archivos seleccionados?".
4. Pulse los botones **▲ o ▼** para seleccionar "Aceptar" y, a continuación, pulse el botón **ENTER**.
- > Las fotos seleccionadas se borran.
- > Si selecciona "Cancelar", se cancela la operación de borrar.
5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.
- > No se pueden borrar los archivos de solo lectura.
- > No se puede restaurar un archivo de fotos suprimido.



Visualización de la información de las fotos

Se muestra la información del archivo de fotografía, incluidos el orden del archivo en el directorio actual, el nombre, el tamaño, la resolución, la fecha de modificación y la ruta.

1. Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Información" y, a continuación, pulse el botón **ENTER**.
- > Aparece la información de la foto seleccionada.




Pulse el botón **INFO** para ver la información.

Visualización de una foto o una presentación

Visualización de una presentación

- Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
- Pulse los botones **◀** o **▶** para ir a "Photo", a continuación pulse el botón **ENTER**.
- Se muestran los archivos de fotos.
- Pulse los botones **◀** o **▶** para seleccionar la foto que desee en la lista.
- Pulse el botón **TOOLS**.
- Pulse los botones **▲** o **▼** para seleccionar "Secuencia", a continuación pulse el botón **ENTER**.
- En la presentación se usan todos los archivos de la lista de fotos.
- En la presentación, los archivos se muestran en orden a partir del archivo que se muestra en este momento.
- La presentación se ejecuta según el orden de la clasificación de la lista de fotos.
- Los archivos de música se pueden reproducir automáticamente durante la presentación si "Música de fondo" está en configurado como "Encendido". (Consulte la página 72)

■ Mientras se muestra la lista de fotos, pulse el botón **[▶]** (Reproducir) / **ENTER** del mando a distancia para iniciar la presentación.




Para ver una presentación sólo con los archivos seleccionados

- Pulse los botones **◀** o **▶** para seleccionar la foto que desee en la lista. A continuación pulse el botón amarillo. Repita el proceso anterior para seleccionar varias fotos.
 - La **✓** marca aparece a la izquierda de la foto seleccionada.
 - Si selecciona sólo un archivo, la presentación no se efectuará.
- Pulse el botón **[▶]** (Reproducir) / **ENTER**.
 - Los archivos seleccionados se usan en la presentación.
 - Si ha seleccionado varios archivos, sólo los archivos seleccionados se usarán en la presentación.

Reproducción Repr. grupo actual

- Pulse los botones **▲** o **▼** para seleccionar una norma de clasificación. ("Mensual", "Fecha", "Color", "Composición", "Carpetas", "Preferencias")
- Pulse los botones **◀** o **▶** para seleccionar la foto que desee en la lista.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀]** (REW) o **[▶]** (FF).
- Pulse el botón **TOOLS**.
- Pulse los botones **▲** o **▼** para seleccionar "Repr. grupo actual", a continuación pulse el botón **ENTER**. En la presentación se usan sólo las fotos del grupo de clasificación que incluye el archivo seleccionado.
- Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Icono de información de la función de presentación (Aparece en la parte superior izquierda de la pantalla)

Icono	Presentación en pantalla	Función
[▶]	(Foto) Presentación	Presentación de fotos en curso.
[II]	Pausa en la foto	Se puede hacer una pausa en la presentación pulsando los botones [■] (Pausa) / ENTER del mando a distancia. Para reanudar la presentación, pulse de nuevo los botones [▶] (Reproducir) / ENTER del mando a distancia.

Visualización de una foto

1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀ o ▶** para ir a "Photo", a continuación pulse el botón **ENTER** .
3. Pulse los botones **◀ o ▶** para seleccionar la foto que desee en la lista. A continuación pulse el botón amarillo para seleccionar sólo un archivo.
4. Pulse el botón **ENTER**  sobre el ícono de la foto.
5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Uso del menú de opciones durante una presentación (o la visualización de una foto)

1. Durante una presentación (o la visualización de una foto), pulse el botón **TOOLS** para establecer una opción.
2. Pulse los botones **▲ o ▼** para seleccionar la opción deseada. A continuación, pulse el botón **ENTER** .

Inicio o detención de una presentación

Se puede iniciar o detener una presentación. Pulse los botones **▲ o ▼** para seleccionar "Iniciar visionado automático" (o "Detener visionado automático"), a continuación, pulse el botón **ENTER** .




Giro de imágenes

Puede girar las imágenes en el modo de pantalla completa. Pulse los botones **▲ o ▼** para seleccionar "Girar", a continuación pulse el botón **ENTER** .

Pulse los botones **◀ o ▶** varias veces para girar la foto los grados deseados.

- Con cada pulsación del botón **◀**, la imagen gira 270°, 180°, 90° y 0°.
- Con cada pulsación del botón **▶**, la imagen gira 90°, 180°, 270° y 0°.
- Si ha seleccionado "Zoom", la función "Girar" está desactivada.
- El archivo girado no se guarda.
- El ícono de información de la función de giro aparece en la parte superior derecha de la pantalla.



Icono	Presentación en pantalla	Función
 0°	Giro (0°)	Para girar una imagen a su estado original.
 90°	Giro (90°)	Así gira una foto 90 grados
 180°	Giro (180°)	Así gira una foto 180 grados
 270°	Giro (270°)	Así gira una foto 270 grados



Ampliación de una imagen

Puede ampliar las imágenes en el modo de pantalla completa. Pulse los botones ▲ o ▼ para seleccionar "Zoom", a continuación pulse el botón **ENTER** . Pulse los botones ◀ o ▶ para disminuir o aumentar el efecto de la ampliación. (x1 → x2 → x4)

Para mover una foto ampliada, pulse el botón **ENTER** y a continuación los botones ▲/▼/◀/▶.

- Tenga en cuenta que si una imagen ampliada es menor que el tamaño de la pantalla original, la función de cambio de ubicación no está operativa.
- El archivo ampliado no se guarda.
- Si ha seleccionado "Girar", la función "Zoom" no está activa.
- El ícono de información de la función de ampliación aparece en la parte superior derecha de la pantalla.

Icono	Presentación en pantalla	Función
	Ampliación (x 2):	Ampliación de una foto dos veces.
	Ampliación (x 4)	Ampliación de una foto cuatro veces.
	Ampliación (x 1)	Restablece una foto a su tamaño original.
	Panorámica abajo	Desplaza el encuadre hacia abajo para ver la parte inferior de una foto ampliada.
	Panorámica arriba	Desplaza el encuadre hacia arriba para ver la parte superior de una foto ampliada.
	Panorámica derecha	Desplaza el encuadre hacia la derecha para ver la parte derecha de una foto ampliada.
	Panorámica izquierda	Desplaza el encuadre hacia la izquierda para ver la parte izquierda de una foto ampliada.



Velocidad de presentación

Se puede seleccionar la velocidad de la presentación.

Pulse los botones ▲ o ▼ para seleccionar "Velocidad visionado automático".

Pulse los botones ◀ o ▶ para seleccionar la opción deseada.

(Rápido → Lento → Normal)

- Sólo durante la presentación se puede seleccionar la velocidad de ésta.



Música de fondo


Si configura Música de fondo como Encendido, la música de fondo se reproducirá cuando se vean las fotos una a una o en una presentación.

Pulse los botones ▲ o ▼ para seleccionar "Música de fondo".

Pulse los botones ◀ o ▶ para seleccionar "Encendido" o "Apagado".

- Si se configura "Música de fondo" como Encendido, se abre inmediatamente una pantalla donde se puede ajustar la música de fondo.

- **Encendido:** Cuando la música de fondo está disponible, si selecciona Encendido, la música se reproducirá. Para usar esta función, en el dispositivo USB debe haber archivos de música y fotos almacenados.
- **Apagado:** La música de fondo no se reproduce.






Configuración de la música de fondo

Se puede configurar la música de fondo.

Pulse los botones ▲ o ▼ para seleccionar "Configuración de la música de fondo" y, a continuación, pulse el botón **ENTER**.

- Si "Música de fondo" está configurado como Apagado, aunque se haya configurado "Configuración de la música de fondo", la música no se reproducirá.
- Se necesitan cargar los archivos de música para cambiar el modo BGM. Reproduzca los archivos de música en la categoría de música para cargar.
- **Se muestra el menú "Configuración de la música de fondo".**
Pulse los botones ▲ o ▼ para seleccionar el modo BGM (música de fondo) deseado. (Mezcla, Arch. Sel., Ánimo)
 - **Mezcla:** Todos los archivos de música se reproducen aleatoriamente.
 - **Arch. Sel.:** Reproduce un archivo de música seleccionado.
 - **Ánimo:** Sólo se reproducen los archivos de música del estado de ánimo seleccionado.



- **Selección de un archivo de música de fondo**
Pulse los botones ▲ o ▼ para configurar el "Modo BGM" como "Arch. Sel.". Pulse los botones ▲ o ▼ para seleccionar "Seleccionar archivo de música", a continuación pulse el botón **ENTER**.
Pulse los botones ▲ o ▼ para seleccionar el archivo de música que desee y pulse el botón amarillo.
La ✓ marca aparece a la izquierda de la música seleccionada.
Repita el proceso anterior para seleccionar varios archivos de música.
Pulse el botón **ENTER**.

- **Selección de un estado de ánimo de un archivo de música de fondo**
Pulse los botones ▲ o ▼ para configurar el "Modo BGM" como "Ánimo".
Pulse los botones ▲ o ▼ para seleccionar "Estado anímico BGM". Pulse los botones ▲ o ▼ para seleccionar el modo de estado de ánimo BGM deseado. Pulse el botón **ENTER**.
Opciones del modo BGM: Dinámico, Rítmico, Triste, Excitante, Tranquilo
- WISELINK identifica el estado de ánimo de los archivos de música y los agrupa en consecuencia analizando los archivos de música del dispositivo USB.

Imagen Modo

Se puede configurar el Imagen Modo. (Consulte la página 20)

Modo de sonido

Se puede configurar el modo de sonido. (Consulte la página 31)

Extracción segura

Se puede quitar el dispositivo del televisor con seguridad.

Pulse los botones ▲ o ▼ para seleccionar "Retirar con seg.", a continuación pulse el botón **ENTER**.


Se muestra el mensaje "Retirando el dispositivo USB con seguridad." y aparece el mensaje "El dispositivo USB puede ser retirado ahora con seguridad del TV."

Retire el dispositivo USB del televisor.

Uso de la lista de música

El menú muestra los archivos MP3 que se encuentran entre los archivos guardados en un dispositivo de memoria USB.

- Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".



- Pulse los botones **◀** o **▶** para seleccionar "Music", a continuación pulse el botón **ENTER**.
- Se muestran los archivos de música.
- Pulse el botón **▶** (Reproducir) / **ENTER** sobre el ícono de la música para reproducir ésta.
- Para ir al grupo anterior/siguiente, pulse los botones **◀◀** (REW) o **▶▶** (FF).



Screen Display



① Música actualmente seleccionada

Muestra la música actualmente seleccionada.

② Norma de clasificación actual

Pulse los botones **▲** o **▼** para cambiar la norma de clasificación de los archivos de música. ("Título", "Artista", "Animo", "Género", "Carpeta", "Preferencias")

③ Ver grupos

Muestra los grupos de clasificación. El grupo de clasificación que incluye el archivo de música seleccionado se resalta.

④ Dispositivo actual

Muestra el nombre del dispositivo actualmente seleccionado. Pulse el botón rojo para seleccionar un dispositivo.



⑤ Información de selección del elemento

Muestra el número de archivos de música seleccionados cuando se pulsa el botón amarillo.


⑥ Elementos de ayuda

- Botón rojo (Dispositivo):** Selecciona el dispositivo conectado.
- Botón verde (Conf fav):** Cambia la configuración de favorito de la música seleccionada. Pulse este botón varias veces hasta que se muestre el valor que desee. (Consulte la página 77)
- Botón amarillo (Selección):** Selecciona archivos de música en la lista. Los archivos de música seleccionados se marcan con el símbolo ✓ situado a su izquierda.
- Botón <>> (Saltar):** Salta al grupo de clasificación anterior/Salta al grupo de clasificación siguiente.
- Botón TOOLS (Opción):** Muestra los menús “Repr. grupo actual”, “Borrar”, “Cambiar info grupo” (en el grupo Ánimo), “Información” o “Retirar con seg”.

Clasificación de la lista de música

Se pueden clasificar los archivos de música de la lista según una norma particular.

- Pulse el botón **WLINK** del mando a distancia para mostrar el menú “WISELINK”.
- Pulse los botones ▲ o ▼ para seleccionar “Music”, a continuación pulse el botón **ENTER** .
➢ Se muestran los archivos de música.
- Pulse los botones ▲ o ▼ para seleccionar una norma de clasificación (“Título”, “Artista”, “Ánimo”, “Género”, “Carpeta”, “Preferencias”)
➢ Los archivos de música se clasifican según la nueva norma de clasificación seleccionada.
- Pulse el botón **ENTER** para iniciar la reproducción de música en el orden elegido.
➢ La información del archivo se establece automáticamente y se puede cambiar la información de favorito.
➢ Los archivos de música cuya información no se puede mostrar se establecen como “Sin clasificar”.
➢ Si no hay información del título de un archivo de música, se muestra el nombre del archivo.
➢ Si la información de Género, Artista, álbum o Año no está disponible, el elemento correspondiente se muestra vacío.



Título

Ordena los archivos de música por el título.

- Ordena los títulos de música en orden alfabético y muestra el archivo de música.
- 1. Seleccione “Título” como orden estándar de la lista de música.
- 2. Pulse los botones ▲ o ▼ para seleccionar en la lista secundaria de archivos agrupados alfabéticamente.
➢ Para ir al grupo anterior/siguiente, pulse los botones (REW) o (FF).
- 3. Pulse el botón **TOOLS**. Pulse los botones ▲ o ▼ para seleccionar “Repr. grupo actual”.
- 4. Pulse **ENTER** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.



Artista

Ordena los archivos de música por el artista.

- Ordena los archivos de música por artista y en orden alfabético.
1. Seleccione "Artista" como orden estándar de la lista de música.
 2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados alfabéticamente.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀] (REW)** o **[▶] (FF)**.
 3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER** **[□]** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.



Ánimo

Ordena los archivos de música por el estado de ánimo.

- Se puede cambiar la información del color del archivo de música.
1. Seleccione "Ánimo" como orden estándar de la lista de música.
 2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por ánimo.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀] (REW)** o **[▶] (FF)**.
 3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER** **[□]** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.



Cambio de la información del estado de ánimo

1. Seleccione "Ánimo" como norma de clasificación en la lista de música y pulse los botones **◀ o ▶** para seleccionar un archivo de música.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Cambiar info grupo". Pulse el botón **ENTER** **[□]**.
 - Wiselink identifica el estado de ánimo de los archivos de música y los agrupa en consecuencia analizando los archivos de música del dispositivo USB.
 - La información de "Ánimo" extraída del archivo de música no siempre coincide con la opción de ánimo. Por ejemplo, un archivo que usted considera "Dinámico" puede haber sido extraído en la opción de ánimo "Excitante".
4. Pulse los botones **◀ o ▶** para seleccionar la opción que desee y, a continuación, pulse el botón **ENTER** **[□]**.
 - La información de grupo del archivo actual se actualiza y el archivo se desplaza al nuevo grupo.
 - Opciones de "Ánimo": Dinámico, Rítmico, Triste, Excitante, Tranquilo, Sin clasificar



Género

Ordena los archivos de música por el género.

1. Seleccione "Género" como orden estándar de la lista de música.
2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por género.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀] (REW)** o **[▶] (FF)**.
3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
4. Pulse **ENTER** **[□]** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.



Carpeta

Ordena los archivos de música por carpetas.

- Si hay varias carpetas en USB, los archivos se muestran ordenados en cada carpeta. El archivo de música en la carpeta raíz se muestra primero y los otros se muestran ordenados alfabéticamente por nombre.

Orden de los archivos de música por carpeta

1. Seleccione "Carpeta" como orden estándar de la lista de música.
2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por carpeta.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀] (REW)** o **[▶] (FF)**.
3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
4. Pulse **ENTER** **[□]** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.




Preferencias

Ordena los archivos de música por las preferencias. (Favoritos)

- Se puede cambiar las preferencias de los archivos de música.
1. Seleccione "Preferencias" como orden estándar de la lista de música.
 2. Pulse los botones **◀ o ▶** para seleccionar en la lista secundaria de archivos agrupados por preferencias.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀] (REW)** o **[▶] (FF)**.
 3. Pulse el botón **TOOLS**. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual".
 4. Pulse **ENTER** **[□]** para reproducir el grupo seleccionado de los archivos de música de la lista secundaria.

Cambio de la configuración de favorito

1. Pulse los botones **◀ o ▶** para seleccionar la música que desee en la lista.
 - **Cambio de la información de varios archivos**
Pulse los botones **◀ o ▶** para seleccionar la música que desee en la lista. A continuación pulse el botón amarillo.
Repita el proceso anterior para seleccionar varios archivos de música.
La **✓** marca aparece a la izquierda de la música seleccionada.
2. Pulse varias veces el botón verde hasta que aparezca el valor de configuración que desee.
 - Se ha completado el cambio de la configuración de los favoritos.
 - Opciones de "Favoritos": **★★★**, **★★★**, **★★★**, **★★★**
 - Los usuarios pueden seleccionar el número de estrellas (hasta 3) de acuerdo con sus preferencias.
3. Pulse el botón **ENTER** **[□]** para iniciar la reproducción de música.



Supresión de archivos de música

1. Pulse los botones **◀ o ▶** para seleccionar el archivo de música que desee en la lista.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Borrar" y, a continuación, pulse el botón **ENTER**

 - Por ejemplo, aparece el mensaje "¿Borrar arch. sel.?"

4. Pulse los botones **◀ o ▶** para seleccionar "Aceptar", a continuación pulse el botón **ENTER**

 - La música se borra.
 - Cuando se borra un archivo de sólo lectura, aparece el mensaje "Archivo(s) de sólo lectura. ¿Borrarlo(s)?"
 - Si selecciona "Cancelar", se cancela la operación de borrar.

5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.
 - Mientras se borran los archivos, no retire el dispositivo de memoria USB.
 - No se puede restaurar los archivos de música suprimidos.



Eliminación de varios archivos de música

1. Pulse los botones **◀ o ▶** para seleccionar la música que desee en la lista. A continuación pulse el botón amarillo.
 - Repita el proceso anterior para seleccionar varios archivos de música.
 - La **✓** marca aparece a la izquierda de los archivos de música seleccionados.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Borrar archivo sel." y, a continuación, pulse el botón **ENTER**

 - Por ejemplo, aparece el mensaje "¿Borrar los archivos seleccionados?"

4. Pulse los botones **◀ o ▶** para seleccionar "Aceptar" y, a continuación, pulse el botón **ENTER**

 - Se borran los archivos de música seleccionados.
 - Si selecciona "Cancelar", se cancela la operación de borrar.

5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.
 - No se pueden borrar los archivos de sólo lectura.
 - No se pueden restaurar los archivos de música eliminados.



Visualización de la información

Se muestra la información del archivo de música, incluidos el orden del archivo en el directorio actual, el nombre, el tamaño, la fecha de modificación y la ruta.

1. Pulse los botones **◀ o ▶** para seleccionar la música que desee en la lista.
2. Pulse el botón **TOOLS**.
3. Pulse los botones **▲ o ▼** para seleccionar "Información" y, a continuación, pulse el botón **ENTER**

 - Aparece la información del archivo seleccionado.



Pulse el botón **INFO** para ver la información.



Reproducción de un archivo de música

Reproducción de un archivo de música

1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀ o ▶** para seleccionar "Music", a continuación pulse el botón **ENTER**.
3. Pulse el botón **◀ o ▶** para seleccionar la música que se desea reproducir y, a continuación, pulse el botón **ENTER**.
 - Se muestran los archivos de música.
3. Pulse el botón **◀ o ▶** para seleccionar la música que se desea reproducir y, a continuación, pulse el botón **ENTER**.
 - Este menú sólo muestra archivos con la extensión MP3. Los archivos con otras extensiones no se muestran, aunque se hayan guardado en el mismo dispositivo USB.
 - Pulse el botón **[▶]** (Reproducir) / **ENTER** sobre el icono de la música para reproducir ésta.
 - **[◀]** (REW) o **[▶]** (FF) no funcionan durante la reproducción.
 - Pulse los botones **[II]** (Pausa) / **ENTER** durante la reproducción del archivo de música para hacer una pausa en la reproducción. Pulse el botón **[■]** (Detener) para salir del modo de reproducción.
 - El archivo seleccionado se visualiza en la parte superior con su tiempo de reproducción.
 - Para ajustar el volumen de la música, pulse los botones **VOL - o VOL +** del mando a distancia. Para silenciar el sonido, pulse el botón **MUTE** del mando a distancia.
 - La duración de la reproducción de un archivo de música puede visualizarse como '00:00:00' si la información del tiempo de reproducción no se encuentra al inicio del archivo.
4. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Reproducción de un grupo de música

1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀ o ▶** para seleccionar "Music", a continuación pulse el botón **ENTER**.
 - Para ir al grupo anterior/siguiente, pulse los botones **[◀]** (REW) o **[▶]** (FF).
3. Pulse los botones **◀ o ▶** para seleccionar el archivo de música que deseé.
4. Pulse el botón **TOOLS**.
5. Pulse los botones **▲ o ▼** para seleccionar "Repr. grupo actual", a continuación pulse el botón **ENTER**.
 - Se reproducen los archivos de música incluidos en el archivo seleccionado.
6. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Reproducción de archivos de música seleccionados

1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀** o **▶** para seleccionar "Music", a continuación pulse el botón **ENTER**.
3. Pulse los botones **◀** o **▶** para seleccionar el archivo de música que desee y, a continuación, pulse el botón amarillo. Repita el proceso anterior para seleccionar varios archivos de música.
 - La **✓** marca aparece a la izquierda del archivo de música seleccionado.
4. Pulse el botón **▶** (Reproducir) / **ENTER**.
 - Sólo se reproduce el archivo seleccionado.
 - Pulse el botón **■** (Parar) durante la reproducción para detener el elemento actual y volver a la lista de música.
5. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Icono de información de la función de la música (aparece en la parte superior izquierda de la pantalla)

Icono	Presentación en pantalla	Función
⟳	(Música) Repetir	Cuando todos los archivos de música de la carpeta (o el archivo seleccionado) se repiten. "Modo rep." está configurado como "Encendido".
⟲	(Música) Una vez	Cuando todos los archivos de música de la carpeta (o el archivo seleccionado) se reproducen una vez. "Modo rep." está configurado como "Apagado".
▶ / II	(Música) Reproducir/ Pausa	Cuando se pulsa el botón ▶ (Reproducir)/ ■ (Pausa)/ ENTER del mando a distancia mientras se está reproduciendo música.

Repetición de la reproducción de música

1. Durante la reproducción del archivo de música, pulse el botón **TOOLS**.
2. Pulse los botones **▲** o **▼** para seleccionar "Modo rep.".
3. Pulse los botones **◀** o **▶** para seleccionar "Encendido" o "Apagado".
 - **Encendido:** Reproduce todos los archivos de música de la carpeta (o el archivo seleccionado) repetidamente.
 - **Apagado:** Cancela la reproducción repetitiva.
4. Para salir del modo "WISELINK", pulse el botón **WLINK** en el mando a distancia.



Uso del menú de configuración

El menú de configuración muestra al usuario la configuración del menú "WISELINK".

1. Pulse el botón **WLINK** del mando a distancia para mostrar el menú "WISELINK".
2. Pulse los botones **◀ o ▶** para seleccionar "Setup", a continuación pulse el botón **ENTER**.
3. Pulse los botones **▲ o ▼** para seleccionar la opción deseada.
(Velocidad visionado automático, Música Modo de repetición, Tiemp ejec. protect.pant., Información, Retirar con seg)
4. Pulse los botones **◀ o ▶** para seleccionar la opción que desee y, a continuación, pulse el botón **ENTER**.




Velocidad de presentación

Puede seleccionar la velocidad de la presentación.

Pulse los botones **▲ o ▼** para seleccionar "Velocidad visionado automático".

Pulse los botones **◀ o ▶** para seleccionar "Rápido", "Normal" o "Lento".




Música Modo de repetición

Puede seleccionar que los archivos de música se repitan continuamente.

Pulse los botones **▲ o ▼** para seleccionar "Música Modo de repetición".

Pulse los botones **◀ o ▶** para seleccionar "Encendido" o "Apagado".




Tiempo de ejecución del salvapantallas

Puede configurar el tiempo de espera necesario para que se ejecute el salvapantallas.

Pulse los botones **▲ o ▼** para seleccionar "Tiemp ejec. protect.pant.".

Pulse los botones **◀ o ▶** para seleccionar "1 min", "3 min" o "5 min".



Información

Puede configurar que se muestre la información del dispositivo conectado.

Pulse los botones **▲ o ▼** para seleccionar "Información", a continuación pulse el botón **ENTER**.

Info dispos.	
T. disposit.	: USB
Dispositivo	: SUM
Memoria disp.	: 852.90MB
Memoria total	: 995.00MB

Aceptar

Extracción segura

Se puede quitar el dispositivo del televisor con seguridad. (Consulte la página 73)


Para salir del modo WISELINK, pulse el botón **WLINK** en el mando a distancia.

Configuración de la red e InfoLink


Configuración de la conexión de red (DHCP) y automática

A continuación se describe el procedimiento para configurar la red mediante el protocolo de configuración dinámica de host (DHCP). Dado que la dirección IP, la máscara de subred, la puerta de enlace y el DNS se asignan automáticamente cuando se selecciona DHCP, no es necesario introducirlos manualmente.

Conexión LAN para un entorno DHCP



1. Conecte el puerto [LAN] del panel posterior del televisor y el módem externo con un cable LAN.
2. Conecte el puerto [LAN] de la pared y el módem externo con un cable de módem.




- Los terminales (la posición del puerto y el tipo) del dispositivo externo pueden variar según el fabricante.
- Si falla la asignación de la dirección IP por el servidor DHCP, apague el módem externo, vuelva a encenderlo al menos después de 10 segundos e inténtelo de nuevo.
- Para las conexiones entre el módem externo y el compartidor (enrutador), consulte el manual del usuario del producto correspondiente.
- Se puede conectar el televisor a la LAN directamente sin usar compartidor (enrutador).
- No se puede usar un módem ADSL de tipo de conexión manual ya que no admite DHCP. Se debe usar un módem ADSL de tipo de conexión automática.

Configuración de red automática

Si conecta un cable LAN en una ubicación que admite DHCP, el protocolo de Internet (IP) se configura automáticamente.


- Antes, debe comprobar si hay un cable LAN conectado.

- 1. Pulse el botón MENU para mostrar el menú.**
Pulse los botones ▲ o ▼ para seleccionar “Configuración” y, a continuación, pulse el botón ENTER .
- 2. Pulse los botones ▲ o ▼ para seleccionar “Configuración de red” y, a continuación, pulse el botón ENTER .**



- 3. Pulse el botón ENTER  para seleccionar “Configuración del protocolo de Internet”.**
 - 4. Pulse los botones ▲ o ▼ para seleccionar “Configuración automática” y, a continuación, pulse el botón ENTER .**
- El protocolo de Internet se configura automáticamente.
- Seleccione “Prueba de red” para comprobar la conectividad de la red.
(Consulte la página 86)


Pulse el botón EXIT para salir.




Configuración de la conexión de red (IP estático) y manual

A continuación se describe el procedimiento para configurar la red con una dirección IP estática. Se debe introducir manualmente la dirección IP, la máscara de subred, la puerta de enlace y el DNS proporcionados por el proveedor de servicios de Internet (ISP).

Conexión LAN para un entorno IP estático



1. Conecte el puerto [LAN] del panel posterior del televisor y el puerto LAN de la pared con un cable LAN.




- Los terminales (la posición del puerto y el tipo) del dispositivo externo puede variar según el fabricante.
- Si usa una dirección IP estática, su ISP le informará de la dirección IP, la máscara de subred, la puerta de enlace y el DNS. Debe introducir estos valores para completar la configuración de la red. Si no los conoce, consulte a su administrador de la red.
- Para obtener información sobre cómo configurar y conectar un compartidor (enrutador), consulte el manual del usuario del producto correspondiente.
- Se puede conectar el televisor a la LAN directamente sin usar compartidor (enrutador).
- Si usa un compartidor IP (enrutador IP) que admite DHCP, se puede configurar el dispositivo como DHCP o IP estático.
- Para saber cómo usar una dirección IP estática, consulte a su proveedor de servicios de Internet.

Configuración de red manual


Para conectar el televisor a una LAN mediante una dirección IP estática, se debe configurar el protocolo de Internet (IP).

- Antes, debe comprobar si hay un cable LAN conectado. (Consulte la página 84.)

1. Pulse el botón **MENU** para mostrar el menú.
Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER**.
2. Pulse los botones **▲** o **▼** para seleccionar "Configuración de red" y, a continuación, pulse el botón **ENTER**.




3. Pulse el botón **ENTER** para seleccionar "Configuración del protocolo de Internet".
4. Pulse los botones **▲** o **▼** para seleccionar "Configuración manual" y, a continuación, pulse el botón **ENTER**.



5. Pulse los botones **▲**, **▼**, **◀** o **▶** para desplazarse a un elemento y pulse el botón numérico para configurar el elemento seleccionado. Pulse el botón **ENTER**.
➤ Seleccione "Prueba de red" para comprobar la conectividad de la red.
(Consulte la página 86)


Pulse el botón **EXIT** para salir.



Prueba de red

Puede comprobar o confirmar el estado de conexión de la red después de configurar la red.

1. Pulse el botón MENU para mostrar el menú.
Pulse los botones ▲ o ▼ para seleccionar "Configuración" y, a continuación, pulse el botón ENTER ▶.
2. Pulse los botones ▲ o ▼ para seleccionar "Configuración de red" y, a continuación, pulse el botón ENTER ▶.



3. Pulse los botones ▲ o ▼ para seleccionar "Prueba de red" y, a continuación, pulse el botón ENTER ▶.
 - Se muestra la configuración de red actual.




Uso de InfoLink

Puede ver servicios de noticias, bursátiles y meteorológicos con el servicio InfoLink de Samsung.


- Configure la red. (Consulte las páginas 83, 85)

Activación de InfoLink

1. Pulse el botón **MENU** para mostrar el menú.
Pulse los botones **▲** o **▼** para seleccionar "Aplicacion" y, a continuación, pulse el botón **ENTER** .
 2. Pulse los botones **▲** o **▼** para seleccionar "InfoLink" y pulse el botón **ENTER** .
 3. Pulse los botones **◀** o **▶** para seleccionar un servicio ("Tiempo", "Noticias", "Valores" o "Configuración") y pulse el botón **ENTER** .
- Puede seleccionar y ver más de un servicio al mismo tiempo sólo en 'Noticias (sin información detallada)', 'Tiempo-Tiempo para hoy' y 'Valores-Valores favoritos, Sumario de mercado'.
- Pulse el botón **EXIT** para salir.



- ④ Pulse el botón **INFO.L** del mando a distancia para mostrar el menú "InfoLink".





Uso del servicio meteorológico

1. Pulse el botón **INFO.L** del mando a distancia.
2. Pulse los botones **◀ o ▶** para acceder al servicio “Tiempo” y pulse el botón **ENTER** .

Ajuste de la región.

3. Pulse el botón amarillo. Escriba el código postal de la región con los botones numéricos del mando a distancia y pulse el botón **ENTER** .

 - Podrá consultar el tiempo de la región seleccionada.
 - Si selecciona el servicio “Tiempo” y la región no está configurada, verá un mensaje que le solicita si desea configurar la región. Si selecciona “Sí” con los botones **◀ o ▶** verá una pantalla donde podrá configurar el código postal.



Configuración de la opción “Tiempo”

4. Pulse el botón rojo mientras usa el servicio para cambiar la opción del servicio “Tiempo”.
5. Pulse los botones **▲ o ▼**, seleccione la opción del servicio “Tiempo” y, a continuación, pulse el botón **ENTER** .

 - Para salir del servicio “Tiempo” pulse el botón azul.
 - Para salir del servicio “InfoLink” pulse el botón **EXIT**.



Uso del servicio de noticias

1. Pulse el botón **INFO.L** del mando a distancia.
2. Pulse los botones **◀ o ▶** para acceder al servicio “Noticias” y pulse el botón **ENTER** .

 - Pulse el botón **ENTER**  para ver un artículo.
 - Pulse los botones **◀ o ▶** para ver el artículo anterior o siguiente.



3. Pulse el botón rojo mientras usa el servicio para cambiar la opción del servicio “Noticias”.
4. Pulse los botones **▲ o ▼**, seleccione una opción del servicio “Noticias” y, a continuación, pulse el botón **ENTER** .

 - La opción del servicio Noticias cambia de acuerdo con el servicio Web proporcionado.
 - Para salir del servicio “Noticias” pulse el botón azul.
 - Para salir del servicio “InfoLink” pulse el botón **EXIT**.



Uso del servicio bursátil

- Pulse el botón INFO.L del mando a distancia.
- Pulse los botones ▲ o ▼ para acceder al servicio “Valores” y pulse el botón ENTER .



- Pulse el botón rojo mientras usa el servicio para cambiar la opción del servicio “Valores”.
- Pulse los botones ▲ o ▼, seleccione la opción del servicio “Valores” y, a continuación, pulse el botón ENTER .


- **Valores favoritos:** Se muestra la información de los mercados bursátiles favoritos. Puede configurar los mercados favoritos pulsando el botón amarillo.
- **Sumário de mercado:** Se cambia entre los índices Dow Jones, Nasdaq y S&P 500 y se muestra el índice completo, el total de subidas y bajadas y el %.
- **Valores y noticias:** Se muestra la información de los mercados favoritos, los índices Dow Jones, NASDAQ y S&P 500 y las noticias financieras.



- > Cotizaciones bursátiles demoradas al menos 15 minutos.
- > Para salir del servicio “Valores” pulse el botón azul.
- > Para salir del servicio “InfoLink” pulse el botón EXIT.

Configuración de los elementos bursátiles favoritos

- Pulse el botón amarillo con “Valores favoritos” o “Valores y noticias” seleccionados. Aparece la pantalla para configurar los mercados bursátiles favoritos.
- Pulse los botones ▲ para desplazarse por las categorías. Pulse los botones ▲ o ▼ para seleccionar una categoría. Pulse el botón ENTER .
- Pulse los botones ▲ o ▼ para seleccionar una opción y pulse el botón ENTER .
- > El mercado seleccionado se establece como favorito.
- > La marca aparece a la izquierda del nombre del mercado.
- > Pulse el botón ENTER  de nuevo para cancelar la configuración. Desaparece la marca .
- > Para cancelar todas las selecciones pulse el botón verde.
- > Si se pulsa el botón rojo se cambia entre NYSE y NASDAQ.
- Para finalizar la configuración pulse el botón RETURN.




Configuración de InfoLink

1. Pulse el botón INFO.L del mando a distancia.
2. Pulse los botones ▲ o ▼ para seleccionar "Configuración" y, a continuación, pulse el botón ENTER ↴.


3. Pulse los botones ▲ o ▼ para seleccionar la opción deseada. ("Arranque automático", "Tiempo visualización", "Tamaño fuente", "Color de fondo", "Posición de InfoLink")
4. Pulse los botones ▲ o ▼ para seleccionar una opción y pulse el botón ENTER ↴

- **Arranque automático:** Establece si se debe ejecutar InfoLink automáticamente al encender el televisor. Puede seleccionar "Apagado" o "Encendido".
- **Tiempo visualización:** Establece el tiempo de visualización del servicio de noticias en la pantalla del televisor. Puede seleccionar "4 Horas", "8 Horas", "10 Horas", o "Siempre".
- **Tamaño fuente:** Puede seleccionar el tamaño de los caracteres ("Normal" o "Grande") del servicio InfoLink .
- **Color de fondo:** Puede seleccionar el color de fondo del servicio InfoLink. El color se aplica a cada ventana del servicio, de la opción y de la configuración.
- **Posición de InfoLink:** Se puede configurar la posición del servicio InfoLink en la pantalla. Se pueden seleccionar seis posiciones preseleccionadas de InfoLink ("Posición 1" ~"Posición 6").


- Para salir del servicio "Configuración" pulse el botón RETURN.
➤ Para salir del servicio "InfoLink" pulse el botón EXIT.




Posición de InfoLink



Posición 1



Posición 2



Posición 3



Posición 4



Posición 5



Posición 6

Acerca de Anynet+


¿Qué es Anynet+?

Anynet+ es una función que permite controlar todos los dispositivos de Samsung conectados que sean compatibles con Anynet+ con el mando a distancia del televisor Samsung.

Conexión de dispositivos Anynet+


El sistema Anynet+ sólo se puede usar con dispositivos de Samsung que tengan la función Anynet+. Para asegurarse de que el dispositivo de Samsung tenga dicha función, compruebe si lleva el logotipo Anynet+.

Para conectar al televisor



Conecte las tomas HDMI 1], [HDMI 2], [HDMI 3] o [HDMI 4] del televisor y la toma HDMI OUT del dispositivo Anynet+ correspondiente mediante el cable HDMI.

Para conectar al sistema de cine en casa



1. Conecte las tomas [HDMI 1], [HDMI 2], [HDMI 3] o [HDMI 4] del televisor y la toma HDMI OUT del dispositivo Anynet+ correspondiente mediante el cable HDMI.

2. Conecte la toma HDMI IN del sistema cine en casa y la toma HDMI OUT del dispositivo Anynet+ correspondiente mediante el cable HDMI.

- Conecte el cable óptico entre la toma Digital Audio Out (Optical) del televisor y la toma Digital Audio Entrada del sistema de cine en casa.
- Si se sigue la conexión anterior, la toma Optical sólo produce la salida de 2 canales de audio. Sólo oirá sonido de los altavoces frontales izquierdo y derecho y el subwoofer del sistema de cine en casa. Para escuchar el canal de audio 5.1, conecte la toma DIGITAL AUDIO OUT (OPTICAL) del reproductor de DVD o del decodificador de cable/satélite (dispositivo Anynet 1 o 2) directamente a un amplificador o un sistema de cine en casa no al televisor.
- Conecte sólo un sistema de cine en casa.
- Puede conectar un dispositivo Anynet+ mediante el cable HDMI 1.3. Algunos cables HDMI pueden no admitir las funciones Anynet+.
- Anynet+ funciona cuando el dispositivo de AV que admite Anynet+ se encuentra en estado de espera o de encendido.
- Anynet+ admite hasta 12 dispositivos de AV en total. Tenga en cuenta que puede conectar hasta 3 dispositivos del mismo tipo.

Configuración de Anynet+

Los parámetros siguientes le ayudarán a usar las funciones Anynet+.


Para usar la función Anynet+, Anynet+ (HDMI-CEC) debe estar configurado como Enc.

- Pulse el botón **MENU**. Pulse los botones **▲** o **▼** para seleccionar "Aplicacion", y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Anynet+ (HDMI-CEC)" y, a continuación, pulse el botón **ENTER**.
- Pulse el botón **ENTER** para seleccionar "Anynet+ (HDMI-CEC)".
- Pulse los botones **▲** o **▼** para seleccionar "Encendido" y, a continuación, pulse el botón **ENTER**.
 - La función "Anynet+ (HDMI-CEC)" está activada.
 - Si selecciona "Apagado", "Anynet+ (HDMI-CEC)" se desactiva.
 - Cuando la función "Anynet+ (HDMI-CEC)" está desactivada, todas las operaciones relacionadas con Anynet+ se desactivan.



Configuración de un dispositivo Anynet+ para que se desactive automáticamente cuando el televisor se apaga

- Pulse los botones **▲** o **▼** para seleccionar "Apagado Automático" y, a continuación, pulse el botón **ENTER**.
- Pulse los botones **▲** o **▼** para seleccionar "Sí" y, a continuación, pulse el botón **ENTER**.
 - La función "Apagado Automático" se activa.
 - Si selecciona "Sí" se cancela la función de "Apagado Automático".Pulse el botón **EXIT** para salir.
 - La fuente activa del televisor remoto se debe configurar como TV para usar la función Anynet+.
 - Si establece "Apagado Automático" en "Sí", los dispositivos externos conectados también se desactivan cuando se apaga el televisor. Sin embargo, si el dispositivo está grabando es posible que no se apague.



Búsqueda y cambio de dispositivos Anynet+

1. Pulse el botón **TOOLS**.

Pulse los botones **▲** o **▼** para seleccionar "Lista Disp." y, a continuación, pulse el botón **ENTER**.

- Se muestran todos los dispositivos Anynet+ conectados al televisor.
- Si no encuentra el dispositivo que desea, pulse el botón rojo para buscar los dispositivos.

2. Pulse los botones **▲** o **▼** para seleccionar el dispositivo que deseé y pulse el botón **ENTER**. Se cambia al dispositivo seleccionado.

El menú "Lista Disp." sólo aparece si la opción "Anynet+ (HDMI-CEC)" del menú "Aplicacion" está configurada como "Encendido".

- El cambio a los dispositivos seleccionados puede tardar unos 2 minutos. No se puede cancelar la operación de cambio de dispositivo mientras ésta se está efectuando.
- El tiempo necesario para la búsqueda de dispositivos depende de la cantidad de dispositivos conectados.
- Cuando finaliza la búsqueda de dispositivos, no se muestra el número de dispositivos encontrados.
- Aunque el televisor explora automáticamente los dispositivos cuando se enciende con el botón **POWER**, los dispositivos conectados cuando el televisor ya está encendido no aparecen en la lista de dispositivos. En tal caso, seleccione el menú Buscando conexiones para buscar los dispositivos.
- Si ha seleccionado el modo de entrada externa pulsando el botón **SOURCE**, no podrá usar la función Anynet+. Asegúrese de cambiar a un dispositivo Anynet+ mediante el botón **TOOLS**.



Menú Anynet⁺

El menú Anynet⁺ cambia según el tipo y el estado de los dispositivos Anynet⁺ conectados al televisor.

Menú Anynet⁺	Descripción
Ver TV	Cambia de Anynet ⁺ al modo de emisión de TV.
Lista Disp.	Muestra la lista de dispositivos de Anynet ⁺ .
Grabar	Comienza una grabación. (Este menú sólo funciona en un dispositivo que admite grabación.)
Menú en dispositivo	Muestra el menú del dispositivo conectado. Ejemplo: Cuando hay una grabadora de DVD conectada, aparece el menú de títulos de la grabadora de DVD.
Funcionamiento del disp.	Muestra el menú de control de reproducción del dispositivo conectado. Ejemplo: Cuando hay una grabadora de DVD conectada, aparece el menú de control de reproducción de la grabadora de DVD.
Grabac. temp.	Permite reservar una grabación. (Este menú sólo funciona en un dispositivo que admite reservas de grabación.)
Detener grab.	Detiene la grabación.
Receptor	La salida de sonido se efectúa a través del receptor (sistema de cine en casa).
Configuración	Se puede configurar que Anynet ⁺ (HDMI-CEC) se apague automáticamente así como la búsqueda de las conexiones para usar Anynet ⁺ .

Botones del mando a distancia del televisor disponibles en el modo Anynet⁺

Tipo de dispositivo	Estado de funcionamiento	Botones disponibles
Dispositivo Anynet⁺	Después de cambiar al dispositivo, cuando el menú de éste aparece en la pantalla.	Botones numéricos Botones ▲/▼/◀/▶/ENTER ⌂ Botones de colores / Botón EXIT
	Después de cambiar al dispositivo, mientras se reproduce un archivo.	[◀] (Búsqueda atrás) / [▶] (Búsqueda adelante) [■] (Parar) / [▶] (Reproducir) / [II] (Pausa)
Dispositivo con sintonizador incorporado	Después de cambiar al dispositivo, mientras se ve un programa de TV.	Botones CH ▼/ CH ▲
Dispositivo de audio	Cuando Receptor está activado.	Botones VOL -/ VOL +/ MUTE

- La función Anynet⁺ sólo es operativa cuando la fuente activa del mando a distancia del televisor está ajustada en TV.
- El botón [●] sólo funciona en el estado Watch TV (Ver TV).
- Los dispositivos Anynet⁺ no se pueden controlar con los botones del TV. Los dispositivos Anynet⁺ sólo se pueden controlar mediante el mando a distancia del televisor.
- El mando a distancia del televisor puede no funcionar en determinadas circunstancias. En ese caso, vuelva a seleccionar el dispositivo Anynet⁺.
- Las funciones Anynet⁺ no están operativas con los productos de otros fabricantes.
- El funcionamiento de [◀], [▶] puede variar según el dispositivo.

Grabación

La grabadora de Samsung permite efectuar una grabación de un programa de televisión.

1. Pulse el botón **TOOLS**.
2. Pulse los botones ▲ o ▼ para seleccionar Recording Immediately y pulse el botón **ENTER ⌂**. Comienza la grabación.

Cuando hay más de un dispositivo de grabación

Cuando se conectan varios dispositivos de grabación, éstos se muestran en una lista. Pulse los botones ▲ o ▼ para seleccionar un dispositivo de grabación y pulse el botón **ENTER ⌂**. Comienza la grabación.

Cuando no se muestra el dispositivo de grabación

Seleccione "Lista Disp." y pulse el botón rojo para buscar los dispositivos.



Pulse el botón **EXIT** para salir.

- Se puede grabar las transmisiones de la fuente seleccionando "Grabar" después de pulsar el botón **TOOLS**.
- Si pulsa el botón [●], grabará lo que está viendo en ese momento. Si está viendo un vídeo desde otro dispositivo, se graba el vídeo de éste.
- Antes de grabar, compruebe si la toma de antena está conectada correctamente al dispositivo de grabación. Para conectar correctamente una antena a un dispositivo de grabación, consulte el manual del usuario de los dispositivos de grabación.

Escucha a través de un receptor

Se puede escuchar sonido a través de un receptor en lugar de hacerlo mediante el altavoz del TV.

1. Pulse el botón **TOOLS**. Pulse los botones **▲** o **▼** para seleccionar "Receptor".
2. Pulse los botones **◀** o **▶** para seleccionar "Encendido". Ahora podrá escuchar el sonido a través del receptor.
3. Pulse el botón **EXIT** para salir.
 - Si el receptor sólo admite audio, quizás no se muestre la lista de dispositivos.
 - El receptor no funcionará si no se ha conectado correctamente la toma Optical IN del receptor con la toma Optical OUT del televisor.
 - Cuando el receptor (sistema de cine en casa) está establecido en Enc. se puede oír la salida de sonido del terminal Optical del televisor. Cuando se ve la televisión a través de un DTV (aéreo), el televisor envía el sonido de 5.1 canales al receptor del sistema de cine en casa. Cuando la fuente es un componente digital, como un DVD, y está conectada al televisor a través de HDMI, sólo se oye el sonido de 2 canales del receptor del sistema de cine en casa.
 - Cuando se usa la función WISELINK, el sonido puede no oírse adecuadamente a través del receptor.
 - Cuando se escucha a través del receptor, hay restricciones para el uso de los menús PIP y los relativos al audio (MTS, idiomas preferidos).
 - Si hay una interrupción en la alimentación del televisor con la opción "Receptor" configurada en "Encendido" (por desconectar el cable de alimentación o por un fallo de corriente), puede que "Altavoz TV" esté establecido como "Apagado" al volver a encender el televisor. (Consulte la página 34)



Solución de problemas de Anynet⁺

Síntoma	Solución
Anynet ⁺ no funciona.	<ul style="list-style-type: none">• Compruebe si el dispositivo es un dispositivo Anynet⁺. El sistema Anynet⁺ sólo admite dispositivos Anynet⁺.• Conecte sólo un receptor.• Compruebe si el cable de alimentación de Anynet⁺ está debidamente conectado.• Compruebe las conexiones de los cables de Video/Audio/HDMI 1.3 del dispositivo Anynet⁺.• Compruebe si Anynet⁺ (HDMI-CEC) está establecido en Enc. en el menú de configuración de Anynet⁺.• Compruebe si el mando a distancia del televisor está en modo TV.• Compruebe si es un mando a distancia exclusivo para Anynet⁺.• Anynet⁺ no funciona en algunas situaciones. (Búsqueda de canales, funcionamiento de WISELINK, Plug & Play, etc.)• Cuando se conecta o se desconecta el cable HDMI 1.3, se han de buscar de nuevo los dispositivos o volver a apagar y encender el televisor.• Compruebe si la función Anynet⁺ del dispositivo Anynet⁺ está activada.
Deseo iniciar Anynet ⁺ .	<ul style="list-style-type: none">• Compruebe si el dispositivo Anynet⁺ está debidamente conectado al TV y si la opción Control HDMI del menú Configuración está establecida en Activado.• Pulse el botón TV del mando a distancia del televisor para cambiar a TV. A continuación pulse el botón Anynet⁺ para visualizar el menú TOOLS y seleccionar el menú que deseé.
Deseo salir de Anynet ⁺ .	<ul style="list-style-type: none">• Seleccione Ver TV en el menú Anynet⁺.• Pulse el botón SOURCE del mando a distancia del televisor y seleccione un dispositivo que no sea Anynet⁺.• Pulse CH, CH LIST, PRE-CH, o FAV.CH para cambiar al modo TV. (Tenga en cuenta que el botón de canal sólo funciona cuando no hay ningún dispositivo Anynet⁺ con sintonizador incorporado conectado.)
En la pantalla aparece el mensaje Conectando a un dispositivo Anynet ⁺	<ul style="list-style-type: none">• El mando a distancia no se puede utilizar cuando se está configurando Anynet+ o cambiando a un modo de visualización.• Utilice el mando a distancia cuando haya terminado la configuración de Anynet+ o el cambio al modo de visualización.
El dispositivo Anynet ⁺ no funciona.	No se puede usar la función de reproducción mientras se efectúa una conexión Plug & Play.
El dispositivo conectado no se muestra.	<ul style="list-style-type: none">• Compruebe si el dispositivo admite las funciones Anynet⁺.• Compruebe si el cable HDMI 1.3 está debidamente conectado.• Compruebe si Anynet⁺ (HDMI-CEC) está establecido en Act. en el menú de configuración de Anynet⁺.• Vuelva a efectuar una búsqueda de dispositivos Anynet⁺.• Sólo puede conectar un dispositivo Anynet⁺ mediante el cable HDMI 1.3. Algunos cables HDMI pueden no admitir las funciones Anynet⁺.• Si se ha interrumpido por una situación anormal como la desconexión del cable HDMI o el de alimentación o por un fallo en la corriente eléctrica, deberá repetir la búsqueda del dispositivo.
El programa de televisión no se puede grabar.	Compruebe la conexión de la toma de antena del dispositivo de grabación.
El sonido del televisor no sale a través del receptor.	Conecte el cable óptico entre el televisor y el receptor.

Apéndice


Identificación de problemas

Si cree que el televisor tiene un problema, compruebe primero esta lista de posibles problemas y soluciones. Si ninguno de los consejos funciona, póngase en contacto con el centro de atención al cliente de Samsung o llame al 1-800-SAMSUNG.

Problema	Possible Solución
Imagen deficiente.	Intente sintonizar otro canal. Ajuste la antena. Compruebe las conexiones de todos los cables.
Calidad de sonido deficiente.	Intente sintonizar otro canal. Ajuste la antena.
No hay imagen o sonido.	Intente sintonizar otro canal. Pulse el botón SOURCE . Compruebe que el TV esté conectado. Compruebe las conexiones de la antena.
No se percibe ningún sonido, o muy bajo, con el volumen al máximo.	Primero, compruebe el volumen de los aparatos conectados al TV (por ejemplo, un receptor digital, DTV, DVD, receptor de cable, VCR, etc.). A continuación, ajuste el volumen del TV según sea más conveniente.
La imagen rueda verticalmente.	Compruebe todas las conexiones de cable.
El TV funciona de forma irregular.	Desconecte el TV durante 30 segundos y, después, intente que funcione otra vez.
El televisor no se enciende.	Compruebe que la toma de la pared funciona.
Anomalías del mando a distancia.	Reemplace las pilas del mando a distancia. Limpie el borde superior del mando a distancia (ventana de transmisión). Compruebe los terminales de la pila.
Mensaje "Verificar cable señal".	Compruebe que el cable de señal esté conectado firmemente con las fuentes del PC.
Mensaje "Modo no compatible".	Compruebe la resolución máxima y la frecuencia de vídeo del dispositivo conectado. Compare estos valores con los datos de los modos de Pantalla.
Problema en pantalla con la emisión digital.	Compruebe la potencia de la señal digital y la antena de entrada.
La imagen es demasiado clara o demasiado oscura.	Ajuste Luminos. y Contraste. Ajuste la función Fino.
Barras negras en la pantalla.	Compruebe que la emisión que se está recibiendo es de alta definición (HD). Los canales HD en ocasiones emiten una programación en SD (definición estándar) que puede dar lugar a la aparición de barras negras. Para eliminar las barras configure el decodificador de cable o satélite en los modos Alargar o Panorámica.
Las imágenes tienen un tono rojo-verde o rosa.	Compruebe que los cables de los componentes estén conectados en los terminales correctos.
Los subtítulos para sordos no funcionan.	Cuando se usa un decodificador de cable o satélite, la opción de los subtítulos para sordos se debe configurar en el decodificador, no en el televisor.
Las imágenes se ven con nieve.	Quizás se necesite actualizar el firmware. Póngase en contacto con el proveedor de cable.
Se ven imágenes superpuestas.	Quizás haya problemas de compatibilidad con el decodificador de cable. Intente conectarse a través de los cables de los componentes.
Unas barras horizontales parpadean, tiemblan u oscilan en la imagen.	Ajuste la función Grueso y después ajuste la función Fino.
Unas barras verticales parpadean, tiemblan u oscilan en la imagen.	Ajuste la función Grueso y después ajuste la función Fino.


Problema	Posible Solución						
La pantalla está negra y el indicador luminoso de alimentación parpadea constantemente.	<p>Compruebe lo siguiente en el equipo: Alimentación, Cable de señal. El TV utiliza su sistema de gestión de energía. Mueva el ratón del equipo o pulse una tecla del teclado.</p>						
La imagen no es estable y parece vibrar cuando se conecta el ordenador en la entrada de PC.	<p>Si el ajuste no es correcto, use la utilidad del ordenador para cambiar los ajustes de pantalla.</p> <p>➤ El televisor admite funciones de visualización multiscan dentro del siguiente rango de frecuencias:</p> <table border="1" data-bbox="642 436 1188 550"> <tr> <td>Frecuencia horizontal (kHz)</td> <td>30~60</td> </tr> <tr> <td>Frecuencia vertical (Hz)</td> <td>60~75</td> </tr> <tr> <td>Índice de barrido máximo (60 Hz)</td> <td>1920 x 1080</td> </tr> </table>	Frecuencia horizontal (kHz)	30~60	Frecuencia vertical (Hz)	60~75	Índice de barrido máximo (60 Hz)	1920 x 1080
Frecuencia horizontal (kHz)	30~60						
Frecuencia vertical (Hz)	60~75						
Índice de barrido máximo (60 Hz)	1920 x 1080						
La imagen no está centrada en la pantalla.	<p>Ajuste la posición horizontal y vertical. La posición de la pantalla se debe ajustar respecto a la fuente de salida (por ejemplo, STB) con una señal digital.</p>						
La imagen aparece distorsionada en la esquina de la pantalla.	<p>Si "Sólo buscar" está seleccionado en algún dispositivo externo, la imagen puede aparecer distorsionada en la esquina de la pantalla. Este síntoma se origina en los dispositivos externos, no en el televisor.</p>						
Aparece el mensaje "Resets all settings to the default values."	<p>Aparece cuando el botón EXIT se mantiene pulsado durante unos momentos. La configuración del producto se restablece con los ajustes predeterminados de fábrica.</p>						
Puede ver pequeñas partículas si mira de cerca el borde biselado de la pantalla del televisor.	<p>Esto es una particularidad del diseño del producto y no es un defecto.</p>						
	<p>El panel LCD TFT utiliza un panel que consta de muchos píxeles de ínfimo tamaño (6 220 800) que requieren de una tecnología altamente sofisticada para su fabricación. Sin embargo, pueden haber unos pocos píxeles poco iluminados u oscuros en pantalla. Estos píxeles no suponen una anomalía en el funcionamiento del producto.</p>						

Instalación del soporte



1. Acople el TV LCD al soporte.
 - > El televisor lo deben transportar dos o más personas.
 - > Cuando monte el soporte debe distinguir entre la parte frontal y la posterior del soporte.
 - > Para asegurarse de que instala el televisor en el soporte al nivel adecuado, no aplique una presión excesiva en la parte superior izquierda y derecha del televisor.
2. Apriete dos tornillos en la posición ① y, a continuación, apriete dos en la posición ②.
 - > Levante el producto y apriete los tornillos. Si aprieta los tornillos con el TV LCD tumbado, éste se puede inclinar hacia un lado.



Desconexión del soporte



1. Desmonte los 4 tornillos de la parte posterior del TV.
2. Separe el soporte del TV.
 - > El televisor lo deben transportar dos o más personas.
3. Cubra el orificio inferior con la tapa.


Ajuste de montaje mural automático (se vende por separado)

Una vez instalado el montaje mural automático, la posición del televisor se puede ajustar fácilmente.




Acceso al menú

- Pulse los botones **▲**, **▼**, **◀** o **▶** del mando a distancia.
 - Se muestra la pantalla del Ajuste del montaje mural.
 - Si no se muestra la pantalla del Ajuste del montaje mural cuando se hace clic en un botón de dirección mientras se está viendo la televisión, se puede usar el menú para mostrar la pantalla.
- Pulse el botón **MENU** para ver el menú en pantalla. Pulse los botones **▲** o **▼** para seleccionar "Configuración" y, a continuación, pulse el botón **ENTER** .
- Pulse los botones **▲** o **▼** para seleccionar "Configuración externa" y, a continuación, pulse el botón **ENTER** .
- Pulse los botones **▲** o **▼** para seleccionar "Ajuste de montaje en pared" y, a continuación, pulse el botón **ENTER** .



Memorización de la posición

- Ajuste la posición deseada con los botones **▲**, **▼**, **◀**, **▶**.
 - Si pulsa un botón de flecha sin que haya aparecido un OSD en la pantalla del televisor, aparece la pantalla de ajuste.
 - Pulse el botón **INFO** para restaurar. Pulse los botones **◀** o **▶** para seleccionar "Sí" y, a continuación, pulse el botón **ENTER** .
 - La posición se inicializa con la configuración predeterminada.
- Pulse el botón azul. Pulse los botones **▲** y **▼** para seleccionar un modo de guardar entre Posición 1, Posición 2 o Posición 3 en este orden para guardar la posición actual.
 - Si no desea guardar la posición actual, pulse el botón **RETURN**.
 - Cuando se selecciona un modo de guardar, no se pueden usar los botones de colores.
- Pulse el botón **ENTER** para guardar.
 - Cuando se selecciona la Posición 1, se muestra el mensaje "Posición actual guardada como Posición1".
- Pulse el botón **ENTER** .
- La posición guardada se muestra en la parte izquierda de la OSD.




Desplazamiento a la posición memorizada

- Complete el paso 1 de "Acceso al menú".
- Pulse un botón de color (rojo, verde, amarillo) para mover el montaje mural a la posición guardada.
 - Se puede mover el montaje mural a una de las tres posiciones preconfiguradas con los botones rojo (posición 1), verde (posición 2) o amarillo (posición 3).
 - Si después de usar una posición preconfigurada se ajusta ésta, la visualización de la posición desaparece.
- Para la instalación, consulte el manual de instalación proporcionado con el equipo de montaje mural.
- Para la instalación del producto, así como la instalación y movimiento del montaje en la pared, consulte a una empresa especializada en instalaciones.
- La instalación manual se debe usar al colocar el equipo de montaje en una pared. Para colocarlo en otros materiales de construcción, póngase en contacto con el distribuidor más cercano.
- El montaje mural no está operativo con Anynet+ o WISELINK.
- Los modelos LN40A650A1F y LN46A650A1F no son compatibles con el anterior modelo de montaje mural (WMN5090A).

Especificaciones del equipo de montaje en la pared (VESA)

Instale el montaje mural en una pared sólida, perpendicular al suelo. Para colocarlo en otros materiales de construcción, póngase en contacto con el distribuidor más cercano. Si se instala en el techo o en una pared inclinada, puede caerse y causar graves lesiones personales.



Familia de producto	pulgadas	Especificaciones VESA (A * B)	Tornillo estándar	Cantidad	
LCD-TV	23~ 26	200 * 100	M4	4	
	32 ~ 40	200 * 200	M6		
	46 ~ 52	600 * 400	M8		
	57	700 * 400 (No VESA)			
	57 ~ 70	800 * 400			
	80 ~	1400 * 800			
PDP-TV	42 ~ 50	600 * 400	M8	4	
	55 ~ 70	800 * 400		6	
	63	No VESA		4	
	80 ~	1400 * 800			


- Las dimensiones estándar de los equipos de montaje mural se muestran en la tabla anterior.
- Al adquirir el equipo de montaje en la pared, también se distribuye un manual de instalación detallado y todas las piezas necesarias para el montaje.
- No use tornillos con un tamaño superior al estándar, ya que pueden causar daños en el interior del televisor.
- Para montajes murales que no cumplen las especificaciones de tornillos estándar VESA, la longitud de éstos puede variar dependiendo de las especificaciones.
- No use tornillos que no cumplan las especificaciones de tornillos estándar VESA. No apriete excesivamente los tornillos, ya que podría dañar el producto o provocar la caída de éste con riesgo de causar lesiones personales. Samsung no se hace responsable de este tipo de accidentes.
- Samsung no se hace responsable de daños o lesiones personales cuando se usa un montaje mural que no cumple las especificaciones VESA o si el cliente no sigue las instrucciones de instalación del producto.
- Nuestros modelos de 57" y 63" no son compatibles con las especificaciones VESA. Por ello, debe usar un equipo de montaje en la pared exclusivo para este modelo.
- No supere los 15 grados de inclinación cuando monte este televisor.



No instale el equipo de montaje mural mientras el televisor está encendido. Se podría producir una descarga eléctrica con riesgo de causar lesiones personales.

Uso del cierre antirrobo kensington (LN32A650A1F, LN40A650A1F, LN46A650A1F)

El bloqueo Kensington es un dispositivo que se usa para fijar físicamente el sistema cuando se usa en un lugar público. La apariencia y el método de bloqueo pueden diferir de la ilustración según los fabricantes. Consulte el manual que acompaña al bloqueo Kensington para utilizarlo correctamente. El dispositivo de bloqueo debe adquirirse por separado.



> La ubicación del "Bloqueo Kensington" puede variar según el modelo.

1. Inserte el dispositivo de bloqueo en la ranura Kensington del TV LCD (Figura 1) y gírelo en el sentido del bloqueo (Figura 2).
2. Conecte el cable del bloqueo Kensington.
3. Fije el bloqueo Kensington a un mueble o a un objeto pesado que no se mueva.


Especificaciones

Nombre del Modelo	LN32A650A1F	LN40A650A1F
Tamaño de pantalla (Diagonal)	32 pulg	40 pulg
PC Resolución	1920 x 1080 @ 60 Hz	1920 x 1080 @ 60 Hz
Sonido Salida	10W X 2	10W X 2
Dimensiones (WxDxH) Cuerpo principal	31,7 x 3,2 x 20,8 pulg (806,0 x 81,0 x 528,2 mm)	39,3 x 3,3 x 25,1 pulg (998,0 x 83,4 x 638,0 mm)
Con soporte	31,7 x 9,9 x 23,0 pulg (806,0 x 251,9 x 584,4 mm)	39,3 x 11,8 x 27,5 pulg (998,0 x 300,0 x 698,2 mm)
Peso Con el soporte	31,3 lbs (14,2 kg)	44,5 lbs (20,2 kg)
Después sw plegar la base	26,5 lbs (12,0 kg)	37,5 lbs (17,0 kg)
Factores medioambientales Temperatura de funcionamiento	Entre 10°C y 40°C (50°F a 104°F)	
Humedad de funcionamiento	Del 10% al 80%, sin condensación	
Temperatura de almacenamiento	Entre -20°C y 45°C (-4°F a 113°F)	
Humedad de almacenamiento	Del 5% al 95%, sin condensación	
Giro del soporte (izquierda/derecha)	-20° ~ 20°	
Nombre del Modelo	LN46A650A1F	LN52A650A1F
Tamaño de pantalla (Diagonal)	46 pulg	52 pulg
PC Resolución	1920 x 1080 @ 60 Hz	1920 x 1080 @ 60 Hz
Sonido Salida	10W X 2	10W X 2
Dimensiones (WxDxH) Cuerpo principal	44,5 x 3,7 x 28,1 pulg (1131,0 x 94,5 x 714,2 mm)	50,2 x 4,1 x 31,7 pulg (1276,0 x 105,0 x 805,7 mm)
Con soporte	44,5 x 11,0 x 30,5 pulg (1131,0 x 279,9 x 774,5 mm)	50,2 x 12,8 x 34,1 pulg (1276,0 x 326,0 x 866,1 mm)
Peso Con el soporte	58,6 lbs (26,6 kg)	76,7 lbs (34,8 kg)
Después sw plegar la base	49,2 lbs (22,3 kg)	64,6 lbs (29,3 kg)
Factores medioambientales Temperatura de funcionamiento	Entre 10°C y 40°C (50°F a 104°F)	
Humedad de funcionamiento	Del 10% al 80%, sin condensación	
Temperatura de almacenamiento	Entre -20°C y 45°C (-4°F a 113°F)	
Humedad de almacenamiento	Del 5% al 95%, sin condensación	
Giro del soporte (izquierda/derecha)	-20° ~ 20°	


- El diseño y las especificaciones están sujetos a cambios sin previo aviso.
- Este dispositivo es un aparato digital de la Clase B.
- Para conocer la fuente de alimentación y el consumo de energía, consulte la etiqueta adherida al producto.

Tamaño


LN32A650A1F




VISTA SUPERIOR



DETALLE DEL PANEL DE TOMAS 3.7"H X 9.1"W



VISTA FRONTAL /VISTA LAT ERAL




VISTA POSTERIOR


NOTA: No todos los dibujos están necesariamente a escala. Algunas dimensiones están sujetas a cambio sin previo aviso. Consulte las dimensiones antes de ejecutar la instalación del televisor. La empresa no se responsabiliza de cualquier error tipográfico o de impresión.
© 2008 Samsung Electronics America, Inc.

Tamaño


LN40A650A1F




VISTA SUPERIOR



DETALLE DEL PANEL DE TOMAS 3.7"H X 9.1"W



VISTA FRONTAL /VISTA LAT ERAL




VISTA POSTERIOR


NOTA: No todos los dibujos están necesariamente a escala. Algunas dimensiones están sujetas a cambio sin previo aviso. Consulte las dimensiones antes de ejecutar la instalación del televisor. La empresa no se responsabiliza de cualquier error tipográfico o de impresión.
© 2008 Samsung Electronics America, Inc.

Tamaño


LN46A650A1F




VISTA SUPERIOR



DETALLE DEL PANEL DE TOMAS 3.7"H X 9.1"W



VISTA FRONTAL /VISTA LAT ERAL




VISTA POSTERIOR


NOTA: No todos los dibujos están necesariamente a escala. Algunas dimensiones están sujetas a cambio sin previo aviso. Consulte las dimensiones antes de ejecutar la instalación del televisor. La empresa no se responsabiliza de cualquier error tipográfico o de impresión.
© 2008 Samsung Electronics America, Inc.

Tamaño


LN52A650A1F




VISTA SUPERIOR



DETALLE DEL PANEL DE TOMAS 3.7"H X 9.1"W



VISTA FRONTAL /VISTA LAT ERAL



VISTA POSTERIOR

NOTA: No todos los dibujos están necesariamente a escala. Algunas dimensiones están sujetas a cambio sin previo aviso. Consulte las dimensiones antes de ejecutar la instalación del televisor. La empresa no se responsabiliza de cualquier error tipográfico o de impresión.
© 2008 Samsung Electronics America, Inc.

*Esta pagina se ha dejado en
blanco expresamente.*