Embedded Systems CS 397 TRIMESTER 3, AY 2021/22

Software Installation

Dr. LIAW Hwee Choo

Department of Electrical and Computer Engineering
DigiPen Institute of Technology Singapore
HweeChoo.Liaw@DigiPen.edu

ST-Link Utility (STSW-LINK004) and ST-Link USB Drivers (STSW-LINK009)

- This utility is for programming STM32 microcontrollers, and the file (en.stsw-link004_v4.6.0.zip) can be downloaded from https://www.st.com/en/development-tools/stsw-link004.html
- Unzip and run "\STM32 ST-LINK Utility v4.6.0\setup.exe" to install the ST-Link utility at the default location:


C:\Program Files (x86)\STMicroelectronics\STM32 ST-LINK Utility

- This utility will also install two USB device drivers, namely
 STMicroelectronics (WinUSB) STLinkWinUSB (06/08/2017 2.01)
 STMicroelectronics (usbser) Ports (06/08/2017 2.01)
- The above USB drivers can also be obtained from https://www.st.com/en/development-tools/stsw-link009.html
- Download and unzip en.stsw-link009_v2.0.2.zip, and
- Run "stlink_winusb_install.bat", which will install the latest USB drivers

- 1. The Development Software STM32CubeIDE
- **STM32CubeIDE** is an all-in-one multi-OS development tool, which is part of the STM32Cube software ecosystem.
- STM32CubeIDE is an advanced C/C++ development platform with peripheral configuration, code generation, code compilation, and debug features for STM32 microcontrollers. It is based on the ECLIPSE CDT framework and GCC toolchain for the development, and GDB for the debugging.
 Eclipse CDT: (C/C++ Development Tooling)
- https://www.st.com/en/development-tools/stm32cubeide.html
 Windows: en.st-stm32cubeide_1.9.0_12015_20220302_0855_x86_64.exe.zip
 Get Software

		Part Number	General Description	Supplier 💠	Download	All versions
	+	STM32CubeIDE-DEB	STM32CubeIDE Debian Linux Installer	ST	Get latest	Select version V
	+	STM32CubeIDE-Lnx	STM32CubeIDE Generic Linux Installer	ST	Get latest	Select version V
	+	STM32CubeIDE-Mac	STM32CubeIDE macOS Installer	ST	Get latest	Select version ~
	+	STM32CubeIDE-RPM	STM32CubeIDE RPM Linux Installer	ST	Get latest	Select version V
Liaw Hwee	+	STM32CubeIDE-Win	STM32CubeIDE Windows Installer	ST	Get latest	Select version >

- Create folders C:\STM32CubeIDE\Repository and C:\STM32_CS397
- Unzip and run "st-stm32cubeide_1.9.0_12015_20220302_0855_x86_64.exe"
 to install it with default settings
- Run STM32CubeIDE, select workspace: C:\STM32_CS397, and click "Launch"





RN0114

Release note will be displayed in the first run


Release note

STM32CubeIDE release v1.9.0

Introduction


This release note is updated periodically to keep abreast of STM32CubeIDE evolution, problems, and limitations. Check the STMicroelectronics website at www.st.com/stm32softwaretools for the latest version. For the latest release summary, refer to


Select: Window -> Preferences (for firmware installation)



Liaw Hwee Choo, June 2022.


C:\STM32CubeIDE\Repository Specify Firmware Installation Repository Preferences ⟨⇒ ▼ □⟩ ▼ type filter text Firmware Updater > General Firmware Updater > C/C++ Repository Setup > Help > Install/Update Firmware installation repository | C:\STM32CubelDE\Repository Browse > Remote Development > Run/Debug Connection Setup ✓ STM32Cube See 'Network Connections' for settings related to network connections Device Configuration To-Connection Mode **End User Agreements** Off Line Mode File Association Firmware Updater Check and Update Firmware packs Settings MPU Serial Automatic Check Interval between two Checks (days) Serial Wire Viewer Target Status Manual Check Toolchain Manager Target Selector Device Database Auto-Refresh SWTChart Extensions O No Auto-Refresh at Application start Terminal Auto-Refresh Data-only at Application start > Version Control (Team) Auto-Refresh Data and Docs at Application start Interval between two data-refreshs (days) 3 Check Connection Check your connection Check Connection Restore Defaults Apply > Apply and Close Cancel





Install STM32CubeIDE MCU Package Locally First, copy the MCU packages to folders:

(do not unzip the files)



- 2. Use J-Link on-board instead of ST-Link on-board with the ST hardware via USB
- The steps for converting the ST-Link on-board to a J-Link on-board are:
 - Make sure that the ST-Link USB drivers (STSW-LINK009) are installed.

Download: https://www.st.com/en/development-tools/stsw-link009.html

Unzip en.stsw-link009.zip, and run "stlink_winusb_install.bat"

- Make sure that the J-Link software package V5.12b or later

(JLink_Windows_V766a_x86_64.exe) is installed (default settings).

Download: https://www.segger.com/downloads/jlink/

Obtain the SEGGER J-Link software package (STLinkReflash_190812.zip)

Download: https://www.segger.com/downloads/jlink#STLink_Reflash


- Unzip and start the **STLinkReflash.exe** utility
- Agree to the license terms
- Connect ST-Link on-board to PC /
- Select an option: "Upgrade to J-Link", "Upgrade J-Link Firmware", or "Restore ST-Link",
- Wait for operation to complete

Info: https://www.segger.com/products/debug-probes/j-link/models/other-j-links/st-link-on-board/
Liaw Hwee Choo, June 2022.


10

- 3. Other Software (1/2)
- RealTerm A serial terminal for engineering and debugging
 - https://sourceforge.net/projects/realterm/files/Realterm/2.0.0.70/
 - Realterm_2.0.0.70_Signed_Wrapper_setup.exe
- Notepad++ A free source code editor
 - https://notepad-plus-plus.org/downloads/
 - npp.8.4.1.Installer.x64.exe
- Sumatra PDF A free PDF, eBook (<u>ePub</u>, <u>Mobi</u>), XPS, DjVu, <u>CHM</u>, <u>Comic Book</u> (CBZ and CBR) reader for Windows
 - https://www.sumatrapdfreader.org/download-free-pdf-viewer.html
 - SumatraPDF-3.4.3-64-install.exe
- 7-Zip A file archiver with a high compression ratio
 - https://www.7-zip.org/
 - 7z2107-x64.exe
- SystemView An application that performs system analysis and verification of embedded systems
 - https://www.segger.com/downloads/systemview/
 - SystemView_Windows_V332_x64.exe
- **EchoTool** Command line echo server and client for Windows
 - https://github.com/PavelBansky/EchoTool/
 - echotool.exe
- htmlgen A 'makefsdata' tool to create C code suitable for httpd for given html pages (or other files) in a directory
 - https://github.com/fetisov/lrndis/tree/master/makefsdata
 - **htmlgen.exe** (in Irndis-master.zip)

- 3. Other Software (2/2)
- Advanced IP Scanner Scan a network to obtain IP addresses
 - https://www.advanced-ip-scanner.com/
 - Advanced_IP_Scanner_2.5.4594.1.exe



4. USB-CAN FD adapter/analyzer







BM-USB-CANFD-X2

Install BUSMASTER_Installer_Ver_3.2.2.21.exe with default settings

5. STM32 Online Training

STM32 Education

https://www.st.com/content/st_com/en/support/learning/stm32-education.html

STM32 Online Training

https://www.st.com/content/st_com/en/support/learning/stm32-education/stm32-online-training.html

STM32 MOOCs (Massive Open Online Courses)

https://www.st.com/content/st_com/en/support/learning/stm32-education/stm32-moocs.html

STM32CubeMX & CubeHAL basics MOOC

https://www.st.com/content/st_com/en/support/learning/stm32-education/stm32-moocs/stm32cubemx-and-cubeHhal-basics.html

STM32H7 Online training

https://www.st.com/content/st_com/en/support/learning/stm32-education/stm32-online-training/stm32h7-online-training.html