

ECx00M&ECx00N&EC800K Series

Low Power Mode Application Note

LTE Standard Module Series

Version: 1.0

Date: 2023-10-18

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2023. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2022-03-14	Evin ZHU/ Chaim QIAN	Creation of the document
1.0	2023-10-18	Evin ZHU/ Chaim QIAN	First official release

Contents

About the Document.....	3
Contents	4
Table Index.....	5
Figure Index	6
1 Introduction	7
1.1. Applicable Modules.....	7
2 Related Hardware Interfaces	8
2.1. Communication Interfaces	8
2.2. Power Management Pins.....	8
3 URC Introduction	9
3.1. Set URC Port	9
3.2. Manage URC Event Report	9
4 Implementation of Low-Power Solutions	11
4.1. Low-Power Solution Based on the UART Interface	11
4.1.1. Hardware Connection	11
4.1.2. Software Initialization	12
4.1.3. Implementation Method.....	12
4.2. Low-Power Solution Based on USB Suspend/Resume	13
4.2.1. Hardware Connection	13
4.2.2. Software Initialization	13
4.2.3. Implementation Method.....	13
5 Software Mechanisms	14
5.1. Module Sleep Mechanism.....	14
5.2. Module Sleep Process	14
5.3. USB Sleep Mechanism	15
5.4. Host Wake-Up.....	15
5.4.1. Host Wake-Up Event.....	15
5.4.2. Host Wake-Up Event Setting	15
5.5. Module Wake-Up	15
6 Appendix References	16

Table Index

Table 1: Applicable Modules 7

Table 2: Power Management Pins 8

Table 3: Related Documents..... 16

Table 4: Terms and Abbreviations 16

Figure Index

Figure 1: Connection Diagram Based on UART	11
Figure 2: Connection Diagram Based on USB Suspend/Resume	13
Figure 3: Module Sleep Process	14

1 Introduction

In embedded applications, the power consumption of products is increasingly valued by users, which is especially important for battery-powered devices. Quectel provides power management solutions on reducing product power consumption and extending battery life to reduce product operating costs and improve product competitiveness. The power consumption can be managed by software or hardware design. This document focuses on how to minimize power consumption through software design.

This document describes peripheral hardware interfaces, URC, low-power implement solutions, and the sleep and wake-up software mechanism of the Quectel ECx00M family, ECx00N family, EC800K series modules.

1.1. Applicable Modules

Table 1: Applicable Modules

Module Family	Module
ECx00M	EC200M-CN
	EC600M-CN
	EC800M-CN
ECx00N	EC200N-CN
	EC800N-CN
-	EC800K Series

2 Related Hardware Interfaces

2.1. Communication Interfaces

The communication between the module and the host system is realized through USB and UART interfaces.

2.2. Power Management Pins

There are some other functional pins provided for the host system to achieve the module's power management.

Table 2: Power Management Pins

Pin Name	I/O	Description
MAIN_DTR	IN	This pin is used for the host to wake up the module from sleep mode or allow the module to enter the sleep mode. When MAIN_DTR is at a high level, the host allows the module to enter the sleep mode. When the module is in the sleep mode, driving MAIN_DTR low will wake up the module.
MAIN_RI	OUT	This pin is used by the module to notify the host that there is a URC event that needs to be reported. When there is no URC event, MAIN_RI keeps at a high level. When there is a URC event to report, MAIN_RI outputs a low pulse. At this time, if the host is in sleep mode, it will be awakened to process the reported URC.

NOTE

1. When MAIN_DTR is at a high level, whether the module enters the sleep mode also depends on other conditions. If MAIN_DTR is at a low level, the module cannot enter the sleep mode.
2. URC can be reported through the UART interface. When there is a URC to report, MAIN_RI generates a low pulse to notify the host, and then the URC content will be output.
3. For detailed interface and pin information of a particular module, refer to the corresponding Hardware Design.

3 URC Introduction

In the interaction between a module and a host, the module not only responds to requests from the host but also actively informs the host of external events, such as incoming calls and SMS. In general, the information actively reported by the module is called URC (Unsolicited Result Code).

The module's processing of URCs includes two aspects: reporting event information to the host actively and generating a low pulse on the MAIN_RI pin. The MAIN_RI pin informs a sleeping host of an incoming URC in the form of a pulse. Because the module supports several types of URCs, it may wake up the host too frequently and reduce the power management efficiency of the whole system. To avoid frequent reporting of URCs, the host should select needed URCs based on its own needs.

3.1. Set URC Port

Generally, the module communicates with the host by either the UART or the USB interface, and so does the reporting of URCs.

The URC-reporting port can be configured by **AT+QURCCFG**. For more details about the command, refer to *document [1]*.

3.2. Manage URC Event Report

The module supports various types of URCs, such as the network status URC used to report the module's current network status, the SMS URC used to report the new incoming short messages, and the ring URC used to report an incoming call.

You can enable or disable the reporting of most URCs by **AT+QINDCFG**. Thus, the host can enable or disable the reporting of URCs according to actual needs.

Two examples are provided below.

- When the host system starts for the first time, enable the reporting of URCs related to network, SMS, and phone calls.
- Before the host enters the sleep mode, disable the reporting of part of network-related URCs and enable the reporting of URCs related to SMS and phone calls only.

In this way, the power management efficiency of the whole system is improved and the basic requirements of the host are met.

NOTE

About how to set the URC report by **AT+QINDCFG**, refer to ***document [1]***.

4 Implementation of Low-Power Solutions

4.1. Low-Power Solution Based on the UART Interface

The host communicates with the module through the UART interface. This chapter describes the specific implementation methods of the low-power solution based on the UART interface.

4.1.1. Hardware Connection

- The host is connected to the module through the UART interface.
- The host I/O pin is connected to the MAIN_RI pin of the module, and the used host I/O pin needs to support the interrupt wake-up function.
- The host I/O pin is connected to the MAIN_DTR pin of the module.




Figure 1: Connection Diagram Based on UART

The UART interface is an important channel for the communication between the module and the host. By multiplexing the DTR as a common GPIO, the host can control the sleep mode of the module to manage the power consumption.

When the host's DTR outputs a high level, the module is allowed to enter sleep mode. When the host's DTR outputs a low level, the module is forbidden to enter sleep mode if it is in a wake-up state or will be awakened if it is in sleep mode.

NOTE

For the design of circuits shown in dotted lines in the above figure, please refer to that shown in solid lines, and pay attention to the direction of connection.

4.1.2. Software Initialization

- **AT+QSCCLK=1**

Allow the module to enter the sleep mode (whether the module enters the sleep mode also depends on other conditions). For more details about the command, refer to **document [1]**.

- **AT+QURCCFG="urcport","uart1"**

Specify the UART interface as the URC-reporting port. For more details about the command, refer to **document [1]**.

4.1.3. Implementation Method

- The module enters the sleep mode:

The host pulls up the MAIN_DTR pin of the module to enable the module to enter sleep mode.

- The module wakes up from the sleep mode:

The host pulls down the MAIN_DTR pin of the module to control the module's exit from sleep mode.

- The module wakes up the host:

When the module has an active event URC to report, the MAIN_RI pin of the module generates a low pulse (120 ms duration by default) to inform the host of the incoming URC. You need to ensure that the host can be woken up by the level change of MAIN_RI when it is in a sleep state.

4.2. Low-Power Solution Based on USB Suspend/Resume

For this low-power solution, the host is required to support USB suspend/resume. This chapter describes the specific implementation methods of the low-power solution based on USB suspend/resume.

4.2.1. Hardware Connection

The host communicates with the module through the USB interface, as shown by the figure below.




Figure 2: Connection Diagram Based on USB Suspend/Resume

4.2.2. Software Initialization

- **AT+QSCLK=1**

Allow the module to enter the sleep mode (whether the module enters the sleep mode also depends on other conditions). For more details about the command, refer to **document [1]**.

4.2.3. Implementation Method

- The module enters the sleep mode:
The host system enters the sleep state and USB is suspended.
- The module wakes up from the sleep mode:
The host uses the USB resume functionality to wake up the module.

5 Software Mechanisms

5.1. Module Sleep Mechanism

There is a lower-priority sleep task inside the module, which is used to detect whether the module can enter the sleep mode or not. The sleep control variables (**AT+QSCCLK**) and other services (such as RF, USB, and UART) have rights to vote on the sleep task to decide whether or not the module can enter the sleep mode. Only when both the sleep control variables and other service tasks agree the module to enter the sleep mode, the sleep task is executed and the module enters sleep mode.

NOTE

After the module enters sleep mode, the RF task is not stopped and the module works in DRX mode. DRX is a method that saves the module's power consumption and its basic principle is to make the module enter the sleep state periodically.

5.2. Module Sleep Process




Figure 3: Module Sleep Process

5.3. USB Sleep Mechanism

When USB is working normally, root hub in the hub or HCD sends SOF package periodically (full-speed USB sends one package at an interval of 1 ms, high-speed USB sends one package at an interval of 125 μ s). At this time, USB on the module votes against the module to enter sleep mode.

According to the description of suspend in the USB specification, when the host system sets the port that is connected to the USB device in hub or root hub as suspend, hub or root hub stops sending SOF package and the USB enters suspend mode. Then the USB interface on the module enters suspend mode and votes for the module to enter sleep mode.

NOTE

1. The module's USB suspend functionality provided by Quectel supports different host systems. Users can control the module's USB to enter suspend mode on the host system.
2. If you are using a USB driver developed on your own, please make sure that the driver supports both global suspend and selective suspend functionalities.

5.4. Host Wake-Up

5.4.1. Host Wake-Up Event

Host wake-up event is the event that the module takes the initiative to wake up the host by reporting information to the host when the host is in sleep mode. Host wake-up event is also called URC. For more details, please refer to **Chapter 3**.

5.4.2. Host Wake-Up Event Setting

The host can configure the URC-reporting port by **AT+QURCCFG**, for example, UART or USB AT port. In particular scenarios, the host can specify the URC-reporting port according to the actual hardware connection. The default port is USB AT port.

5.5. Module Wake-Up

The host wakes up the module by pulling down the MAIN_DTR pin or by USB Resume. For more details, refer to **Chapter 4.1.3** and **Chapter 4.2.3**.

6 Appendix References

Table 3: Related Documents

Document Name
[1] Quectel_ECx00M&ECx00N&EC800K_Series_AT_Commands_Manual

Table 4: Terms and Abbreviations

Abbreviation	Description
DRX	Discontinuous Reception
DTR	Data Terminal Ready
HCD	Host Controller Driver
I/O	Input / Output
PDCCH	Physical Downlink Control Channel
RF	Radio Frequency
RI	Ring Indicator
SOF	Start-of-Frame
UART	Universal Asynchronous Receiver/Transmitter
UE	User Equipment
URC	Unsolicited Result Codes
USB	Universal Serial Bus