Clock Timer User Manual

I. Product Features

1.Four Modes: Clock, Count–Up, Count–Down and Alarm.
2.Volume Adjustment: High Volume, Low Volume, Silent with Flashing Light
3.Automatic key lock in Clock mode prevents accidental changes 60 seconds after setting the time.
4.Two alarms can be set independently and run simultaneously. Alarm 1 supports snooze (up to 7 repeats).
5.Repeat Mode 6.Screen–off Mode

II. Typical Uses

Study timer, Kitchen timer, Workout timer, Nap timer, Parking timer, Medication timer, and more.

III. Volume Adjustment

In Clock mode, press the [CLEAR/FLASH] button to switch between sound and silent with flashing light mode. In sound mode, press [START/STOP] to switch between High and Low volume.

IV. Count-down Timer

1.Press [MODE] to enter Timer mode. Clear any previous setting before entering a new countdown time.
2.Use the [HOUR], [MIN], and [SEC] buttons to set the time, then press [START/STOP] to begin the count–down.
3.When the countdown reaches zero, press [START/STOP] to stop the alert and reset the timer. The beeper sounds for 60 seconds.
4.Press [CLEAR/FLASH] to display last record (MEMORY FUNCTION) and press [START/STOP] to restart.

V. Count-up Timer

1.Press [MODE] to enter Timer mode.
2.Press [START/STOP] to start counting up.
3.Press [START/STOP] again to pause.
4.While paused, press [CLEAR/FLASH] to reset the timer.

VI. Clock Timer

1.When you first insert batteries, the unit beeps once, the LCD lights up fully for 1 second, then enters Clock mode.
2.Press the [HOUR], [MIN], and [SEC] buttons to adjust the corresponding time values. The buttons lock automatically after 60 seconds.
3.To change the time again, press the [MODE] button to cycle back to Clock mode, then adjust as needed.
4.Time format: 24–hour.

VII. Alarm Settings

Alarm 1
1.Press [MODE] until [ALARM 1] appears.
2.Use the [HOUR], [MIN], and [SEC] buttons to set the alarm time.
3.Press [START/STOP] to enable or disable the alarm.
4.The [AL1] icon appears when the alarm is active.
5.To reset the alarm again, press the [MODE] button to cycle back to Alarmmode, then adjust as needed.

Alarm 2
1.Press Mode again to enter [ALARM 2].
2.Set the alarm in the same way as ALARM 1.
3.The [AL2] icon appears when the alarm is active.

Alarm Operation
1.When the preset time is reached, the timer beeps and both [Time's Up] and [AL X] (X = 1 or 2) flash on the display.
2.Press [START/STOP] to stop the alarm and flashing icons.
3.If no button is pressed, the alert stops automatically after 60 seconds.
4.In Clock mode, the corresponding Alarm icon remains visible while the alarm is enabled.
5.If Alarm 1, Alarm 2, and the countdown timer are triggered one after another, the latest alert overrides previous alerts.

Snooze Function (Alarm 1 Only)
After setting Alarm 1, press [CLEAR/FLASH] to turn Snooze on or off.
When Alarm 1 sounds, press [START/STOP] to stop the alarm and end Snooze mode.

VIII. Screen-off Mode

In Clock mode, press and hold the [START/STOP] button for 3 seconds to turn off the display. Press the [START/STOP] button briefly (1 second) to wake the screen. All functions continue to operate normally while the screen is off.

IX. Repeat Timer Function

In Count–down mode, after setting the desired duration, press and hold both the [MIN] and [SEC] buttons at the same time to enable the repeat function. The repeat [⟲]indicator appears on the screen. When the count–down reaches zero, it automatically restarts. 60–second alert sounds after each cycle. Press the [START/STOP] button to pause the timer temporarily. To turn off the repeat function, press and hold both the [MIN] and [SEC] button again.

X. Fast Time Setting

Press and hold any of the [HOUR], [MIN], or [SEC] buttons for more than 2 seconds to quickly adjust the selected value.

XI. Battery Replacement

1.Replace the batteries when the display becomes faint or the sound weakens.
2.Requires 2 AAA batteries (not included).
3.Open the battery cover, remove the old batteries, insert the new ones with the correct polarity (+/－). Replace the cover after installation.