

©SuperHouse Plantower PMS5003 Pinout



Pin	Purpose
1	VCC (5V)
2	GND
3	SET (3.3V, active low)
4	RX data in (3.3V)
5	TX data out (3.3V)
6	RESET (3.3V, active low)
7	nc
8	nc

Power is 5V. All logic is 3.3V!

