Controller Side load. from datapath (Jump, JSR) load = 1 for JSR, Pc. load = 1 depends on condition for JUMP >PC to PM >PC+2 to datapath (for JSR) from PM 14 from datapath. /> 1mm deroding logicis ⇒ Rdest, Rsrc to datapath. PFRI RFRI. >C1, C2. -. Cop to Latapath.

Datapath Side.

