

Immobilizer Programming Procedure (M-C)

Mazda CX-7 (2007-2012, without Advanced Keyless Entry/Start)

Mazda CX-9 (2007-2015, without Advanced Keyless Entry/Start)

Mazda2 (2011-2015, without Advanced Keyless Entry/Start)

Mazda3 (2005-2013, without Advanced Keyless Entry/Start)

Mazda5 (2007-2017, without Advanced Keyless Entry/Start)


Mazda6 (2009-2013, without Advanced Keyless Entry/Start)

Mazda MX-5/Miata (2006-2015, without Advanced Keyless Entry/Start)

Mazda RX-8 (2004-2011, without Advanced Keyless Entry/Start)

Please make sure the battery is fully charged before proceeding

DIRECTIONS



CAUTION: Before starting Step 1, complete the procedure for the PCM replacement

- 1. Have two keys (key 1, key 2) ready for registration.
- 2. Connect the WDS, M-MDS, or equivalent to the DLC-2.
- 3. Using key 1, turn the ignition switch to the ON position.

NOTE: Although the security light remains illuminated and DTC 23 is displayed after approx. 1 min, this does not indicate an improper procedure. Continue to perform the procedure as indicated.

- 4. Select "Body/Security/PATS Function" from the WDS, M-MDS, or equivalent screen menu.
- 5. Select "Parameter Reset" from the WDS, M-MDS, or equivalent screen menu.
- 6. Perform security access as indicated on the M-MDS screen.
- 7. Select the replaced part as indicated on the M-MDS screen.

NOTE: At this time, do not select any other parts from the WDS, M-MDS, or equivalent screen menu.

- 8. After verifying that the PATS function menu is displayed again on the screen, select "Exit (From This Menu)" to finish the WDS, M-MDS, or equivalent procedure.
- 9. After Step 8, wait 5 s or more and then turn the ignition switch to the LOCK position.
- 10. Disconnect the WDS, M-MDS, or equivalent from the DLC-2.
- 11. Using key 1, turn the ignition switch to the ON position.
- 12. After verifying that the security light illuminates for 3 s or more, turn the ignition switch to the LOCK position, remove key 1.
- 13. Repeat steps 11 and 12 using key 2.
- 14. Verify that the engine can be started with all the keys.

Contact Us