Index

CARE OF TIRES Page
- Care of Inner Tubes 48
- Casings—How Repaired 48
- How to Remove Tires 48
- Repair Puncture 49

COOLING SYSTEM
- Causes of Overheating 17
- Purpose 17
- Radiator Care in Winter 19
- Repairing Radiator 19
- What to Do When Overheated 17

ENGINE
- Carbon—How Removed 14
- Connecting Rod and Bearings 15
- Engine Fails to Start 61
- Engine Lacks Power—Runs Irregularly 61
- Engine Stops Suddenly 61
- Engine Overheats 61
- Engine Knocks 61
- Knocking—Causes 14
- Main Bearing—How Adjusted 16
- Piston 9
- Power Plant—How Removed 15
- Valves 9

GASOLINE SYSTEM
- Carburetor—How to Adjust 21
- Carburetor—How Controlled 21
- Carburetor—Trouble 22
- Carburetor—How it Works 21

IGNITION SYSTEM
- Coils 25
- Commutator—Its Purpose 26
- Magneto 25
- Magneto Trouble 29
- Spark Plugs 28
- Where to Look for Trouble 27

LUBRICATING SYSTEM
- How it Differs from Others 45
- Kind of Oil to Use 45
- To Fill "Dope" Cups 45

MAINTENANCE
- Care of Top ..... [illegible]
- Storing Cars ..... [illegible]
- To Keep Car Clean ..... [illegible]

MUFFLER
- What It Is For ..... [illegible]
- How to Disconnect ..... [illegible]

OPERATION
- Adjustments—What to Do ..... [illegible]
- Gasoline ..... [illegible]
- Getting Ready to Start ..... [illegible]
- Hand Lever ..... [illegible]
- Oiling ..... [illegible]
- Slow Speed, Brake and Reverse ..... [illegible]
- Spark—How Controlled ..... [illegible]
- Speed—How Controlled ..... [illegible]
- Starting ..... [illegible]
- Starting in Cold Weather ..... [illegible]

REAR AXLE
- Differential Gear—How Removed ..... [illegible]
- Rear Axle—How to Remove Parts ..... [illegible]
- Universal Joint—To Disconnect ..... [illegible]

RUNNING GEAR
- About Wheels ..... [illegible]
- Care of Springs ..... [illegible]
- Cups—How Installed ..... [illegible]
- Its Care ..... [illegible]
- Lubricating the Bearings ..... [illegible]
- Remove Front Axle ..... [illegible]
- Roller Bearings—How Installed ..... [illegible]
- Steering Apparatus ..... [illegible]
- Wheels ..... [illegible]

TRANSMISSION
- Bands ..... [illegible]
- Clutch ..... [illegible]
- Planetary Transmission—What Is It ..... [illegible]
- Transmission—How Assembled ..... [illegible]

Model T Truck

Worm, How Removed ..... [illegible]
Lubricating the Differential ..... [illegible]

The Ford Starting and Lighting System

Type of System ..... [illegible]
The Starting Motor—What if it Fails to Act ..... [illegible]
Oiling the Starter and Generator ..... [illegible]
The Starter—How Removed ..... [illegible]
The Bendix Drive—How Assembled to Starting Motor ..... [illegible]
The Generator—How Removed ..... [illegible]
The Battery—Repairing and Recharging ..... [illegible]