

Nintendo 3DS – Sky3DS+ Guide

Very easy and complete guide to use Sky3DS+ without modifying the console. Ideal for beginners and totally Plug & Play.

Recommended Links

-  Official Sky3DS+ Firmware:

[Download official firmware](#)

Here you download the file that makes the cartridge work correctly.

-  Recommended videos – Retro Game Corps:

[Sky3DS+ guides on YouTube](#)

If you get lost at any step, you can see how it's done here.

Recommended Material

Before starting, make sure you have everything:

 Sky3DS+ (Amazon)

 MicroSD 128GB (Amazon)

 Sky3DS+ (AliExpress)

- ✓ A Nintendo 3DS / 2DS / New 3DS / New 2DS XL.
- ✓ A Sky3DS+ cartridge (orange buttons).
- ✓ A 32–128GB MicroSD.
- ✓ A PC to copy files.

LEGAL NOTICE: This guide is intended for using backups of games you already own physically. It does not support or explain how to download games illegally.

What is Sky3DS+?

Sky3DS+ is a special cartridge that works just like an original 3DS game, but instead of containing a single game, it uses a MicroSD where you can store several.

It's like a "multi-game cartridge":

- ✓ It does not modify the console.
- ✓ Works on any firmware version.
- ✓ Totally Plug & Play.
- ✓ Switch games using the orange buttons.

Compatibility

- ✓ Nintendo 3DS
- ✓ Nintendo 3DS XL
- ✓ Nintendo 2DS
- ✓ New Nintendo 3DS
- ✓ New Nintendo 3DS XL
- ✓ New Nintendo 2DS XL
- ✓ Works in any region (EU, USA, JAP)
- ✓ Works on the latest official update

1 Prepare the MicroSD

We will prepare the card so Sky3DS+ works on the first try.

1. Connect the MicroSD to the PC.
2. Format the card in **exFAT** or **FAT32**.
3. Download the official firmware (`firmware.bin` file).
4. Copy it to the root of the MicroSD.
5. Copy your legal `.3ds` games also to the root.

2 Update Sky3DS+

1. Insert the MicroSD into the Sky3DS+.
2. Insert the Sky3DS+ into the console while it is off.
3. Turn on the console.
4. The cartridge LED will blink while updating.
5. When it stops blinking, it is ready.

3 How to switch games

In the HOME Menu:

- The first game will appear as a normal cartridge.
- Press the orange button → next game.
- Press the other orange button → previous game.

```
NINTENDO 3DS - HOME MENU
-----
[ CART SLOT ] : Mario Kart 7

> Pressing orange button...
> Loading next game...
> Emulating: Zelda Ocarina of Time 3D
```

Common Errors

No game appears:

- ✓ The MicroSD is not properly inserted.
- ✓ The .3ds file is corrupted.
- ✓ The filename contains strange symbols.

The LED keeps blinking:

- ✓ The firmware is incorrect.
- ✓ The MicroSD is in the wrong format.

Useful Tips

- ✓ Always leave 10% free space on the MicroSD.
- ✓ Use brand-name MicroSDs (SanDisk, Samsung).
- ✓ Do not fill the card to the maximum.
- ✓ Back up your save files.