

SNES – FXPak Pro Guide

Very simple and complete guide to use FXPak Pro on your Super Nintendo, step by step.

Recommended Links

-  Official FXPak Pro / SD2SNES Firmware:
[Download official firmware](#)
Here you download the files the cartridge needs to work.
-  Recommended videos – Retro Game Corps:
[FXPak / SD2SNES guides on YouTube](#)
Ideal if you want to see the process in video, step by step.
-  Retro content – NanospeedGamer:
[SNES and classic hardware videos – NanospeedGamer](#)
Good channel for general Super Nintendo and retro mod content.

Recommended Material

Before starting, make sure you have everything:



FXPak Pro (Amazon)



MicroSD 64GB (Amazon)



SD2SNES / FXPak (AliExpress)

- ✓ A Super Nintendo, Super Famicom or compatible console.
- ✓ An FXPak Pro cartridge (or original SD2SNES).
- ✓ A MicroSD of at least 16–64GB, class 10.
- ✓ A PC to copy files to the MicroSD.

LEGAL NOTICE:

This guide is intended for using backups of games you already own physically or free software. It does not

What is FXPak Pro?

FXPak Pro (formerly called SD2SNES) is a special cartridge for Super Nintendo. On the outside it looks like a normal cartridge, but inside it contains modern electronics and a MicroSD slot.

It's like a "magic cartridge" where you can put many legal games on a single card:

- ✓ Works on the original console with your usual controller.
- ✓ Does not modify the console.
- ✓ Loads games very fast.
- ✓ Supports special chips like Super FX and SA-1 (Star Fox, Yoshi's Island, etc.).

Compatibility

- ✓ Super Nintendo (PAL / NTSC).
- ✓ Super Famicom (Japanese).
- ✓ SNES Jr.
- ✓ Analogue Super Nt.

Note that the cartridge shape may vary by region (PAL / NTSC / Super Famicom), but functionality is the same.

Required Material

- FXPak Pro / SD2SNES cartridge.
- Class 10 MicroSD (preferably 32–64GB).
- Firmware files (`sd2snes` folder from the official website).
- Legal backups of your games in `.sfc` or `.smc` format.

1 Prepare the MicroSD

We will prepare the card so FXPak works on the first try.

1. Connect the MicroSD to the PC (with adapter if needed).
2. Format the MicroSD:
 - Recommended: **FAT32**.
 - **exFAT** may also work with recent firmwares.

In Windows: right-click the card → "Format" → File system: FAT32 → Start.
3. Download the firmware from the official website and extract the file. Inside you will see a folder named `sd2snes`.
4. Copy the entire `sd2snes` folder to the root of the MicroSD (so it appears as `/sd2snes/`).
5. Inside `sd2snes` make sure files like these are present:
 - `firmware.img`
 - `menu.bin`
6. Create a folder for your games, for example `Games`, and copy your legal backups there.

2 Special Chips (Super FX, SA-1, etc.)

Some SNES games used extra chips inside the cartridge (like Super FX or SA-1) for advanced features. FXPak Pro can emulate them, but sometimes needs extra files.

- If a game doesn't boot or shows an error, a chip file may be missing.
- These files are usually named things like `dsp1.bin`, etc.
- They go inside the `/sd2snes/` folder on the MicroSD.

```
FXPAK PRO v1.10.x
-----
> [DIR] Games
> [DIR] Homebrew
> System Information

FPGA: OK | SuperFX: OK | SA-1: OK
[A] Open [B] Back
```

If the information screen shows “OK” for the chips, everything is configured correctly.

3 First Boot and Game Selection

1. Safely eject the MicroSD from the PC.
2. Insert the MicroSD into the FXPak Pro.
3. Insert the FXPak into your powered-off Super Nintendo.
4. Turn on the console.
5. You will see a menu with folders and games.
6. Move with the D-pad, press **A** to enter folders and select games.
7. When you select a game, the console will load it as if it were a normal cartridge.

```
FXPAK PRO - GAME BROWSER
-----
> [DIR] Games
- Super Mario World.sfc
- The Legend of Zelda.sfc
- Star Fox.sfc

[A] Load [B] Back
```

MSU-1 (Optional – CD-quality Music)

FXPak Pro can also use a technology called MSU-1. This allows some games to have CD-quality music and enhanced videos.

1. Create a folder for the MSU-1 game (e.g., `Games/Zelda_MSU1`).
2. Copy the game file (`.sfc`) and the audio files (`.pcm`) inside.
3. Select the game from the menu like any other.

Common Errors

“Chip not found” or game won’t boot:

- ✓ Missing special chip file (DSP, Super FX, etc.).
- ✓ Check they are in the /sd2snes/ folder with the correct name.

Console stays black:

- ✓ MicroSD not inserted correctly.
- ✓ Incomplete firmware files.
- ✓ Incorrect card format (try FAT32).

Games from another region have issues:

- ✓ Some NTSC games on PAL consoles (or vice versa) may glitch.
- ✓ Enable “Auto-Region” options if the firmware allows it.

Optimization and Tips

- ✓ Do not fill the MicroSD to 100%. Leave 10–15% free.
- ✓ Use brand-name MicroSDs to avoid strange errors.
- ✓ Organize your games in folders (by genre, alphabetically, etc.).
- ✓ Some firmwares allow returning to the menu with a button combo (in-game reset).