```
"userAccount": "xxx@xxx.xxx",

"userEmail": "xxx@xxx.xxx",

"userDescription": "the description of user",

"userPhoneCountryCode": "0086",

"userPhone": "11111111111",

"isInitPassword": true,

"sendInitEmailEnable": true

}
```

1.4.2.18.3 Query a Tenant

Typical Scenarios

A tenant needs to be queried.

Functions

Query tenants in pagination query mode.

Constraints

- 1. This API can be invoked by users attached to the open API operator role in the MSP view and can be used only after user sessions are established.
- 2. The pagination query mode is recommended. If this mode is not used, the system may take a long period of time to respond due to a large volume of data.

HTTP Method

GET

URI

/controller/campus/v1/baseservice/tenants

Table 1-243 query parameters

| Param eter | Mand atory | Туре | Value Range | Defaul t Value | Description | Example |
|---------------|---------------|-------|------------------------|-------------------|-------------|---------|
| pageln dex | No | int32 | [0-214 74836 47] | 0 | Page index. | 1 |
| pageSi ze | No | int32 | [1-100 0] | 20 | Page size. | 20 |

Request Parameters

N/A

Sample Request

HTTP

GET /controller/campus/v1/baseservice/tenants?pageIndex=1&pageSize=20 HTTP/1.1

Host: 192.168.1.125:18002 Content-Type: application/json Accept: application/json Accept-Language: en-US X-ACCESS-TOKEN: x-yyyyyy

Response Parameters

Response status code 200: OK.

Table 1-244 TenantListDto parameters

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|------------------|-------------------------|--------------------------------------|-------------------|--------------------------|---------|
| errcod e | string | - | - | Error code. | "0" |
| errmsg | string | - | - | Error message. | ш |
| totalRe cords | integer | - | - | Number of tenants. | 100 |
| pageln dex | int32 | - | - | Page index. | 1 |
| pageSi ze | int32 | - | - | Page size. | 20 |
| data | ARRAY _REFER ENCE | For details, see Table 1-245. | | Tenant list information. | - |

Table 1-245 TenantData parameters

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|---------------|--------|----------------|-------------------|-------------|---|
| tenantl d | string | - | - | Tenant ID. | "00000000-000 0-0000-0000-0 00000000000 |

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|-------------------|-------------|--------------------------------------|-------------------|---|-----------|
| countr yCode | string | 2 characters. | - | This field may contain sensitive or personal data. Keep it secure. | "CN" |
| | | | | Country/region code. If this parameter is not set, the default value CN is used. This field corresponds to "Country/Region" on the controller web UI. | |
| provinc eCode | string | 0 to 16 characters. | - | This field may contain sensitive or personal data. Keep it secure. | "BEIJING" |
| | | | | Province code. This field corresponds to "Province/State" on the controller web UI. | |
| isLogol nherit | boolea n | truefalse | false | Whether the tenant logo is inherited from the MSP. This field corresponds to "Default logo" on the controller web UI. | true |

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|-------------------------|---------|---------------------|-------------------|--|----------|
| limitAc count Num | integer | [1-1000] | 20 | Number of administrators. The value ranges from 1 to 1000. The default value is 20. It is recommended that the number of administrators be greater than or equal to that of workgroups. This field corresponds to "Number of administrator accounts" on the controller web UI. | 20 |
| limitOr gNum | integer | [1-1000] | 20 | Number of workgroups. The value ranges from 1 to 1000. The default value is 20. It is recommended that the number of workgroups be less than or equal to that of administrators. This field corresponds to "Number of workgroups" on the controller web UI. | 20 |
| postal Code | string | 0 to 19 characters. | - | This field may contain sensitive or personal data. Keep it secure. Postal code. This field corresponds to "Postal code" on the controller web UI. | "111111" |

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|----------------------------|-------------|--------------------------------------|-------------------|---|---------------|
| authen ticatio nType | integer | [0-10] | 0 | Authentication mode. The options are 0 (username and password authentication) and 1 (SMS + username and password two-factor authentication). The parameter value defaults to 0. This field corresponds to "Login authentication mode" on the controller web UI. | 1 |
| accredi tToMs p | boolea n | truefalse | false | Whether tenant services are authorized to the MSP. The default value is false. This field corresponds to "Authorize MSP" on the controller web UI. | false |
| tenant Name | string | 1 to 64 characters. | - | This field may contain sensitive or personal data. Keep it secure. Tenant name. This field corresponds to "Tenant name" on the controller web UI. | "tenant" |
| tenant Email | string | 0 to 128 characters. | - | This field may contain sensitive or personal data. Keep it secure. Email address of the tenant. This field corresponds to "Service email" on the controller web UI. | "xxx@xxx.xxx" |

| Param eter | Туре | Value Range | Defaul t Value | Description | Example |
|---------------------------|--------|-------------------------|-------------------|--|----------------------------|
| tenant Phone | string | 0 to 64 characters. | - | This field may contain sensitive or personal data. Keep it secure. | "888888888" |
| | | | | Service phone number of the tenant. This field corresponds to "Service phone number" on the controller web UI. | |
| tenant Descri ption | string | 0 to 255 characters. | - | Tenant description. This field corresponds to "Description" on the controller web UI. | "this is a tenant" |
| tenant Addres s | string | 0 to 255 characters. | - | This field may contain sensitive or personal data. Keep it secure. | "No. 328, Xia Fei Road" |
| | | | | Tenant address. This field corresponds to "Address" on the controller web UI. | |

Sample Response

Response status code 200: OK.

```
"limitOrgNum": 20,
    "postalCode": "111111",
    "authenticationType": 1,
    "accreditToMsp": false,
    "tenantName": "tenant",
    "tenantEmail": "xxx@xxx.xxx",
    "tenantPhone": "8888888888",
    "tenantDescription": "this is a tenant",
    "tenantAddress": "No. 328, Xia Fei Road"
    }
]
```

1.4.2.18.4 Delete a Tenant

Typical Scenarios

A tenant needs to be deleted.

Functions

Delete a tenant by the tenant ID.

Constraints

This API can be invoked by users attached to the open API operator role in the MSP view, and can be used only after user sessions are established.

NOTICE

Calling this API may directly or indirectly affect live network services and may even cause service interruption and key data loss. Exercise caution when performing this operation.

HTTP Method

DELETE

URI

/controller/campus/v1/baseservice/tenants/{tenantId}

Table 1-246 path parameters

| Param eter | Mand atory | Туре | Value Range | Defaul t Value | Description | Example |
|---------------|---------------|--------|----------------------------|-------------------|---------------------------------|---|
| tenantl d | Yes | string | 1 to 64 charac ters. | - | ID of the tenant to be deleted. | "00000000-000 0-0000-0000-0 00000000000 |