Welcome to your vehicle. Read this guide before driving. Store this booklet inside the glove compartment.

Lane keep assist keeps the car in its lane. To turn off lane keep assist, press the lane assist button.

Check tire pressure monthly. Inflate tires to the pressure shown on the label inside the door jamb.