

NT-C400 Smart Security Camera

User Manual v1.8 | NextTech Co., Ltd.

1. Product Overview

The NT-C400 is a 4K outdoor security camera with AI-powered person detection, color night vision, and two-way audio. Built for all-weather use with IP67 rating, it integrates seamlessly with the NextTech Home ecosystem.

Key Specifications

- Resolution: 4K (3840x2160) at 30fps
- Field of view: 130 degrees diagonal
- Night vision: Color up to 10m, IR up to 30m
- Storage: Local microSD (up to 256GB) + Cloud storage
- Weather resistance: IP67 (dust-tight, waterproof up to 1m)
- Audio: Built-in microphone + speaker, two-way communication
- Power: Wired (12V DC) or solar panel (optional)

2. Installation

2.1 Mounting

Choose a location with a clear view of the area you want to monitor. The camera should be mounted at 2.5-3m height for optimal coverage. Use the included mounting template to mark drill holes. Ensure the mounting surface can support at least 2kg.

2.2 Network Setup

1. Download the NextTech Home app and create an account.
2. Tap '+' > 'Add Camera' > 'NT-C400'.
3. Scan the QR code on the bottom of the camera.
4. Enter your Wi-Fi credentials (2.4GHz or 5GHz supported).
5. Wait for the LED to turn solid green indicating successful connection.

3. AI Detection Features

3.1 Person Detection

The NT-C400 uses on-device AI to distinguish people from animals, vehicles, and other motion. Enable Person Detection in the app under Camera Settings > Detection > Person. Adjust sensitivity (1-10) to reduce false alerts.

3.2 Facial Recognition

Add familiar faces in the app to receive personalized alerts. Go to Settings > Faces > Add Face and follow the enrollment process. The camera can store up to 100 face profiles locally.

3.3 Activity Zones

Draw custom detection zones in the app to focus alerts on specific areas. Up to 4 activity zones can be configured per camera. Zones can be scheduled to activate only during specific hours.

4. Storage & Privacy

4.1 Local Storage

Insert a microSD card (Class 10 or higher recommended) into the slot on the bottom of the camera. The camera supports continuous recording or event-based recording. Local footage is encrypted with AES-256.

4.2 Privacy Mode

Enable Privacy Mode in the app to pause all recording and detection. The LED will turn solid orange when Privacy Mode is active. You can schedule Privacy Mode to activate automatically (e.g., during work hours).

5. Troubleshooting

Camera offline in app

Check that the camera LED is solid green. If flashing red, the camera has lost Wi-Fi connection. Press the reset button for 5 seconds to restart the network configuration. Ensure your router's 2.4GHz band is enabled.