

# NT-R300 Robot Vacuum

User Manual v3.0 | NextTech Co., Ltd.

## 1. Product Overview

The NT-R300 is an intelligent robot vacuum cleaner with LiDAR navigation, 3000Pa suction power, and automatic dirt disposal. It creates precise floor maps and supports multi-floor mapping for homes with multiple levels.

### Key Specifications

- Suction power: 3000Pa (max)
- Dustbin capacity: 400ml (robot) + 3L (auto-empty station)
- Battery: 5200mAh, up to 180 minutes runtime
- Navigation: LiDAR + AI obstacle avoidance
- Noise level: 65dB (standard mode)
- Compatible surfaces: Hardwood, tile, carpet (up to 20mm pile)

## 2. Setup

### 2.1 Charging Station Placement

Place the charging station against a wall with at least 0.5m clearance on each side and 1.5m in front. Keep the area around the station clear of obstacles. Connect the station to a power outlet using the provided cable.

### 2.2 First-Time Mapping

1. Place the robot on the charging station and power it on.
2. Open the NextTech Clean app and add the NT-R300.
3. Tap 'Start Mapping' to begin the initial room scan.
4. The robot will explore your home and create a floor map (15-30 minutes).
5. Review and edit the map in the app to label rooms and set no-go zones.

## 3. Cleaning Modes

- Auto Mode: Intelligent room-by-room cleaning
- Spot Mode: Intensive cleaning of a specific area (1.5m x 1.5m)
- Edge Mode: Cleans along walls and corners
- Quiet Mode: Reduced suction for noise-sensitive environments
- Max Mode: Maximum suction for deep carpet cleaning
- Scheduled Cleaning: Set up to 7 weekly schedules

## 4. Maintenance

### 4.1 Cleaning the Dustbin

Empty the dustbin after each cleaning session or when the app notifies you. Remove the dustbin by pressing the release button on the back. Rinse with water and allow to dry completely before reinstalling.

#### 4.2 Brush Maintenance

Clean the main brush every 2 weeks by removing it from the bottom panel. Use the included cleaning tool to remove hair and debris. Replace the main brush every 6-12 months depending on usage.

### 5. Troubleshooting

#### Robot getting stuck frequently

Update the floor map by running a new mapping session. Add virtual walls in the app to block problem areas. Ensure cables and small objects are removed from the floor before cleaning.