

01 / READ FIRST

A19 LED Bulb User Manual

Read all instructions before use. Keep this manual for future reference and pass it on with the product.

This guide covers KINSOR clear-glass A19 dimmable LED filament bulbs in **2200K, 2700K, 3000K and 4000K**, supplied in **12-bulb or 24-bulb packs**. Check your package for the color temperature and quantity you purchased. Each bulb has a fixed color temperature.

WARNING - Electrical shock, fire, burns and broken glass
Disconnect power before installation, removal or inspection. Let the bulb cool completely. Never install or test a cracked, broken, wet or otherwise damaged bulb. Do not use in fully enclosed fixtures.

Product reference

Feature	Specification
Bulb and base	A19 shape; E26 medium screw base
Electrical rating	120V AC, 60Hz; 8W per bulb
Light output	800 lumens per bulb; 60W incandescent equivalent
Dimming	Approximately 10% to 100% with a compatible LED dimmer
Size	Approx. 2.4 in diameter x 4.2 in height (61 x 107 mm)
Color rendering and life	CRI 85+; 20,000-hour average rated life
Ambient conditions	Package-stated range: -4 to 113 degrees F (-20 to 45 degrees C)

Specifications are per bulb. The 60W equivalent describes light output, not electrical consumption. Follow all bulb, fixture and control ratings; a matching screw base alone does not establish compatibility. Rated life is an estimate, not a warranty period.

Before every installation

- **Inspect first.** Check glass, base and visible internal parts for damage; keep glass and packaging away from children and pets.
- **Check the fixture.** Use a compatible, ventilated E26 fixture on the stated supply. Keep the bulb clear of fabric, paper and other combustible materials.
- **Keep it dry.** Do not expose the bulb or socket to water, rain, condensation or spray. See page 4 for location and control restrictions.

Find it fast: Arrival and broken glass p. 2 | Installation and care p. 3 | Dimming and compatibility p. 4 | Troubleshooting p. 5 | Stop-use conditions and support p. 6

02 / ARRIVAL AND FRAGILE GLASS

Inspect before switching on

Do not energize a damaged bulb to see whether it still works.

When your package arrives

- 1 Open carefully**
Place the carton on a stable surface. Open it without cutting deeply into the protective inserts. Do not shake or tip out the box. Remove bulbs one at a time.
- 2 Check every bulb**
In good light, look for chipped or cracked glass, a bent or loose base, exposed parts, loose or broken internal pieces, moisture and signs of impact. Do not shake a bulb to inspect it.
- 3 Confirm what you received**
Compare the quantity and color temperature on the package with your order. If pieces are missing or the variant is wrong, contact the seller through your order.
- 4 Separate any damaged item**
Do not install, plug in, repair, glue or tape a damaged bulb. Keep it and any loose glass away from people and pets. Inspect the remaining bulbs individually before use.

If glass is broken in the carton or on the floor

- Keep children and pets out of the area. Wear closed shoes and suitable cut-resistant gloves. Never pick up fragments with bare hands.
- If the bulb was installed, disconnect electrical power first, only if safe to do so, and let the fixture cool. Do not clean around a live or wet socket.
- Use stiff cardboard and a dustpan to collect accessible loose glass. Use adhesive tape for small fragments on a suitable surface. Do not reach blindly into packaging or brush glass away by hand.
- Place fragments and damaged bulbs in a rigid, puncture-resistant container. Secure it and mark it as broken glass. Follow local disposal or recycling rules for LED lamps; do not place loose shards in a bag.

Broken glass with the metal base still in the socket

Leave the circuit disconnected and have a qualified electrician remove the base and inspect the socket. Do not insert fingers, pliers, food or other improvised tools into the socket.

Report shipping damage safely

Contact the seller through **Amazon > Your Orders > the relevant order** using the available support option. If safe, photograph the carton, protective inserts, affected bulbs and package label. Note how many bulbs are damaged. Do not handle shards or re-create a failure for a photograph.

Keep order and label details. Retain packaging only if it can be stored safely. Do not mail loose broken glass; obtain return and packing instructions through your order before sending a damaged item. See page 6 for contact details.

03 / INSTALLATION AND CARE

Install and replace safely

Use dry hands and a stable working position. Ask for help if you cannot safely reach or isolate the fixture.

- 1 Disconnect the power**
Switch the light off. Unplug a portable lamp. For a hardwired fixture, switch off the relevant circuit breaker. A dimmer set to its lowest level is not a safe power disconnect. If you cannot identify or safely isolate the circuit, contact a qualified electrician.
- 2 Allow complete cooling**
Wait until the old bulb and fixture have cooled. Support the fixture as needed and remove an intact old bulb gently, turning counterclockwise. Stop if it is stuck, cracked or separating from its base.
- 3 Check fit and condition**
Confirm an E26 socket, 120V AC 60Hz supply and enough clearance for a 2.4 x 4.2 in bulb. Follow the fixture wattage and bulb-type limits using the actual 8W rating. Do not use fully enclosed fixtures, damaged sockets or loose fittings.
- 4 Insert by hand**
Hold the intact bulb gently near its base without squeezing the glass. Align the threads and turn clockwise until securely seated. Do not cross-thread, overtighten, use tools, force the fit or bend the socket contacts.
- 5 Restore power and observe**
Restore power only after installation is complete and all hands are clear. With a compatible dimmer, begin at a high brightness setting, then lower it gradually. If the bulb flickers, see pages 4-5. For smoke, sparks, burning odor or visible damage, stop use immediately.

Removing a used bulb

Disconnect power and allow complete cooling every time. Turn an intact bulb counterclockwise by hand. If the glass cracks, the base loosens, or removal requires force, stop and ask a qualified electrician. Never move a suspect bulb to another socket to test it.

Cleaning and storage

An operating LED bulb can become warm. Let it cool before touching it; do not judge safety by touching a lit bulb. Scorching, melting or a burning odor requires immediate stop-use.

- Clean only when power is disconnected and the bulb is cool. Use a soft, dry cloth with gentle pressure. Do not immerse, spray, use solvents or let liquid enter the socket or base.
- Keep ventilation openings clear. Do not cover the bulb, attach decorations, paint the glass or modify any part. The bulb has no user-serviceable parts.
- Store unused bulbs in their protective inserts in a dry place, away from impacts and children. Avoid stacking heavy items on the carton. Inspect again after a drop or hard impact.

For disposal, follow local LED-lamp or electronic-waste guidance. Do not assume an LED bulb belongs in household glass recycling. Protect handlers from broken glass.

04 / DIMMING AND COMPATIBILITY

Match the bulb to its setting

Dimming performance depends on the bulb, dimmer, number of bulbs and installation.

Using a dimmer

- Use a dimmer intended for **dimmable LED bulbs** and confirm compatibility with this bulb model. An LED rating alone does not guarantee compatibility.
- Observe the dimmer manufacturer's LED load limits and supported bulb count. Use 8W per bulb when checking load, and also observe model-specific lamp-count limits. Do not size an LED load using the 60W equivalent rating.
- Start at high brightness and lower gradually. If flicker or dropout begins near the bottom, raise the setting. If supported, adjust the dimmer's minimum-brightness setting according to its instructions. Do not open or rewire the control yourself.
- The approximate 10%-100% range is not a promise for every control. Use matching bulb models and color temperatures on one dimmer for more consistent results. A standard compatible on/off switch may be used when dimming is not needed.

Fixture and location requirements

Situation	What to check
Fully enclosed fixtures	Do not use. A sealed globe or housing can retain heat; an E26 socket does not remove this restriction.
Covered outdoor locations	Use only where both bulb and fixture labeling permit the location; protect from moisture. A porch cover alone does not establish suitability. If unclear, use a dry indoor location and contact KINSOR.
Ceiling fans	Use only in a compatible light kit that permits this bulb type and size. The bulb must not be controlled by a fan-motor speed control. Stop use if vibration loosens the bulb or fixture.
Sensors, timers and smart or touch controls	Check the control manufacturer's LED compatibility. This bulb is not a connected smart bulb. Do not assume it provides three separate brightness levels in a 3-way lamp.
Special-purpose equipment	Do not use in ovens, heat lamps, emergency lighting or other specialized equipment unless the equipment instructions expressly permit this bulb.

Color temperature and pack quantity

2200K: amber warm light | **2700K:** soft warm light
3000K: warm white light | **4000K:** neutral white light

These are separate fixed-color variants. Dimming changes brightness; it does not select another listed color temperature. A 12-pack and a 24-pack use the same handling and installation steps. Confirm the label rather than judging color from a photograph.

05 / TROUBLESHOOTING

Check the symptom first

For any sign of damage, burning, smoke, sparks or a tripped breaker, skip testing and follow page 6.

Before touching or moving a bulb

Disconnect power and let it cool. Only an intact, dry bulb with no signs of electrical or physical damage may be checked in another known-good, compatible fixture. Do not test suspect sockets or alter wiring.

Symptom	Safe checks and next action
Bulb does not light	Confirm the lamp is plugged in and its control is on; raise a dimmer above minimum. With power disconnected and the bulb cool, check gentle, secure seating. If undamaged, try it in a known-good compatible non-dimming fixture. If it still fails, stop using that bulb and contact support.
Flickers only when dimmed low	Increase brightness. Check the dimmer's LED compatibility and bulb-count limits. Adjust minimum brightness only as the dimmer instructions permit. If it cannot run stably, stop using that bulb-control combination.
Flickers at normal or full brightness	Disconnect power and inspect the cooled bulb. If intact, check seating and try a known-good compatible non-dimming fixture. If flicker stays with the original fixture or affects other lights, have an electrician inspect the control or circuit.
Buzzing or humming	A dimmer mismatch can cause noise. Raise brightness and check compatibility. Persistent bulb noise in a compatible non-dimming fixture needs support. Noise from a socket or switch, crackling, odor or heat damage requires immediate stop-use and an electrician.
Faint glow or occasional flash after switch-off	Some electronic controls allow small leakage current. Check the control maker's LED guidance. Do not assume the socket is de-energized, and do not add resistors or modify wiring. An electrician can assess persistent symptoms.
Delayed start, limited dimming or uneven output	Check the dimmer's instructions, supported bulb count and minimum setting. Use matching bulb models on one control. Persistent behavior in a compatible non-dimming fixture needs KINSOR support.
Turns off after warming up or repeatedly cycles	Disconnect power and allow cooling. Check for an enclosed fixture, blocked ventilation or conditions outside the label limits. Do not repeatedly restart the bulb. Stop use and contact support if the cause is unclear or the issue repeats.
Wrong color or different colors in a fixture	Compare the Kelvin value on each package and order. Use the same color-temperature variant together. Color cannot be changed by a switch sequence or dimmer. Contact the seller if the supplied variant is incorrect.
Only one bulb in a multi-bulb fixture fails	Disconnect power before inspecting. If the bulb is intact, the known-good fixture check can help isolate the issue. Do not keep using a suspect socket. If the failure stays with the socket, contact an electrician.
Short life or repeated bulb failures	Check fixture enclosure, ventilation, ambient conditions, dimmer compatibility and vibration. Stop repeatedly replacing bulbs in a suspect fixture. Ask an electrician about fixture or supply issues and report the bulb and control details to KINSOR.

06 / STOP USE AND GET HELP

Know when to stop

A bulb that still lights can still be unsafe if its glass, base or electrical parts are damaged.

Disconnect power and do not reuse the affected bulb

Stop for cracked glass, a loose or detached base, exposed parts, water entry, smoke, sparks, burning odor, scorching, melting, electric shock or repeated breaker trips. Do not move a damaged bulb to another fixture or keep resetting a breaker.

Choose the right next action

What happened	What to do
A bulb is damaged or defective	Keep it out of use. Contact KINSOR or use the support options on your Amazon order. Protect people from broken glass as described on page 2.
The socket, switch, dimmer or circuit may be faulty	Keep the affected fixture or circuit off and contact a qualified electrician. Do not dismantle the bulb, adjust socket contacts or attempt wiring repairs.
There is smoke, fire or an immediate danger	Move away and get others to safety. Disconnect power only if it is safe. Call emergency services when needed. Do not touch energized or wet equipment, use water on electrical equipment, or delay leaving to save the product.

Contact KINSOR

For an Amazon purchase: Open **Your Orders**, choose the relevant order, and use the available seller-contact or product-support option. Return or replacement options, when available, are shown with your order.

Product support email: kinsor-service@outlook.com

To help identify the product and issue, have the following information ready:

- Order number and purchase date; package model/SKU or ASIN, color temperature and pack quantity; any lot or batch marking, if present.
- Number of affected bulbs; when the issue started; fixture type; whether the fixture is enclosed or outdoors; dimmer/control brand and model, if used.
- Safe photos of the bulb, label and packaging, plus a short description of checks already performed. Do not energize a faulty bulb or touch broken parts to collect evidence.

Service and product information

Keep your proof of purchase and package identification. Rated life is not a warranty period. This guide does not add a separate warranty or promise a particular refund or replacement outcome.

Follow any specific safety marking supplied with your bulb and fixture. If a label conflicts with this guide, or the intended use is unclear, stop installation and contact KINSOR before use. Keep this manual with the product information.